



MANUAL ON WATER SUPPLY AND TREATMENT

THIRD EDITION - REVISED AND UPDATED

Prepared by
THE EXPERT COMMITTEE

Constituted by
THE GOVERNMENT OF INDIA

**CENTRAL PUBLIC HEALTH
AND ENVIRONMENTAL ENGINEERING ORGANISATION**

**MINISTRY OF URBAN DEVELOPMENT, NEW DELHI
MAY, 1999**

All rights reserved


No portion of this document may be reproduced or used for commercial purposes without the prior written permission of the Ministry of Education, Ontario, Toronto, Ontario, Canada.

FOREFWORD

Water is a basic need. The provision of safe and adequate drinking water to the burgeoning urban population continues to be one of the major challenging tasks. Lack of safe drinking water could undermine the health and well being of the people, particularly, the urban poor and economically weaker sections.

The Central Public Health & Environmental Engineering Organisation (CPHEEO) in this Ministry had brought out the 3rd edition of the Manual on Water Supply and Treatment in March, 1991 with a view to provide valuable guidelines to the Public Health Engineering Departments, Water Boards and municipal bodies on the basic norms, standards and latest developments in this field. Subsequent to the publication of the said Manual, the CPHEEO had received comments and suggestions from field practitioners and manufacturers for revising and updating certain aspects such as water quality, per capita water supply norm, water conservation, metering and availability of various kinds of pipes. A two member Expert Committee was set up by this Ministry in November, 1997 to look into these aspects.

I am pleased to acknowledge the contribution made by the Expert Committee in further revising and updating the Manual, which I am sure would be of considerable help to the Public Health Engineers and field practitioners for proper planning, design and quality control of water supply systems.



(ASHOK PATHWA)
SECRETARY TO THE GOVERNMENT OF INDIA
MINISTRY OF URBAN DEVELOPMENT

Members

- Shri A.K. Sawalaha,
 Deputy Director, Wildlife Management,
 Bureau of Wildlife Conservation, New Delhi
6. Shri H. Ramalingam,
 Director & Chief Wildlife Warden,
 Director, National Institute of Environmental
 Research, Bangalore, Bangalore
7. Shri E.C. Agrawal,
 Professor, Deptt. of Soil Engineering,
 National Institute of Technology College,
 Mandla, Madhya Pradesh
8. Dr. S.K. Ghose,
 Professor, Deptt. of Soil Engineering,
 University Regional Engineering College,
 Coimbatore
9. Shri P.M. Jaiswal,
 Director, Foresty, Maharashtra Wildlife
 Deptt. & Foresty, Board, Bombay
10. Shri M. Chandramohan,
 Director of Forests & Wildlife,
 Mysore
11. Sh. S.K. Biswas,
 Wildlife Warden (RWS) Department of
 Rural Development, New Delhi
12. Shri V. Jayakumar,
 Chairman, Director, Environment
 Water Supply & Drainage Board,
 Mysore

18. Dr. D. M. Murgatroyd,
 Senior Lecturer, College of Health, School of
 Health, Behavior & Society, University of North
 Carolina
19. Dr. N. Perkins,
 Director of Health, Behavior & Society, International
 Studies, Johns Hopkins University, Baltimore,
 Maryland, USA
20. Susan S. Cole,
 Executive Director, Population Council,
 Population Department,
 Government of Jamaica, Kingston
21. Stephen Ablan, *Chairman*,
 Executive Director, Population Council, Jamaica
 Association, Jamaica
22. Dr. Y. H. Ramesh Chandra,
 Deputy Adviser (PH),
 Central Public Health
 Services, Director, Directorate of International
 Ministry of Health & Family Welfare, New Delhi
23. Dr. B. B. J. J. Jansz,
 Assistant Adviser (PH),
 Central Public Health
 & Family Welfare Engineering, Director, International
 Ministry of Health & Family Welfare, New Delhi
24. Dr. S. K. Ghosh,
 Deputy Adviser (PH),
 Central Public Health
 & Family Welfare Engineering, Director, International
 Ministry of Health & Family Welfare, New Delhi

The Committee held 11 meetings under the Chairmanship of Shri V. Venugopalan between April 1986 and August, 1989, and has drawn freely from all available literature, in finalising the revision of the Manual. The Committee wishes to thank the Urban Ministry of Urban Dev. Deptt. for rendering all the help needed for successfully carrying and updating the Manual. The Committee also wishes to thank National Institute of Engineering Research Institute, Nagpur, and the Maharashtra Water Supply & Sewerage Board for the arrangements made for the meeting of the Committee outside Delhi.

The Committee wishes to place on record their deep sense of appreciation for the unsparring and diligent efforts of Shri M.R. Parthasarthy and Dr. S.R. Shukla who ensured that the meetings were held regularly to enable the Committee to complete its work in spite of their heavy official duties. The Committee also places on record its appreciation of the services rendered by the various officers and staff of Central Public Health and Environmental Engineering Organisation and Public Health Engineering Section of the Ministry without whose cooperation and active participation the enormous task assigned to the Committee could not have been accomplished.

A Sub-Committee for setting the draft Manual was constituted comprising of the Members Dr. D. Agarwal, Shri M.R. Parthasarthy and Dr. D.M. Mohan. The Sub-Committee finalised the editing of the draft Manual in four sittings between September and December, 1989. The Committee also wishes to thank the Members of the Editing Sub-Committee for the devoted and sincere work without which the final draft of the Manual would not have been completed.

The 3rd edition of the Manual was brought out by the CPHEEO in March, 1991 for the benefit of Public Health Engineers, Consultants, Water Supply Departments/Boards, Local Bodies, Educational Institutions. However, subsequent to the publication of the said Manual, a few suggestions, observations and comments have been received from various product manufacturers, field engineers, consultants, etc. for revising and updating certain aspects, such as, water quality guidelines, per capita water supply norms, water conservation measures, metering, availability of various pipes, selection of pipes under different field conditions, etc.

respectively, a two member Expert Committee, comprising Dr. U.C. Agrawal, Director, Bangalore Institute of Engineering and Technology, Bengaluru, and Dr. H.M. Nataraj, former Director, Technical, Hyderabad Metropolitan Water Supply & Sewerage Board, was set up by the Ministry in February, 1996 on a definite terms of reference to examine the proposals by providing latest developments in the field of water supply, treatment and distribution.

Both the Expert Committee Members had completed their job in the satisfaction of the Ministry. The draft Manual (revised version) was discussed & approved by the Civil Engineers Conference held in Bangalore, 1998 at Chandigarh. The Expert Committee had reviewed the suggestions made by the Civil Engineers Conference and modified the draft Manual accordingly so as to make it comprehensive and more useful to Government engineers dealing with water supply sector. The committee members, Sri M.B. Karra Prasad, Sri R. Subramanian, Sri B.B. Upadhyay, Deputy Secretary, Sri M. Sankaranarayanan, Sri M. Dharmapalan, Sri J.S. Mohchandani, Assistant Adviser and Sri Sulama Rao, Member Office in successful completion of the task is duly appreciated. The services rendered by Dr. U.C. Agrawal, Director, Dr. Rajee Srivastava, Sr. Project Manager and other staff of Bangalore Institute of Engineering & Technology, Bengaluru, for completing the work assigned is duly acknowledged.

In case but not the least, the sincere & hearty cooperation of the Ministry in completing the exercise is greatly acknowledged.

Dr. S.R. Shukla,
Adviser (PHEE)
C.P.H.E.D.O.
Ministry of Urban Development
Government of India

Dated: May, 1999
New Delhi

CONTENTS

1. INTRODUCTION	1
2. PLANNING	4
2.1 OBJECTIVE	4
2.2 BASIC DESIGN CONSIDERATIONS	4
2.2.1 Water Quality And Quantity	1
2.2.1.1 Water Conservation	5
2.2.1.2 Increase/Alter Water Availability And Supply & Demand Management	5
2.2.2 Final Stage	6
2.2.3 de-familiarization	6
2.2.4 service Building	6
2.2.5 Other Utilities	6
2.2.6 Design Period	6
2.2.7 Population Forecast	7
2.2.7.1 General Considerations	7
2.2.7.2 Final Forecast	9
2.2.8 PER CAPITA SUPPLY	9
2.2.8.1 Basic Needs	9
2.2.8.2 Factors Affecting Consumption	10
2.2.8.3 Recommendations	10
2.2.9 Quality Standards	13
3. PROJECT REPORT	19
3.1 GENERAL	19
3.1.1 Project Reports	19
3.2 IDENTIFICATION REPORT	20
3.3 PRE-FEASIBILITY REPORT	21
3.3.1 Contents	22
3.3.1.1 Executive Summary	22
3.3.1.2 Introduction	22
3.3.1.3 The Project Area And The Need For The Project	23
3.3.1.4 Long Term Plan For Water Supply	26

3.3.1.7 Proposed Water Supply Project	24
3.3.1.8 Conclusion and Recommendations	26
3.0 CONCLUSION AND FUTURE	27
3.1 Introduction	27
3.1.1 Background	27
3.1.2 The proposed Project	27
3.1.3 Objectives and Importance	31
3.1.4 Guidelines for Recommendations	31
4. MEASUREMENT OF FLOW	37
4.1 OBJECTIVE OF MEASUREMENT	37
4.2 MEASUREMENT TECHNIQUES AND METHODS	37
4.2.1 List of Hydrological Instruments	37
4.2.1.1 Nozzle	38
4.2.1.2 Weir	39
4.2.1.3 orifice (over Flowing)	40
4.2.1.4 Flumes	41
4.2.2 Discharge Method	41
4.2.3 Current Meter and Probe Method	41
4.3 ADVANCEMENT IN CLOSING COURSES	41
4.3.1 Pitot-static Probes and Devices	41
4.3.1.1 Venturi Meter	41
4.3.1.2 Orifice Plates and Nozzles	42
4.3.1.3 Pitot Tube	43
4.3.1.4 Area Meter	46
4.3.2 Pitot-static Methods	47
4.3.2.1 General	47
4.3.2.2 Orifice Method	47
5. SOURCES OF SUPPLY	49
5.1 KINDS OF WATER SOURCES AND THEIR CHARACTERISTICS	49
5.1.1 Water from Precipitation	49
5.1.2 Surface Waters	50
5.1.3 Groundwater	50
5.1.4 Edge Infiltration	51
5.1.5 Spring Survey	51
	50

5.2.1.1. Assessment of the Hydrological Conditions of the Subsoil	52
5.2.1. General	52
5.2.2. Hydrological Estimates of the	59
5.2.3. Methodology for Assessment of the Hydrological Conditions	62
5.2.3.1. Hydrological Conditions and the Environment	62
5.2.3.2. Hydrological Conditions and the Environment	64
5.2.3.3. Assessment of the Hydrological Conditions	64
5.2.3.4. Hydrological	66
5.2.3.5. Hydrological Conditions and the Environment	66
5.2.3.6. Hydrological Conditions and the Environment	67
5.2.4. Hydrological Conditions and the Environment	68
5.2.5. Hydrological Conditions and the Environment	69
5.2.5.1. Hydrological Conditions and the Environment	69
5.2.5.2. Hydrological Conditions and the Environment	70
5.2.5.3. Hydrological Conditions and the Environment	71
5.2.6. Hydrological Conditions and the Environment	73
5.2.6.1. Hydrological Conditions and the Environment	73
5.2.6.2. Hydrological Conditions and the Environment	74
5.2.6.3. Hydrological Conditions and the Environment	75
5.2.6.4. Hydrological Conditions and the Environment	76
5.2.6.5. Hydrological Conditions and the Environment	77
5.2.6.6. Hydrological Conditions and the Environment	78
5.2.6.7. Hydrological Conditions and the Environment	79
5.2.6.8. Hydrological Conditions and the Environment	80
5.2.6.9. Hydrological Conditions and the Environment	81
5.2.6.10. Hydrological Conditions and the Environment	82
5.2.6.11. Hydrological Conditions and the Environment	83
5.2.6.12. Hydrological Conditions and the Environment	84
5.2.7. Hydrological Conditions and the Environment	85
5.2.7.1. Hydrological Conditions and the Environment	85
5.2.7.2. Hydrological Conditions and the Environment	86
6. TRANSMISSION OF WATER	100
6.1. TRANSMISSION OF WATER AND ITS DISTRIBUTION	100
6.1.1. General	100
6.1.2. Velocity	100
6.1.3. Pressure	100
6.1.4. Velocity	101
6.2. TRANSMISSION OF WATER	101

6.2.1	Formulae	107
6.2.2	Coefficient Of Roughness	108
6.2.3	Hazen Williams Formula	110
6.2.3.1	Discussion On Various Formulae For Estimation Of Frictional Resistance	111
6.2.4	Modified Hazen Williams Formula	113
6.2.5	Effect of Temperature on Coefficient of Roughness	113
6.2.6	Experimental Estimation of C _z Values	113
6.2.7	Reduction in Carrying Capacity of Pipes with Age	115
6.2.8	Design Recommendations for use of Modified Hazen Williams Formula	114
6.2.9	Resistance due to Surchin and Apparatuses	115
6.2.10	Guidelines for cost effective design of pipelines	116
6.3	PIPE MATERIALS	117
6.3.1	Choice Of Pipe Material	117
6.3.2	CHECK LIST FOR SPECIFICATIONS FOR MANUFACTURE, SUPPLY, LAYING, JOINING, TESTING AND COMMISSIONING PIPELINE	120
6.3.2.1	General	120
6.3.3	CHECK LIST FOR SPECIFICATIONS FOR MANUFACTURE, SUPPLY, LAYING, JOINING, TESTING AND COMMISSIONING PIPELINES	121
6.4	CAST IRON PIPES	123
6.4.1	General	123
6.4.2	Laying And Jointing	124
6.4.2.1	Excavation And Preparation Of Trench	124
6.4.2.2	Handling Of Pipes	124
6.4.2.3	Detection Of Cracks In Pipes	124
6.4.2.4	Lowering Of Pipes And Fittings	125
6.4.2.5	Cleaning Of Pipes And Fittings	125
6.4.3	Joints	126
6.4.3.1	Categories Of Joints	126
6.4.4	Testing of the Pipeline	126
6.4.4.1	General	126
6.4.4.2	Testing Of Pressure Pipes	126
6.4.4.3	Testing Of Non-Pressure Conduits	128
6.5	STEEL PIPES	128
6.5.1	General	128
6.5.2	Protection Against Corrosion	128

6.5.1 Laying And Joining	126
6.6 DUCTILE IRON PIPES	129
6.6.1 General	129
6.6.2 Ductile Iron fittings	130
6.6.3 Joints	130
6.6.4 Laying And Joining	130
6.6.5 Testing Of Ductile Iron Pipelines	130
6.7 ASBESTOS CEMENT PIPES	130
6.7.1 General	130
6.7.2 Laying	131
6.7.2.1 Laying, And Joining	131
6.7.3 Pipe joints	131
6.7.4 Pressure Testing	132
6.8 CONCRETE PIPES	132
6.8.1 General	132
6.8.2 Laying and joining	133
6.8.3 Pressure Test	134
6.9 PRECAST REINFORCED CONCRETE PIPES	134
6.9.1 General	134
6.9.2 Laying And Joining	136
6.9.3 Pressure Testing	136
6.9.4 Bar Wrapped Steel Cylinder Concrete Pressure Pipes	136
6.9.4.1 General	136
6.9.4.2 Manufacture	136
6.9.4.3 Joints	136
6.10 PLASTIC PIPES	137
6.10.1 General	137
6.10.2 PVC Pipes	137
6.10.3 Precautions in Handling and Storage	138
6.10.4 Laying and joining Procedures	138
6.10.4.1 Trench Preparation	138
6.10.4.2 Laying And Joining	138
6.10.4.3 Pre-Fabricated Connections	139
6.10.4.4 Standard Threaded Connections	140

6.16.8 Pressure-Reducing Valves	157
6.16.9 Pressure Sustaining Valves	157
6.16.10 Ball Valves Or Ball Float Valves	157
6.16.11 Automatic Shut-Off Valves	157
6.16.12 Automatic Burst Control	158
6.16.13 Venturiometers	158
6.16.14 Spring-Off Valves And Interconnections	158
6.16.15 Manifolds	158
6.16.16 Insulation Joints	159
6.16.17 Expansion Joints	159
6.16.18 Anchorage	161
6.17 WATER HAMMER	161
6.17.1 Occurrence	163
6.17.2 Computations	164
6.17.3 Control Measures	165
6.17.3.1 Causes Of Water Hammer And Remedial Measures	165
6.17.3.2 Rapid Closing-Of Valves	165
6.17.3.3 Remedial Measures For Sudden Shut-Off Of Pumps	165
6.17.4 Air Vessels	171
6.17.4.1 Design Of Air Vessel	177
6.17.4.2 In-Line Reflex Valves	179
6.17.4.3 Release Valves	182
6.17.4.4 Shut-Off Effects On Suction Line	183
6.17.4.5 Reciprocating Pump Or Hydraulic Ram	183
6.18 SPECIAL DEVICES FOR CONTROL OF WATER HAMMER	183
6.18.1 Zero Velocity Valve	184
6.18.2 Air Cushion Valve	184
6.18.3 Opposed Poppet Valve	184
6.19 WORKING OF THE SPECIAL DEVICES AS A SYSTEM	185
6.19.1 Choice Of Protective Device	187
7. WATER TREATMENT	18
7.1 METHODS OF TREATMENT AND FLOW SHEETS	184
7.2 AERATION	183
7.2.1 Facilitators of Aeration	

1.1.1 Types of Suspended Solids	223
1.1.2 Settling Velocity of D-sphere Particles	226
1.1.3 Kinetic Characteristics of Urea-released Chloride in Suspensions	229
1.1.4 Types of Tanks	229
1.1.4.1 Horizontal Flow Tanks	229
1.1.4.2 Vertical Flow Tanks	226
1.1.4.3 Tank Geometries	226
1.1.2 Tank Efficiency	226
1.1.6 Surface Scumming, Floating, and Detention Periods	227
1.1.7 Wind and Weather	227
1.1.8 Wind Velocity	230
1.1.9 Sludge Accumulation	230
1.1.10 Sealing Tank Efficiency	231
1.1.11 Sedimentation and Storage	232
1.1.11.1 Solids	232
1.1.11.2 BOD Analysis of Solids	233
1.1.11.3 FLTRATION	233
1.1.11.4 Sludge	233
1.1.11.5 Flow and Overflows	234
1.1.11.5.1 Control	234
1.1.11.5.2 Flocculation	234
1.1.11.5.3 Effluent Control or Slow Sand Filter	235
1.1.11.5.4 Flocculation Solutions	236
1.1.11.5.5 Flocculation Experiments	236
1.1.11.5.6 Flocculation of Suspensions	239
1.1.11.5.7 Flocculation	241
1.1.11.5.8 Effluent Control	243
1.1.11.5.9 Flocculation Process	243
1.1.11.5.10 Principal Characteristics of Particle Removal	243
1.1.11.5.11 Rate of Flocculation	245
1.1.11.5.12 Flocculation Interactions	245
1.1.11.5.13 Flocculation and UF Filtration	246
1.1.11.5.14 Flocculation	245
1.1.11.5.15 Depth of Tanks	246

7.6.3.8 Preparation Of Filter Sand	246
7.6.3.9 Filter Bottoms And Strainer Systems	247
7.6.3.10 Filter Grave	249
7.6.3.11 Wash Water Gutters	249
7.6.3.12 High Rate Backwash	250
7.6.3.13 Surface Wash	250
7.6.3.14 Operation Of Filters	251
7.6.3.15 Hydraulics Of Filtration	252
7.6.3.16 Hydraulics Of Backwashing	253
7.6.3.17 Optimum Backwashing	255
7.6.3.18 Appurtenances	256
7.6.3.19 Pipe Gallery	258
7.6.3.20 Limitations Of Rapid Sand Filters	258
7.6.4 Rapid Gravity Dual Media Filters	259
7.6.4.1 Constructional Features	259
7.6.4.2 Filtration Media	259
7.6.4.3 Design Of Media Depth And Media Sizes	260
7.6.4.4 Filtration Rates And Filtrate Quality	261
7.6.5 Multimedia Filters	261
7.6.6 PRESSURE FILTERS	261
7.6.6.1 General	261
7.6.6.2 Disadvantages	262
7.6.7 DIATOMACEOUS EARTH FILTERS	262
7.6.8 Additional Modifications of Conventional Rapid Gravity Filters	263
7.6.8.1 Constant And Declining Rate Filtration	263
7.6.9 UP-Flow Filters	265
7.6.10 Grid Or Immedium Type Filters	265
7.6.11 Bi flow Filters	266
7.6.12 Submerged Filters	266
7.6.13 Radial Flow Filters	266
7.6.14 Automatic Valveless Gravity Filters	266
7.7 DISPOSAL OF WASTES FROM WATER TREATMENT PROCESSES	267
DISPOSAL METHODS	267
7.8 PERFORMANCE CAPABILITIES	267

7.8.1 Slow Sand Filters	267
7.8.2 Rapid Sand Filters	268
6. DISINFECTION	269
8.1 INTRODUCTION	269
8.2 CRITERIA FOR A GOOD DISINFECTANT	269
8.3 MECHANISMS OF DISINFECTION	270
8.4 FACTORS AFFECTING EFFICIENCY OF DISINFECTION	270
8.4.1 Type, Condition and Concentration of Organisms to be Destroyed	270
8.4.2 Type and Concentration of Disinfectant	271
8.4.3 Chemical and Physical Characteristics of Water to be Treated	271
8.4.4 Time of Contact Available for Disinfection	271
8.4.5 Temperature of the Water	271
8.5 MATHEMATICAL RELATIONSHIPS GOVERNING DISINFECTION VARIABLES	271
8.5.1 Contact Time	272
8.5.2 Concentration of Disinfectant	272
8.5.3 Temperature Of Water	273
8.6 CHLORINATION	273
8.6.1 Chlorine and its Properties	273
8.6.2 Chlorine-Water-Reactions	274
8.6.2.1 Free Available Chlorine	273
8.6.2.2 Combined Available Chlorine	274
8.6.2.3 Chlorine Demand	275
8.6.2.4 Estimation Of Chlorine	275
8.6.3 Chlorination Practices	277
8.6.3.1 Free Residual And Combined Residual Chlorination	277
8.6.4 Chlorine Residual	280
8.7 APPLICATION OF CHLORINE	280
8.7.1 Safe Handling Practices	281
8.7.1.1 Storing Shipping Containers	281
8.7.1.2 Filling Containers	281
8.7.1.3 Connecting And Disconnecting Containers	282
8.7.2 Chlorinators	282
8.7.2.1 Types Of Feeders	282
8.7.3 Engineering Control of Hazards	283

8.7.1.1	Flow Systems	176
8.7.1.2	Number Of Cylinders Or Columns	177
8.7.1.3	Maintenance	185
8.7.4	Filtering	176
8.7.5	Alarm Components	187
8.7.6	Another Equipment	187
8.7.6.1	Scoping Systems	187
8.7.6.2	Pressure Protection Equipment	188
8.7.6.3	Alarms Detectors	187
8.7.6.4	Automatic Control System	187
8.7.7	Safety Considerations	187
8.7.8	Emergency Energies	188
8.7.9	Personnel Training	187
8.8	CHLORINE COMPOUNDS	186
8.9	DISINFECTANTS: METHODS OF USE AND EVALUATION	188
8.9.1	Chlorine	187
8.9.2	Chlorine Disinfectants	188
8.9.2.1	Halogen Other Than Chlorine	187
8.9.2.2	Ozone	189
8.9.2.3	Elementary Peroxides	189
8.9.2.4	Metal Ions	189
8.9.2.5	Acids And Bases	189
8.9.3	Radiation	189
8.9.3.1	Ultraviolet Radiation	189
9. SPECIFIC TREATMENT PROCESSES		188
9.1	INTRODUCTION	189
9.2	CONTROL OF ALGAE	189
9.2.1	General	189
9.2.2	Caustic Factors For Growth	189
9.2.2.1	Nutrients In Water	189
9.2.2.2	Temperature	189
9.2.2.3	Effect Of Turbidity	189
9.2.2.4	Light	189
9.2.2.5	Characteristics Of Recovery	189
		189

9.2.2.6. Acetylene Filaments	305
9.2.3. Keratinal Measures	305
9.2.3.1. Nucleolar Measures	307
9.2.3.2. Central Nucleolar Algebrical Treatment	311
9.2.3.3. Relative Measure of Cell Area And Nucleolar Volume	311
9.3. CYTOLOGICAL FASTS AND COLLECTOR MATERIALS	312
9.3.1. General	312
9.3.2. Control of Factors and Objects	313
9.3.2.1. Preparing Measures	315
9.3.2.2. Preparing Measures	315
9.4. REMOVAL OF COLOUR	316
9.4.1. Classes of Colour	317
9.4.2. Colour Removal	318
9.4.2.1. Colour Due To Dyes And Minerals	318
9.4.2.2. Colour Due To Yeast	319
9.4.2.3. Colour Due To Colloidal Suspensions	31
9.4.2.4. Colour Due To Industrial Waste	318
9.4.2.5. Oxidation Of Colour	318
9.4.2.6. Treatment By Acetone And Alcohol	319
9.5. STAINING	319
9.5.1. General	319
9.5.2. Methods of Staining	320
9.5.2.1. Fine And Fine Structure Staining	321
9.5.2.2. Ion Exchange Staining	322
9.5.2.3. Combination Of Fine And Ziehl Staining	323
9.6. REMOVAL OF IRON AND METALS FROM	324
9.6.1. Staining and Stains	325
9.6.2. Removal Methods	325
9.6.2.1. Permeation	329
9.6.2.2. Organic Reils	329
9.6.2.3. Zeolite	327
9.6.2.4. Organic Mixtures	329
9.6.3. Staining Techniques For 2.6. Removal of Iron And Metals from	325
9.6.3.1. Application of Removal of Pigments and Dyes	329

2.5.1.7.10 Reviews for Large Communities	329
2.6 DEFLORIDATION OF WATER	331
2.6.1 Removal Methods	332
2.6.1.1 Ion-exchange	332
2.6.1.2 Adsorption	332
2.6.1.3 Activated Carbon	332
2.6.1.4 Aragonite Salts	333
2.6.1.5 Amorphous Salts	333
2.6.2 Simple Method of Defluoridation	334
2.6.2.1 Mechanism of Defluoridation By Na ₂ CO ₃ Technique	339
2.6.2.2 Water Supply Using Precipitation, Settling, Filtration Scheme of Na ₂ CO ₃ for Large Communities Operation	339
2.7 MINERALIZATION OF WATER	341
2.7.1 Evaporation	341
2.7.1.1 Salinities	343
2.7.1.2 Seawater Distribution	343
2.7.1.3 Multiple Effect Evaporation	343
2.7.2 Desalting	345
2.7.3 Natural Desalting	345
2.7.3.1 Desalting	345
2.7.4 Ion Exchange Process	346
2.7.5 Performance of Reverse Osmosis	347
2.8 CORROSION	348
2.8.1 Acceleration of Corrosion	348
2.8.2 Types of Corrosion	349
2.8.2.1 Galvanic Corrosion	349
2.8.2.2 Concentration Cell Corrosion	350
2.8.2.3 Stray Current Corrosion	351
2.8.2.4 Stress Corrosion	351
2.8.2.5 General Biocorrosion of Corrosion	351
2.8.3 Physical and Chemical Factors of Water-Induced Corrosion	352
2.8.4 Cathodic Protection	352
2.8.5 Anodic Protection	353
2.8.6 Corrosion Control	354
2.8.6.1 Cathodic Protection	354

9.6.6.2 Protection by Sacrificial Anode	355
9.6.6.3 Control Of Internal Corrosion	356
10. DISTRIBUTION SYSTEM	359
10.1 GENERAL	359
10.2 BASIC REQUIREMENTS	359
10.2.1 Continuous Versus Intermittent System of Supply	359
10.2.2 System Pattern	359
10.2.3 Zoning	360
10.2.4 System of Supply	360
10.2.5 Location of Service Reservoirs	360
10.3 GENERAL DESIGN GUIDELINES	360
10.3.1 Peak Factor	360
10.3.2 Peak Demand	361
10.3.3 Residual Pressure	361
10.3.4 Minimum Pipe Sizes	361
10.3.5 Layout	361
10.3.6 Elevation of Reservoir	361
10.3.7 Boosting	362
10.3.8 Location of Mains	362
10.3.9 Valves	362
10.4 SERVICE RESERVOIRS	362
10.4.1 Function	362
10.4.2 Capacity	363
10.4.3 Structure	363
10.4.4 Inlets and Outlets	363
10.5 BALANCING RESERVOIRS	364
10.6 HYDRAULIC NETWORK ANALYSIS	364
10.6.1 Principles	364
10.6.2 Methods of Balancing	365
10.7 DESIGN OF PIPE NETWORKS	372
10.7.1 Approximate Methods	372
10.7.2 Equivalent Pipe Method	372
10.7.3 Pipe Network Cost Minimization Problems	373
10.7.3.1 Formulation Of The Objective Function	374

10.7.5.1 Enumeration of the Constraints	374
10.7.5.2 Analysis	375
10.7.5.3 Generating a Starting Solution	377
10.7.5.4 Generating a Feasible Solution	377
10.7.5.5 Selected Random Search Procedure	379
10.8. APPLICATION OF GENETIC ALGORITHMS TO THE DESIGN OF PIPE	384
10.8.1. SCOPE OF THE CONSTRUCTION	388
10.8.2. Layout	388
10.8.3. System of Supply	388
10.8.4. Downside Supply System	395
10.8.5. Materials for House Service Connections	399
10.10. REVIEW AND MAINTENANCE	381
10.10.1. General	381
10.10.2. Waste Assessment and Abatement	381
10.10.3. Cleaning of Pipes	386
11. PRODUCTION AND MAINTENANCE OF WATER SERVICES AND SERVICES	386
11.1.1. Pipe and Segments	388
11.1.2. Vertical Support	389
11.1.3. Unusual Conditions	389
11.2. PROTECTION AGAINST BURSTS	389
11. PUMPING STATIONS AND MACHINERY	391
11.1. REQUIREMENTS	391
11.1.1. Selection of Pumps	392
11.1.2. Types and Constructions of Pumps	397
11.1.2.1. Pump Types Based On The Method of Operating Principle	397
11.1.2.2. Pump Types Based On The Form of Energy Input	397
11.1.2.3. Pump Types Based On The Method Of Coupling the Drive	397
11.1.2.4. Pump Types Based On The Construction of Pump Case	397
11.1.2.5. Pumps Types Based On Constructional Features	397
11.1.3. Criteria for Pump Selection	399
11.1.4. Considerations of the Parameters of Flow Discharge and Speed in the Selection of a Pump	399
11.1.5. Consideration of the Sectional Output for Pump Selection	399
11.1.5.1. The Meaning Of NPSH	399
11.1.5.2. Vapor Pressure and Cavitation	399
	380

11.8.1	Periodic inspection and Test	421
11.8.2	Daily Observations	421
11.8.3	Semi Annual Inspection	421
11.8.4	Annual Inspection	422
11.8.5	Facilities for Maintenance and Repairs	423
11.8.5.1	Consumables And Lubricants	423
11.8.5.2	Replacement Spares	423
11.8.5.3	Repair Work Shop	423
11.9	TROUBLE SHOOTING	423
11.10	SELECTION OF ELECTRIC MOTORS	429
11.10.1	General	429
11.10.2	Selection Criteria	429
11.10.2.1	Constructional Features Of Induction Motors	429
11.10.2.2	Method Of Starting	429
11.10.2.3	Voltage Ratings	429
11.10.2.4	Type Of Enclosures (Table 11.11)	430
11.10.2.5	Class Of Duty	430
11.10.2.6	Insulation	431
11.10.2.7	Selection Of Motor Rating	431
11.11	STARTERS	431
11.11.1	TYPES	431
11.11.2	STARTERS FOR SQUIRREL CAGE MOTORS	431
11.11.2.1	Selection Of The Tapping Of Auto Transformer Type Starter	432
11.12	PANELS	432
11.12.1	Regulators	432
11.12.2	Various Functions	432
11.12.3	Improvement of Power Factor	433
11.12.3.1	Selection Of Capacitors	433
11.12.3.2	Installation Of Capacitors	433
11.12.3.3	Operation And Maintenance Of Capacitors	437
11.13	CABLES	437
11.14	TRANSFORMER SUBSTATION	438
11.14.1	Essential Features	438
11.14.2	Duplicate transformer may be provided, where installation so demands	439

11.15	MAINTENANCE AND REPAIRS OF ELECTRICAL EQUIPMENT	439
11.15.1	Consumables	439
11.15.2	Replacement Spaces	439
11.15.3	Tools and Test Equipments	439
11.15.4	Preventive maintenance	439
11.15.4.1	Daily	439
11.15.4.2	Monthly	439
11.15.4.3	Quarterly	440
11.15.4.4	Semi-Annual	440
11.15.4.5	Annual	441
11.15.4.6	Bi-Annual	441
11.16	TROUBLE SHOOTING FOR ELECTRICAL EQUIPMENT	441
11.16.1	Motor gets Overheated	441
11.16.2	Motor gets Over loaded: (drawing more than the rated current at the rated voltage)	441
11.16.3	Starter/Breaker trips	442
11.16.4	Vibration in Motor	442
11.16.5	Cables Get Over-heated	442
12.	INSTRUMENTATION AND CONTROLS IN WATER TREATMENT PLANT	443
12.1	INTRODUCTION	443
12.2	PURPOSE AND OBJECTIVE	443
12.2.1	Instruments & Control Systems	443
12.3	SYSTEMS AVAILABLE	444
12.3.1	Mechanical	444
12.3.2	Pneumatic	444
12.3.3	Electric	444
12.3.4	Electropneumatic	444
12.3.5	Hydropneumatic	444
12.3.6	Method of Control	445
12.3.6.1	Manual	445
12.3.6.2	Semi Automatic	445
12.3.6.3	Automatic	445
12.4	DESIGN PRINCIPLES AND PRACTICES	445
12.5	LEVEL MEASUREMENT	445

13.4.1. Measurement of Pumps & Pumping Machinery	466
13.4.2. Measurement of Turbomachinery drives	466
13.5. COMPRESSOR AND FAN CHARACTERISTICS AND PERFORMANCE PLANTS	467
13.5.1. Definitions	467
13.5.2. Requirements	468
13.5.3. Cent. Comp.	468
13.5.4. Flow Measurement Device	468
13.5.5. Dynamic Loading Curve	468
13.5.6. Axial Flow	469
13.5.7. Slow Speed	470
13.5.8. Characterization Data Tables	470
13.5.9. Rapid Capacity Filters	470
13.5.10. Standard Data	471
13.5.11. Characteristics	472
13.5.12. Clearances, Stagnation & Inlet Loss	472
13.5.13. Losses	473
13.6. AIR COMPRESSORS	473
13.7. COMPRESSOR SYSTEMS, KIN. VARIABLES AND PERFORMANCE VARIABLES	473
13.8. COMPRESSOR SYSTEMS	474
13.9. NETWORK DESIGN AND OPTIMIZATION	475
13.10. FLOW NETWORKS, DESIGN, ETC.	476
13.11. NETWORK SYSTEMS	476
14. WATER WORKS MANAGEMENT	477
14.1. ASPECTS OF MANAGEMENT	477
14.1.1. Government of India, 1956 Act	477
14.1.2. State Government Act	478
14.1.3. Local Body Act	478
14.1.4. OTHER ASPECTS OF WATER WORKS MANAGEMENT	478
14.2. MUNICIPAL WATER SUPPLY SYSTEMS	479
14.2.1. Laws and Regulations	479
14.2.2. General Administration of Operating Level	480
14.2.3. Sewerage Administration	481
14.3. DESIGN OF COLLECTION	481
14.4. COLLECTION SYSTEMS & PLANNING	481

14.6 INSERVICE TRAINING	482
14.7 LONGTERM PLANNING	483
14.8 PUBLIC RELATIONS	484
15. LABORATORY TESTS AND PROCEDURES	485
15.1 GENERAL	485
15.2 TYPES OF EXAMINATIONS	485
15.3 SAMPLING	486
15.3.1 Sampling for Physical and Chemical Analysis	486
15.3.2 Sampling for Bacteriological Analysis	487
15.3.2.1 Sampling Bottles	487
15.3.2.2 Decalcification	487
15.3.2.3 Sample Collection	487
(a) Sampling from Taps	487
(b) Sampling Direct from a Source	488
15.3.2.4 Size Of The Sample	488
15.3.2.5 Preservation And Storage	489
15.3.3 Sampling for Biological Analysis	489
15.3.4 Frequency of sampling	489
15.4 STANDARD TESTS	490
15.4.1 Physical Examination	490
15.4.2 Chemical Examination	490
15.4.3 Bacteriological Examination	491
15.4.4 Schedule of Tests	491
15.5 METHODS OF EXAMINATION	491
15.5.1 Reporting of Results	491
15.6 LABORATORY EQUIPMENT AND FACILITIES	492
15.6.1 Recommended Minimum Tests and Equipment	492
15.6.2 Facilities	493
15.6.3 Equipment	493
15.7 RECORDS	493
15.8 LABORATORY PERSONNEL	494
16. COMPUTER AIDED OPTIMAL DESIGN OF WATER TREATMENT SYSTEM	495
16.1 GENERAL	495

16.2 DYNAMIC PROGRAMMING	493
16.2.1 Concept	495
16.3 APPLICATION TO WATER TREATMENT SYSTEM DESIGN	497
16.4 PERFORMANCE MODELS	497
16.4.1 Rapid Mix Unit	497
16.4.2 Slow Mix (Flocculation Unit)	498
16.4.3 Sedimentation Unit	500
16.4.4 Rapid Sand Filtration	500
16.4.5 Disinfection	503
16.5 COST MODELS	503
16.6 PROBLEM FORMULATION	505
17. FINANCIAL AND MANAGEMENT OF WATER SUPPLY PROJECTS	508
17.1 WATER SUPPLY FINANCING	508
17.1.1 Scope	508
17.2 CAPITAL AND REVENUES	509
17.3 SOURCES FOR RAISING CAPITAL	509
17.3.1 Authority Responsible	510
17.3.2 The Relative Merits of the Various Methods	511
17.4 METHODS OF RAISING REVENUES	511
17.4.1 Water Tax	511
17.4.2 Water Rates	511
17.5 WATER SUPPLY MANAGEMENT	513
17.5.1 Scope	513
17.5.2 Tasks	513
17.6 FINANCIAL APPRAISAL OF WATER SUPPLY PROJECTS	513
17.6.1 Introduction	514
17.6.2 Project Cycle	515
17.6.3 Financial Appraisal	517
17.6.4 Financial Analysis Statements	520
17.7 STATUTORY WATER AND SANITATION BOARDS	520
17.8 CONCLUSION	522
18. LEGAL ASPECTS	526
18.1 GENERAL	526

(XVIB)

18.2 SYSTEM OF ACQUISITION OF WATER USE RIGHTS	526
18.2.1 Riparian Rights System	526
18.2.1.1 Natural Flow Doctrine	527
18.2.1.2 Reasonable Use Doctrine	527
18.2.1.3 Loss Of Riparian Rights	528
18.2.2 Prior Appropriation System	528
18.2.2.1 Elements Of An Appropriation	528
18.2.2.2 Beneficial Uses	529
18.2.2.3 Quantity Of Water	529
18.2.2.4 Place Of Use	529
18.2.2.5 Preferences	529
18.2.2.6 Changes In Appropriation	530
18.2.2.7 Transfers Of Appropriation	530
18.2.2.8 Loss Of Appropriation	530
18.2.3 System of Administrative Disposition of Water	530
18.3 SURFACE WATER	531
18.3.1 Power of Legislation Regarding Water	531
18.3.2 National Water Policy	531
18.4 GROUNDWATER	532
18.5 PREVENTION AND CONTROL OF POLLUTION	533

APPENDICES

A ABBREVIATIONS AND SYMBOLS	535
B CONVERSION FACTORS	537
C LIST OF INDIAN STANDARDS RELATIVE TO WATER SUPPLY	541
D LAYOUT OF A TYPICAL SCHEM	559
3.1 CPM NETWORK DIAGRAM FOR A TYPICAL WATER SUPPLY AUGMENTATION SCHEME	564
3.2 MASS DIAGRAM FOR IMPOUNDING STORAGE	575
3.3 GROUND WATER RESOURCES AND IRRIGATION POTENTIAL	578
3.4 CLASSIFICATION OF SOIL	583
3.5 VALUES OF THE WELL FUNCTION $W(u)$ FOR VARIOUS VALUES OF u	584
3.6 TYPE CURVE	586

(xxix)

5.6	YIELD TESTS FOR WELLS	587
5.7	RADIAL COLLECTOR WELL	594
5.8	DISINFECTION OF NEW OR RENOVATED WELLS, TUBEWELLS AND PIPELINES	595
6.1	Hazen Williams Chart	599
6.2	Mannings Chart	600
6.3	Modified Hazen's William Chart	601
6.4	HYDROSTATIC TEST PRESSURES FOR PIPES	602
6.5	DESIGN FOR ECONOMIC SIZE OF PUMPING MAIN]	604
6.6	DESIGN OF THRUST BLOCKS	609
6.7	DESIGN OF AIR VESSEL	612
7.1	DESIGN OF SPRAY TYPE AERATOR	616
7.2	DESIGN OF MECHANICAL RAPID MIX UNIT	621
7.3	DESIGN OF CLARIFLOCCULATOR	623
7.4	DESIGN OF RECTANGULAR PLAIN SEDIMENTATION TANK	626
7.5	DESIGN FOR RADIAL CIRCULAR SETTLING TANK	630
7.6	DESIGN FOR TUBE SETTLERS	632
7.7	DESIGN FOR RAPID GRAVITY FILTER	634
7.8	PREPARATION OF FILTER SAND FROM STOCK SAND	639
7.9	INFORMATION TO BE INCLUDED IN THE TENDER SPECIFICATIONS FOR WATER TREATMENT PLANT	640
7.10	COMMON CHEMICALS USED IN WATER TREATMENT	644
9.1	COMPUTATION OF CHEMICAL DOSAGES IN WATER SOFTENING	
9.2	TYPE DESIGN OF IRON REMOVAL PLANT	655
9.3	DESIGN OF IRON REMOVAL UNITS	656
9.4	SOLAR RADIATION	661
10.1	CALCULATION OF CAPACITY OF SERVICE RESERVOIR	665
10.2	DETAILS OF BELL MOUTH FOR OUTLET CONNECTIONS IN SERVICE RESERVOIRS	669
10.3	SOLUTION TO THE PROBLEM ON HARDY CROSS METHOD OF BALANCING HEAD LOSSES BY CORRECTING ASSUMED FLOWS	670
11.1	DESIGN CALCULATIONS FOR A PUMPING PLANT	673

13.1	RECOMMENDED MENIUM OPERATION AND MAINTENANCE STAFF PATTERN SURAFACE SOURCE: TYPICAL STAFF PATTERN (UPTO 5 MLD SYSTEM) WITH CONVENTIONAL TREATMENTS	682
13.2	RECOMMENDED MENIUM OPERATION AND MAINTENANCE STAFF PATTERN SURAFACE SOURCE: TYPICAL STAFF PATTERN (FOR 5 TO 25 MLD SYSTEM) WITH CONVENTIONAL TREATMENTS	683
13.3	RECOMMENDED MENIUM OPERATION AND MAINTENANCE STAFF PATTERN SURAFACE SOURCE: TYPICAL STAFF PATTERN (FOR 25 TO 50 MLD SYSTEM) WITH CONVENTIONAL TREATMENTS	685
13.4	RECOMMENDED MENIUM OPERATION AND MAINTENANCE STAFF PATTERN SURAFACE SOURCE: TYPICAL STAFF PATTERN (FOR 50 TO 75 MLD SYSTEM) WITH CONVENTIONAL TREATMENTS	688
13.5	RECOMMENDED MENIUM OPERATION AND MAINTENANCE STAFF PATTERN ABOVE 75 MLD UPTO 150 MLD	690
13.6	RECOMMENDED MENIUM STAFFING PATTERN FOR OPERATION AND MAINTENANCE SOURCE : BATTERY AND BOREWELLS TUBEWELLS, OPENWELLS (EACH WELL YIELDS 5000 GPM MAXIMUM)	692
13.7	RECOMMENDED MENIUM STAFFING PATTERN FOR OPERATION AND MAINTENANCE SOURCE : LARGE DIA. HIGH YIELDING TUBEWELL	693
13.8	SCHEDULE OF PREVENTIVE MAINTENANCE CLARIFLOCCULATORS & THEIR DRIVE	696
14.1	SUGGESTED STAFFING PATTERN FOR SUPERVISORY ENGINEERING DIVISION (WORKLOAD RS - 200 LAKHS ANNUALLY 1988) AND SUPERVISION (WORKLOAD RS - 50 LAKHS ANNUALLY 1988) FOR O. & M. OF WATERWORKS	697
14.2	REQUIREMENT OF STAFF FOR O & M	698
15.1	MINIMUM STAFF RECOMMENDED FOR WATER WORKS LABORATORIES	699
15.2	PARTICULARS TO BE SUPPLIED WITH THE SAMPLES	700
15.3	SPECIMEN FORM FOR SHORT PHYSICAL AND CHEMICAL EXAMINATION	702
15.4	SPECIMEN FORM FOR COMPLETE PHYSICAL, CHEMICAL AND EXAMINATION	704
15.5	SPECIMEN FORM FOR SHORT BACTERIOLOGICAL EXAMINATION OF WATER	708

15.6	SPECIMEN FORM FOR SHORT BACTERIOLOGICAL EXAMINATION OF WATER	709
15.7	MINIMUM EQUIPMENTS NEEDED FOR PHYSICAL AND CHEMICAL TESTS	710
15.8	EQUIPMENT NEEDED FOR BACTERIOLOGICAL EXAMINATION BACTERIOLOGICAL MEDIA	711
15.9	TEST TO BE DONE BY WATER WORKS LABORORIES	712
17.1	AVERAGE INCREMENT COST PER 1000 LITERS	713
17.2	NET PRESENT WORTH AND BENEFIT COST RATIO OF THE PROJECT AT DISCOUNT RATE 8.5% AND INTERNAL RATE OF RETURN	714
17.3	ASSUMPTIONS FOR FINANCIAL FORECASTS	716
17.4	INCOME AND EXPENDITURE STATEMENT OF WATER SUPPLY AND SEWERAGE/SANITATION PROJECT	718
17.5	FUNDING MATTERS	725
17.6	PROJECT SOURCES AND APPLICATION FOR FUNDS (CASH FLOW) STATEMENT	726
17.7	INTEREST ADDED TO THE CAPITAL DURING MORATORIUM PERIOD	730
17.8	CALCULATION OF ANNUITY	
	CALCULATION OF PRINCIPAL & INTERESTS OF ANNUITY	731
17.9	PROJECT BALANCE SHEET (WATER SUPPLY & SANITATION) AS ON 31 ST MARCH	732
	BIBLIOGRAPHY	739



CHAPTER I

INTRODUCTION

Water constitutes one of the important physical environments of man and has a direct bearing on his health. There is no gainsaying that contamination of water leads to health hazards. Water is precious to man and therefore WHO refers to "control of Water Supplies to ensure that they are pure and wholesome as one of the primary objectives of environmental sanitation". Water may be polluted by physical, chemical and bacterial agents. Therefore, protected water supply is a sine qua non of public health of a community.

The population of India is likely to be around a thousand million by the end of the century. The urban population would be around four hundred million by that time. This means a very large demand on the civic amenities including water supply for domestic purposes and in addition more water would be needed for purposes such as irrigation, industry, etc., which have to keep pace with the increasing demands of rising population. Therefore, identification of sources of water supply, their conservation and optimal utilization is of utmost importance. Even the present scale of water supply to urban and rural population is grossly inadequate and not all communities are provided with safe water supply, let alone piped water system; hardly any metropolitan city has a continuous water supply; and very few cities could boast of providing adequate water supply to meet their growing demands at adequate pressure.

Many facets are involved in tackling the problem of providing protected water supply to all communities at the minimum cost and in the shortest possible time. Emphasis has to be laid on both the aspects of the system namely, planning and management technical and financial. At present a number of decisions, both at policy and technical levels, are being based on empirical considerations and divergent practices are in vogue in the country in so far as designing the system itself is concerned. The Manual would have to attempt at the unification of these practices and help to inculcate rationale to policy and managerial decisions apart from giving guidance to the public health engineers in achieving the target of providing safe water to all communities economically and expeditiously.

Obviously, it would be in the interest of public health engineers to have a standard manual in public health engineering and a code of practice which could serve as a guide in their day to day practice. This Manual would discuss the basic principles such as planning, identification of source of supply, development and transmission, water treatment, distribution system, testing and other related administrative aspects and also explain in detail the proper approach to each problem.

This Revised Manual has taken into account the recent technical advances and trends in the development of protected water supply systems, some of the major changes and additions as highlighted in the following areas:

- ◆ Ground water potential and its development in hard rock regions;
- ◆ Well development, failure of wells and remedial measures;
- ◆ Ground water abstraction through radial wells;
- ◆ Measurement of flow;
- ◆ Minimum requirements for domestic, non-domestic, institutional, fire fighting and industrial needs;
- ◆ Minimum residual pressure and quality standards including virological aspects;
- ◆ Concept of unit operations;
- ◆ Scheme of pumping and feeding;
- ◆ Recent concepts of coagulation and flocculation;
- ◆ Advances in filtration;
- ◆ Operation and maintenance problems in various unit operations involved in water supply, from source development to the actual supply;
- ◆ Pumping stations and equipment;
- ◆ Hydraulic network analysis, direct design of networks and computer programming;
- ◆ Preventive maintenance including detection and prevention of wastage;
- ◆ Protection against pollution and freezing;
- ◆ Corrosion and its prevention;
- ◆ Water hammer problems;
- ◆ House service connections;
- ◆ Optimal design of water treatment systems;
- ◆ Instrumentation & controls in water treatment plants;
- ◆ Financing and management;
- ◆ Legal aspects;
- ◆ Laboratory tests and procedures with special reference to the classification of the water works laboratories

In keeping with the changeover to the metric system, the various units of measurements, operational parameters and design criteria have all been confined to the metric system only, with deliberate omission of equivalents in the British System generally furnished alongside. This has been felt necessary, since there is, still an apathy on the part of the field engineer to break away from the conventional, in which he feels at home, since tradition dies hard.

However, a table of conversion factors has been appended to facilitate the verification of any of the parameters by conversion to the units he is accustomed to.

This Manual also contains a set of appendices furnishing useful information helpful in solving day to day problems which the practicing engineer is likely to encounter. Model problems have been worked out which have a relevance in design. Useful references of the Bureau of Indian Standards, are also listed in a separate appendix. Charts for Hazen-Williams formula as well as Manning's formula, which are frequently used, are presented in the same system in separate appendices.

A companion Manual on Sewerage and Sewage Treatment has been brought out by the erstwhile Union Ministry of Works and Housing, (Central Public Health and Environmental Engineering Organisation) which has been revised and published in 1993. The recommendations of this Manual and the provisions of the Water (Prevention and Control of Pollution) Act, 1974 should be followed wherever applicable.

CHAPTER 2 PLANNING

2.1 OBJECTIVES

The objective of a public protected water supply system is to supply safe and clean water in adequate quantity, continuously and as economically as possible. The planning can be required at national level for the country as a whole, or for the state or region or community. Though the responsibility of the various organizations involved in planning of water supply systems at each of these levels is different, they still have to function within the priorities laid out by national and state governments, taking into consideration, the needs to be provided with water supply and the most economical way of doing it, keeping in view the overall requirements of the entire region.

The water supply projects formulated by the various state authorities and local bodies at present do not contain all the essential elements for appraisal and when projects are absorbed for their cost bearing and for investment or other funding, they are not amenable for comparative study and appraisal. Also, different guidelines and norms are adopted by the central and state agencies, for example, use of pipes regarding per capita water supply, design period, population criterion, management of flow, water treatment, specifications of materials, etc. Therefore, there is a need to specify appropriate standards, planning and design criteria to be developed and adopted.

2.2 BASIC DESIGN CONSIDERATIONS

Engineering decisions are required in respect of the area and population to be served. In design period, the per capita rate of water supply, other water needs in the area, the option and location of facilities to be provided, the utilization of centralized or multiple means of treatment facilities and points of water supply in area and waste water disposal. Projects have to be identified and prepared in adequate detail in order to enable timely and proper implementation. Organization may call for planning for a number of phases relating to plant capacity and the degree of treatment to be provided by determining the capacities for several units, working out capital cost required, interest charges, period of repayment or loan, water rate and water rate. Uncertainties in such studies are many, such as the difficulties in anticipating new technology and changes in investment pattern, the latter being characterized by increasing financing costs.

2.2.1 WATER QUALITY AND QUANTITY

The wastes to be handled may vary both as quantity and quality and in the degree of treatment required, seasonally, monthly, daily and sometimes even hourly. The public health engineer may use his ingenuity to mitigate the variations in quantity by provision of storage

which may be drawn upon during peak demand. Availability in quality can be managed by provision for the introduction of suitable process adjustments at the water treatment plant.

2.2.1.1 Water Conservation

Increasing demand for water in urban centres has led to population increases, commercial and industrial development and improvements in living standards as putting enormous pressure on earth and economically exploitable water resources. Not only the quantity of traditional fresh water resources is being depleted but also the quality is deteriorating. Ground water may be effectively contaminated, for example, due to excessive discharge of urban solid wastes, non-point run-off and even leakage in some cases. The uncontrolled extraction of ground waters for agricultural and industrial uses, the problem is the non-agricultural factors, water pollution, heavy subsurface flows for discharge of municipal and industrial wastewater, and lower quality parameters which may require application of advanced water treatment processes. It has therefore, become essential to initiate an holistic, effective and integrated approach for water conservation.

Water conservation may be possible through the following methods: (a) use of available water resources, (b) prevention and control of wastage of water and effective demand management.

2.2.1.2 Increasing The Water Availability And Supply & Demand Management

The measures required to increase the water availability involve augmentation of water resources by storing rainwater on the surface or below the surface. Surface storage is usually contemplated either in natural ponds, reservoirs and hills or artificially created depression ponds, impounding reservoirs or tanks. Subsurface storage of water is effected by constructing subsurface dikes, artificial recharge wells, etc. For storing subsurface water in rocky areas, several techniques have been employed independently like packed Well Technique, Bed Block Technique, Fracture Seal Cementation etc. These techniques have been deployed to improve porosity, storage volume as well as impermeability between fractures/fissures and other types of pores. Artificial recharge of ground water may be contemplated in some areas.

Water supply management aims at improving the supply by minimizing losses and wastage and unaccounted for water (UFW) in the transmission mains and distribution system (Reference may also be made to section 10.10). The unaccounted for water constitutes a significantly higher fraction of total water supplied in poorly managed water transmission and distribution systems. Measures like detection, control and prevention of leakage, metering of water supply, installation of properly designed waste not taps and prompt action to repair and maintain distribution system components should be adopted.

Water demand management involves measures which aim at reducing water demand by optimal utilization of water supplies for all essential and desirable uses. It focuses on identification of all practices and uses of water in excess of functional requirement. Use of plumbing fixtures, such as low volume and dual flush systems in place of conventional 12.5 litre capacity systems which conserve water may be encouraged. Practices like reuse and recycling of treated wastewater may be promoted for which references may be made to

depending on the time of the project. If the design period can however be modified to agree to certain components of the project depending on their useful life or the facility to be designed, arrangements should be made and one's interest in that respect should be clearly defined. Necessary data for future or future augmentation components should be supplied at the beginning itself. Where large scale tunnels and large structures are involved existing large capacity during the design period may be designed for future proper equipments. Where large scale as in pipes or small pipes or distribution pipe line in case of construction for a long time or for special cases present in the form of such as flood, fire and emergency adaptation will not be necessary.

Practical equipments may be designed to suit the requirements of the following design periods:

Sr. No.	Items	Design period in years
1	Storage tanks	30
2	Distribution works	30
3	Pumping	
	a. Pump house (civil work)	30
	b. Electrical works and pumps	15
4	Water treatment units	15
5	Pipes, conduits for sewerage treatment units and other small apparatuses	30
6	Rise water and discharge control equipments	30
7	Raw water reservoirs at the intake, distribution tanks and service reservoirs, reticulation mains etc.	15
8	Distribution system	30

2.2.7 POPULATION FORECAST

2.2.7.1 General Considerations:

The design population will have to be estimated with due regard to all the factors governing the future growth and development of the project area in the industrial, commercial, administrative, social and administrative aspects. Special factors causing sudden surge in population should also be assessed to the extent possible.

A study should be made in this regard to determine whether the present or the predicted future population growth in the area is likely to be the cause of the future population growth, graphically represented in the following manner:

a) Demographic Method of Population Projection

Population change can occur only in three ways (i) by birth (population gain) (ii) by deaths (population loss) or (iii) migration (population loss or gain depending on whether movement out or movement in occurs in excess). Annexation of an area may be considered as a special form of migration. Population forecasts are frequently obtained by preparing and summing up of separate but related projections of natural increase and of net migration and is expressed as below:

The net effect of births and deaths on a population is termed natural increase (total decrease if deaths exceed births).

Migration also affects the number of births and deaths in an area and so, projections of net migration are prepared before projecting the natural increase.

This method thus takes into account the prevailing and anticipated birth rates and death rates of the region or city for the period under consideration. An estimate is also made of the origin of those who immigrate to the city, growth of city area wise, and the net increase in population is obtained statistically by considering all these factors, by arithmetical & geometric.

b) Arithmetical Increase Method

This method is generally applicable to large and old cities. In this method the average increase of population per decade is calculated from the past records and added to the present population to find out population in the next decade. This method gives a low value and is suitable for well settled and established communities.

c) Incremental Increase Method

In this method the increment in arithmetical increase is determined from the past decades and the average of that increment is added to the average increase. This method increases the figures obtained by the arithmetical increase method.

d) Geometrical Increase Method

In this method percentage increase is assumed to be the rate of growth and the average of the percentage increase is used to find out future increment in population. This method gives much higher value and mostly applies for growing towns and cities having vast scope for expansion.

e) Decreasing Rate Of Growth Method

In this method it is assumed that rate of percentage increase decreases and the average decrease in the rate of growth is calculated. Then the percentage increase is modified by deducting the decrease in rate of growth. This method is applicable only in such cases where the rate of growth of population shows a downward trend.

f) Graphical Method

In this method the demographic methods of a city, only the city in question is considered and in the second, other than cities are also taken into account.

(i) Graphical Method Based On Single City

In this method the population curve of the city (i.e. the Population vs. Past Decade) is suitably extended for getting future value. This extension has to be done carefully and it requires vast experience and good judgement. The line of best fit may be obtained by the method of least squares.

(ii) Graphical Method Based On Cities With Similar Growth Pattern

In this method the city in question is compared with other cities which have already undergone the same phases of development. Such the city in question is likely to undergo and based on this comparison, a graph between population and decade is plotted.

g) Logistic Method

The S-shaped logistic curve, for a given city, normally, tends to growth of the city right from beginning to saturation level of population of the city.

h) Method of Density

In this method, total number of dwellings and population in each section of a city is noted out and population figures is done for each section based on above approach. Addition of section wise population gives the population of the city.

2.2.7.2 Final Forecast

While the forecast of the prospective population of a projected area at any given time during the period of design can be derived by any one of the foregoing methods appropriate to each case, the density and distribution of such population within the several areas, zones or districts will again have to be made with a discerning judgement on the relative probabilities of expansion within each zone or district, according to its nature of development and based on existing and contemplated town planning regulations.

Whenever population growth forecasts or master plans prepared by town planning or other appropriate authorities are available, the decision regarding the design population should take into account them. Figures 2.2.10, 2.2.11 and 2.2.12 are examples for estimation of the future population by some of the methods as given in Appendix 2.1.

2.2.8 PER CAPITA SUPPLY

2.2.8.1 Basic Needs

Fixed water supplies for communities should provide adequacy for the following as applicable:

- Domestic needs such as drinking, cooking, bathing, washing, flushing of toilets, garden and individual air conditioning.
- Instructional needs.
- Public purposes such as street washing or street watering, flushing of sewers, watering of public parks.
- Industrial and commercial uses including central air conditioning.

- (c) Fire fighting
- (d) Requirement for livestock; and
- (e) Minimum permissible UFW (Ref. Table 2.1)

2.2.3.2 Factors Affecting Consumption

a) Size of City

Larger the size, more the consumption.

b) Characteristics of Population and Standard of Living

In the high value residential area of the city or in a suburban community, per capita consumption is high. Other areas of large cities have low per capita consumption. A person staying in an independent bungalow consumes more water compared to a person staying in a flat. Habit of person also affects consumption, the type of bath (e.g. tub bath or otherwise) and interest used for dilution etc. also affect the type of consumption.

c) Industries and Commerce

The type and number of different industries also affect consumption. Commercial concern like is that of the retail and wholesale mercantile houses and office buildings.

d) Climatic Conditions

In hot weather, the consumption of water is more compared to that during cold weather.

e) Metering

The consumption of water when supply is metered is less compared to that when the water charges are on flat rate basis.

2.2.3.3 Recommendations

The Environmental Hygiene Committee suggested certain minimum service levels for communities based on population groups. In the Code of Basic Requirements of Water Supply, Drainage and Sanitation (LIC, 1977) as well as the National Building Code, a minimum of 135 lpd has been recommended for all residences provided with full flushing system for excreta disposal. Though the National Sewerage and Sewage Treatment standards stipulate a supply of 150 lpd where no sewerage is existing/contemplated, with a view to conserve water, a minimum of 135 lpd is recommended.

It is well recognised that the minimum water requirements for domestic and other essential beneficial uses should be met through the water supply. Other needs for water including industries etc. may have to be supplemented from other systems depending upon the requirements imposed by the availability of capital funds, and the proximity of water sources having adequate quantities of acceptable quality which can be economically utilised for public water supplies.

Based on the objectives of full coverage of urban communities with easy access to public drinking water in quantities recommended to meet the domestic and other essential needs of the community, the following recommendations are made:

ii) Domestic and non-domestic needs

The recommended values for domestic and non-domestic per capita water supply are given in Table 2.1

TABLE 2.1

RECOMMENDED PER CAPITA WATER SUPPLY LEVELS FOR DIFFERENT SCHEMES

Sl. No.	Classification of towns/cities	Recommended Maximum Water Supply Levels (lpcd)
1	Towns provided with pipe water supply but without sewerage system	30
2	Towns provided with pipe water supply with sewerage system	45
3	Metropolitan and Mega cities provided with piped water supply with sewerage system is existing or envisaged	50

Note:

- (i) In urban areas, where water is provided through public standposts, the head should be considered.
- (ii) Figures include an allowance of 5% (WWT) which should be factored in.
- (iii) Figures include requirements of water for commercial, institutional and other industries. However, the bulk supply to such establishments should be assessed separately with proper justification.

9) Institutional Needs

The water requirements for institutions are also provided in addition to the provisions indicated in 10) above, when required. The water requirements for institutions are given in the provisions as follows. The institutional requirements are given as follows:

Sl.No	Institutions	litres per head per day
1	1. Hospital (incl. Ekg. laundry)	100
2	2. N.Y. of public buildings	200
3	3. N.Y. of beds not exceeding 100	200
4	4. Laundry	100
5	5. Hospital	100
6	6. N.Y. of hotels and medical centres	100
7	7. Training schools/colleges	100
8	8. Government	100
9	9. N.Y. of public places	100

Sl.No.	Institutions	Litres per head per day
8.	Junction Stations and intermediate sections where road or express stoppage (both railways and bus sections) is provided	70
9.	Terminal stations	45
10.	Intermediate stations (excluding road and express stops)	45 (could be reduced to 25 where bathing facilities are not provided)
11.	Day schools / colleges	45
12.	Offices	45
13.	Factories	45 (could be reduced to 30 where no bathrooms are provided)
14.	Cinema, concert halls and theatre	15

c) Fire Fighting Demand

It is usual to provide for fire fighting demand as a circulation draft on the distribution system along with the normal supply to the consumers as assured. A provision in litres per day based on the formula of $100q\sqrt{p}$ where, q = population in thousands may be adopted for communities larger than 25,000. It is desirable that one third of the fire fighting requirements form part of the service storage. The balance requirement may be distributed in several static tanks at strategic points. These static tanks may be filled from the main supply through or across by water mains wherever feasible. The high rise buildings should be provided with adequate fire storage from the practical water supply distribution as indicated in 14.12.

d) Industrial Needs

While the per capita rates of supply recommended will normally include the requirement of small industries (subject that factories) situated within a town, separate provisions will have to be made for meeting the demands likely to be made by large industries within the urban areas. The demand of this demand will be based on the nature and magnitude of each such industry and the quantity of water required per unit of production. The present industrial expansion should be carefully monitored, so that the availability of adequate water supply may attract such industries and add to the economic progress of the community. As can be seen from the tabulation, the quantities of water used by industries vary widely. They are also affected by many factors such as cost and availability of water, waste disposal facilities, management and the types of processes involved. Individual studies of the exact requirement of a specific industry should therefore, be made for each location, the values given below serving only as guidelines. In the context of reuse of water in several industries, the requirement of fresh water for fighting, would considerably

Industry	Unit of production	Water requirement in kilolitres per unit
Agriculture	Acres	4
Distillery	(84 litres/kg of m)	125-150
Flour mill	Tonne	80-100
Laundry	100 kg (laundry)	4
Paper	Tonne	7-12
Special grade	Tonne	60-100
TEXT		
Textile	Tonne	5-10
Textile	Percentage	2
Refrigerator		
Steel	Tonne	200-250
Sugar	Tonne (Cane or sugar)	1-2
Textile	100 Kg (goods)	4-14

e) Pressure Requirements

Piped water supplies should be designed to maintain a 24 hours basis to distribute water to consumers at adequate pressure at all points. Intermittent supplies are neither desirable from the public health point of view nor economical for towns where one-storied buildings are common and for supply to the ground level storage tanks in multi-storied buildings. The minimum residual pressure at service point should be 2m for direct supply. Where two-storied buildings are common, it may be 3m and where three-storied buildings are prevalent, 4 m or is stipulated by local bylaws. The pressure required for fire fighting would have to be located by the fire engines.

2.2.9 QUALITY STANDARDS

The objective of Water Works Management is to ensure that the water supplied is free from pathogenic organisms, clear, palatable and free from undesirable taste and odour, of reasonable temperature, is not corrosive nor scale forming and free from chemicals which could produce undesirable physiological effects. The establishment of minimum standards of quality for public water supply is of fundamental importance in achieving the objective. Standards of quality form the yardstick against which the quality control of public water supply has to be assessed.

Safety inspections are intended to provide a source of information and to locate potential problems. The inspections cover the overall aspect of any fact or situation with a water supply system, including the water works and the distribution system. Moreover such an appraisal is to be verified and confirmed by test readings and tests, which will indicate the severity of the problem. Safety inspections also provide a direct method of pinpointing possible problems and sources of water loss. They are also important in the prevention and control of accidental losses, including overflowing, epidemics of water borne diseases. The data obtained may be used, for example, to operate valves and any deviations from normal that may affect the quality of water.

distribution of safe drinking water. When the inspections are properly carried out at appropriate regular intervals and when the inspectors have the knowledge necessary to detect problems and suggest practical solutions, the position of good quality water is assured.

The establishment of standards for the quantitative aspect of public water supplies has to take into account the limitations imposed by local factors in the several regions of the country. The Environmental Hygiene Committee (1972) recommended that the objective of a public water supply should be to supply water "free from any drink free from risks of transmitting diseases, is pleasing to the senses and available for ordinary and laudatory purposes" and added that "freedom from risks is comparatively more important than physical appearance or hardness" and that safety is an obligatory standard and physical and chemical qualities are optional either a map. These observations are relevant in the development of a comprehensive programme of protected water supply systems for communities, big and small, making use of the available water resources in the different regions, with a wide variation in their physical, chemical and aesthetic qualities, that can be achieved by communities in the course of water supply of their limited resources. The immediate goal is for minimum standards, consistent with the safety of public water supplies. Considering the standards described in the United Nations and further development in the international standardsization and the conditions of the country, the following guidelines are recommended:

of Physical And Chemical Quality Of Drinking Water

The physical and chemical quality of drinking water should be in accordance with the recommended guidelines presented in Table 2.

TABLE 2

RECOMMENDED GUIDELINES FOR PHYSICAL AND CHEMICAL PARAMETERS

No.	Parameter	*Acceptable	**Cause for Rejection
1	total dissolved solids (TDS)	5	25
2	total solids (total dissolved + total suspended)	10	25
3	total suspended solids (TSS)	10	25
4	total hardness (as CaCO ₃)	300	500
5	total hardness (as CaCO ₃)	20	50
6	total hardness (as CaCO ₃)	200	400
7	chlorides (as Cl ⁻) (mg/l)	10	15
8	nitrate (as NO ₃ ⁻) (mg/l)	15	15
9	fluorides (as F ⁻) (mg/l)	1.5	1.5
10	iron (as Fe) (mg/l)	0.3	1.5

Sl. No.	Characteristics	Acceptable	*% Cause for Rejection
13	Iron (as Fe) (mg/l)	0.1	1.0
14	Manganese (as Mn) (mg/l)	0.05	0.5
15	Copper (as Cu) (mg/l)	0.05	1.5
16	Aluminium (as Al) (mg/l)	0.01	0.2
17	Alkalinity (mg/l)	200	1.0
18	Residual Chlorine (mg/l)	0.2	0.5
19	Zinc (as Zn) (mg/l)	5.0	15.0
20	Phenolic compounds (as Phenol) (mg/l)	0.001	0.02
21	Aromatic hydrocarbons (mg/l) as AHS	0.2	1.0
22	Mineral Oil (mg/l)	0.1	0.05

TOXIC MATERIALS

23	Arsenic (as As) (mg/l)	0.05	0.5
24	Cadmium (as Cd) (mg/l)	0.01	0.1
25	Chromium (as hexavalent Cr) (mg/l)	0.05	0.05
26	Cyanides (as CN) (mg/l)	0.05	1.0
27	Lead (as Pb) (mg/l)	0.05	0.05
28	Selenium (as Se) (mg/l)	0.1	0.01
29	Mercury (total as Hg) (mg/l)	0.007	0.001
30	Polynuclear aromatic hydrocarbons (PAH) (mg/l)	0.2	0.2
31	Residual Chlorine (mg/l)	0.2000	Factor to WHO guidelines for drinking water (0.50 mg/l) x 100

BATHO ACTIVITY*

32	Uranium (as U) (mg/l)	0.1	1.0
33	Gross Beta activity (Bq/l)	1	1.0

NOTES

* Factors indicated under the column "Cause for rejection" are the limits upto which the water is generally acceptable to the consumer.

** Figures in excess of these limits will render water unfit for drinking and not

It is recognized that, in the great majority of rural water supplies in developing countries, faecal contamination is widespread. Under these conditions, the national surveillance agency should set medium term targets for progressive improvement of water supplies, as recommended in volume 3 of WHO *Guidelines for drinking-water quality* (1993).

c) Virological Quality

Drinking water must essentially be free of human enteroviruses to ensure negligible risk of transmitting viral infection. Any drinking water supply subject to faecal contamination presents a risk of a viral disease to consumers. Two approaches can be used to ensure that the risk of viral infection is kept to a minimum: providing drinking water from a source verified free of faecal contamination, or adequately treating faecally contaminated water to reduce enteroviruses to a negligible level.

Virological studies have shown that drinking water treatment can considerably reduce the levels of viruses but may not eliminate them completely from very large volumes of water. Virological, epidemiological, and risk analysis are providing important information, although it is still insufficient for deriving quantitative and direct virological criteria. Such criteria can not be recommended for routine use, because of the cost, complexity, and lengthy nature of virological analysis, and the fact that they can not detect the most relevant viruses.

The guideline criteria shown in Table 2.4 are based upon the likely viral content of source waters and the degree of treatment necessary to ensure that even very large volumes of drinking water have negligible risk of containing viruses.

Ground water obtained from a protected source and documented to be free from faecal contamination from its zone of influence, the well, pumps, and delivery system can be assumed to be virus-free. However, when such water is distributed it is desirable that it is disinfected, and that a residual level of disinfectant is maintained in the distribution system to guard against contamination.

TABLE 2.4
RECOMMENDED TREATMENT FOR DIFFERENT WATER SOURCES TO PRODUCE
WATER WITH NEGLIGIBLE VIRUS RISK*

Type of Source	Recommended Treatment
Ground water	
Protected, deep wells; essentially free of faecal contamination	Disinfection ^b
Unprotected, shallow wells; faecally contaminated	Filtration and disinfection
Surface water	
Protected, impounded upland water, essentially free of faecal contamination	Disinfection
Unprotected impounded water on upland river; faecal contamination	Filtration and disinfection

Type of Source	Recommended Treatment
Unimproved (land rivers, creeks, streams, etc.)	Pre-disinfection or storage, filtration, disinfection
Unimproved water (lake, heavy forest, impoundment)	Pre-disinfection or storage, filtration, additional treatment and disinfection
Unimproved water with gross suspended material	Not recommended for drinking water supply

For all sources, the maximum value of turbidity before treatment (disinfection) must not exceed 10 nephelometric turbidity units (NTU) per liter (or 10 NTU per 1.0 L sample).

Residual disinfectant concentration (residual concentration of free chlorine of 0.5 mg/litre or 0.5 mg/litre) maintains a residual water pH of 8.5 or less to be shown to be an essential disinfection process in terms of the degree of microorganism inactivation (99.9%) .

Unimproved water better served than treated water (rapid filtration (sand, dual or mixed media) or slow sand filtration) or slow sand filtration (sand, dual or mixed media) (rapid filtration or filtration process demonstrated to be equivalent for virus reduction) can also receive the degree of virus reduction must be 99.9% .

Additional treatment may include ozonation, slow sand filtration, ozonation with granular activated carbon, adsorption, or another process demonstrated to achieve > 99% virus reduction .

Disinfection should be used continuously to reduce the presence of *E. coli* (forming indicator coliform bacteria).

Model 1: Water Quality Index for Drinking Water Quality (1995)

CHAPTER 3

PROJECT REPORT

3.1 GENERAL

All projects have to follow distinct steps between the period of time committed and completed. These various stages are

- ◆ Pre-implementation Planning
 - Identification of a project
 - Preparation of project
- ◆ Appraisal and sanction
- ◆ Construction of facilities and carrying out of approved activities
- ◆ Operation and Maintenance
- ◆ Monitoring and feedback

3.1.1 PROJECT REPORTS

Project reports deal with the aspects of project selection, planning and execution. It covers as well as the feasibility of projects, economic, financial, social, cultural, environmental, legal, and institutional. For the projects economic feasibility may also have to be examined. Project reports should be prepared in three stages viz. identification report, pre-feasibility report and feasibility report. Projects for small towns or those having a form of a project are not require preparation of feasibility reports. Detailed engineering and preparation of technical specifications and tender documents are not necessary for taking investment decisions, since these activities can be carried out during the implementation phase of projects. For small projects, however, it may be convenient to include detailed engineering in the project report. Standards, layout and drawings can be adopted.

Since project preparator's own expenses and time involved in a project should normally increase through three stages, and at the end of each stage a decision should be taken whether to proceed to the next planning stage, and compare the necessary manpower and financial resources for the next stage. Report at the end of each stage should include a time table and cost estimate for making up the next stage activity, and a realistic schedule for all future stages of project development, being into consideration time required for review and approval of the report, providing funding for the next stage, including resources of funding agency for the next stage of project processing, data gathering, physical survey, site investigations etc.

The basic design of a project is influenced by the authorities/organizations who are involved in approving, implementing and operating and maintaining the project. Therefore, the institutional arrangements through which a project will be brought into operation, must be considered at the project preparation stage. Finality responsibility for project preparation may change at various stages. Arrangements in this respect should be finalized for each stage of project preparation. Organisms more than one organization may have a role to play in the various stages of preparation of a project. It is, therefore, necessary to identify a single entity to be responsible for overall management and coordination of each stage of project preparation. It is desirable that the implementing authority and those responsible for operation of a project are identified in the project preparation stage.

3.2 IDENTIFICATION REPORT

Identification report is basically a "desk study", to be carried out relying primarily on the existing information. It can be prepared relatively quickly by those who are familiar with the project area and need of project environment. This report is essentially meant for establishing the need for a project, indicating likely objectives, which would meet the requirements. It also provides an idea of the magnitude or cost categories of a project to be taken into account in the planning and budgeting cycle, and makes out a case for obtaining sanction to incur expenditure for carrying out the next stages of project preparation. The report should be brief and include the following information:

- ◆ Identification of project area and its physical environment
- ◆ Commercial, industrial, educational, cultural and religious institutions and activities in and around the project area (also point out special activities or establishments like defence, or others of national importance)
- ◆ Existing population, its place and distribution and socio-economic analysis
- ◆ Present and supply existing status and quality of service in the project area, pointing out deficiencies, if any, in quality, quantity and delivery system
- ◆ Population projection for the planning period according to existing and future land use plans, or master plans, if any
- ◆ Water requirements during planning period for domestic, industrial, commercial and other uses
- ◆ Establish the need for taking up a project in the light of existing and future deficiencies in water supply services, pointing out adverse impacts of non-implementation of the project, on a broad scale
- ◆ Bring out how the project would fit in with the national, regional/sectoral strategies and with the general overall development in the project area
- ◆ Identify a strategic plan for long term development of water supply services in the project area, in the context of existing regional development plans, water resources studies and such other reports, indicating phases of development.

- ◆ State the objectives of the short term project under consideration, in terms of population to be served, other consumers, if any, service standard to be provided, and the impact of the project after completion clearly mark the design period.
- ◆ Identify project components, with alternatives if any, both physical facilities and supporting activities.
- ◆ Preliminary estimates of costs (on a parwise) of construction of physical facilities and supporting activities, cost of operation and maintenance, identify source for financing capital costs, and capital cost mechanism, such as annual budget facility, revenue = operation & expenditure.
- ◆ Indicate institutions responsible for project approval, financing, implementation, operation and maintenance (e.g. National Government, State Government, Zilla Parishad, Local Body, Water Supply Board).
- ◆ Indicate organization responsible for preparing the project (pre-feasibility report, feasibility report), cost estimates for preparing project report, and sources of funds to finance preparation of project reports.
- ◆ Give the time table for carrying out all future stages of the project, and the earliest date by which the project might be operational.
- ◆ Concrete personnel strength reported for implementation of the project, indicate if any particular/possible difficulties of nature or other nature are likely to be encountered for implementation; the project and how these could be resolved.
- ◆ Recommended actions to be taken on project further.

The following items may be enclosed with the report:

- (a) An index plan on a scale of 1 cm = 2 km showing the project area, existing works, proposed works, location of community / township or institution to be served.
- (b) A schematic diagram showing the salient levels of project components.

3.3 PRE-FEASIBILITY REPORT

After clearance is received, on the basis of identification report from the concerned authority and/or owner of the project, and commitments are made to finance further studies, the work of preparation of pre-feasibility report should be undertaken by an appropriate agency, which may be a central planning and design cell of a Water Supply Department / Board, Local Body, or professional consultants working in the water supply-sanitation environmental areas. In the latter case, terms of references for the study and its scope should be carefully set out. Pre-feasibility study may be a separate and discrete stage of project preparation or it may be the first stage of a comprehensive feasibility study. In either case it is necessary that it proceeds with making up of a feasibility study because the pre-feasibility study is essentially carried out for screening and ranking of all project alternatives, and to select an appropriate alternative for carrying out detailed feasibility study. The pre-feasibility study helps in selecting a short term project which will fit in the long term

strategy for improving services in the cultural, educational, reproductive and development of the project area.

3.3.1 CONTENTS

A detailed table of contents can be taken to be a good manner to give the reader the structure and compactness of the report as follows:

- ◆ Executive Summary
- ◆ Introduction
- ◆ The project area and the need for a project
- ◆ The objectives of the water supply
- ◆ Proposed water supply project
- ◆ Conclusions and recommendations
- ◆ Tables, figures, maps and annexes

3.3.1.1 Executive Summary

It is a good practice to provide an Executive Summary at the beginning of the report, giving the essential features, basic strategy, approach adopted in developing the study, project, and the source to start of technical and administrative aspects.

3.3.1.2 Introduction

This section explains the origin and motives of the project, how it was prepared and the scope and status of the report. These should be as far as is detailed as possible.

(a) Project Genesis

- ◆ Describe how the need of the project originated, agency responsible for promoting the project, list and explain previous studies and reports on the project, including the project identification report, and as well as when prepared there.
- ◆ Describe how the project fits in the regional development plan, long term sectoral plan, land use plan, urban master plan, and water resources development etc.

(b) How Was The Study Organised

- ◆ Explain how the study was conducted, agencies responsible for carrying out the various elements of work, and their role in preparing the study.
- ◆ Time table followed for the study.

(c) Scope And Status Of The Report

- ◆ How the preliminary report fits in the overall process of project preparation.
- ◆ Describe delimitation.
- ◆ List interim reports prepared during the study.

- Explain if the size, timing, report, or details to be used for obtaining approval for the project is correct.

4.3.1.3 The Project Area And The Need For The Project

The section establishes the need for the project. It should cover the following:

(a) Project Area

- Give geographical description of the project area with reference to maps. Describe surface features such as topography, climate, culture, religion, natural events, etc. Also include area, proper design, population, location and operation.
- Map showing geographical and political boundaries.
- Describe if any ethnic, tribal and/or religious aspects of the community which may have a bearing on the project are noted.

(b) Cultural Factors

- Determine specific needs of the project concerning the socio-cultural aspects of the community.
- Review historical population patterns and growth rates and causes.
- Estimate future population growth with different methods and indicate the most probable growth rates and compare with past population growth trends.
- Compare growth trends within the project area with those for the region, state and the entire country.
- Assess factors likely to affect population growth rates.
- Estimate probable increases in population in different parts of the project area at future intervals of time (e.g. 10, 20, and 30 years ahead).
- Discuss present and projected migration trends within the area.
- Indicate implications of the estimated growth pattern on land use patterns since land is restricted.

(c) Economic and Social Conditions

- Describe current living conditions of the people of different socio-economic and ethnic groups.
- Identify local as well as regional social levels or other indicators of socio-economic status.
- Show current population growth as a base case through an exponential growth curve and with the same assumptions, indicate current and future land use requirements of the project.
- Indicate any other socio-cultural and related proportions of the area which may

- ◆ Provide data on education, literacy and unemployment by age and sex
- ◆ Provide data and make projection for housing standards, and average household occupancy in various parts of the project area
- ◆ Describe public health status within the project area, with particular attention to diseases related to water and sanitary conditions, provide data on crude maternal and infant mortality rates, and life expectancy
- ◆ Discuss the status of health care programmes in the area, as well as other projects which have bearing on improvements in environmental sanitation.

(d) Sector Institutions

- ◆ Identify the institutions (Government, Semi-Government, Non-Government) which are involved in any of the stages of water supply and sanitation project development in the area (planning, preparing projects, financing, implementation, operation and maintenance, and evaluation)
- Formulate the roles, responsibilities and limitation (jurisdiction or others) of all the identified institutions, in relation to water supply and sanitation (This may also be indicated on a diagram)

(e) Available Water Resources

- ◆ Summarise the quantity and quality of surface and ground water resources, actual and potential, in the project area and vicinity (use various sources of information)
- ◆ Indicate studies carried out or being carried out concerning development of potential sources, and their findings
- ◆ Mention the existing patterns of water use by all sectors (ranging from industrial energy, domestic and commercial supply, supply for domestic use and possible conflicts over the use of a river, at present and in future)
- ◆ Characterise pollution problems, if any, which might affect available surface and ground water resources
- Mention the role of agencies/authorities responsible for managing water resources, their policies and quality control

(f) Existing Water Supply Systems and Development thereof

- ◆ Describe each of the existing water supply systems in the project area including the details as under:
 - Location of water source and quality available in various seasons, components of the system such as head works, transmission main, pumping stations, treatment works (where applicable), reservoirs, distribution system, reliability of supply in all seasons
 - Areas supplied, location supply water pressure, operating problems, peak rates, maximum supply, maximum supply period, for commercial, residential use, and domestic use

- Private water supply services such as, wells, bore, water vendors etc
- Number of people served according to water supply systems of the following category:
 - Unimproved sources like dugwells, rivers, lakes, ponds, etc
 - Protected private sources like, wells, bore, rain water storage tanks etc. Pipe-borne water
- Number of house connections, number of stand pipes
- Consumers opinion about standpipe supply (e.g. Distance, hours of supply, waiting time etc.)
- How many people obtain water from more than one source, from these sources, and how their water are used, (eg. Drinking, cooking, washing, etc.) and reasons for their practices
- Estimate an account of the water, production, uses and trends and efforts made to increase losses
- Comment on engineering and social problems of existing systems and possible measures to solve these problems and the expected improvement

(g) Existing Sanitation Systems and Population served

State if the proposed project may be for providing a single service (e.g. water supply) and if sanitation, the existing sanitation arrangements should be described giving details of the existing sanitation and waste disposal systems in the project area, and the number of people served by each system. Comment on the impact of existing system on drinking water quality and environment.

(h) Drainage and Solid Wastes

Briefly describe existing systems of storm water drainage and solid waste collection and disposal. This discussion should be focused in terms of their impact on water supply and environment.

(i) Need for a Project

Explain as to why the existing system cannot satisfy the existing and projected demands for services with reference to population to be served and the desired service standards or the demand like residential and industrial. Describe the consequences of not taking up a project (which may include relaxation/abandonment of the existing system and/or developing a new system), indicate measures for improvement of existing system, expansion of system, construction of new system, supply for domestic use, industrial and commercial use, impact of the project on community education in hygiene and comments on impact of project preparation and implementation.

3.3.2.4 Long Term Plan for Water Supply

- (a) Long-term water supply schemes has to be planned as a part of development projects and the near-term projects should be such as would fit in the long-term strategy. Such long-term plans or the tentative plan should be consistent with the future overall development plans for the area. A long-term plan may be prepared for a period of 25 to 30 years and alternative development options may be identified to provide any, or some, coverage and standards as a feasible extension of these alternative development scenarios. A priority project is to implement and near-term extension and it is this process which then becomes the subject of a comprehensive feasibility study.
- (b) Alternative development scenarios should be identified in the light of the above coverages to be achieved during the planning period in phases. The cells to be identified are as follows:
1. Population, location of population and water supply facilities
 2. Other consumers (public works, government, commercial, government, development etc.)
 3. Service standards to be provided for various sections of population (e.g. those working at night, public standard and peak hours etc.)
 4. Target dates for availability of water, operational service coverage should be extended within the planning period, in suitable phases.
- (c) It may be noted that service standards can be upgraded over a period of time. Therefore, various options can be considered for different years. While selecting service standards, compatibility of services and standards should be ascertained through dialogue with utility beneficiaries. Only those projects which are affordable to the people they serve, must be selected. This calls for a careful analysis of the economic utility policies and practices, as to the users for various service standards, requirements of various groups or people in the population.
- (d) The long-term plan of the population coverage in service over a plan period, present requirements of users can be worked out for near future on suitable coverage, adopting different standards, under different years. It is this near future demand for industrial, commercial, domestic and users that water service should meet. To evaluate the plan, service can be provided only by assessing various alternatives for meeting the water and sewage and a period period for each, in alternative service standard and service coverage. These demands form the basis for planning and providing the water requirements.
- The actual water requirements should include the minimum guaranteed water demands for supply, in different categories of properties, as per their respective use and nature. Coverage of water and sewerage has to be provided according to the following water supply and sewerage services:

- (e) It must be noted that availability of funds is one of the prime factors which will ultimately decide the scope and scale of a feasible project.

(f) Selection of a Strategic Plan

Each of the alternative development sequences, which can overcome the existing deficiencies and meet the present and future needs, consists of a series of improvements and expansions to be implemented over the planned period. Since all needs cannot be satisfied in immediate future, it is necessary to carefully determine priorities of target groups for improvement in services and stages of development and thus restrict the number of alternatives.

(g) Planning For System Requirement Includes Consideration Of The Following

- ◆ Possibilities of rehabilitating and/or de-bottlenecking the existing systems
- ◆ Reduction in water losses which can be justified economically, by deferring development of new sources
- ◆ Alternative water sources, surface and ground water with particular emphasis on maximising the use of all existing water sources
- ◆ Alternative transmission and treatment systems and pumping schemes
- ◆ Distribution system including pumping station and balancing reservoirs
- ◆ Providing alternative service standards in future, including upgrading of existing facilities and system expansion

(h) Need Assessment For Supporting Activities

It may also be necessary to ascertain if supporting activities like health education, staff training and institutional improvements etc. are necessary to be included as essential components of the project. All the physical and supporting input need to be carefully costed (capital and operating) after preparing preliminary designs of all facilities identified for each of the alternative development sequences. These alternatives may then be evaluated for least cost solution by net present value method; which involves

- ◆ Expressing all costs (capital and operating) for each year in economic terms,
- ◆ Discounting future costs to present value;
- ◆ Selecting the sequence with the lowest present value.

(i) Costings And Their Expressions

As stated above, costs are to be expressed in economic terms and not in terms of their financial costs. This is because the various alternatives should reflect resource cost to the economy as a whole at different future dates. Costing of the selected project may however, be done in terms of financial costs, duly considering inflation during project implementation.

3.3.1.5 Proposed Water Supply Project

(a) Details Of The Project

The project to be selected are those components of the least cost alternative of development sequence, which can be implemented during the next 5 years. Components of the selected project may be as follows:

- ◆ Rehabilitation and de-bottlenecking of the existing facilities
- ◆ Construction of new facilities for improvement and expansion of existing systems
- ◆ Support activities like training, consumer education, public motivation etc. Equipment and other measures necessary for operation and maintenance of the existing and expanded systems
- ◆ Consultancy services needed (if any) for conducting feasibility study, detailed engineering, construction supervision, socio-economic studies, studies for reducing water losses, tariff-studies, studies for improving accounts support activities

(b) Support Documents Required

All project components should be thoroughly described, duly supported by documents such as:

- ◆ Location maps
- ◆ Technical information for each physical component, and economic analysis where necessary
- ◆ Preliminary engineering designs and drawings in respect of each physical component, such as head works, transmission mains, pumping stations, treatment plants, balancing reservoirs, distribution lines

(c) Implementation Schedule

A realistic implementation schedule should be presented, taking into consideration time required for all further steps to be taken, such as conducting feasibility study, appraisal of the project, sanction to the project, fund mobilisation, implementation, trial runs and commissioning. In preparing this schedule, due consideration should be given to all authorities/groups whose inputs and decisions can affect the project and its timing.

(d) Cost Estimates

Cost estimates of each component of the project should be prepared and annual requirement of funds for each year should be worked out, taking into consideration the likely annual progress of each component. Due allowance should be made for physical contingencies and annual inflation. This exercise will result in arriving at total funds required annually for implementation of the project.

(e) Environment And Social Impact

The pre feasibility report should bring out any major environment and social impact the project is likely to cause and if these aspects will affect its feasibility.

(f) Institutional Responsibilities

The pre-feasibility report should identify the various organisations/departments, agencies who would be responsible for further planning and project preparation, approval, sanction, funding, implementation and operation and maintenance of the project and indicate also the strength of personnel needed to implement and later operate and maintain the project. It should also discuss special problems likely to be encountered during operation and maintenance, in respect of availability of skilled and technical staff, funds, transport, chemicals, communication, power, spare parts etc. Quantitative estimates of all these resources should be made and included in the project report.

(g) Financial Aspects

The capital cost of a project is a sum of all expenditure required to be incurred to complete design and detailed engineering of the project, construction of all its components including support activities and conducting special studies. After estimating component-wise costs, they may also be worked out on annual basis, throughout the implementation period, taking into consideration construction schedule and allowances for physical contingencies and inflation. Basic item costs to be adopted should be of the current year. Annual cost should be suitably increased to cover escalation costs during the construction period. Total of such escalated annual costs determines the final cost estimate of the project. Financing plan for the project should then be prepared, identifying all the sources from which funds can be obtained, and likely annual contribution from each source, until the project is completed. The possible sources of funds include:

- ◆ Cash reserves available with the project authority
 - ◆ Cash generated by the project authority from sale of water from the existing facilities
 - ◆ Grant-in-aid from government
 - ◆ Loans from government
 - ◆ Loans from financing institutions like Life Insurance Corporation, Banks, ILLDCC etc
 - ◆ Open market borrowings
 - ◆ Loans/grants from bilateral/international agencies
 - ◆ Capital contribution from voluntary organisations or from consumers
- (h) If the lending authority agrees, interest payable during implementation period can be capitalised and loan amount increased accordingly
- (i) The next step is to prepare recurrent annual costs of the project for the next few years (say 10 years) covering operating and maintenance expenditure of the entire system (existing and proposed). This would include expenditure on staff, chemicals, energy, spare parts and other materials for system operation, transportation, up-keep of the systems and administration.

The annual financial burden imposed by a project comprises the annual recurring cost and payment towards loan and interest (debt servicing). This has to be met from the operational revenue, which can be realised from sale of water. The present and future tariff for sale of water should be identified and a statement showing annual revenue for ten years period, beginning with the year when the project will be operational, should be prepared. If this statement indicates that the project authority can generate enough revenue to meet all the operational expenditure as well as repayment of loan and interest, the lending institution can be persuaded to sanction loans for the project.

- (i) Every State Government and the Government of India have programmes for financing water supply scheme in the urban and rural areas, and definite allocations are normally made for the national plan periods. It will be necessary at this stage to ascertain if and how much finance can be made available for the project under consideration, and to estimate annual availability of funds for the project till its completion. This exercise has to be done in consultation with the concerned department of the Government and the lending institutions, who would see whether the project fits in the sector policies and strategies, and can be brought in an annual planning and budgetary cycle taking into consideration the commitments already made in the sector and the overall financial resources position. The project may be finally sanctioned for implementation if the financing plan is firmed up.

3.3.1.6 Conclusions And Recommendations

(a) Conclusions

This section should present the essential findings and results of the pre-feasibility report. It should include a summary of

- ◆ Existing service coverage and service standards
- ◆ Review of the need for the project
- ◆ Long term development plans considered
- ◆ The recommended project, its scope in terms of service coverage and service standards and components
- ◆ Priorities concerning target-groups and areas to be served by the project
- ◆ Capital costs and tentative financing plan
- ◆ Annual recurring costs and debt servicing
- ◆ Tariffs and projection of operating revenue
- ◆ Urgency for implementation of the project
- ◆ Limitation of the data/information used and assumptions and judgements made; need for in-depth investigation, survey, and revalidation of assumption and judgements, while carrying out feasibility study.

The administrative difficulties likely to be met with and risks involved during implementation of the project should also be commented upon. These may pertain to boundary question for the project area, availability of water, sharing of water sources with other users, availability of land for constructing project facilities, coordination with the various agencies, acceptance of service standards by the beneficiaries, tenancy problems, acceptance of recommended future tariff, shortage of construction materials, implementation of support activities involving peoples' participation, supply of power, timely availability of funds for implementation of the project and problems of operation and maintenance of the facilities.

(b) Recommendations

- (i) This should include all actions required to be taken to complete project preparation and implementation, identifying the agencies responsible for taking these actions. A detailed time table for actions to be taken should be presented, if found necessary and feasible, taking up of works for rehabilitating and/or de-bottlenecking the existing system should be recommended as an immediate action. Such works may be identified and costed so that detailed proposals can be developed for implementation.
- (ii) It may also be indicated if the project authority can go ahead with taking up detailed investigations, data collection and operational studies, pending undertaking feasibility study formally.
- (iii) In respect of smaller and medium size projects, the pre feasibility report can be considered sufficient for obtaining investment decision for the project if:
 - ◆ The results of the pre-feasibility study are based on adequate and reliable data/information
 - ◆ Analysis of the data and situation is carried out fairly intensively
 - ◆ No major environmental and social problems are likely to crop up that might jeopardise project implementation
 - ◆ No major technical and engineering problems are envisaged during construction and operation of the facilities
- (iv) In that case the pre feasibility study with suitable concluding report, should be processed for obtaining investment decision for the project. The feasibility study, can then be taken up at the beginning of the implementation phase and results of the study if noticed to be at variance with the earlier ones, suitable modification may be introduced during implementation.
- (v) In respect of major projects however, and particularly those for which assistance of bilateral or international funding agencies is sought for, comprehensive feasibility study may have to be taken up before an investment decision can be taken.

3.4 FEASIBILITY REPORT

Feasibility study examines the project selected in the pre-feasibility study as a near-term project, in much greater details, to see if it is feasible technically, financially, economically, socially, legally, environmentally and institutionally. Enough additional data/ information may have to be collected to examine the above mentioned aspects, though the details necessary for construction of project components may be collected during execution of works.

It is a good practice to keep the authority responsible for taking investment decision, informed of the stage and salient features of the project, if there are good prospects of the project being funded immediately after the feasibility study is completed, detailed engineering of priority components may be planned simultaneously.

3.4.1 CONTENTS

The feasibility report may have the following sections :

- ◆ Background
- ◆ The proposed project
- ◆ Institutional and financial aspects
- ◆ Conclusion and recommendations

3.4.1.1 Background

In this section describe the history of project preparation, how this report is related to other reports and studies carried out earlier and in particular its setting in the context of a pre-feasibility report. It should also bring out if the data/information and assumption made in the pre-feasibility report are valid, and if not, changes in this respect should be highlighted. References to all previous reports and studies should be made.

In respect of the project area, need for a project and strategic plan for water supply, only a brief summary of the information covered in pre-feasibility report, should be presented, highlighting such additional data/ information, if any, collected for this report. The summary information should include planning period, project objectives, service coverage, service standards considered and selected for long-term planning and for the project, community preferences and affordability, quantification of future demands for services, alternative strategic plans, their screening and ranking, recommended strategic plan and cost of its implementation.

3.4.1.2 The Proposed Project

This section describes details of the project recommended for implementation. Information presented here is based on extensive analysis and preliminary engineering designs of all components of the project. The detailing of this section may be done in the following sub-sections :

(a) Objectives

Project objectives may be described in terms of general development objectives such as health improvements, ease in obtaining water for consumers, improved living standards, staff development and institutional improvements; and also terms of specific objectives such as service coverage and standards of service to be provided to various target groups.

(b) Project Users

Define number of people by location and institutions who will benefit and/or not benefit from the project area and reasons for the same, and users involvement during preparation, implementation and operation of the project.

(c) Rehabilitation and De-bottlenecking of The Existing Water Supply Systems

In fact rehabilitation, improvements and de-bottlenecking works, if necessary, should be planned for execution prior to that of the proposed project. If so these activities should be mentioned in the feasibility report. If however, these works are proposed as components of the proposed project, necessity of undertaking the rehabilitation/improvement/ de-bottlenecking works should be explained.

(d) Project Description

This may cover the following items in brief:

- ◆ Definition of the project in the context of the recommended development alternative (strategic plan) and explanation for the priority of the project
- ◆ Brief description of each component of the project, with maps and drawings
- ◆ Functions, location, design criteria and capacity of each component
- ◆ Technical specification (dimension, material) and performance specifications
- ◆ Stage of preparation of designs and drawings of each component
- ◆ Method of financing and constructing in house facilities, like plumbing and service connection etc.

(e) Support Activities

Need for and description of components such as staff training, improving billing and accounting, consumer education, health education, community involvement etc. and timing of undertaking these components and the agencies involved.

(f) Integration Of The Proposed Project With The Existing And Future Systems

Describe how the various components of the proposed project would be integrated with the existing and future works.

(g) Agencies Involved In Project Implementation And Relevant Aspects

- ◆ Designate the lead agency
- ◆ Identify other agencies including government agencies who would be involved in project implementation, describing their role, such as granting administrative approval, technical sanction, approval to annual budget provision, sanction of loans, construction of facilities, procurement of materials and equipment etc.

- ◆ Outline of arrangements to coordinate the working of all agencies
- ◆ Designate the operating agency and its role during implementation stage
- ◆ Role of consultants, if necessary, scope of their work, and terms of reference
- ◆ Regulations and procedures for procuring key materials and equipment, power, and transport problems, if any,
- ◆ Estimate number and type of workers and their availability
- ◆ Procedures for fixing agencies for works and supplies and the normal time it takes to award contracts
- ◆ List of imported materials, if required, procedure to be followed for importing them and estimation of delivery period
- ◆ Outline any legislative and administrative approvals required to implement the project, such as those pertaining to riparian rights, water quality criteria, acquisition of lands, permission to construct across or along roads and railways, high-tension power lines, in forest area and defence or other such restricted areas
- ◆ Comments on the capabilities of contractors and quality of material and equipment available indigenously

(h) Cost Estimates

- ◆ Outline basic assumption made for unit prices, physical contingencies, price-contingencies and escalation
- ◆ Summary of estimated cost of each component for each year till its completion and work out total annual costs, to know annual cash flow requirements
- ◆ Estimate foreign exchange cost if required to be incurred
- ◆ Work out per capita cost of the project on the basis of design population, cost per unit of water produced and distributed and compare these with norms, if any, laid down by government or with those for similar projects

(i) Implementation Schedule

Prepare a detailed and realistic implementation schedule for all project components, taking into consideration stage of preparation of detailed design and drawings, additional field investigations required, if any, time required for preparing tender documents, notice period, processing of tenders, award of works/supply contract, actual construction period, period required for procurement of material and equipment, testing, trials of individual component and commissioning of the facilities etc.

If consultants' services are required, the period required for completion of their work should also be estimated.

A detailed PERT diagram (ref. Appendix 3.1) showing implementation schedule for the whole project, as well as those for each component should be prepared, showing linkages and inter-dependence of various activities

Implementation schedule should also be prepared for support-activities such as training, consumers education etc. and their linkages with completion of physical components and commissioning of the project should be established.

(j) Operation And Maintenance Of The Project

Estimate annual operating costs, considering staff, chemicals, energy, transport, routine maintenance of civil works, maintenance of electrical/mechanical equipment, including normal cost of replacement of parts and supervision charges. Annual cost estimates should be prepared for a period of 10 years from the probable year of commissioning the project, taking into consideration expected out-put levels and escalation.

Proposal for monitoring and evaluating the project performance with reference to project objectives should be indicated.

(k) Environmental Impact

Brief description of the adverse and beneficial impacts of the project may be given covering the following aspects:

BENEFICIAL IMPACT	ADVERSE IMPACT
☐ Ease and convenience in obtaining water by the consumers	☐ Risk of promoting mosquito breeding, effect of with-drawing surface/ground water
☐ Improvement in public use of water in household premises or by water authority	☐ Effect of disposal of backwash water and sludge from water treatment plant
☐ Effect of construction of storage reservoirs on flood moderation, navigation, ground water table, power generation etc.	☐ Effects of construction of storage reservoirs on ground water table, down stream flow of the stream, the reservoir bed etc. and effects on ecology.

3.4.1.3 Institutional And Financial Aspects

(a) Institutional Aspects

It is necessary to examine capabilities of the organisations who would be entrusted with the responsibility of implementing the project and of operating the same after it is commissioned. The designated organisation(s) must fulfil the requirements in respect of organisational structure, personnel, financial, health and management procedures, so that effective and efficient performance is expected. This can be done by describing the following aspects .

- ◆ History of the Organisation, its functions, duties and powers, legal basis, organisational chart, (present and proposed), relationship between different functional groups of the organisation, and with its regional offices, its relation with government agencies and other organisations involved in sector development

- ◆ Public relations in general and consumer relations in particular, extension services available to sell new services, facilities for conducting consumer education programme, and setting compliance
- ◆ Systems for budgeting for capital and recurring expenditure and revenue, accounting of expenditure and revenue, internal and external audit arrangements, inventory management
- ◆ Present positions and actual staff, comments on number and quality of staff in each category, ratio of staff proposed for maintenance and operation of the project to the number of people served, salary ranges of the staff and their comparison with those of other public sector employees
- ◆ Staff requirement (category wise) for operating the project immediately, after commissioning, future requirements, policies regarding staff training, facilities available for training
- ◆ Actual tariffs for the last 3 years, present tariff, tariff proposed after the project is commissioned, its structures, internal and external subsidies, procedure required to be followed to adopt, new-tariff, expected cost and revenues in future years, proposal to meet shortage in revenue accruals
- ◆ Prepare annual financial statements (income statements, balance sheets and cash flows) for the project operating agency, for three years after the project is commissioned, explain all basic assumptions for the financial forecast and the terms and conditions of tapping financial sources, demonstrate ability to cover all operating and maintenance expenditure and loan repayment, working rate of return on net fixed assets and the internal financial rate of return of the project

(b) Financing Plan

Identify all sources of funds for implementation of the project, indicating year by year requirements from these sources, to meet expenditure as planned for completing the project as per schedule; state how interest during construction will be paid, or whether it will be capitalised and provided for in the loan; explain the procedures involved in obtaining funds from the various sources

3.4.1.4 Conclusions And Recommendations

This section should discuss justification of the project, in terms of its objectives, cost-effectiveness, affordability, willingness of the beneficiaries to pay for services and the effect of not proceeding with the project

Issues which are likely to adversely affect project implementation and operation should be outlined and ways of tackling the same should be suggested. Effect of changes in the assumptions made for developing the project, on project implementation period, benefits, tariff, costs and demand etc. should be mentioned¹

Definite recommendations should be made regarding time-bound actions to be taken by the various agencies, including advance action which may be taken by the lead agency pending approval and financing of the project.

CHAPTER 4

MEASUREMENT OF FLOW

4.1 POINTS OF MEASUREMENT

The measurement of flow in water supply systems is of importance in connection with assessment of source and its development, transmission, treatment, distribution, control of wastage and other factors.

The probable locations where flow measurement may be needed in a water supply system are:

- (a) River flow gauging upstream of intake by floats and current meters or weirs and flumes or dilution methods.
- (b) Measuring yield from wells (yield test) using the head differential through an orifice meter or venturi meter for pipe flows or by weirs or flumes for open channel flow.
- (c) Intake structure-raw water input rate by venturi or orifice meter for pipe flows or by weirs or flumes for open channel flow.
- (d) Flow at the entry to the treatment works (normally after aeration if it is practiced) by weirs or flumes.
- (e) Filtrate flow from each filter by weirs or notches or orifice meters or venturi meters.
- (f) Bulk flow measurements of water supplied from treatment plant and clear water reservoir by venturi meter.
- (g) Bulk flow measurements (integrating and instantaneous) for supply to distribution zones, sub-zones or industries by bulk meters or venturi meters.
- (h) Measurement of domestic water supply through service connections by domestic consumer water meters.
- (i) Assessment of wastages and leakages in pipes and plumbing systems by waste flow measuring or recording meters.

There are several types of flow measurements of which the more common ones are described below with some detail. The choice of the particular type depends on the specific circumstances and desired accuracy.

4.2 MEASUREMENT IN OPEN CHANNELS

4.2.1. USE OF HYDRAULIC STRUCTURES

Several types of hydraulic structures like notches, weirs, flumes and drops are in use for measurement of flow in open channels.

4.2.1.1. Notches

These are cut from thin metal plates, the general forms being either triangular or trapezoidal.

(a) Triangular Notches

90° triangular notches are used for measuring small quantities of flows upto about 1.25 m³/s.

(i) Installation Requirements

The approach channel should be reasonably smooth, free from disturbances and straight for a length equal to at least 10 times the width. The structures in which the notch is fixed shall be rigid and water-tight and the upstream face vertical. The downstream level should be always at least 5 cm below the bottom-most portion of the notch (inverted apex) ensuring free flow.

(ii) Specification for Materials

The plate should be smooth and made of rust-proof and corrosion resistant material. The thickness should not exceed 2 mm, with the downstream edge chamfered at an angle of not less than 45° with the crest surface.

(iii) Measurement of Head Causing the Water Flow

The head causing flow over the notch shall be measured by standard hook gauge upstream at a distance of 3 to 4 times the maximum depth of flow over the notch.

(iv) Discharge Equation

The discharge Q (in m³/sec) for V-Notch is given by the expression:

$$Q = \frac{8}{15} C_d \sqrt{2g} \tan \frac{\theta}{2} h^{5/2} \quad (4.1)$$

where,

- C_d = effective discharge coefficient
- g = acceleration due to gravity (9.8066 m/s²)
- θ = angle of the notch at its vertex
- h = measured head causing flow in m,

For 90° V Notch which is generally used, the discharge is given by the expression

$$Q = 2.347 C_d H^{3/2} \quad (4.2)$$

C_d values vary from 0.603 to 0.686 for values of head varying from 0.060 to 0.377m

(v) Limitations

The triangular notches should be used only when the head is more than 60 mm

(vi) Accuracy

The values obtained by the equation for triangular notches would vary from 97 to 103% of the true discharge for discharges from 0.008 to 1.25 m³/s.

(b) Rectangular Notches

The installation requirements, specifications, head measurements, head limits and accuracy will be the same as for triangular notches. The width of notch should be at least 150 mm.

There are two types of rectangular notches viz (i) with end contractions and (ii) without end contractions.

(i) With End Contractions

The contraction from either side of the channel to the side of the notch should be greater than 0.1 m

The discharge (m³/s) through a rectangular notch with end contractions is given by the equation

$$Q = \frac{2}{3} C_d \sqrt{2g} b_e H^{3/2} \quad (4.3)$$

where,

b_e = effective width = actual width of the notch + k (value of k being 2.5 mm, 3 mm and 4 mm for b/B ranges of upto 0.4, 0.4 to 0.6 and 0.6 to 0.8 respectively);

b/B = ratio of the width of the notch to the width of the channel,

H = effective head = actual head measured (h) + 1 mm;

g = acceleration due to gravity (9.806 m/s²); and

C_d = varies from 0.58 to 0.70 for values of b/B from 0 to 0.8

(ii) Without End Contractions

The discharge (m³/s) through a rectangular notch without end contractions is given by the following expression;

$$Q = \frac{2}{3} C_d \sqrt{2g} b H^{3/2} \quad (4.4)$$

where,

b = width of the notch (m)

H = effective head = actual / measured head (h) + 1.2 mm

$$C_d = 0.602 - 0.075 h/p$$

where,

p = height of the bottom of the notch from the bed of the channel

(c) Trapezoidal Notches (Cipoletti Notches)

The main advantage of a trapezoidal or Cipoletti notch is that as the flow passes over the weir, the end contractions are either eliminated or considerably reduced. The sides of the notch should have a slope of 1 : 4 such that the top width of discharge is equal to the bottom width of the notch (b) + half the head of water over the sill of the notch ($1/2 h$). Thus the loss of discharge due to end contractions is made good. Discharge equation $Q = 1.859 bh^{3/2}$ where b is bottom width of notch and h is the head over the sill.

4.2.1.2 Weirs

These are similar to rectangular notches but the thickness in the direction of flow is considerable and therefore coefficient of discharge will be less. The installation conditions will be the same as for the notches.

(a) Without End Contractions (Suppressed Weirs)

The discharge equation to be used is

$$Q = 0.5445 C_d \sqrt{g} b h^{3/2} \quad (4.5)$$

C_d varies from 0.864 to 1.0 depending upon the h/p (ratio of measured head to length of weir in the direction of flow) value from 0.4 to 1.6, for h/p values lower than 0.4, C_d may be taken as 0.864.

(b) With End Contractions

Same equation 4.5 is to be used replacing the 'b' by $(b - n h)$ where n is the number of contractions.

(c) Limitations

The weirs should be used only when the head is more than 60 mm. Minimum width of the weir should be 300 mm.

(d) Accuracy

The discharge values obtained by weir measurements would vary from 2% to 10% of the true discharge.

4.2.1.3 Flumes (Free Flowing)

There are two types of flumes, namely:

- Standing wave flumes in which standing wave of hydraulic jumps is formed down stream

♦ Venturi flumes

The installation conditions will be the same as for the notches.

(ii) Standing Wave Flumes

- (i) **Discharge equation** The discharge equation for standing wave flumes is given by :

$$Q = \frac{2}{3} \sqrt{2g} C_c (h_1 - mh + 2C_c mH) H^{3/2} \quad (16)$$

Where,

Q = discharge in m^3/s

C_c = coefficient of friction having the following values

0.97 for $Q = 0.05$ to $0.3 m^3/s$

0.98 for $Q = 0.3$ to $1.5 m^3/s$

0.99 for $Q = 1.5$ to $15 m^3/s$

1.00 for $Q = 15 m^3/s$ and above

B_1 = overall throat width including piers

m = number of piers

h = thickness of each pier

C_c = Coefficient of contraction, having a value of 0.045 for piers with round nose and 0.047 for piers with pointed nose and $H = D_1$; h_1 = upstream head over sill corrected for velocity of approach

$$H = D_1 + \frac{V_a^2}{15.2}$$

Where,

D_1 = the depth upstream over sill of throat and

V_a = the mean velocity of approach. Effect of velocity of approach is greater than $V_a^2/2g$ because the velocity in the central portion will be higher than V_a . Therefore, the head due to velocity of approach should be taken as :

$$h_a = \frac{V_a^2}{15.2}$$

(ii) Limitations

Standing wave flumes should be used only when the head is more than 60 mm. Ratio of (D_2/D_1) (Depth downstream above sill of throat/depth upstream over sill of throat) should always be greater than 0.5 for the application of standing wave flumes. If this ratio is less than 0.5, sharp may be adopted.

Minimum width of the flumes should be 30 mm

(iii) Accuracy

The discharge values obtained by measurements with standing wave flumes would vary from 95 to 105% of the true discharge.

Parshall Flume is a type of standing wave flume widely used. However, its use requires application of different equations, based on the throat size, if accuracy in results similar to other types of flumes is expected.

The approximate equation applicable for the entire range of its usage, namely, discharges varying from 0.001 m³/s to 100 m³/s (i.e. throat widths varying from 75 to 15,000 mm) is given by:

$$Q = 2.42 W h^{3/2}$$

Where,

Q = discharge in m³/s

W = throat width in m and

h = upstream gauged depth in m.

The numerical factors 2.42 and 2.58 are subject to 4% variation in extreme cases (less in case of smaller widths).

The minimum head and accuracy will be the same as for standing wave flumes.

(b) Venturi Flumes

(i) Discharge equation

The discharge equation is given by

$$Q = 0.5445 C_v C_d \sqrt{g} h^3 \quad (4.8)$$

Where,

C_v is the coefficient of velocity which varies from 1.04 to 1.15

C_d is the effective coefficient of discharge varying from 0.885 to 0.99 depending upon h/l varying from 0.05 to 0.70 where 'l' is the length of throat in the direction of flow.

(ii) Limitations

Venturi flumes should be used only when head available is between 50 and 1800 mm. Minimum width of the flume should be 90 mm.

(iii) Accuracy

The discharge values obtained by measurement with venturi flumes would vary from 95 to 105% of the true discharge.

4.21.4 Drops

(i) Discharge Equation

When the flow falls freely from a channel or conduit to a lower level (ground), measurement can be conveniently made at the point of drop which offers a rough estimate

of the discharge. There should be a minimum straight length of 20 times the end depth in the approach channel. The ratio of the end depth to the critical depth in horizontal and mildly sloped channels has a value of 0.70. The discharge may be calculated from

$$Q = d_c^{3/2} \sqrt{gb} \quad (4.9)$$

Where,

d_c = critical depth (m)

b = width of channel (m)

(ii) Limitations

Width of channel should be a minimum of 300 mm. Critical depth d_c should be a minimum of 50 mm.

(iii) Accuracy

The discharge values obtained by measurements made at drops would vary from 90 to 100% of the true discharge.

4.2.2 VELOCITY AREA METHODS

The rate of flow through a section of a pipe or open channel is often determined by multiplying the cross sectional area of water at the section at right angles to the flow by the mean velocity of water at the section. Cross sectional area is usually determined by direct measurements. Determination of the mean velocity is generally more difficult and time consuming, since the velocity differs considerably from point to point in the cross section. For determining the mean velocity, several methods such as use of current meter, float, velocity rod, pitot tube, tracer technique and trajectory method are available.

When velocity measurements are made at only one point, this point is usually around 0.6 m. depth. The exact location of this point is decided on the basis of vertical velocity distribution experiments.

Average velocity of flow at any subsection of the cross section can be approximated by the average of velocities at 0.3 and 0.8 depths in that subsection. The cross section is accordingly divided into various small vertical sections and average velocity v_i of each section is found.

The mean velocity of flow in the cross section is found by the expression

$$\frac{\sum_{i=1}^n (a_i v_i)}{\sum_{i=1}^n a_i} \quad (4.10)$$

Where a_i is area of the individual section and v_i is the average velocity in that section.

The velocities are usually obtained by current meter. For floats, the surface velocities are found and the average velocity is computed approximately as 0.87 of surface velocity. Normally the discharge measurements are 95 to 105% of the true discharges.

4.2.3 ELECTRO-MAGNETIC PROBLEMS

When an electric field is set up in a system, a magnetic field will be induced around the pipe. This field is induced by the current induced in the system, which flows through the cable in the control box. The induced field will be flowing through the magnetic field of the pipe. The result is a field of water. This field will be an electric field, which is one of the major factors in the system. The result is a field of water, which is one of the major factors in the system.

4.3 MEASUREMENT IN CLOSED CONDUITS

4.3.1 DIFFERENTIAL PRESSURE DEVICES

The differential pressure devices are used to measure the flow rate of a liquid or gas. They are used in a wide range of applications, including flow measurement in closed conduits. The differential pressure devices are used to measure the flow rate of a liquid or gas. They are used in a wide range of applications, including flow measurement in closed conduits.

4.3.1.1 Venturi Meters

Venturi meters are used to measure the flow rate of a liquid or gas. They are used in a wide range of applications, including flow measurement in closed conduits. The venturi meter is a device that is used to measure the flow rate of a liquid or gas. It is used in a wide range of applications, including flow measurement in closed conduits.

The venturi meter is a device that is used to measure the flow rate of a liquid or gas. It is used in a wide range of applications, including flow measurement in closed conduits. The venturi meter is a device that is used to measure the flow rate of a liquid or gas. It is used in a wide range of applications, including flow measurement in closed conduits.

The venturi meter is a device that is used to measure the flow rate of a liquid or gas. It is used in a wide range of applications, including flow measurement in closed conduits. The venturi meter is a device that is used to measure the flow rate of a liquid or gas. It is used in a wide range of applications, including flow measurement in closed conduits.

The venturi meter is a device that is used to measure the flow rate of a liquid or gas. It is used in a wide range of applications, including flow measurement in closed conduits. The venturi meter is a device that is used to measure the flow rate of a liquid or gas. It is used in a wide range of applications, including flow measurement in closed conduits.

Considering the effect of the venturi meter, the equation is

$$Q = C_d A_1 \sqrt{\frac{2 \Delta P}{\rho}} \quad (4.3.1)$$

where

Q = flow rate (m³/s)

C_d = discharge coefficient (0.95-0.98)

... of the

Discussion

The

References

...

...

...

...

...

...

Appendix

...

...

...

...

curve supplied by the manufacturers or to be calibrated. For a given velocity, this type produces a greater differential head than the simple type.

$$V = K \sqrt{2ghH} \quad (4.13)$$

Where,

V = Velocity of flow, mps at the point

K = Instrument coefficient

g = gravitational head in m of water between the impact and static (or trailing) orifices

H = Differential head in meters of water between the impact and static (or trailing) orifices

The coefficient has a value of about 0.97

Pitot tubes should offer hindrance to flow and hence may be restricted to pipes larger than 50 mm dia. The values obtained with pitot tubes would vary from 98 to 102% of the true discharge. For 100 mm dia or larger pipes, i.e. smaller diameters, the variation would be larger depending upon the obstruction caused.

4.31.4 Water Meters

Water meters are generally used for measuring flows in the mains and house service connections. There are of different types but several of water meters of single jet or multiple jet with dry case are commonly in use.

(a) Domestic consumer meters

The domestic consumer meters normally suffer from the following deficiencies

- (i) They involve a high head loss and hence consumers are liable to over-pay the bill.
- (ii) The minimum flow rate can be registered as high as 40 litres per hour.
- (iii) Disturbance of silt and foreign particles disturb the meter and hence the meter gives erroneous results.
- (iv) Since the casing is not fully water tight, the metallic gears get rusted and the plastic gears get broken due to solvent by the water gases and oil or kerosene.
- (v) In the absence of hermetically sealed units, there is an ingress of moisture on to the face of dial and hence the meter becomes unreliable.
- (vi) Meters with pointers can be tampered by changing the position of pointer needles.

As per the standard IS: 279 - 1961 (ISO: 6061) for the domestic consumer meters, the meter case is hermetically closed and hermetically sealed. It is preferable to use anti-magnetic meter (ISO: 1961).

Some features of these meters are (i) there is no contact of the meter mechanism with water, (ii) the meter gives registration at very small flows (minimum flow of 10 litres) with

minimum head loss, (ii) the meter chamber remaining completely dry, (iv) the gears are self-lubricating and readings can be directly read and are clearly visible in any weather.

Some of the advantages of these meters are

- (i) The inferential meters are magnetically driven. Since there is no contact of the meter mechanism with water, there is no friction. Hence the meter starts registration at very small quantities of flow (at 10 litres per hour) and involves a head loss of about 1.5 cm.
- (ii) The hermetically sealed meters cannot be tampered and the readings can be read directly. Further, in the absence of agents of moisture, the dial is clearly visible.
- (iii) Since the dial is hermetically sealed, the gear train is fully dry, is above the water and is self-lubricating.
- (iv) Since there is no change in direction of flow, the head loss through the meter is small.

(b) Bulk Meters

For use on distribution mains the bulk meters of Vane Wheel type with sizes of 50 to 300 mm or Helical type with sizes of 50 to 300 mm conforming to IS 2373 (1971) are in use. These meters also suffer from the same deficiencies stated in previous section (a) for domestic meters.

The IS 2373 is being revised (fourth revision) to incorporate the following modifications which are likely to address some of the deficiencies:

- (i) Indicating devices to include pointers, digital and combination of the two.
- (ii) Class A and Class B meters are to be introduced and performance requirements are to be more stringent.
- (iii) Pressure-loss requirement is to be more stringent.
- (iv) Removable type helical meters are to be introduced in addition to fixed type.
- (v) Sizes of 65 mm, 69 mm and 80 mm are to be added.

4.4 SPECIAL METHODS

4.4.1 GENERAL

There are several special methods. The dilution techniques and the pulse velocity methods are applicable to both open channels as well as closed conduits. The trajectory measurements and bend or centrifugal head meters are applicable to closed conduits only. The more common method of dilution techniques is described below.

4.4.2 DILUTION METHOD

This is based on the fact that a chemical or radioactive tracer, injected into a river or pipe will be completely and uniformly mixed with the natural flow and that the diluted concentration down stream will decrease with increase discharge. Chemical concentrations are measured by means of colorimetric methods and radioactivity by Geiger counter. This method permits the

to the computation of the long wavelength modes and the slow oscillations, and the fast modes and the slow oscillations are computed separately. The long wavelength modes are computed using the method described in the previous section.

The fast modes are computed using the method described in the previous section. The slow oscillations are computed using the method described in the previous section.

The fast modes are computed using the method described in the previous section. The slow oscillations are computed using the method described in the previous section. The long wavelength modes are computed using the method described in the previous section.

$$\begin{aligned} \text{[Equation content]} \end{aligned} \tag{1}$$

3.2. Long Wavelength Modes

The long wavelength modes are computed using the method described in the previous section. The slow oscillations are computed using the method described in the previous section. The fast modes are computed using the method described in the previous section.

3.3. Fast Modes and Slow Oscillations

The fast modes and slow oscillations are computed using the method described in the previous section. The long wavelength modes are computed using the method described in the previous section.

$$\text{[Equation content]} \tag{2}$$

The long wavelength modes are computed using the method described in the previous section. The fast modes and slow oscillations are computed using the method described in the previous section.

The fast modes and slow oscillations are computed using the method described in the previous section. The long wavelength modes are computed using the method described in the previous section.

CHAPTER 5

SOURCES OF SUPPLY

5.1 KINDS OF WATER SOURCES AND THEIR CHARACTERISTICS

The concept of different kinds of water sources is defined as follows: A fallow or a cultivated field, the ground surface, or a body of water, which provides an expected quantity of water for a particular use, is regarded as a source of water. The actual quantity of water available from the source is called the yield from the source. In this section, we shall study the various kinds of water sources in detail.

5.1.1 WATER FROM PRECIPITATION

It is well known that water is not a fixed quantity. It is constantly being replenished by the atmosphere and evaporated from the surface. Moreover, there is a continuous expenditure of water in the atmosphere and in the ground. The requirement of water for the existing systems of users is to be fulfilled by the atmosphere.

5.1.2 SURFACE WATERS

(a) *Natural Quiescent Waters As In Lakes And Ponds*

The sources would be more numerous and of higher importance than in any stream. Long average periods of calm and a surface windless or very blowing of wind in an occasional storm. Self-purification ability is a property of water to purify itself as well as it does in respect to smaller lakes than in larger ones. Open lakes are also subject to periodic variations of temperature, and a high degree of thermal stratification. The main source remains a very low rate in such waters. The process of the attachment is protected and the muddy or stained water may be required for the treatment of effluent effluents.

(b) *Artificial Quiescent Waters As In Impounding Reservoirs*

Impounding reservoirs developed by impounding streams in mountainous river valleys, are always found at less or more considerable distances and to be a wide top layers of water are usually developing with the passage of water from the high turbidity carbon dioxide and ammonia and various other impurities. High rate of velocity produced by the water would be the impounding of the water.

(c) *Flowing Waters As In Rivers, Other Natural Courses And Irrigation Canals*

Waters from rivers, streams and canals are usually not used from nature and are considered that they have like a river and a reservoir. The nature of the water depends upon the character and nature of the material, its geology and topography. The extent and nature of development by the source may vary from a low water condition. It means that relatively fresh, available source. It would certainly be the same from

eroded catchments, organic debris and mineral salts. Substantial variations in the quality of the water may also occur between the maximum and minimum flows. In populated regions, pollution by sewage and industrial wastes will be direct. The natural and man-made pollution results in producing color, turbidity, tastes and odors, hardness, bacterial and other micro-organisms in the water supplies.

(d) Sea Water

Though this source is plentiful, it is difficult to extract economically water of potable quality because it contains 3.5% of salts in solution, which involves costly treatment. Offshore waters of the oceans and seas have a salt concentration of 30,000 to 36,000 mg/l of dissolved solids including 19,000 mg/l of chloride, 10,600 mg/l of sodium, 1,270 mg/l of magnesium, 880 mg/l of sulphur, 400 mg/l of calcium, 380 mg/l of potassium, 65 mg/l of bromine, 28 mg/l of carbon, 13 mg/l of strontium, 4.5 mg/l of boron. Desalting or demineralizing processes involve separation of salt or water from saline waters. This is yet a costly process and has to be adopted in places where sea water is the only source available and potable water has to be obtained from it, such as in ships on the high seas or a place where an industry has to be set up and there is no other source of supply.

(e) Waste Water Reclamation

Sewage or other waste waters of the community may be utilized for non domestic purposes, such as water for cooling, flushing lavats, parks, etc., fire fighting and for certain industrial purposes, after giving the necessary treatment to suit the nature of use. The supply from this source to residences is prohibited because of the possible cross connection with the potable water supply system.

5.1.3 GROUNDWATER

(a) General

Rain water percolating into the ground and reaching permeable layers (aquifers) in the zone of saturation constitutes groundwater source. Groundwater is normally beyond the reach of vegetation except certain species of plants called phreatophytes, and is usually free from evaporation losses. Groundwater resources are less severely affected by vagaries of rainfall than surface water resources.

The water as it seeps down, comes in contact with organic and inorganic substances during its passage through the ground and acquires chemical characteristics representative of the strata it passes through.

Generally, groundwaters are clear and colorless but are harder than the surface waters of the region in which they occur. In limestone formations, groundwaters are very hard, tend to form deposits in pipes and are relatively non-corrosive. In granite formations they are soft, low in dissolved minerals, relatively high in free carbon dioxide and are actively corrosive. Bacterially, groundwaters are much better than surface waters except where subsurface pollution exists. Groundwaters are generally of uniform quality although changes may occur in the quality because of water logging, over draft from areas adjoining saline water sources and recycling of water applied for irrigation and pollution.

While some of the chemical substances like fertilizers and those causing hardness are readily soluble in water, others such as those causing alkalinity and hardness, are soluble in water containing carbon dioxide absorbed from the air or from decomposing organic matter in the soil. Such decomposing matter also removes the dissolved oxygen from the water percolating through. Water deficient in oxygen and high in carbon dioxide dissolves iron and manganese components in the soil. Hydrogen sulphide also occurs, sometimes, in groundwater and is associated with a deficiency of oxygen, the decomposition of organic matter or the reduction of sulphate. Percolation into the soil and also results in the filtering out of bacteria and other living organisms from soil and its solid rock formations such as limestone, however, surface pollution can be easy. The ground water is without material change.

(b) Spring

Springs are due to the emergence of groundwater to the surface. If it is out on the surface as a spring, the groundwater is less mineralized than that of the deep layers, which may supply the nutrients in a few organisms. A filtered spring, if it flows as a surface stream. Spring waters from shallow strata are more likely to be affected by surface pollution than deep seated waters. Springs may be either perennial or intermittent. The discharge of a spring depends on the nature and size of catchment, recharge and leakage through the sub-surface. Their usefulness as sources of water, apply depends on the discharge and its variability during the year.

5.1.4 SALINE INTRUSION

Saline intrusion or salt water creep occurs near or tidal estuaries or in groundwater longitudinal mixing in tidal estuaries is kept in check by the prevention of fresh water and salt water flow components to mix normally. Long term studies are needed to examine the salt water creep viz. the upstream progress of a tongue of salt water moving inland which overriding fresh water may still flow towards the sea estuary. The salt content of such river waters may also vary with the tides and it is essential to determine the periods when the supply should be tapped to have the minimum salt content.

Groundwater in coastal aquifers overlies the denser saline water. Every metre rise of the water table above the sea level corresponds to a depth of 41 metres of fresh water lens floating over the saline water. In such cases the pumping from wells has to be carefully controlled or a fresh water barrier created to avoid the salt water tongue entering the well and contaminating the same.

5.1.5 SANITARY SURVEY

Though the specific characteristics of the several sources have been delineated above, the importance of sanitary survey cannot be over emphasized. This survey is a study of the environmental conditions that may affect its fitness as a source. The scope of the sanitary survey should include a discerning study of the geological, geophysical, hydrological, climatic, industrial, commercial, agricultural, recreational and land development factors influencing the water drainage into the source and the surface and the subsurface pollution likely to affect it. The subsurface pollution may be derived from privy pits, leaching cess pools, leaking sewers and land fills. Pollution near and/or below the groundwater table is especially

which involves a plot of $\log Q$ against $\log t$ and a series of curves are prepared, each for a different discharge rate.

9.2. ASSESSMENT OF THE NEED AND DEFEASIBILITY OF THE SOURCE

9.2.1. USE OF RAIN

The first step in the assessment of the feasibility of rainwater as a source of water supply is to determine the potential yield of the catchment.

The potential yield is an estimate of the water that can be made available to the catchment area over a period of the year.

The potential yield is the difference between the total rainfall and the potential evaporation from the catchment area.

9.2.2. FACTORS TO BE TAKEN INTO CONSIDERATION

The first factor to be considered is the rainfall. The water content of the rain is an important factor in determining the potential yield of the catchment. The water content of the rain is determined by the amount of water that is available in the atmosphere. The water content of the rain is also determined by the amount of water that is available in the ground. The water content of the rain is also determined by the amount of water that is available in the surface water bodies.

The second factor to be considered is the evaporation. The evaporation from the catchment area is an important factor in determining the potential yield of the catchment. The evaporation from the catchment area is determined by the amount of water that is available in the atmosphere. The evaporation from the catchment area is also determined by the amount of water that is available in the ground. The evaporation from the catchment area is also determined by the amount of water that is available in the surface water bodies.

9.2.5. METHODS FOR ASSESSMENT OF SOURCE FLOWS

9.2.5.1 Comparison of Methods of Estimating Discharges

(a) Use of River Gauging Data

When gauging data is available for a river, it is the most accurate method of estimating discharge. The discharge is measured at a gauging station and the data is used to estimate the discharge at other gauging stations.

(b) Other Methods

When gauging data is not available, other methods of estimating discharge are used. These methods are:

- (i) The use of a weir or a dam to measure discharge.
- (ii) The use of a stream gauge to measure discharge.
- (iii) The use of a stream gauge to measure discharge.
- (iv) The use of a stream gauge to measure discharge.

6) Time hydrograph method

This is a graphical procedure which is used to determine the hydrograph of a catchment area. It is based on the fact that the hydrograph of a catchment area is the sum of the hydrographs of its constituent parts. The hydrograph of a catchment area is the sum of the hydrographs of its constituent parts. The hydrograph of a catchment area is the sum of the hydrographs of its constituent parts.

(a) Example 1

(i) The hydrograph of a catchment area is shown in the figure below. The catchment area is 100 km².

(ii) The hydrograph of a catchment area is shown in the figure below. The catchment area is 100 km².

(iii) The hydrograph of a catchment area is shown in the figure below. The catchment area is 100 km².

(b) Example 2

The hydrograph of a catchment area is shown in the figure below.

(i) The hydrograph of a catchment area is shown in the figure below.

(ii) The hydrograph of a catchment area is shown in the figure below.

(c) Frequency analysis method

The frequency analysis method is used to determine the hydrograph of a catchment area. It is based on the fact that the hydrograph of a catchment area is the sum of the hydrographs of its constituent parts.

The frequency analysis method is used to determine the hydrograph of a catchment area. It is based on the fact that the hydrograph of a catchment area is the sum of the hydrographs of its constituent parts.

(d) Example 3

The hydrograph of a catchment area is shown in the figure below. The catchment area is 100 km².

(e) Example 4

The hydrograph of a catchment area is shown in the figure below. The catchment area is 100 km².

from the observations of actual hydrographs in the frequency analysis methods, flows occurring once in 100 years as to the highest or minimum quantity likely to occur once in 30 years can be determined.

5.2.3.2 Use Of Maximum And Minimum Discharge Figures Mass Diagram

The maximum discharge figures are used for the design of the spill ways of the dam of any impounding reservoir across the stream. The figures will also be useful in determining the minimum storage capacity and the maximum water level likely to be attained, so that construction of the dam and related structures should be designed on this basis.

The probable minimum flow is computed by some methods the catchment area could be used in assessing the dependability of the source and for determining the minimum period of storage called for with the use of a mass diagram drawn up for the purpose as detailed in Appendix-5.1.

While the computed figures for surface runoff from catchments contributing to the stream flow represents the total inflow to the stream surface flow from its catchment area, the stream discharge may be supplemented by a subsurface flow from the catchment basin, seeping into the stream through the substrate, depending on the geological formations and hydrological conditions in the area valley. This subsurface seepage contributing to the river flow can not usually be computed by the use of any formula as such because of the several indefinite factors involved. Continuous flow gaugings at any point however, would be the total discharge at the point, contributed both by the surface and subsurface flows which join the stream.

In assessing the desirable yield from natural lakes and ponds, the computations may be reckoned largely on the capacity of the lake with reference to the total catchment area and the comparable runoff available therefrom. Here again, supplemental quantities received by the basin through any subsurface flow from the catchment area is usually not a comparable factor and usually not taken into account in assessing the total quantity available for the project. In all computations on the reservoir storage and capacity, suitable losses due to seepage and evaporation should be given due consideration.

5.2.4 ASSESSMENT OF GROUNDWATER RESOURCE POTENTIAL

Prior to the year 1970 for the assessment of exploitable groundwater resource potential, various methods were being adopted by the States and the Central Groundwater Board (CGWB). However, with a view to project a unified view and assessing the resource on scientific lines, a committee known as "Over-Exploitation Committee" was constituted with the then Chairman, Central Groundwater Board as the Chairman to suggest methodology for estimation of the groundwater potential and also to lay down the norms for development of various types of structures and areas. The methodology suggested by the committee has been adopted by the Agricultural Reformation and Development Corporation (ARDC). The Committee had further recommended that the methodology may be further revised to make it more scientific as and when data from the work carried out by the Central Groundwater Board was available.

The National Bank for Agriculture & Rural Development (NABARD) approved the Government of India to contribute material for inclusion in an appraisal for availing World Bank Assistance under SIB/RII-2 project which was of two year duration (1984 and 1985). The Central Groundwater Board (CGWB) of the center was referred, examined the methodology suggested by the Director of the center in great detail and felt that there was enough scope for improvement of the methodology for its incorporation in the existing project under various conditions. It prepared a paper suggesting a revised methodology.

The Groundwater Estimation Committee (GCET) which submitted its report to Government of India in 1986, consisting of the members as follows on evaluation of groundwater resources recommended that the groundwater resource should be estimated based on ground-water level fluctuation method. The annual table in conjunction with aquifer corresponds to the rainfall of the year of estimation. The rainfall average estimated should be corrected to the long term normal (city) rainfall as given by Indian Meteorological Department (IMD). To estimate the classes of drought or super-normal, the hydro-geologic zoning may be estimated for a period of 10 to 20 years and an average value obtained. From which rainfall may also be estimated on the same lines.

Local groundwater resources for water and supplies is the sum of a local recharge and potential recharge in shallow water table and water logged areas. It also recommended that 15 percent of total groundwater resources be kept for drinking and industrial purposes, for computed base flow and to account for other minor variable flows. In case the domestic base flow and the domestic and industrial flows are more than 15% of the total groundwater resource, the available resource for irrigation in these areas may be decreased accordingly.

The quantity of groundwater available for direct ground is usually restricted to long term average quantity of the aquifer and is the replenished source of supply.

Groundwater being a dynamic and replenishable resource has to be estimated primarily based on normal annual recharge which will be developed by means of suitable groundwater observation structures and suitable techniques for various purposes. The non-normal groundwater recharge might be due to the climatic and hydrogeological conditions. The physical geographic setting of soils permeability presents the heavier rainfall in the north eastern part of the country and the low rainfall in the south, the character of a desert or semi desert part with low rainfall presents some special case. In the west central part of peninsular India, the average rainfall of the country being of the order of 1100 mm and distributed unevenly over the country during the winter and south west monsoon and timing of such rains in different areas and comparison to the direct systems in north and south India. The quantity of water resources in the country. The hydrogeologic conditions and resources available for and quality of such resources in the second edition of Part I of the hydrogeology of India, as a part of the 2000 and the 2005 and Board, Government of India which may be referred to for more details.

A scientific assessment of the groundwater potential of the country has been made tentatively on the basis of reconnaissance of CGWB water Estimation Manual of 1982 and data being generated by Centre for Groundwater Board. Total annual replenishable

is not practical. It is also difficult to find a way to do the development of a new vehicle as the two normal functions of the vehicle are to move on the road and to allow the driver to control it. The development of a new vehicle is a complex task. It is not only a matter of design, but also a matter of construction. The development of a new vehicle is a complex task. It is not only a matter of design, but also a matter of construction.

Vehicle development is a complex task. It is not only a matter of design, but also a matter of construction. The development of a new vehicle is a complex task. It is not only a matter of design, but also a matter of construction. The development of a new vehicle is a complex task. It is not only a matter of design, but also a matter of construction.

5.2.4.2 Characterization of groundwater for design

The characterization of groundwater for design is a complex task. It is not only a matter of design, but also a matter of construction. The development of a new vehicle is a complex task. It is not only a matter of design, but also a matter of construction. The development of a new vehicle is a complex task. It is not only a matter of design, but also a matter of construction.

The characterization of groundwater for design is a complex task. It is not only a matter of design, but also a matter of construction. The development of a new vehicle is a complex task. It is not only a matter of design, but also a matter of construction. The development of a new vehicle is a complex task. It is not only a matter of design, but also a matter of construction.

5.2.4.3 Methods for Groundwater Prospecting

5.2.4.3.1 Remote sensing

Remote sensing is a method for groundwater prospecting. It is not only a matter of design, but also a matter of construction. The development of a new vehicle is a complex task. It is not only a matter of design, but also a matter of construction. The development of a new vehicle is a complex task. It is not only a matter of design, but also a matter of construction.

supplement the existing techniques of hydrogeological and geophysical techniques and are not a replacement for these techniques.

In a general sense, we can divide the aquifers into two groups: (i) Aquifers in alluvial areas, and (ii) Aquifers in bed rock areas.

(i) Aquifers In Alluvial Areas

Most well sorted sands and gravels are fluvial deposits, either in the form of stream channel deposits and valley fills or as alluvial fans. The remainder are cheniers, beach ridges, benches, and some well developed dunes. Table 5.1 lists the keys to detection of such aquifers on the satellite imagery. Although hydrogeologically significant landforms etc. can be delineated easily on Landsat images, more details are visible on aerial photographs. In favorable cases Landsat images can be used to select locations for test wells. In other areas local's can be marked for more detailed ground surveys or examination of aerial photographs.

TABLE 5.1
KEYS TO DETECTION OF AQUIFERS IN ALLUVIAL
AREAS ON SATELLITE IMAGES

SHAPE OR FORM	
Sl. No.	Description
1.	Stream valleys, particularly wide, meandering (low gradient) streams with a large meander wavelength and with broad and/or slightly incised valleys
2.	Uplifted valleys (not related by topography to a low, denude areas with irregular drainage or with a small meander wavelength smaller than that of the floodplain or terraces)
3.	Natural necks (becks themselves may be fine grained materials)
4.	Meander necks showing low flow and relative thickness of point bars
5.	Meander scars in the channel network (note dissection of upland areas)
6.	Braided fluvial channel scars
7.	Drainage line shifts, change in drainage pattern, or change in size or frequency of meanders (may be caused by faults and/or by changes in lithology)
8.	Wind delta (dunes, sand bars) and other dunes
9.	Cheniers, beach ridges, and beach dunes
10.	Alluvial fans, including fine topilas
11.	Aligned elongated areas of different nature (vegetation representing landlocked bars, spits, meander benches, or other coarse and well sorted materials)

PATTERNS

1. Drainage patterns imply lithology and degree of structural control; drainage density of hard regions and drainage texture (and regions) imply joint size, frequency, and permeability.
2. Snowmelt, if every thing else is equal, anomalous early melting snow and greening of vegetation show areas of poor or water discharge are free areas on rivers and basins.
3. Distinctive types of native vegetation commonly show upstream extensions of drainage patterns, areas of high soil moisture, and landform outlines (flooded regions); abrupt changes in land cover type or land use imply landforms that may be hydrologically significant but do not have a characteristic shape.
4. Elongate lakes, sinuous lakes, and aligned lakes and ponds representing remnants of a former stream valley.
5. Parallel and sub-parallel.
6. Splay of parallel linear patterns representing old alluvial fans or faulted and checked channel complexes.

TOPE

1. Soil type, but ground soils commonly are darker than coastal ground soils.
2. Soil moisture, wet soils are darker than dry soils.
3. Type and species of native vegetation, vegetation is well adapted to type and thickness of soil, drainage characteristics, and seasonal period of saturation of root zone.
4. Land use and land cover, for example, no-cut bare soil may correlate with drainage density; also for example, native vegetation in lowlands and drainage density, and agriculture on uplands may indicate periodic flooding.
5. Anomalous early or late seasonal growth of vegetation at areas of high soil moisture, as when water table is close to land surface.

TEXTURE

1. Uniform or mixed types of native vegetation, some species and vegetation associations are indicators of wet versus dry sites, thick versus thin soils, or particular mineral compositions of soils.
2. Contrast between sparse vegetation on topographic highs and denser vegetation in low (wetter) areas.
3. Texture contrasts at boundaries of grass, bush and forest cover types; possible boundaries of soil types or moisture conditions.

(ii) *Aquifers In Hard Rock Areas*

The groundwater abundance depends on rock type, amount and intensity of fracturing. The keys to location of aquifers in hard rock areas is given in Table 5.3. The only space for storage and movement of groundwater in such areas is in fractured enlarged by brecciation, weathering, solution or corrosion. These have surface expressions, in fact weathering, solution, and corrosion operate on land surface as well, in addition to geomorphic processes such as mass wasting and frost wedging. A fracture that is a plane of weakness for

enlargement by groundwater may be represented on the land surface by topographic depression, a different soil type, or a vegetation anomaly at land surface.

Many fractures are vertical, in this case, lineaments may represent favourable locations for water wells. Other fractures may be oblique.

TABLE 5.2

KEYS TO DETECTION OF AQUIFERS IN HARD-ROCK AREAS ON SATELLITE IMAGES

OUTCROPPING ROCK TYPE	
Sl.No.	Description
1.	Lineaments, topographic relief
2.	Outcrop patterns, banded patterns for sedimentary rocks (outlined by vegetation in some regions), lobate outline for basalt flows; circling patterns for folded beds.
3.	Shape of drainage basins
4.	Drainage patterns, density and texture
5.	Fracture type and symmetry (as implied by lineaments), triangular facets above fault or fault line scarps, and alluvial fans below; discontinuities in bedding patterns, topography or topographic texture, and vegetation types
6.	Relative abundance, shape and distribution of lakes
7.	Forms and textures (difficult to describe, best determined by study of known examples)
8.	Types of native land cover

FOLDS

1. Crests and hogbacks: asymmetric ridges and valleys, variations on dip slope and irregular topography on back slope; uniform distribution of vegetation on dip slope and vegetation banding parallel to ridge crest on back slope; bands on dip slope and separate alluvial fans on back slope.
2. Banded outcrop patterns not related to topography, closed to arcuate patterns; U shaped to V shaped map patterns of ridges; sedimentary rock patterns with an igneous core
3. Trellis, radial, annular, and centripetal drainage patterns, partly developed patterns of these types superimposed on drainage patterns of other types
4. Major deflections in stream channels; changes in meander wavelength or changes from meandering to straight or braided patterns
5. Asymmetric drainage channels not centered between drainage divides,

LINEAMENTS

1. Continuous and linear stream channels, valleys, and ridges, discontinuous but straight and aligned valleys, draws, swags and gaps.
2. Elongate or aligned lakes, large sinkholes and volcanoes
3. Identical or opposite deflections (such as doglegs) in adjacent stream channels, valleys, or ridges; alignment of nearby tributaries and tributary junctions.
4. Elongate or aligned patterns of native vegetation; thin strips of relatively open (may be rights of way) or dense vegetation.
5. Alignment of dark or light soil tones.

(iii) Limitation

Though remote sensing is a versatile tool, the presence of important indicators of groundwater occurrence can-not always be recognised as such on satellite images especially where morphological expressions of geologic structures are relatively small. The tone differences between rock types are indistinct and variation in the inclination of rock formations minimal.

The limitations of remote sensing in groundwater exploration are:

1. No quantitative estimates of expected yield of wells can be given from remotely sensed data
2. No depth estimation of aquifers can be made. It may, however, be noted that empirical observations show that length of a lineament (fracture zone) is related to the depth of the basement
3. Assessment of quality of water is also not possible. Although the type and vigour of vegetation present on the land surface does provide a clue to the quality of water underneath
4. In high-relief areas, satellite imagery may not be adequate to locate groundwater controls. Aerial photography may also have to be used
5. Lateral extent of only those aquifers which are directly exposed or manifest through land covered e.g. shallow aquifers (vegetation), valley fills etc. can be delineated

(b) Geophysical

Geophysical methods play an important role in any groundwater exploration work. Geophysical methods detect differences or anomalies of physical properties within the earth's crust. Density, magnetism, elasticity and electrical resistivity are the properties most commonly measured. Experience and research have enabled difference in these properties to be interpreted in terms of geologic structures, rock type and porosity, water content and water quality.

All the four major geophysical methods viz; electric, magnetic, seismic and gravimetric find their use in groundwater exploration in addition to the method of electrical logging which is used extensively to study the physical character, especially porosity and permeability

of aquifers penetrated by bore holes. Of the four major methods, electrical and seismic refraction generally had the maximum use in that order.

In unconsolidated and consolidated sediments, the problem from the geophysical point of view may more often be not specifically of locating groundwater as such, but determination of water table and delineation of saline aquifers from potable water zones. On the other hand, in igneous and metamorphic rocks where groundwater generally occurs in fissures and shattered zones or in basins of decomposition, the problem is mainly to locate such structural features which constitute the possible location of the aquifers yielding sufficient quantities of water.

(i) The Electrical Resistivity Method

The electrical resistivity of a rock formation means the amount of current passing through the formation when an electrical potential is applied. It may be defined as the resistance in ohms between opposite faces of a unit cube of the material. If a material of resistance R has a cross sectional area A and a length l , then its resistivity ρ can be expressed as

$$\rho = \frac{RA}{l} \quad (5.1)$$

In the metric system, units of resistivity are ohms m^2/m or simply ohm m.

Resistivities of rock formations vary over a wide range, depending upon the material, density, porosity, pore size and shape, water content, quality and temperature.

(ii) Seismic Refraction Method

This method involves the creation of a stress shock at the earth's surface either by the impact of a heavy instrument or by exploding a small dynamic charge and measuring the time required for the resulting sound, or shock wave to travel known distances.

Electric logging and other related geophysical tools, such as gamma ray, neutron logging, help to determine where the aquifers are located to reduce the number of failures. Besides, surface operated equipment, such as the seismograph (non explosive type) are necessary adjuncts for maximum groundwater exploitation.

5.2.5 HYDRAULICS OF GROUNDWATER FLOW

(a) General Hydrologic Equation

Hydrological equilibrium is expressed by the following equation.

$$\sum R = \sum D + \Delta S \quad (5.2)$$

where,

$\sum R$ = summation of flows due to hydrological factors of recharge

$\sum D$ = summation of flows due to hydrological factors of discharge

ΔS = associated change in storage volume.

More specifically the recharge (ΣR) is composed of the following

1. Natural infiltration derived from rainfall and snow melt;
2. Infiltration from surface bodies of water;
3. Underflow;
4. Leakage through confining layers, or water displaced from them by compression; and
5. Water derived from diffusion, charging and water spreading operations.

Conversely, the discharge includes

1. Evaporation and transpiration;
2. Seepage into surface bodies of water;
3. Underflow;
4. Leakage through confining layers or absorbed by them by reduction or compression; and
5. Water withdrawal through wells and infiltration galleries.

The associated change in storage volumes, ΔS , depends on the properties of soil or rock particularly, the porosity or void ratio, size, shape and compaction of the formation which are all reflected in the specific yield of the formation. ΔS increases with the specific yield.

(b) Rate Of Groundwater Flow

The flow of groundwater through aquifers under the hydraulic conditions of non turbulent or straight line flow is governed by Darcy's Law which states that head loss due to friction varies directly as velocity of flow and is expressed as

$$V = KI \quad (5.3)$$

where

- V = velocity of flow in metres per day
- I = slope of hydraulic grade line, i.e. slope of the groundwater table or piezometric surface
- K = Coefficient of permeability or proportionality constant for water of a given temperature flowing through a given material in metres/day

and

$$Q = AvV \quad (5.4)$$

where,

- Q = Groundwater flow in m^3 per day
- A = cross section of aquifer in m^2
- v = velocity of water bearing medium, it being assumed that the product Av^2 represents the areas of the channels through which flow is taking place.

This should not be used for flows having Reynolds number greater than 10. This limit is generally reached as water approaches face of wells in coarse grained sandy soils. In practice no lower limit has been observed even at small hydraulic gradients.

Since f is dimensionless ratio, K has the dimension of velocity and in fact is the velocity of flow under a hydraulic gradient of unity.

(c) Conditions Of Groundwater Flow

The groundwater is obtained from aquifers through a "gravity well" or "pressure well" or an "infiltration gallery".

In the "gravity well" the surface of the water outside of and surrounding the well is at atmospheric pressure.

In a "pressure well" the aquifer holds water under pressure greater than atmospheric.

An "infiltration gallery" is a horizontal tunnel or open ditch constructed through the aquifer in a direction nearly normal to the direction of groundwater flow. The tunnel type of gallery is sometimes called a horizontal well.

If a gravity or pressure well is pumped at a constant rate, the drawdown in the well around the area of influence will continue to increase until the rate of replenishment is equal to the rate of pumping i.e. until the equilibrium has been established. The flow into the well until this equilibrium is established is under "Non-equilibrium" conditions. The flow into the well after the equilibrium has been established will be under "Equilibrium" conditions and the flow will be called steady. The steady flow may be "unconfined" or "confined". The flow in a gravity well is "unconfined" and in a pressure well is "confined".

(d) Formulae For Flow Under Equilibrium Conditions

Assumptions

- ◆ Direction of the flow of groundwater is horizontal,
- ◆ The flow is at a constant rate and in a radial direction towards the centre of the well; and
- ◆ The well penetrates to the bottom of the aquifer and is in equilibrium condition unless it is specified to the contrary.


(i) Flow Into A Gravity Well Under Equilibrium Conditions (Refer Fig 5.1)

The flow into a gravity well under equilibrium conditions is given by the formula:

$$Q = \frac{1.36K(H^2 - h^2)}{\log \frac{R}{r}} \tag{5.5}$$

Where,

- Q = Rate of flow into well in m³/d
- K = Permeability constant in m/d
- H = Depth of the water in the well before pumping in m



FIGS. 1: GRAVITY WELL UNDER EQUILIBRIUM CONDITIONS

- h = Depth of water in the well after pumping = $(H - \text{drawdown})$ in m
- R = Radius of influence in m
- r = Radius of well in m

(ii) Flow into a pressure well under Equilibrium Conditions. (Refer fig 5.2)

Flow into a pressure well under equilibrium conditions is given by the formula:

$$Q = \frac{2.72K m(H - h)}{\text{Log} \frac{R}{r}} \quad (5.9)$$

Where,

- Q = rate of flow into well in m^3/d
- K = permeability constant in m/d
- m = thickness of the confined aquifer in m
- H = depth of water in the well before pumping in m
- h = depth of water in the well after pumping in m




FIG 5.2 : PRESSURE WELL UNDER EQUILIBRIUM CONDITIONS

R = radius of influence in m

r = radius of well in m.

(iii) Flow Into An Infiltration Gallery Under Equilibrium Conditions (Refer Fig 5.3)

The expression for the rate of flow into an infiltration gallery is given by the formula.

$$Q = \lambda l \frac{H^2 - h^2}{2R} \quad (5.7)$$


where,

Q = rate of flow in m^3/d

λ = permeability constant in m/d

l = length of the gallery in m

H = initial depth of water level in m



FIGS.3: INFILTRATION GALLERY UNDER EQUILIBRIUM CONDITIONS

h = height of water level in m

R = radius of influence in m

(iv) Partial Penetration Of An Aquifer By A Well

If the gravity well does not penetrate to the bottom of the aquifer, the expression (5.5) is not applicable. The flow into a partially penetrating gravity well is given by the expression

$$Q = 136K \left(\frac{H^2 - h^2}{\log \frac{R}{r}} \right) \left[\frac{1}{\sqrt{1 + \frac{1}{\sqrt{H_1}}}} \right] \quad (5.8)$$

where,

R = radius of influence in m

r = radius of well in m

H = thickness of aquifer in m

H_1 = thickness of aquifer penetrated in m

$\rho = H_1/H$

$\pi p/2$ = angular perimeter in radians

(e) Flow Into Wells Under Non-Equilibrium Conditions Or Unsteady Flow Conditions

The rate of flow under non equilibrium conditions is given by the expression:

$$p = \frac{114.6Q}{T} \cdot F(u) \quad (5.9)$$

$$u = \frac{250S}{T} \frac{x^2}{t} \quad (5.10)$$

where,

$F(u)$ = well function of u whose values could be found out from the Table at Appx 5.4 or the type curve at Appendix-5.5 for different values of u

Q = uniform rate of pumping in lpm

S = storage coefficient

t = time during which the well has been pumped (expressed in days)

T = coefficient of transmissibility in lps per metre width

x = distance from the well in m

p = draw-down in m.

Q , S and T are considered to be constant.

Then, $\frac{Q \times 114.6}{T} = C_1$, $\frac{T}{250S} = C_2$ are also constants

The equations (5.9) and (5.10) above be written as:

$$\log C_1 = \log p + \log F(u) \quad (5.11)$$

and

$$\log C_2 = \log \frac{x^2}{t} + \log(u) \quad (5.12)$$

The values of C_1 and C_2 can be found out from the field observations. Drawdowns in the observation wells (x metres away from the central well) are observed at different intervals, when the central well is pumped out at uniform rate.

The measured values of ' p ' are plotted as ordinates against measured values of x^2/t as abscissae on a log-log paper and a curve drawn as at Appendix 5.5

Because of the similarity of expressions (5.11) and (5.12) and the methods of plotting this curve and the type curve (plotted with values of $F(u)$ as ordinates against values of u as abscissae on a log-log paper) there is a corresponding point on the type curve which is displaced vertically by a fixed distance representing $\log C_1$ and horizontally by a fixed amount

representing $\log C_2$. Therefore, a fixed amount of vertical and horizontal shift will bring the two curves into coincidence.

If transparent paper is used for the plot of the observed data and it is placed over the type curve, to be shifted horizontally and vertically until a best fit of the plotted points to the type curve is obtained, then any matching point will identify the values of $P(u)$ and u that correspond to the values of p and x^2/t by which equations (5.9) and (5.10) can be solved for T and S .

Though these equations apply rigidly only when (i) the aquifer is homogeneous; (ii) the aquifer is infinite in areal extent; (iii) the well penetrates the entire thickness of the aquifer (iv) the coefficients of transmissibility and storage are constant at all times and places; and (v) water is released from storage as soon as the cone of depression develops, they could be used in the field conditions generally encountered.

This method is very useful for long term prediction of groundwater yield and regional planning of groundwater extraction (Appendix 5.6)

5.2.6 DEVELOPMENT OF SUBSURFACE SOURCES

The subsurface sources include springs, wells and galleries. The wells may be shallow or deep. Shallow wells may be of the dug well type, sunk or built, of the bored type or of the driven type. They are of utility in abstracting limited quantity of water from shallow pervious layers, overlying the first impermeable layer.

Deep wells are wells taken into pervious layers below the first impermeable stratum. They can be of the sunk well type or the bored or drilled type. They are of utility in abstracting comparatively larger supplies from different pervious layers below the first impervious layer. Because of the longer travel of groundwater to reach pervious layers below the top impermeable layers, deep wells yield a safer supply than shallow wells.

5.2.6.1 Classification Of Wells

The wells are classified according to construction as follows

- (a) dug wells;
- (b) sunk wells;
- (c) driven wells; and
- (d) bored wells.

(a) Dug Wells

Dug well of the built type has restricted application in semi-permeable hard formations. The depth and diameter are decided with reference to the area of seepage to be exposed for intercepting the required yield from the sub-sed layers. Unsafe quality of water may result if care is not taken in the well construction. It is necessary to provide a water-tight stemming upto a few metres below the vertical zone of pollution which usually extends 3 to 5 m or more below natural ground surface.

The stemming should extend well above the ground surface and a water tight cover provided with water tight manholes.

The bottom of the well should be at a point sufficiently below the lowest probable summer water table allowing also for an optimum drawdown when water is drawn from the well. Adequate provision should also be made to take care of interference by other pumping wells. To facilitate infiltration into the well, after the stemming is constructed in the case may be, weepholes are left in the stemming at suitable intervals. It is usual to insert six lengths of pipes in the stemming with the outer end covered with a wire gauze and surrounded with gravel or crushed bricks of fine material.

(b) Sunk Wells

Sunk wells depend for their success on the water bearing formations which should be of adequate extent and porosity. The sunk well is only the water position of a man-made barrel into such a deposit so as to intercept, as large a quantity of water, as is possible.

(i) Size vs Yield

The yield of any form of a well is dependent on the rate of flow of the groundwater and the area made tributary by the depression of the water level in the well rather than on the size or form of construction. As is well known, the effect of size alone is very small and an increase in the yield of large wells will not commensurate with the increase in size.

The large well has an advantage over the small well in its storage capacity and facility for placement of pumps sets economically. Trouble may often be experienced in the small wells through clogging and the entrance of fine sand. This is largely avoided in the large well as the entrance velocity of the water is correspondingly small. Opportunity is also given for the setting of fine material.

Wells for water supply are constructed of diameters normally ranging from 3 m. and above. As the cost of a well increases with increase in diameter, more rapidly than does the yield, any large diameter should be adopted after careful consideration.

(ii) Construction Methods

The minimum depth of a well is determined by the depth necessary to reach and penetrate, for an optimum distance, the water bearing stratum allowing a margin for dry seasons for storage and for such draw down as may be necessary to secure the required yield. The method of construction employed depends on the size and depth of the well, characteristics of material to be excavated and quantity of water to be encountered. The procedure generally adopted is to have open excavation upto the sub-soil water table and thereafter to commence sinking the stemming built in convenient heights, over a wooden or R.C.C. curb with a curbing edge at the bottom, the curb projecting about 4 cms beyond the outside face of the stemming to facilitate easy sinking. Mild steel holding down rods are run from the bottom of the curb through the stemming spaced about 2 metres circumferentially, with horizontal ties in steel or of concrete rings spaced about 2 metres vertically. The material from inside the well is dished and removed either mechanically or by manual labour using chisels with driving equipment.

(iii) Measures to Increase Yield

Lowering the well to an optimum extent is resorted to, during the sinking operations. The construction supervision should ensure uniform vertical sinking of the stemming. Entry for the infiltration water into the well is usually at the bottom below the curb. In order to reduce the velocity of entry and to abstract a larger yield for the same draw down, weepholes in the stemming at suitable intervals, horizontally and vertically, would be useful. These could be of cut length of pipes 75 or 100 mm dia, built into the stemming with wire gauze at the outer end, which will be kept flush with the outside face of the stemming. Such weepholes would draw water from the various layers extending over the depth of the stemming, apart from the index at the bottom. In the initial stages of pumping and during the raising of the yield, the fines from water bearing strata round each weephole would be drawn out facilitating a larger index through each weephole, under normal pumping.

(iv) Porous Plugs

In the case of infiltration wells sunk in sandy soils, a porous plug in the form of a reverse filter is placed at the bottom of the well after the initial raising of the yield from such well, to facilitate the abstraction of a greater yield, as the plug would permit increased velocities of entry without sand blows. The graded plug is usually an inverted filter comprising of coarse sand and broken material of appropriate sizes to suit the texture of the soil strata in the aquifer immediately below the well curb. The depth and the composition of the porous plug will be designed to maintain the natural sandy layer immediately below the curb level undisturbed during pumping.

Radial strainer pipes are driven horizontally from the interior of sunk wells into the water bearing pervious strata as a measure of increasing the yield for the same draw down. The arrangement in effect enlarges the zone of collection of the well. Further details are given under Radial Collector Wells in 1.10.2.

(v) Protection Measures

All wells should be covered so as to prevent direct pollution of water. Where infiltration wells are sunk in the bed of streams liable to carry floods, the top of the well should be kept 0.5 m. or more above the maximum flood level if it is not very high. If the well top is kept below flood level, provision should be made for sealing the well with a porous concrete ring placed below the cover slab of well house in the cover slab filled with a graded filter material.

(c) Driven Wells

(i) Construction

The shallow tube well, also called a driven well, is sunk in various ways depending upon its size, depth of well and nature of material encountered. The closed end of a driven well comprises a tube of 40 to 100 mm in diameter, closed and pointed at one end and perforated for some distance then from. The tube thus prepared is driven into the ground by a wooden block until it penetrates the water bearing stratum. The upper end is then connected to a pump and the well is complete. When the material penetrated is sand, the perforated portion is covered with wire gauze or suitable sized bedding upon the face of the sand (1).

prevent injury to the gauze and closing of the perforations, the head of the shoe is usually made larger than the tube or the gauze may be covered by a perforated jacket.

Such a driven well is adopted for use in soft ground or sand upto a depth of about 25 m and in places where the water is thinly distributed. On account of the ease with which it can be driven, pulled up and redriven, it is especially useful in prospecting at shallow depths and for temporary supplies. It is useful as a community water standpost in rural area.

(ii) Protection Measures

Special care is necessary during construction to avoid surface pollution reaching the sub-soil water level directly, through any passage between the pipe and the soil. The usual precaution is to have the perforations confined to the lower depths of the aquifer with the plain tubing extending over the top few metres of the soil. In addition, a water-tight concrete platform with a drain should be provided above ground level, in order to deflect any surface pollution away from the pipe.

(d) Bored Wells

(i) General

Bored wells are tubular wells drilled into permeable layers to facilitate abstraction of groundwater through suitable strainers inserted into the well extending over the required range or ranges of the water bearing strata. There are a variety of methods for drilling such wells through different soils and for providing suitable strainers with a gravel shrouding where necessary.

Bored wells useful for obtaining water from shallow as well as deep aquifers are constructed employing open end tubes, which are sunk by removing the material from the interior, by different methods. The deeper strata are usually more uniform and extensive than strata near the surface, so that in regions already explored, deep wells can be sunk with far more certainty of success than is usually the case with shallow wells. Methods of sinking deep wells are in many respects different from those already described and matters of spacing, pipe friction, arrangement of connections, etc., are much more important than in the shallow wells.

For bored wells, the hydraulic rotary method and the percussion method of drilling such wells through hard soils are popular. For soft soils, the hydraulic jet method, the reverse rotary recirculation method and the sludger method are commonly used.

(ii) Direct Rotary Method

With the hydraulic direct rotary method, drilling is accomplished by rotating suitable tools that cut, chip and abrade the rock formations into small particles. The equipment used consists of a derrick, suitable cables and reels for handling the tools and lowering the casing into the hole, a rotary table for rotating the drill pipe and bit, pumps for handling mud laden fluid and a suitable source of power. As the drill bit attached to the lower end of the drill pipe is rotated, circulating mud is pumped down the drill pipe, out through opening in the bit and up the surface through the space between the drill pipe and the walls of the hole. The mud laden fluid removes the drill cuttings from the hole and also prevents caving by plastering and supporting the formations that have been penetrated. For soft and moderately

hard materials a drilling tool shaped like the tail of a fish, the 'fishtail bit' is used. In hard rock a 'rock bit' or 'roller bit' is substituted. This bit has a series of toothed cutting wheels that revolve as the drill pipe is rotated.

Water wells drilled by the hydraulic rotary method generally are cased after reaching the required depth, the complete string of casing being set in one continuous operation. If the water-bearing formation lies so deep that it probably cannot be reached by a hole of uniform diameter, the hole is started one or more sizes larger than the size desired through the water-bearing formation, separate strings of casing are used as required through the separate sections of the hole. If the formation is so well consolidated that the hole will remain open without casing, a well may be finished with one string of casing and a well screen.

This method is most suitable for drilling deep holes in unconsolidated formations. It is unsuitable for drilling in boulders and hard rocks due to slow progress and high cost of bits. It is also unsuitable for drilling in slanted and fissured formations and serious lost circulation zones. Mud drilling is harmful in low pressure formations due to mud invasion. The hydraulic rotary drilling generally requires large quantity of water which may have to be brought from long distances, if not locally available. Because of adding large quantities of water and sand or clay to the drill cuttings, the hydraulic rotary method is less suitable for obtaining accurate logs of the strata encountered.

A recent advance is the use of organic drilling fluids instead of inorganic and permanently gelatinous clays such as bentonite. The organics are almost completely self-destructive within a period of few days which means no drilling muds are left in the pores of the aquifer and, therefore, almost always higher yields are obtained with accompanying lesser development expenditures. In addition to higher specific capacities, cleaner holes (more cuttings settle on the surface equipment) and faster drilling rates also result.

(iii) Percussion Method

In the percussion method of drilling, the hole is bored by the percussion and cutting action of a drilling bit that is alternately raised and dropped. The drill bit, a clublike, chisel edge tool, breaks the formation into small fragments and the reciprocating motion of the drilling tools mixes the loosened material into a sludge that is removed from the hole at intervals by a bailer or a sand pump. The drilling tools are operated by suitable machinery, which is usually of the portable type mounted on a truck or a trailer so that it can be moved readily from job to job. This method is best suited for drilling on boulders, slanted and fissured formations and lost circulation zones. Rate of drilling in alluvial formations, particularly those having clay or sticky shale strata, is much lower as compared to direct or reverse rotary methods. Percussion drilling in hard rock is a slow process and is being gradually replaced by pneumatic rotary drilling because of economy and speed of completion regardless of the higher initial cost.

'Pneumatic Drilling'

Pneumatic drilling with top hammer and eccentric bit and pneumatic drilling with down the-hole hammer are the two principal methods available for drilling in consolidated (hard rock) formations:

(a) Top Hammer and Eccentric Bit

This rapidly expanding drilling method is most valuable when drilling in hard rocks covered with difficult overburden. The overburden, even if it is of the collapsible type, presents no problem as the method is based on the simultaneous drilling and inserting of casing tubes down to and even into the bed rock. The principle of the drilling method is as follows:

A compressed air powered rock drill with a separate rotation coupled to it, works at the top of a drill string. At the bottom of the string is a tungsten carbide set drill bit, the pilot bit, to which the impact and rotation is transmitted. Immediately above this bit is a reamer with a tungsten carbide set cutting edge. With normal rotation to the left, the reamer will swing eccentrically and cut a hole which is of larger diameter than the pilot bit, allowing the casing tubes which enclose the drill string to run into the hole at the same pace as the drilling proceeds. Since no external obstructions can be tolerated on the string of casing tubes, they will have to be flush-jointed with male and female threads or, preferably, by adding. The cuttings are flushed up between the drill string and the casing tubes. To make this effective and also prevent the formation of large amounts of dust, foam producing chemicals are introduced into the flushing air.

(b) Down-the-Hole Hammer

This drilling method, called DHH for short, permits rapid and effective drilling in rock and through overburden which is not susceptible to collapse. In this method the impact mechanism blows directly on the drill bit and accompanies it down into the hole. Compressed air for the impact mechanism is supplied through drill hoses which are joined as required as the drilling advances. The same air is, after it has passed the hammer, made use of for flushing. The necessary rotation is supplied from a rotation unit connected to the upper drill tube.

As the drill tubes are not required to transmit the violent impact energy of the hammer, they can be manufactured with large diameter and still be relatively thin walled. This gives the method better flushing characteristics than conventional top hammer drilling. Theoretically, the rate of penetration is independent of the hole depth with the DHH method no water is required during drilling. The equipment is also cheaper and lighter as a much smaller compression is required than for top hammer drilling.

(c) Hydraulic Jet Method

This is the best and most efficient method for small diameter holes in soft soils. Water is pumped into the boring pipe fitted with a cutter at the bottom and escapes out through the annular space between the pipe and the bored hole. The pipe is rotated manually with the aid of pipe wrenches with a steady downward pressure. The soil under the cutter gets softened and loose by the action of the jet of water and is washed with it as the cutter proceeds, down with the weight of the pipe. Additional lengths of pipe are added till the required depth is reached. The wash water circulating in the annular space indicates the type of soil that is being encountered by the cutter. When the desired depth is reached, the pipes are withdrawn and the well tube with the strainer is located by the same process using a plug cutter with the plug removed instead of the ordinary steel cutter. When the pipe is in position, the plug

is chopped down to seal the bottom. Then the tube well is cleaned by forcing water through a 20-mm pipe lowered right to the bottom of the tube well. Then it is withdrawn and the pump fitted on top.

In bigger diameter tube wells, compaction of sand and mechanical driven pump set is used for pumping. The tube well pipe with the strainer is lowered into the casing pipe and the outer casing is withdrawn. Generally compressed air is used for developing the well. To economise, the use of water during the operation, the wash water carrying from the bore is led to a sump where from the water is again pumped for being forced into the bore.

(iv) *Reverse Rotary Method*

In this method, the water is pumped out of the bore through the pipe and fed back into the annular space between the bore and the central pipe. No casing is required in this method which is used only in clayey soil with little or no sand. This method is suitable for large diameter bores upto a depth of 15 m. The rotating pipe is clamped to a turn table which rotates slowly operating the cutter. The water pumped out of the tube contains the washings and is led to a series of sumps for effective sedimentation of the solid particles before the water is put back to flow into the bore. Bentonite or some clayey material which can adhere to the sides of the bore finally is used from time to time.

After the required depth is reached, the pipe with the cutter is taken out of the bore and the well pipe with the strainer then lowered into the bore. The annular space between the bore and the well pipe will be then surrounded with pea gravel.

(v) *Sludger Method*

In this method the boring pipe with the cutter attached is raised and lowered by lever action and the bore is drilled with water being pumped vertically. When the boring has proceeded a few metres down, the pumping out of the water from the inside of the bore pipe is carried out in an improvised manner by the operation of using the top end of the pipe during the upward stroke and allowing it during the downward stroke. This method when done with quick up and down strokes enables the sludgers from the bore pipe to come out of the pipe. The bore is always kept full with the water in the sump. Bentonite or some clayey material is added occasionally. This method is suitable for depths upto about 50 metres. When the proper depth is reached, the bore pipe is taken out and the well tube with the strainer is lowered as in other methods. This method is suitable for small diameter wells in soft soils and medium hard soils. This is particularly applicable for use in areas not easily accessible where labour is available for the manual workmen.

(vi) *Casing of Wells*

Wells in soft soils must be cased throughout. When bored in rock, it is necessary to case the well at least through the soft upper strata to prevent caving. Casing is also desirable for the purpose of excluding surface water and it should extend well into the solid stratum below. Where artesian conditions exist and the water will eventually stand higher in the well than the adjacent groundwater, the casing must extend into and make a tight joint with the impervious stratum, otherwise water will seep into the ground above.

If two or more water bearing strata are encountered, the water pressures in different strata are likely to be different, that from the lower usually being the greater. Where different pressures thus exist, it is only possible to determine their amount by separately testing each stratum as reached, the others being cased off. This operation is an essential part of the boring and should be carefully performed. Important differences in quality and yields are discovered in this way.

When quality stratification exists, which may be ascertained from geophysical logs or drill stem tests, blank casings should be provided against zones containing undesirable quality of water and the annular space between the casing and hole wall should be sealed with cement grout or packers. This will ensure that the fresh water aquifers are not contaminated by leakage.

Large casing is generally made of welded or riveted steel pipe. For smaller sizes of pipe which are to be driven, the standard wrought iron pipe is ordinarily used, but for heavy driving extra strong pipe is necessary. The life of good heavy pipes is ordinarily long, but they are liable to rapid corrosion due to the presence of excess amount of carbon and the use of rust resisting alloys would be economical in such special cases. Non-reinforced plastic, usually PVC, casing upto 150 mm dia and reinforced plastic casing and fibre glass for longer dia upto 300 mm are coming into vogue.

(viii) Well Strainer and Gravel Pack

In providing the strainer arrangement whereby water is admitted and sand or gravel excluded, it is desirable to make the openings of the strainer as large as practicable in order to reduce friction, while at the same time preventing entrance of any considerable amount of sand.

The openings in well strainers are constructed in such a fashion as to keep unwanted sand out of the well while admitting water with the least possible friction. In fine uniform strata, the openings must be small enough to prevent the entrance of the constituent grains. Where the aquifer consists of particles that vary widely in size, however, the capacity of the well is improved by using strainer coverings through which the finer particles are pulled into the well, while the coarser ones are left behind with increased void space. A gravel filter is thereby created around, with the aid of back flushing operations or by high rates of pumping.

The selection of the well screen is important, on it depends the capacity and the life of the well. The size of the openings must be selected after a study of the mechanical analysis of the aquifer, to permit the passage of all fine particles representing a certain percentage by weight, of the water bearing material. It is common practice to use openings that will pass about 70 per cent or more of the sand grains in the natural aquifer whose uniformity coefficient should range between 2 to 2.5, or sands with uniformity coefficient less than 1.5, gravel should be used. The shape of the openings should be such as to prevent clogging and bridging, which can be diminished by V shaped openings with the taper end towards the inside of the well. Long, narrow, horizontal or vertical slotted pipes are preferred for large diameters. The openings should be placed as close together as the strength of the screen will permit.

The material used for opening in a screen could be such as to facilitate an entrance and, if necessary, to carry the fine particles of sand that is to be excluded by the screen. In general, it should be well screened to prevent gravel shoaling. It is generally desirable that the length of the screen be made slightly less than the thickness of the aquifer penetrated to be placed centrally in respect of the aquifer. The length, diameter and total number of independent screen elements should be adjusted to give the desired entrance velocity over a range of stream or surge flow conditions to allow for sedimentation and scouring, and to provide the life of the screen.

When the water-bearing sand contains a thin bed of fine or no gravel, it is very advantageous to insert a coat of fine gravel between the screen and the sand strata, thus permitting the use of the gravel bed in the screen and avoiding increasing ground friction. The gravel will so provided may vary in diameter from 0.5 to 1.5 mm and depth of the bearing. It may vary from 10 mm to 25 mm in thickness and may be 10 to 20% of the gravel to be provided would be decided by the particle size distribution in the layer penetrated and the slot size in the well screen provided to be filled. Such screen sizes may now be custom tailored to fit any grading of desired gravel that is available. It is better to have multiple (concentric) placed gravel beds as explained above.

Velocity of flow and water losses may be adversely affected if the gravel pack ratio (ratio of the diameter of gravel divided by the average size of formation material) exceeds 5. Below this limit, the loss is not too large. For larger development of the ratio is excessive, the sand particles may sand properties after the casing in future. The gravel size should be at least the size of the coarsest material in the finest section of the aquifer material's general size distribution provided.

The gravel pack should be screened so that 90% of the gravel is about the same size or smaller than the specific material in the gravel pack (or natural pack) well. It should be larger than the size that is present in 90 percent of the finer fractions of gravel.

(a) Horizontal Strainers

The small diameter well pumps of 75 to 100 mm dia. the strainers are generally of horizontal structure, called as steel screens. It consists of a galvanized iron pipe with about 100 mm length. It is covered with a screen of length of pipe of 1.8 m, having an area of opening of about 17% and having a screen mesh of 25 or 30 mesh which again is covered by a second steel bars mesh of size of 36 gauge, having a net 2 to 3 holes of 3 mm dia per cm square area of opening of area of 16.5%. The effective area of opening resulting is about 5 to 6%. The screen is 150 mm outer dia. Corrosion coating is not provided for this pump screen.

(b) Vertical strainers

The horizontal type screens are generally with diameters in the range 30 mm to 300 mm available in 100 to 150 mm dia. It is made of 10 to 12. These have V shape slots of varying cross-sections per perspective of the screen. The slot size in the diameter 50 to 75 mm is about 50 mm to 100 mm.

Screening should be done at regular intervals in such cases.

Sometimes the brass nonmetal strainer is strengthened with an inner G.I. slotted pipe for greater rigidity and longer service.

(c) *Slotted Pipe Strainers*

Galvanised iron or brass pipes having bigger slots about 3 mm in width and 100 mm in length are provided in conjunction with pea gravel around, 100 mm to 250 mm thick. The slots are V shaped with the smaller opening on the outside. The gravel should make it possible to use strainers with large sized slots and abstract a larger yield than is otherwise possible. The slots are preferably to be kept horizontal with unslotted strips left between successive rows or columns of slots.

The advantage with this type of strainer over the others is that there is less damage by galvanic action or clogging due to incrustation.

(d) *New Type of Strainers*

Strainers of different makes are marketed claiming specific advantage for each. One such is a slotted mild steel pipe core, coated with special and corrosive plastic paint and provided with an enveloping graded sand slotted bonded with heat resistant, water repellent plastic.

Strainers made of special alloys such as stainless steel (types 304 and 316), nickel metal, and brass etc., are also used where indicated and if available.

High density polythene or P.V.C. and metal reinforced strainers are gaining popularity on view of their non-choking, non-corroding and non-increasing properties which give long and uninterrupted service.

5.2.6.2 Infiltration Galleries

(a) *Wells Vs. Galleries*

Infiltration galleries offer an improvement over a system of wells, in that a gallery laid at an optimum depth in a shallow aquifer serves to abstract the subsoil flow along its entire length, with a comparatively lower head of depression. Moreover, in the case of a multiple system of infiltration wells, the frictional loss contributed by the several connecting pipes diminish the draw down in the farther wells to that extent and the utility of a well becomes less and less in the total grid. All the same, wells have to be located with a minimum distance in between each pair, so as to avoid mutual interference under normal pumping. It also becomes uneconomical to lay long lengths of connecting pipes in river beds or depths where constructional difficulties add to the cost of their laying and jointing against high subsoil water level conditions. These pipes are themselves vulnerable to damages from rubble scum during high floods if adequate safeguards are not provided. The pipes are liable to break at their junction with the well stenting, should there be a subsidence of the well structure under floods.

(b) *General Layout*

Essentially, a gallery is a porous barrier inserted within the permeable layer, either usually along or across the groundwater flow. A collecting well at the shore end of the gallery serves as the sump from where the infiltrated supply is pumped out. The collecting well is the point at which the maximum head of depression is imposed under pumping operation. The

depression head being diffused throughout the length of the gallery to collect flow from the furthest reach.

The exact alignment of a gallery must be decided with reference to the actual nature of the sub-soil layers, after necessary probe investigations to map out the entire sub-soil. A gallery could be laid axially along a river or across a river. In both the cases, the head of depression induced is the factor influencing the abstraction of the sub-surface flow into the gallery line, and the zone of influence covered along the entire length of the gallery line will have the same variations irrespective of the direction of the gallery. A cross gallery would have the advantage of the same potential head in the sub-soil water level along its entire length, whereas the axial gallery will have a varying potential at the sub-soil water level, from a maximum at the furthest end upstream to a minimum at its other end down stream. But a cross gallery has a definite advantage when it is used as an instrument for abstracting the maximum available sub-surface flow, in the river bed if this was possible, in which case the cross gallery becomes virtually a sub-surface barrage.

(c) Structure of a Gallery

The normal cross-section of a gallery comprises closely packed or porous pipe or rows of pipes, enveloped by filter media of graded sizes, making up a total depth of about 2½ m and a width of 2 to 3 m or above, depending on the number of pipes used for collection of the infiltrated water. The enclosing media round the collecting pipe functions more as a graded plug whereby water from the sub-surface sandy layers of the river bed is abstracted without drawing in fine particles at the same time. This feature need not, therefore, be placed on the filter media of the gallery as such, for effecting the full scale purification of the inflow.

The gallery has necessarily to be located sufficiently below the lowest groundwater level in the aquifer, under optimum conditions of pumping during adverse seasons. The gallery should, of course, be located lower than the seeping zone of the river bed under high floods, so that the top most sand layer of the gallery media remains undisturbed at all time. The natural permeable layers of the aquifer over the gallery media serve as the natural filtering layers for the sub-soil flow and also separate the gallery from seeping effects.

The disposition of the filter media around the porous collecting pipe and the particle size distribution is of great importance. If the invert of the gallery is taken up to an impervious layer, there is no need to provide any filter media underneath the collecting pipe except perhaps a nominal layer of coarse aggregate to separate the pipe from the soil immediately below and to ensure a uniform bedding for the pipe. The galleries consist of either a single or double row of stoneware or concrete pipes (also protected with cement back fills). Perforated PVC pipes can also be used. The pipes are laid usually horizontally to the gradient of ground in the direction of flow. The coarse aggregate envelope in the pipe material is in three layers, followed by coarse and medium sand layers, as detailed below.

Filtering medium near pipe line	38 to 60 mm stones
2nd layer	38 to 19 mm broken stone
3rd layer	12 to 6 mm broken stone

4th layer	coarse sand (sieve size approx. 60) 100 mm thick, retained on sieve 1.18 mm (No. 15)
5th layer	fine sand (sieve size approx. 60) 100 mm thick, retained on sieve 0.425 mm (No. 40)

In the table position, the pipe was normally to be surrounded by coarse layers of the coarse media, while the finer layers of the coarse sand and sand formed rather loose and layers on the top alone. This is not quite correct as the coarse media (gully media) is to reach the sides and a repetition of all the layers of the coarse pipe material on both sides of the collecting pipes is also necessary.

The particle size distribution in between of the surface of the filter pipe may be based on a multiple of four. Precast perforated concrete blocks are also used to collect the pipes with the enveloping media on the three sides.

Filter media around the gallery pipes may also lead to filter media placed above or infiltration well is porous. In the latter case, the plug has to be designed so that the actual particle sizes of the subsoil layers on which the well is founded, in order to allow the entry of fine particles into the well under normal operating conditions and to induce a greater head of depression than is otherwise possible without the plug. It is common to say that the yield into the well will increase to a certain quantity under normal pumping operations. Likewise, the enveloping media on the gallery pipes may be substituted to suit the actual layers of the subsoil which will immediately surround the gallery media. Preliminary boring operations and sieve analysis of samples could help to decide on the different variations in such soils, so that a gallery system was on an extensive scale, the gallery media could be designed suitable for the different practices, in order to obtain maximum yield under optimum conditions of operation.

(d) *Constructional Features*

The constructional features during the construction of each gallery (size of impurities, trenches are dug with adequate sloping on three sides) should down to the required level decided upon for the invert of the gallery, which would normally be placed several metres below the subsoil water level, a greater depth may be required to control the yield from the gallery. The gallery can be laid under cover of skimming the trench completely for the purpose is not feasible or economical. If a shallow trench is provided it may be 1.5 to 2 or 75 m for inspection. These are sunk into the soil below the gallery level and the floor of these wells are taken a tick below the invert level of the gallery pipe. The pipes are covered with R.C.C. slab with water tight mastic on the joints.

A practical limit on the yield potential of a gallery is set by the diameter effect of the depression head of the gallery is usually limited to one single point of pumping. For maximum effects to be realised, the pumping operations are best located centrally with reference to the gallery grid, with marked points shown on a plan of all gallery runs as also at the blind end of each gallery arm. The end of each arm should be equipped with a second pumping point if the grid system is to be used. In the special case of a grid system, a grid for non-extensive and widely spaced pipes may be used, but having to be on the outer limit of gallery under the design of a grid system, it will always be of a quantity

abstracted and the total sub-surface flow in the river past the gallery section. So long as the flow abstracted is less than the total flow past the area, additional gallery systems could be inserted in the same area, with one or more pumping points, in order to draw out the maximum quantity. When the maximum quantity possible has been abstracted through a gallery system at a single location, the potentiality of the source at that point will have been fully exploited. In such a case, any augmentation of the supply from the same river as the source will have to be attempted at a new point either upstream or downstream, with a distance left in between, such as would bring into the stream course adequate supplies from the catchment, which could be tapped, without affecting the yield from the gallery already in service.

When infiltration gallery systems are inserted in aquifers with confined groundwater, the rate of abstraction from the gallery must bear a practical relation to the replenishable capacity of the sub-surface area which comes within the influence of the gallery under pumping.

The provision of a gallery within a tank or a lake-bed suffers certain inherent disadvantages in that the static water on top, in a state of continuous sedimentation, builds up a silt blanket on the top of the gallery, which may retard the free passage of water through the lake-bed and layers and into the gallery media. Periodical removal of the surface silt layer or cleaned would overcome such a handicap.

(c) Check-dams

Under certain conditions, the provision of a tub-sid barrage or check-dam across a river just downstream of a gallery system, helps in maintaining the river-bed area over the gallery and providing permanent saturation of the sub-soil layers contributing to the yield through the gallery. The barrage is usually keyed into the river bed on an impervious layer and into the banks for a foundation successfully. Incidentally, it would also save the gallery system against damage by scour during floods.

5.2.6.3 Radial Collector Wells

A collector well consists of a cylindrical well of reinforced concrete say 4 to 5 m in diameter, going into the aquifer to as great a depth of the sub-strata as possible, i.e. upto an impermeable stratum. Normally the saturated aquifer should not be less than 7 m above the top of the radial pipes. From the bottom of the well, sloped steel pipes, normally of 200 mm to 300 mm diameter on the inside and going upto 30-35 metres in length are driven horizontally. The length is determined by the composition and yield from the aquifer. The drain pipes are made up of 60m length of pipes each 2.4 metres in length which are welded to each other vertically one after the other.

These steel pipes are driven horizontally into the aquifer by means of suitable twin jacks placed in the well and crossing the staveing of the well, through the special openings or port holes. At the same time, desanding operation is carried out through the head of the drain pipes. This operation is very important and results in the removal of all the fine particles in the aquifer thus increasing the draw-off.

A sketch of a collector well is given in Appendix 5.7.

(a) Desanding Operation while Driving Borehole

An important operation in the driving of the drains is the operation of desanding of drain tubes of 200 mm to 300 mm dia which will return back the sand bed being driven over certain distance. An inner tube is then introduced into the drain which is used for sending a blast of compressed air for loosening and separating the fine particles at the alluvium at the head of the drain. When the compressed air is turned off, the pressure of the water, due to the head of the water table, enables the fine particles into the interior of the well to be carried until clear water without any fine particles is obtained. This indicates that the pressure of the water is insufficient to move the fine particles from the drains any further.

This process ensures formation of bag sand around the steel drain, composed of the coarse particles in the alluvium; this shell of sand forms a drain of large section of a reverse filter. During the course of desanding, the quantities of sand removed are measured carefully which enables one to estimate the frequency of desanding that is required to clear the drain.

(b) Advantages

- (i) The surface of draw-off of collector well is many times greater than that in the case of an ordinary or traditional well. It also ensures a very low velocity of flow with a high total yield.
- (ii) The danger of clogging is eliminated by the process of desanding, which removes all fine particles around the drains and creates a high shear through which a large yield with low velocity is obtained.
- (iii) The collector well uses 90% of the head available from the water table whereas ordinary well under water table conditions can use only 60%.
- (iv) The collector well is able to draw highly varying flow from 500-2500 m³/hr depending upon the season and depth of sub-surface.
- (v) The draw-off from a collector well is regulated by valves controlling each radial pipe. The valves have shafts extending to the top of the well, which make control and regulation of the supply easy. This device also helps the well to be easily cleaned by closing the valves, and clearing is very easy. The facility of cleaning by separating the desanding process, that all the problems of clogging and resulting falling off in the yield, ensures a much longer life for the installation, while cleaning of infiltration gallery is difficult and expensive.
- (vi) In coarse and medium size fields, installation of radial collector well system is cheaper both in capital and operating costs than any conventional method.

(c) Limitations

- (a) A saturated aquifer of minimum depth of 7' water necessary.
- (b) The aquifer should be cross section 200m.
- (c) The aquifer should be homogeneous and isotropic.

5.2.6.4 Filter Basins

When there is a perennial flow in a river and the sub soil underneath is hard rock, below an average depth of 1.5 to 3 m filter basins are constructed to take advantage of the potential flow, assuming a filter rate similar to that of slow sand filter. Sand in this area is removed and under-drains, usually loose jointed concrete pipes or pre-cast PVC pipes, are laid and covered with sand. The water from the rock surface will be led to a collecting well by Galva or A.C.C. pipes. The collecting well which is also used as pump house is located on the bank of the river.

5.2.6.5 Syphon Wells

When the depth of saturated aquifer is 2 – 30 m and the conventional wells and galleries cannot be laid to take full advantage of this depth, a siphon alternate device has to be tried. A siphon well will be most suitable in this case. A siphon well consists of a masonry well, 4-5 m diameter, sunk to a shallow depth and sealed at the bottom. Tube wells are to be sunk all round the well to the full depth of the aquifer, and siphoned into the central well from where the water is pumped.

5.2.6.6 Determination Of The Specific Capacity Of A Well

The specific capacity of a well is the discharge per metre of drawdown at the well. In the case of artesian wells it is usually assumed that the specific capacity is constant within the working limits of the drawdown. The specific capacity decreases with duration of pumping, increase in drawdown and the life of well. High specific capacity can be ensured by proper selection of screens and gravel and thorough development.

(a) Measurement of Drawdown

The actual drawdown in wells under pumping is measured in several ways. In the case of shallow tubewells, dug or sunk wells, the more common method is to drop a weighted string upto the water level, to raise and drop, pumping and computing the difference. In the case of deep tubewells, a satisfactory procedure is to adopt the air pressure method. An air tube is inserted into the well to reach below the anticipated maximum depressed water level. Air is pumped into the tube and based on the air pressure initially required to depress the water level in the air tube down to its bottom and the reduction in such pressure with increasing drawdown in the well under pumping, the drawdown during the pumping operations is measured by a calibrated gauge at the top.

The specific capacity may be determined either by the discharge method or by the recuperation method.

(b) Discharge Method

Using a pump discharging at a constant rate, the water level is lowered in a well and at intervals of time Δt , the water levels are read.

The discharge equation for this method is given by,

$$Q = V \frac{dH}{dt} = A \Delta h \frac{dH}{dt} \quad (5.13)$$

where,

- Q = steady state rate of pumping
- A = area of section of well
- K = specific capacity of well
- h = average drawdown during one interval Δt
- M = number of time used
- Δx = depth of drawdown interval $\Delta x = \Delta h$

In the above equation, Q , A and M are known. M is observed, h is measured and K can be calculated for each set of observation.

The selection of the pump capacity should be such that a desirable drawdown is obtained finally. The time interval Δt should be such that the drawdowns during the time interval are neither too great nor too small.

When the water level is remaining constant during a particular drawdown, the equation becomes:

$$QM = KA^2 \quad (5.14)$$

or

$Q = KAh$, i.e., the rate of pumping, equals the discharge at particular draw down and specific capacity Q/A .

A practical way to confidently predict yield and drawdown for larger dia gravel packed permanent production wells is to construct one or two smaller test wells (1.5 to 3m dia), pumping one well with a controlled pump (about 10% of rated capacity) and measuring the drawdown in the other. The resulting discharge divided by the drawdown in the well streamway is the expected specific capacity of 1.2m gravel annular wall to be drilled at the site.

5.2.6.7 Maximum Safe Yield And Critical Yield

If the well is not developed to the full capacity of the aquifer, the maximum yield is limited by the maximum permissible drawdown of the well and by the size and the method of construction of the well. In the case of drilled circular wells, the maximum permissible drawdown may be limited by the suction lift of the pump or by the depth of the wells. In the case of unconsolidated wells as well as in a well, the drawdown can be further restricted with a view to preventing sand blow which can disturb the aquifer matrix. Sand blows which help to remove the fines and help in increasing of the yield are, however, desirable. The maximum quantity that can be drawn may be fixed with reference to the diameter of the well and the hydraulic subsidence value of the largest size of the outlets proposed to be removed during the running of the well. This may be termed the critical yield.

5.2.6.8 Maximum Safe Head Of Depression Or Critical Head Of Depression

From the maximum safe yield (as the calculated specific capacity) for a given maximum head of depression can be calculated. The maximum safe head of depression, usually termed the critical head of depression is the rate at which, when extended, the maximum number of flows which will exhaust the aquifer and cause damage to the well.

5.2.6.9 Other Influencing Factors

(a) Head Losses

The reasons to flow are usually considered as the friction of the water into the well tube or well, friction in the tube itself and the entrance loss.

Inadequate area of openings near or at the well, the effects of clogging and corrosion may cause the loss of head of entrance to be a large proportion of the total head. The velocity head is usually too small to be worth considering. The friction head in well tubes 50 metres in depth is usually small, but in deeper wells of 100 metres or more, when a very large casing and needs to be carefully considered. If a well is cased for large portion of its length, the friction in the casing tube may be very important. Where not cased, the friction would probably be greater, the amount depending on the roughness of the well surface, it may be assumed as 75 percent greater than that for a steel pipe.

Where friction losses are of considerable amount, the yield will not be proportional to draw down but to drawdown minus friction. In such cases, for deep wells of small diameter and with high pressures the yield is largely dependent on the pipe friction but with large diameters, the yield depends rather upon the ground friction and is affected little by the casing. Thus, while predicting performance of wells, it is essential to know the proportion of each given, well losses must be computed and added.

If the well does not penetrate to an aquifer, or even to an artesian layer, then the yield will be increased as distance near the well for higher specific yields of water or, for the same head, the flow will be decreased. This added resistance due to decreased cross section occurs only in the immediate vicinity of the well and if the total head or total depression is great and if the well extends half or two-thirds the depth or porous stratum, the added resistance will be but a small proportion. When the water-bearing formation is made up of layers of different degrees of porosity and the water table above from the stratum in question is great, the yield will be largely influenced by the depth of the well.

(b) Rate of Draw and Replenishment

In the case of the new groundwater supplies, conditions of equilibrium between flow of groundwater and draw from wells are established and the yield of a well or group system will continue for many years or even work indefinitely, but the yield of a well or group system will continue for many years or even work indefinitely. In the case of dry and arid supplies of large capacity, however, this is generally not so. The extent of the immense reservoir of stored water emanating from such cases is such that equilibrium of draw or pressure is established very slowly and the pressure head in ground water level is likely to continue to decrease for many years. It would be necessary in the case of such an area of the well system, constantly to increase the depth of pumping.

(c) Yield from Fissures

When groundwater flow takes place through fissures and not through the interstices of a porous material, the effect is greatly to increase the capacity of the material and at the same time to modify the law of flow. The resistance to flow through large fissures will vary approximately as the square of velocity instead of the first power. As a result, the yield of a well supplied through fissured sources will not increase at the same rate as the lowering of the water in the well, but much more slowly.

(d) Draft and Total Flow

When developing a collecting system, the problem to be decided is the extent to which the groundwater flow can be tapped or utilised. In the case of shallow seated supplies, almost the entire flow over a given width can be captured by suitable design and the ultimate capacity may be a question of total porosity in the tributary area. With a system of wells, the total flow can be utilised only when the water is lowered such that there is no head to cause flow away from the wells on the lower side.

(e) Mutual Interference

If two or more wells penetrating to the same strata are placed near together and are simultaneously operated, the total yield will be relatively much less than the sum of their individual yields when pumped independently to the same level. This mutual interference in wells depends upon the size and spacing of the wells, the radius of the circle of influence of the wells when operated singly and upon the drawdown. The amount of the interference is expressed as the percentage of reduction in yield per well below that of a single well maintained by others.

(f) Arrangement of Wells

The most favourable arrangement for a system of small wells is in a line at right angles to the direction of flow of the groundwater, as in this way the largest possible area will be drawn upon. By placing the wells across the line of flow or along a groundwater contour, the advantage of equal heads in the several wells is also secured. Where an area of small width needs to be drawn upon, the arrangement is not so material, as the water will flow towards the wells from all directions. But with a long line of wells and a large draw-off, it is of much importance.

(g) Spacing of Wells

The amount of water which can be obtained from a system of wells depends upon the extent to which the water level can be lowered along the line of wells. The maximum amount of water obtainable from a given system of wells would be when they are spaced far enough apart so that their circles of influence will not overlap. But on account of cost of pumping and loss of head by friction, this would not be the most economical spacing. If wells are deep and therefore, expensive, they should be spaced far apart, comparatively to a lesser extent than the shallow wells which could be spaced closer. The extent of mutual interference can be judged by pumping test or trial wells, or on those first sunk, the wells being operated at different rates and at various combinations. With the information so

obtained together with a knowledge of comparative costs of wells, the best spacing of subsequent wells could be determined.

The economical spacing for deep wells will be much greater than for shallow wells and likewise the economical draw-down and yield per well will be much greater. Questions of the size and spacing also depend upon the economy of different types of pumps and a correct solution requires a careful study of all relevant factors governing local conditions.

(h) Coastal Aquifer and Salinity Ingress

In coastal areas the principal aquifers are the unconsolidated quaternary sedimentary formations deposited under various sedimentary environments. Occasionally, the underlying tertiary formations also contain potential aquifers. Usually, the aquifers in coastal areas occur under confined conditions under high hydraulic head. Often the potential fresh water aquifers are overlying the saline water aquifer or more commonly wedged between the overlying and underlying saline water bodies. Depletion of such potential fresh water aquifers brings in problems of unseasonal lowering of piezometric surface coupled with decrease in yields controlled by the reservoir capacity of the aquifers.

Construction of suitable groundwater structures in coastal aquifers is also beset with hazards like vertical downward percolation, salt water seeping of saline water and corrosion of casing of tubewells while tapping the relict stored fresh water aquifers wedged between the saline water aquifers. The peculiar problem of sand washing in tubewells tapping marginal aquifers is also observed very frequently.

The variability of geologic conditions at the site of groundwater occurrence in the coastal tracts demands special attention for hydrogeological investigations both at exploratory and development stages. Continuous research and improvements in well screens and well design to cater to the special needs of the groundwater development in the coastal tract is essential. Monitoring of groundwater regime is also vital to excessive groundwater development would help in suggesting suitable methods to prevent salt intrusion and land subsidence hazards.

State Groundwater Departments and Central Groundwater Board have a good network of observation stations to monitor the water levels and water quality. Some reports on specific studies are also available which may be consulted.

5.2.6.10 Well Development

The object of well development is the removal of silt, fine sand and other such materials from a zone immediately around the well screen, thereby creating large passages in the formation through which water can flow more freely towards the wells and the developmental process continued until the stabilisation of sand and gravel pack is fully assured. Well development incidentally corrects any clogging or constricting of the water bearing formation which has occurred during drilling and also grades the material by the water bearing formation immediately around the screen in such a way that the well yields sand free water at the maximum capacity. Well development involves the operations of flushing, testing and equipping the wells before they are put into service.

(a) Flushing

Flushing can be done either by (i) surging or using a slush and agitator, or by (ii) pumping and backwashing with air. ¹¹

(ii) Surging

In the development operation, as in the case of a mud cake, reversal of flow through the screen opening of the formation immediately around the well. This is necessary to avoid the bridging of openings by groups of particles as a result when flow is continuously in one direction. Reversals of flow are caused by forcing the water out of the well through the screen and into the water bearing formation and then allowing the force to allow flow to take place from the formation through the screen and back into the well. This process is known as surging. The inflow to the casing of the well portion of the surge cycle breaks down any bridging of openings that may be caused. The inflow portion moves the fine material towards and through the screen from the well from which it is later removed. Surging is done by raising and lowering a slush agitator on the downstroke. Casing water outwards through the screen, the pump being a bell or ball plunger or valve type.

(a) Solid type plunger

A simple solid type surge plunger consists of two rubber or rubber belt discs sandwiched between wooden discs, all assembled over a pipe couple with steel plates serving as washers under the end couplings. The rubber or the material between forming a reasonably close fit in the well casing.

Before surging, the well should be washed and a jet of water and bailed or pumped to remove some of the mud cake on the wall of the casing hole and any sand that may have settled in the screen. This means that a sufficient flow of water will take place from the aquifer into the well to permit the plunger to move slowly and freely. The surge plunger is then lowered into a well to a depth of 2 or 3 m below the water level above the top of the screen. A spudding motion is then applied by gradually raising and lowering the plunger through a distance of 0.5 to 1 m. It is advisable to drill through casing if should be operated on the long hole spudding motion. It is important that enough weight be attached to the surge plunger to make it descend readily to its lower position. A drill stem or heavy string of pipes is usually found adequate for this purpose.

Surging should be started slowly, gradually increasing the speed but keeping within the limit at which the plunger will rise and fall smoothly. Surging is done for several minutes, the speed, stroke and time for descent being increased. Then the plunger is withheld and the balance mud pump lowered to its normal position. The sand accumulation in the screen bailed out and recirculated. The surging operation is performed in a similar manner but is not so rapid into the well. The same general procedure is used for each successive period of surging as the necessary volume of mud in the well is removed. The mud pump type of ladder is generally preferred for this work, avoiding the danger of work.

(b) Valve type plunger

The valve type surge plunger differs from the solid type surge plunger in that the former carries a number of small part pieces that act as a plunger which are covered by a cut valve leather.

Valve type surge plungers are operated in a similar manner to solid plungers. The inflow water from the aquifer into the well on rising pressure in the flowing column of the water in the well to press upward through the valve cuttings and so on to produce a smaller reverse flow in the aquifer. This entrance of a pressure surge of water to the well than the one which during the surging operation is the principal and most important feature of this type of plunger. The valve type surge plunger, because of their nature, is particularly suited to use in developing wells in formations with low permeability. In such a case a net flow of water into the well rather than out of it. A net general flow can result in the water moving upward to wash around the casing or the casing itself. The low permeability of the aquifer will not permit flow readily inside. Washing around the outside of the casing could cause caving of the upper formation and thus create very difficult problems. An incidental benefit gained from the use of this type of plunger is the accumulation of water above the plunger with the eventual discharge of some portion of the mud at the top of the well. The valves in effect produce a sort of pumping action and cause the cleaning of the well and thus reduce the number of times it is necessary to clean the plunger to seal and fix it in the well.

Surge plungers can also be operated within a screen. This may be desirable in developing wells with long screens. By operating a plunger within the screen, the surging action can be concentrated at chosen levels in the well. In fully developed wells, over the entire length of the screen, the surge plungers should be made to pass freely through the screen and as things feel not to be a free fit in terms, as in the case when opening within the well casing. Special care should be exercised when surging within the screen to prevent the plunger from becoming stuck by getting it caught down. For this reason the use of plungers within the screen should only be attempted by experienced drillers. Care must also be exercised when using surge plungers to develop wells in aquifers containing many clay streaks or clay beds. The action of the plunger can, under such conditions, cause the clay to plasticize and the screen surface with a cement like substance rather than merely in part. In addition, a surge of the water or wholly plugged screen can produce high differential pressures, with possibility of collapse of the screen.

(ii) Pumping and Backwashing

(a) High velocity jetting

High velocity pumping or back washing of an aquifer with a high velocity jets of water directed horizontally through the screen opening is generally the most effective method of well development. The principal items of equipment required are a mud pump, or a high pressure pump, the necessary hose, piping, valves, and water tank or other source of soft water supply.

The procedure is to lower the tool on the kinetic pipe to a point near the bottom of the screen. The upper end of the pipe is connected through a swivel and hose to the discharge end of a high pressure pump such as the mud pump used for hydraulic rotary drilling. The

output should be capable of generating a pressure of about 70 kg/cm² and preferably at about 100 kg/cm² while delivering 0.5 to 1.0 m³ of water per minute per inch nozzle. While pumping water through the nozzle and against the formation, an jetting effect is slowly developed, the nozzle and the jetting device is driven into the bottom of the well screen. The jetting is continued until the bottom of the well is reached and the process repeated until the entire length of the screen has been fully cleaned and fully developed. It has been found that about 10 to 15% of the water should be returned from the well than pumped into, creating a certain depression and causing the cleanable filter to be cleaned by jetting are pumped from the well. Often an lift or combined pump is used, the pump portion of the water being recirculated through a jetting pipe to be used as supply, the high pressure pump for jetting being a change as jetting pipe is jetted, like the water for measuring the progress of the work. If both are terminated, or a few minutes rest water level is return to static, the pumping there can be recommenced with possible water level measurement, and determine the specific capacity with time of jetting, and in production, possibly the theoretical expected specific capacity, the actual specific capacity, and the effect instantaneous efficiency measurement, and whether the sand is returned to the bearing area with increased development relative can be determined.

The high velocity jetting method is a more effective and less expensive method with a more shut top well screen. The greater percentage of energy used in this type of screen process is more effective use of the energy of the water, and will be more efficient in material rather than being dissipated to maintain pressure upon the solid mass of the drilled pipe jetting. The most efficient jetting method is achieved because the energy of the jets is concentrated over small areas, and the nozzle and every part of the screen can be effectively treated. Thus maintenance and development is achieved throughout the length of the screen. This method is also suitable to apply and use every to cause trouble as a result of their application.

(b) Pumping

Another well cleaning method or development suitable for use in small wells is one which uses a centrifugal pump with a screen on the discharge, near the top of the well casing and casing pump screen valve can be discharge end. This process is simply emptying the possible opening and closing of the discharge valve when the pump is in operation. This creates a surging effect on the well. The pump is a centrifugal pump, the discharge is clean and sand free. The method is only applicable to wells with water levels are such as to permit pumping by surface lift, some damage to the pump can occur through the wearing of its parts by the sand pumped through it, but a lot of large quantities. The use of the pump to be permanently installed, it is not so expensive, and is not needed for use in development of well by this method.

Development of gravel around the screen is necessary to maintain the annular space of relatively impervious material selected as a seal, and to seal the hole and to be held in place by the nature of the bearing formation and the surrounding gravel pack. The use of gravel development around the screen is difficult and costly, and the success depends on the grading of the gravel, the method of development, and the condition of the casing and the gravel pack. The jetting method, however, is a more efficient and less expensive method, and is usually

more effective than the other methods in gravel-pipe gravel-packed wells. The thinner the gravel pack, the more likely is the removal of all the undesirable materials, including any fine sand and silt.

The use of dispersing agents such as polyphosphates at about 6 kg per kiloliter of washwater effectively assist in loosening and removing silt and clay from the aquifer as well as the fact of the drilled hole flushing is stopped when the presence of fine sand in the discharging water is insignificant. During development, the discharge should correspond to the depression of 5 per cent higher than the normal depression at which the tubewell is later pumped in continuous duty. Where a depression of 50 per cent higher than the normal depression can not be arranged, the tubewell may be over developed so as to yield a discharge 20 per cent in excess of the rated discharge.

(c) Testing

A tubewell out of alignment and containing kinks or bends should be rejected because such deviations cause severe wear on the pump shaft, bearings and discharge casing and, in a severe case, might make it impossible to get a pump in or out. If a deep well turbine pump is to be installed in a tubewell, the housing should be out of line within permissible limits of deviation from a vertical to a point just below the maximum depth at which it is proposed to set the pump. If an in-lift or suction pump is used for pumping, the alignment is not so important and the same claim has been advanced for the inaccessible type of pump. It is suggested, however, that even if it is intended to install a type of pumping equipment that will function satisfactorily in an out of line well, the requirements of these specifications should be considered.

Tubewells are to be tested for plumbness and alignment normally after completion of drilling but immediately after the housing pipes are installed but prior to commencing the gravel pump in the case of gravel-shrouded tubewells.

In the case of gravel-shrouded tubewells, if the pipe assembly is found inclined in a certain position before filling the gravel, the assembly should be pulled in a desired direction by applying force through jacks or by other means with a view to returning the alignment and bringing the pipe assembly within the permissible limits of verticality. The gravel operation should be undertaken immediately after the verticality has been tested and verified. If necessary, remedial measures should be adopted in between by means of jacks or any other means to bring the pipe assembly within the permissible limits of verticality.

For wells cased with pipes less than 100 mm diameter, the deviation of the tubewell shall have a deviation not exceeding 10 cm per 30 m of depth of the tubewell and the deviation shall be in one direction and in one plane only. The deviation of the tubewell shall be determined according to the method as recommended in IS 2899 (1964).

After the tubewell is completed, step drawdown tests and pump performance tests are done to determine the well characteristics such as specific capacity and the limits of transmissibility and permeability of the aquifer to select suitable size and type of pumps to be installed in the tubewells as the well spacing.

The water is also collected during aquifer performance test and analysed chemically for the different constituents depending upon the use to which the tubewell water is to be put.

(d) Equipping

(i) Selection of Pumps

Depending upon the discharge and drawdown noted during the tests, a suitable pump, such as a centrifugal pump, vertical turbine pump, submersible pump or reciprocating pump should be used in the tubewells.

A recent innovation is to use airtight pliers or seals between pump columns and well casings to (i) produce less than atmospheric pressure beneath them which enables more draw down (a maximum additional of about 6m) and (ii) prevent oxygen entering the lower portion of the well and thus inhibiting the growth of aerobic iron bacteria.

(ii) Sanitary Sealing

In all drinking water tubewells it is necessary that the annular space between the bore and the housing pipe be cement grouted upto at least 5 m below ground level or upto first impervious layer like clay bed. In gravel packed tubewells, two gravel feeding pipes on either side of the housing pipe should be provided to the full depth of foundation.

5.2.6.11 Failure Of Wells And The Remedial Measures

The clogging of wells by filling with sand or by corrosion or incrustation of the screen may reduce the yield very greatly. Well may be made free from sand by means of a sand pump or by removal of the screens, etc. provided they must be pulled out, cleaned and reworked or replaced. The design of the sand collecting courses for intake should be made so as to allow for a time when the well is under high pressure. The use of a float valve to prevent the entry of sand into the well and of the well being clogged by the sand at the well point is also a possibility. A slow drip probably is a gradual removal of the sand from the mouth of the sand collecting well.

(a) Surging

The principal purpose of surging a well is as described in 5.2.6.10 (i) to dislodge the sand from the pump intake. Surging is done immediately after a well has been surged. It is done by "cutting and maintaining" the level of the groundwater table. Surging is not done to recover water continually in case of a permanent damage.

In surging with a plunger, the draw pipe is removed from the well and a solid plunger fitting the well of the casing is lowered beneath the water in the well. The plunger is pushed up and down to and fro violently and down is so sudden, causing water to rush up and out of the well through the screen. By placing a check valve on the plunger, water to be drawn through the screen will be drawn upwards. If the top of the well casing is somewhat depressed water is discharged down and back water is likely back through the screen. This operation is done several days before "air is gone" or stopping of the pump with production of air.

(b) Use of Dry Ice

Dry ice or solidified carbon dioxide when dropped into a well quickly turns to a gas generating a strong pressure if the gas is confined. The charge is suddenly released to fill into the well and vaporise, generating pressure. The method has its own dangers such as freezing the hand and suffocation of the operator due to fumes of carbon dioxide and rupture or lifting of the casing or collapse of the screen. The method is also not to be advocated because of its practical limitations in operation and utility.

(c) Chemical Treatment

Chemicals such as acids, chlorine and sodium hexametaphosphate may be added to a well for the purpose of dissolving or dislodging clogging material or incrustation on the screen or in the sand surrounding the screen.

(i) Acids

Acid treatment may be resorted to only where the metal of the screen will not be seriously attacked by them. They should be introduced in sufficient high concentrations that the acid concentration will reach at least 25 per cent near the screen by means of a wide mouthed funnel and 75 cent or smaller diameter iron or plastic pipe. When used in long screens, acid should be added in quantities to fill 1/3 of the screen and the circulation kept raised 1 to 2 m after pouring each treatment. The acid solution in the well should be agitated by means of a wire plunger or other suitable means for 1 to 2 hours following, when the well should be bled until the water is relatively clear and the operation repeated if necessary. If acid is added in quantities to fill the screen, it should be mixed on the road by means of water standing in the well and be certain that in the screen, at least a quantity of permanganates be circulated like an persons handling the acid wearing goggles and water proof gloves, pouring the acid down into the well to operate for a short period of adequate ventilation in pump houses or other confined spaces used in acid well and disallowance of personnel to stand in a pool of effluents around the well down to do so. As the heavier toxic gases tend to settle in the lower part of the well, it has been found it should be pumped or water to ensure an immediate removal of all acid before it is used in normal supply.

(ii) Chlorine

Chlorine treatment (10 to 20 mg/l) is advised. This is done by using well made solution of sodium hypochlorite being used in a solution of diluting with proper agitation by the use of high velocity jetting or spraying with a special pump or the well to be treated should be treated, especially in the presence of iron, manganese and silica deposits which often accompany the deposition of iron scale. Iron scale may be removed with the use of the jetting technique greatly improves the effectiveness of the treatment. The treatment should be repeated 3 or 4 times to reach every part of the screen in that may be affected and may also be alternated with acid treatment, such as being performed first.

(iii) Polyphosphates

Polyphosphates effectively disperses silt, clay and the oxides and hydroxides of iron and manganese and be dispersed uniformly in the well by means of jetting. In a dose of 10 to

are safe to handle and therefore, and to minimize application is the chemical treatment of wells.

For effective treatment, 17.5 to 25 kg of polyphosphates are needed for every kilolitre of water in the well. A solution is usually made by suspending a wire basket or gunny bag containing the polyphosphate in a tank of water. About a kg. of calcium hypochlorite should be added for every kilolitre of water in the well in order to facilitate the removal of microorganisms and their slimes and also for disinfection purposes. After pouring this polyphosphate and hypochlorite solution into the well, a surge plunger or the more effective high velocity jetting technique is used to agitate the water in the well. Two or more successive treatments may be used for better results.

No single treatment is suitable for all tubewells. But with proper diagnosing of the well sickness and taking appropriate steps as discussed above the best and cost effective method can be selected. Table 5.3 gives well clogging problem and suggested treatment and Table 5.4 gives application of various well rehabilitation methods on different types of formations.

(iv) Disinfection

The procedure to be adopted for disinfection of new or renovated wells etc. is presented in Appendix 5.6.

TABLE 5.3

WELL CLOGGING PROBLEMS AND SUGGESTED TREATMENTS

Sl.No	Problem	Treatment Suggested
1.	Clogging due to fine sand, clay and silt.	Sodium hexametaphosphate (or gel) depending on the capacity of well should be put in the well (6-24 kg). The same should be diluted by surging, wiring, or shock treatment or normal de-aerating. If well is lined from clogging.
2.	Chemical clogging	Hydrochloric acid or sulphuric acid with inhibitor are added to the well. The dosage can be kept as in the case of sodium hexametaphosphate.

3. Bacterial clogging	Chlorine has been found to be effective in loosening this type of clogging. It not only kills the bacteria but it oxidises the material so that it is dissolved. Calcium hypochlorite should be used in form solution of 200mg/litre which is circulated in well through small polythene pipe. We need 280 gms of hypochlorite at 20% concentration for 1,000 litres in water to give a solution of 200 mg/litre for the killing of bacteria. The well is agitated through surging method then left for 1-3 hrs for removal of slimes. The following surging or air jetting or air lifting.
-----------------------	---

TABLE 5.4
WELL REHABILITATION FOR VARIOUS ROCK FORMATIONS
AND METHODS EMPLOYED

Sl. no.	Method Employed	Unconsolidated (a)	Consolidated Sand Stone (b)	Consolidated Lime Stone (c)
1.	Use of compressed air	Removes the settled deposits of fine silt and clay	Not very applicable	Not very applicable
2.	Use of Polyphosphates	Removes fine sands, silt, shak and soft iron deposits	Not very effective	Not very effective
3.	Use of hydrochloric acid, followed by chlorine	Removes sulphates, carbonates and iron deposits	Not very effective	Sometimes beneficial, but treatment is recommended
4.	Dynamiting	Not used	Effective for all types of well screen deposits	Effective if large charges are involved
5.	Surging	Same as compressed air	Same as (a)	Rarely used

Sl. no.	Method Employed	Unconsolidated (a)	Consolidated Sand Stone (b)	Consolidated Lime Stone (c)
1	Dry ice (compressed) or air (dry state gas)	Same as consolidated air	Rarely used	Not effective
2	Chlorine	Removes iron and other bacteria	Same as under (a)	Same as under (a)
3	Sodium soda	Removes iron, some sulphate and lubricated pumps	Same as under (a)	Same as under (a)

5.2.6.12 Design Criteria

(a) Tubewells

The design of the tubewell is based on the following considerations:

- The effective area of opening of the strainer (the length and diameter of a strainer) is based on the general velocity of entry of water through the strainer openings normally 1 to 6 cm/s.
- Velocity of flow in the pipe is usually restricted to 0.6 to 1.5 mps.
- The allowable drawdown arrived at, the formula is usually restricted to 3 to 5 m in soft rocks.
- In a well over water table condition at least one third to half the bottom of the aquifer should be screened.

(b) Dugwells

In a shallow dug well, the allowable pumping rate depends on the critical draw-down when the velocity of entry of water may carry the sand, thus resulting in the wells in silting.

5.2.7 DEVELOPMENT OF SURFACE SOURCES

5.2.7.1 Intakes

A water works intake is a device or structure placed in a surface water source to permit the withdrawal of water from the source. They are used to draw water from lakes, reservoirs or rivers in which there is either a wide fluctuation in water level or when it is proposed to draw water at the most desirable depth.

(a) Types of Intakes

- Wet intakes;
- Dry intakes;

- (iii) Submerged intakes; and
- (iv) Movable and floating intakes.

(b) Location

The following factors should be considered in locating the intake:

- (i) The location where the best quality of water is available
- (ii) Absence of currents that will threaten the safety of the intake
- (iii) Absence of ice float etc.
- (iv) Interruption of silt and bars should be avoided
- (v) Navigation channels should be avoided as far as possible
- (vi) Fetch of wind and other conditions affecting the waves
- (vii) Ice straits
- (viii) Floods
- (ix) Availability of power and its reliability
- (x) Accessibility
- (xi) Distance from pumping station
- (xii) Possibilities of damage by moving objects and other hazards

Conditions affecting the quality of water will include currents due to wind, temperature and seasonal turnover and other cause that will bring water of uncertain quality at the intake. Channels with high velocity currents carrying floating debris and ice are hazardous to the safety of the structure. Navigation channels add to the danger of pollution from boats and other refuse discharged from ships. Ice floes are hazardous because of its impact on the structure and closing of the ports even 10 metres below the water surface. Waves are hazardous to the superstructure of an intake; also they stir up mud and silt from the bottom in such quantity as to affect the quality of the water.

A study of the currents in a lake or river should be made before the location of an intake is selected in order to ensure water of the best quality and the avoidance of polluted water.

An intake in an impounding reservoir should be placed in the deepest part of the reservoir, which is ordinarily near the dam, to take full advantage of the reservoir capacity available. Provision for gates at different depths to take advantage of better water quality should be made.

(c) Design Considerations

The intake structures design should provide for withdrawal of water from rising free surface to cope with seasonal variations of depth of water. Underdrains should be provided for release of less desirable water held in storage.

In the design of intake, numerous factors of safety must be allowed as waves will be raised by intakes at low water level approximately 1/3 the intake in or be unacceptable channels should be protected by clusters of piles or other devices against blows from moving objects.

Undermining of foundations due to water contents or overturning pressures, due to deposits or silt against one side of an intake structure, are to be avoided.

The entrance of large objects into the intake pipe is prevented by coarse screens or by obstructions offered by small openings in the curb work placed around the intake pipe. Fine screens for the exclusion of small fish and other small objects should be placed at an accessible point. The area of the openings in the intake curb should be sufficient to prevent an intake velocity greater than about 5 metres per minute to avoid carrying siltable matter into the intake pipe. Summings of ports should be designed and controlled to prevent air from entering the suction pipe, by keeping a depth of water over the ports of at least three diameters of the port opening.

The conduit for conveying water from the intake should lead to a storage well in or near the pumping station. For conduits laid under water, standard cast iron pipe may be used. Large conduits may be of steel or concrete. A tunnel, although more expensive, makes the safest conduit.

The capacity of the conduit and the depth of the suction well should be such that the intake ports of the suction pipes of pumps will not draw air. A velocity of 6 to 90 cm/s in the intake conduit with a lower velocity through the ports will give satisfactory performance. The horizontal cross-sectional area of the suction well should be three to five times the vertical cross-sectional area of the intake conduit.

The intake conduit should be laid on a continuously rising or falling grade to avoid accumulation of air or gas pockets of which would otherwise restrict the capacity of the conduit.

5.2.7.2 Impounding Reservoirs

Impounding reservoir is a tank constructed in the valley of a stream to store water during excess stream flow and to supply water when the flow of the stream is insufficient to meet the demand for water. For water supply purposes the reservoir should be full when the rate of stream flow begins to become less than the rate of demand for water.

(a) Choice of Reservoir Site

The suitability of a site must be judged from the following stand points.

(i) Quantity of water available.

(ii) Quality of source.

(iii) Possibility of the construction of a reasonably water tight reservoir.

(iv) Distance of the source from the consumer.

(v) Elevation of the supply.

(vi) Possibility of biological troubles in the case of a shallow reservoir.

(b) Physical Considerations

The estimation of the quantity of water which any impounding works will yield is the first consideration in any scheme. This consists essentially of relating the capacity of the reservoir and therefore the height of the dam to the distribution of run-off from the catchment area.

the variations in stream flow during the period of the assessment should receive consideration on its merits as a new provision should be considered suitable to enable to provide the material yield from the forest for the assessment period.

In the preliminary stage of the study, a preliminary map of the river catchment of the dam, the first stage will be the topography of the valley and a contour map of the catchment. Contour maps themselves are not suitable for a detailed study of investigation. A study of a contour map of the valley will suggest a possible line of dam, its preferred location and the pattern of gravity stresses on which and the contour lines indicate whether such a site could be developed as a dam site or not.

Any scheme designed to develop a particular site as a dam site, especially a preliminary considered site, to be capable of further expansion, however small, the dam site should be suitable for the development of a reservoir. The preliminary study of the basement and design of dam structures, more or less complete, the design and construction of an earth dam which carries a number of gates should be able to be carried out, great credit.

Factors of topography to consider as the design of dam site should be considered are such factors as the height of dam required, the regional variation of the flood and the pattern of submergence, the effect of the dam on the natural preservation and the height of the dam, the diversion around or over the dam reservoir, the position and level of gates of the dam. A careful comparison of all these factors will determine whether a site can be proposed.

(c) Geological Considerations

The decisions as to the practicability of a dam site should be based on a number of factors, one of which is largely geological in character. These will include the geological, viz., the geology of the catchment area of the dam, the nature and the height of the dam.

The geological maps should be used to study the nature of the catchment area, the reservoir area and the dam site. In addition, the latter should be particularly detailed and exhaustive geological exploration. The geological features and sequence of the strata in a catchment may have a profound effect on the location of the dam and the presence of permeable strata may account for high potential leakage, particularly if the dam is built on the dip is away from the valley. Permeable strata dipping into a catchment area from a neighbouring valley may result in increased infiltration and higher infiltration flow, hence the tendency will be for the water stored under the dam to be lost in the catchment area.

(d) Site Exploration

The geological investigation should not stop at the determination of a suitable stratum into which a water tight cut off can be made, but it should extend to the exploration of the foundations to determine their ability to carry the structure. This will involve the sinking of numerous trial holes or borings in addition to those sunk along the centre line of the dam.

Preliminary exploration work should also include an examination of the valley floor above the dam in order to discover whether any ground in the vicinity of the dam has been subject to disturbances in the past and whether further movement may be due to slippage. The safety of the dam and its auxiliary works.

In general, therefore, the preliminary geological investigations should be as complete and exhaustive as possible and the expense of such work (often considerable) will be well justified. Inadequate examination may prove calamitous.

(c) *Computation of Storage*

To determine the required capacity of a storage reservoir, the first step is to prepare a table showing the amount of rain fall for months for as long a period in the past as possible. Rain records of the Meteorological Department for the locality under consideration are best. If they are not available, the best possible data should be obtained from places as which conditions compare and as closely as possible to those at the place under consideration. The required storage is then based on the drought year expected once in 30 years. In exceptional cases, the figures for the drought year expected once in 20 years may be adopted and during the drought years worse than anticipated once in 2 years, rationing of supplies and more rational use of water will have to be enforced.

The second step is to obtain and study run-off records, if there are any, to determine for each month of the year the percentage of rainfall available as run-off. Usually, such data are very limited and it may be necessary to use known data from an area having similar characteristics.

The third step is to establish and tabulate monthly evaporation losses. These are based on reservoir area, which is not known before hand but generally ranges from 5 to 10 per cent of the water shed area. A table is then prepared to show the expected draft or consumption for each month of the year. The amount of stream flow for each month is determined from runoff record, i.e. multiplying the rainfall by the percentage of runoff. The required quantity of water is found by adding the consumption and the estimated losses from evaporation, percolation and leakage.

These data will show the difference between supply and demand for each month. The required storage capacity will be the greatest total deficiency during any succession of months when the stream flow is less than the draft on the reservoir.

A mass diagram can be drawn to determine the required storage. The deficit value occurring once in 30 years may be statistically worked out and used.

Other information furnished by the mass diagram includes, (1) date that the reservoir is full and stops overflowing; (2) dates that the reservoir is full and starts overflowing; (3) the dates that the reservoir is empty; (4) the date that the level of the surface of the water in the reservoir stops falling and starts to rise, the reservoir not being completely empty; and (5) whether the flow of stream is sufficient or insufficient to fill the reservoir.

The volume of water that can be held in an impounding reservoir can be determined approximately by multiplying average surface areas between contours by contour interval or the prismatic formula may be used

$$V = \frac{h}{6} (A_1 + A_2 + A_3) \quad (3.15)$$

Where,

V = Volume between contours, corresponding to surface areas A_1 and A_2

A_1, A_2 & $A_3 = B$ Respective area enclosed within lower, medium and upper contour, where contour interval is b

(f) Biological Considerations

The catchment area should be arranged so that water from the catchment grounds can flow quickly into the reservoir instead of collecting in pools and swamps where it can pick up organic matter. The area to be submerged should be prepared by cutting all the trees and bushes close to the ground and burning on the spot. Rocks that may be exposed to wave action should also be removed. Ditches, low mounds, mounds, heaps and other sources of pollution should also be carefully removed from the area to be flooded. The margins of the reservoir should be drained to avoid irregularities where the water may collect in stagnant pools and favour the growth of weeds. The reservoir should be made on a suitable slope margin of a reservoir which may be tedious and requires a lot of labour. Itation may be exercised in the use of herbicides as it can impart only a small amount of water and can be toxic to fish. Channels should be cut in pockets within the reservoir bottom to provide self drainage when the level is lowered. The reservoir should be made as deep as practicable. They should consist of at least two compartments for reasons explained in 2.2.3.3 (g) (i) (d). The outlet should permit water to be drawn off at different depths so that the operator can change the depth of draft to exclude the algae laden water.

(g) Reservoir Management

(i) Silting

Loss of capacity due to the deposition of silt in a reservoir may impair, if not destroy, the usefulness of the reservoir in a few years. It may be minimised by proper site selection, erosion control, correct operation and design works. The reservoir size may preferably be chosen on a seasonal bearing stream, or the reservoir may be situated to a basin off the main channel so that heavily silt-laden water may be bypassed around the basin. Reservoirs should be located on the smallest drainage area possible. The rate of silting therefore varies per ha per sq kilometre under Indian conditions varies from 1 to 1.2.

After silt has been deposited in a reservoir, there is no practicable method, widely applicable, for removing it other than to excavate, gates in the dam to flush out the silt to some extent at times of high stream flow. Dredging is expensive and the disposal of the dredged material presents a serious problem.

Sed erosion and control are closely related to the silting of reservoirs, since without erosion there would be no silting. Erosion prevention methods recommended for soil conservation include proper crop rotation, strip cropping, contouring, terracing, strip cropping, protected drainage channels, check dams, contour farming, fire control and grazing control.

Hence it is necessary to provide for silting capacity for all approaching reservoirs, based on studies or data pertaining to similar catchments.

(ii) Evaporation

By evaporation, a process by which water passes from the liquid state to the vapour state, water is lost from water surface and moist earth surfaces. Hence it is of importance in determining the storage requirements and estimating losses from impounded reservoirs, and

Other open reservoirs. Evaporation from water surface is influenced by temperature, barometric pressure, mean wind velocity, vapour pressure of saturated vapour and vapour pressure of mixture air and dissolved salt content of water. The evaporation loss in storage tanks in India amount to 2.25 m/year. It is essential that the available surface storage is adequately protected from evaporation as losses upto 50% can be reduced economically.

A number of liquid and solid organic compounds have the property of spreading on the water surface and forming a thin film. It is possible to select organic compounds which give thinner better films and are capable of expansion and contraction by wave action thus forming and regenerating film conditions. Such a monomolecular film offers resistance to the evaporation from surfaces as a result of which the rate of evaporation is reduced.

The alcohol of cetyl alcohol and Cetelevalol (Ceteal Alcohol) or a mixture of these two materials is commonly used for suppressing evaporation from lakes and reservoirs. No. 217-101 which is mixture of Cetyl and Cetyl alcohols and indigenously available may be used for suppressing evaporation from lakes and reservoirs by spraying or water surface is to cover the entire surface with this film. The solution can be used in solution, reservoirs or as an emulsion. Spraying in powder form is the simplest and most widely used process. A dose of 1-1.2 kg. hexalol/day is adequate for wind velocities below 8 kmph.

(iii) Seepage

Seepage occurs whenever the sides and bottom of the reservoir are sufficiently permeable to permit entrance of water and its discharge through the ground beneath the surrounding embankment from making them impervious, to the extent possible economically, erosion control measures such as proper crop rotation, contour ploughing, terracing, strip cropping, contouring or afforestation, cut-off drain or percolation systems and the prevention of gull formation through the construction of check dams, could also be used on a long term basis.

(iv) Algal Problems

Reservoir management is also of value in reducing the algal problems. Small inflows of water from the source should be bypassed wherever possible instead of allowing them to infect the main body of the water. The water weeds in the reservoir should be controlled by suitable methods such as cutting and water-weed cutting. Algalal measures as described in chapter 9 may be adopted to control algae in reservoirs.

CHAPTER 6

TRANSMISSION OF WATER

Water supply systems basically involve transmission of water from the sources to the area of consumption, through free flow channels or conduits or pressure mains. Depending on topography and local conditions, conveyance may be in free flow and/or pressure conduits. Transmission of water accounts for an appreciable part of the capital outlay and hence careful consideration of the economics is called for, before deciding on the type mode of conveyance. While water is being conveyed, it is necessary to ensure that there is no possibility of pollution from surrounding areas.

6.1 FREE FLOW AND PRESSURE CONDUITS

6.1.1 OPEN CHANNELS

Economical sections for open channels are generally trapezoidal while rectangular sections prove economical when rock cutting is involved. Uniform flow occurs in channels where the dimensions of the cross section, the slope and the nature of the surface are the same throughout the length of the channel, not when the slope is just equal to that required to overcome the friction and other losses at the velocity at which the water is flowing.

Open channels have restricted use in water works practice in view of the losses due to percolation and evaporation as also the possibility of pollution and misuse of water. Also they need to be taken along the gradient and therefore the initial cost and maintenance cost may be high. While open channels and canals are not recommended to be adopted for conveyance of heated water, they may be adopted for conveying raw water. Sometimes diversion channels meant for carrying flood waters from other catchments are also used to augment the yield from the reservoirs.

6.1.2 GRAVITY AQUEDUCIS AND TUNNELS

Aqueducts and tunnels are designed such that they flow three quarters full at required capacity of supply in most circumstances. For structural and not by traffic reasons, gravity tunnels are generally horseshoe shaped.

Gravity flow tunnels are built to shorten the route, conserve the head and to reduce the cost of aqueducts, traversing uneven terrain. They are usually lined to conserve head and reduce seepage but they may be left unlined when they are constructed by blasting through stable rock.

Mean velocities, which will not erode channels after gauging, range from 0.33 to 0.50 m/s.

for unlined canals and 1 to 2 metres per second for lined canals.

6.1.3 PRESSURE AQUEDUCTS AND TUNNELS

They are ordinarily circular in section. In the case of pressure tunnels, the weight of overburden is relied upon to resist internal pressure. When there is not enough counter-balance to the internal pressure, steel cylinders or other reinforcing structure, for example, provide necessary tightness and strength.

6.1.4 PIPELINES

Pipelines normally follow the profile of the ground surface quite closely. Gravity pipelines have to be laid below the hydraulic gradient. Pipes are of cast iron, ductile iron, mild steel, prestressed concrete, reinforced concrete, concrete, CRP, asbestos cement, plastic etc.

6.2 HYDRAULICS OF CONDUITS

The design of supply conduits is dependent on resistance to flow, available pressure or head, admissible velocities of flow, silt, sediment transport, quality of water and relative cost.

6.2.1 FORMULAE

There are a number of formulae available for use in calculating the velocity of flow. However, Hazen-Williams formula for pressure conduits and Manning's formula for free flow conduits have been popularly used.

(a) Hazen-Williams Formula

The Hazen-Williams formula is expressed as

$$V = 0.849 C_1 i^{0.54} S^{0.54} \quad (6.1)$$

For circular conduits, the expression becomes

$$V = 4.767 \times 10^{-3} C_1 d^{0.54} S^{0.54} \quad (6.2)$$

and

$$Q = 1.492 \times 10^{-3} C_1 d^{2.63} S^{0.54} \quad (6.3)$$

where,

- Q = discharge in cubic metres per hour
- d = diameter of pipe in mm
- V = velocity in mps
- i = hydraulic radius in m
- S = slope or hydraulic gradient in %
- C₁ = Hazen-Williams coefficient

A chart for the Hazen-Williams Formula is given in Appendix 6a.

(b) Manning's Formula

The Manning's formula is

$$V = \frac{1.49 R^{2/3} S^{1/2}}{n} \quad (6.5)$$

For circular conduits:

$$V = \frac{3.968 \times 1.49 \times d^{2/3} \times S^{1/2}}{n} \quad (6.6)$$

$$Q = 8.561 \times 10^{-7} \times \frac{1}{n} d^{8/3} \times S^{1/2} \quad (6.7)$$

Where,

- Q = discharge in cubic metre per second
- S = slope or hydraulic gradient
- d = diameter of pipe in mm.
- r = hydraulic radius in metres,
- V = velocity in mps. and
- n = Manning's coefficient of roughness

A chart for Manning's formula is given in Appendix 6b.

(c) Darcy-Weisbach's Formula

Darcy and Weisbach suggested the following formulae for pipe flow problems as,

$$S = \frac{H_f}{L} = \frac{f V^2}{2gD} \quad (6.8)$$

Where

- H_f = head loss due to friction (i.e. length L) in metres
- f = Darcy-Weisbach friction factor, and
- g = acceleration due to gravity in m/s²
- V = velocity in mps
- L = length in metres
- D = dia. in metres

(ii) Colebrook-White formula

The Colebrook-White formula for calculation of frictional coefficient is

$$\frac{1}{\sqrt{f}} = 2.3 \log_{10} \left[\frac{k}{3.7D} + \frac{2.51}{Re \sqrt{f}} \right]$$

Where

- (i) f = Darcy's friction coefficient
- (ii) Re = Reynolds Number = Velocity \times Diameter / Viscosity
- (iii) k = Diameter of pipe; k = Roughness projection

In the use of the Colebrook-White formula, reference may be made to any standard text on Fluid Mechanics, or standard Design Values of roughness (k) to adopt, that is available below:

Sl. No.	Pipe Material	Value of 'k' mm	
		New	Design
1	Metallic Pipes - Cast iron and mild steel	0.15	0.2
2	Metallic Pipes - Mild Steel	0.075	0.1
3	Adverse Gradient Cement Conduits, Cast Iron, Bituminum or epoxy lined steel, C.P. and M. pipes	0.355	0.55
4	FRP's, Glass or plastic pipes	0.063	0.103

* *Reference may be made to IS: 2157 for roughness value of steel metallic pipes.*

6.2.2.5. HYDRAULIC EFFICIENCY

The hydraulic efficiency factor, it is assumed that all water utilities agree that their main assets are a matter of performance and value, rather than a mere need to avoid over designing of the pipelines. Despite technological advances in improved methods of manufacturing of all types of pipes and at various pipe materials, the current practice of adopting conservative Darcy frictional coefficients, resulting in under utilization of the pipe capacity.

The utilization of a pipeline depends on Reynolds number (function of velocity and

diameter) and relative roughness (d/k). For Reynolds number greater than 10^5 , the friction factor ' f ' (and hence the C value) is relatively independent of diameter and velocity. However, for normal ranges of Reynolds number of 4000 to 10^5 the friction factor ' f ' (and hence the C value) do depend on Diameter, Velocity and relative roughness.

PVC, Glass Reinforced Plastic (GRP) and other plastic pipes are inherently more smooth compared to Asbestos Cement (AC), Concrete and cement mortar/epoxylined metallic pipes. Depending on quality of workmanship during manufacture and the manufacturing process, the AC, Concrete and cement mortar/epoxylined metallic pipes tend to be as smooth as PVC, GRP and other plastic pipes.

The metallic pipes lined with cement mortar or epoxy and Concrete pipes behave as smooth pipes and have given C values ranging from 140 to 145 decreasing on diameter and velocity. Reference may be made to "Manual of Water Supply Practices", AWWA/M9 published by American Water Works Association (AWWA), second edition 1995.

With a view to reduce corrosion, increase smoothness, and prolong the life of pipe materials, the metallic pipes are being provided with durable smooth internal linings. AC, Concrete and cement mortar/epoxylined metallic pipes, PVC, GRP and other plastic pipes may not show any significant reduction in their carrying capacity with age and therefore the design roughness coefficient values (C values) should not be substantially different from those adopted for new pipes.

However, pipes carrying raw water are susceptible to deposition of silt and development of organic growth resulting in reduction of carrying capacity of such pipes. In case of build-up of substantial growth/buildup of deposits in such pipes, they can be removed by scraping and pigging the pipelines. Reference may be made to Chapter 10 section 10.3 of this manual (Preventive maintenance/cleaning of pipes).

Unlined metallic pipes under several field conditions such as carrying waters having tendency for incrustation and corrosion, low flow velocity and stagnant water and alternate wet and dry conditions (leading to incrustation/oxidation), undergo substantial reduction in their carrying capacity and design roughness coefficient ' C ' values have been recommended in design of unlined metallic pipes. As such, use of unlined metallic pipes should be discouraged.

The cases of the Hazen-Williams coefficient ' C ' for many common materials and the values to be adopted for design purposes are shown in Table 11.

Table 6.1: HAZEN - WILLIAMS COEFFICIENTS

Pipe Material	Recommended C Values	
	New Pipes ^(a)	Design Purpose
<i>Unlined Metallic Pipes</i>		
Cast Iron, Ductile Iron	130	100
Mild Steel	140	100
Galvanized Iron above 50 mm dia ^(c)	120	100
Galvanized Iron 50 mm dia and below used for house service connections ^(c)	120	55
<i>Centrifugally Lined Metallic Pipes</i>		
Cast Iron, Ductile Iron and Mild Steel Pipe lined with cement mortar or epoxy		
Up to 1200 mm dia	140	140
Above 1200 mm dia	145	145
<i>Projection Method Cement Mortar Lined Metallic Pipes</i>		
Cast Iron, Ductile Iron and Mild Steel Pipes	130 ^(c)	110 ^(c)
<i>Non Metallic Pipes</i>		
RCC Spin Concrete, Prestressed Concrete		
Up to 1300 mm dia	140	140
Above 1200 mm dia	145	145
Asbestos Cement	150	140
PVC, CRP and other Plastic pipes	150	145

(a) The C values for new pipes included in the Table 6.1 are for determining the acceptability

of surface finish of new pipelines. The sewer agency may specify that flow test may be conducted for determining the C values of laid pipelines.

- # The quality of galvanized iron should be in accordance with the relevant standards to ensure resistance to corrosion throughout its design life.
- * For pipes of diameter 500 mm and above the range of C values may be from 99 to 125 for pipes less than 500mm.
- ** In the absence of specific data, this value is recommended. However, in the authentic field data is available, higher values upto 170 may be adopted.

The coefficient of roughness for use in Manning's formula for different materials as presented in Table 6.2 may be adopted generally for design purposes unless local experimental results or other considerations warrant the adoption of any other lower value for the coefficient. For general design purposes, however, the value for all sizes may be taken as 0.013 for plastic pipes and 0.014 for other pipes.

Table 6.2 : MANNING'S COEFFICIENT OF ROUGHNESS

Type of lining	Condition	n
Glazed coating of enamel Timber	In perfect order	0.010
	(a) Plane boards carefully laid	0.014
	(b) Plane Boards inferior workmanship or aged	0.016
	(c) Non plane boards carefully laid	0.016
	(d) Non plane boards inferior workmanship or aged	0.018
Masonry	(a) Neat cement plaster	0.013
	(b) Sand and cement plaster	0.015
	(c) Concrete, Steel troweled	0.014
	(d) Concrete, wood troweled	0.015
	(e) Brick in good condition	0.015
	(f) Brick in rough condition	0.017
	(g) Masonry in bad condition	0.020
Stone work	(a) Smooth, dressed ashlar	0.015
	(b) Rubble set in cement	0.017
	(c) Fine, well packed gravel	0.020
Earth	(a) Regular surface in good condition	0.020
	(b) In ordinary condition	0.025
	(c) With stones and weeds	0.030

Type of lining	Condition	n
	(d) In poor condition	0.035
	(e) Partially obstructed with debris or weeds	0.050
Steel	(a) Welded	0.013
	(b) Riveted	0.017
	(c) Slightly tuberculated	0.020
	(d) Cement Mortar lined	0.011
Cast Iron & Ductile Iron	(a) Unlined	0.013
	(b) Cement mortar lined	0.011
Asbestos Cement		0.012
Plastic (smooth)		0.011

Note: Values of n may be taken as 0.015 for unlined metallic pipes and 0.011 for plastic and other smooth types.

The friction factor values in practice for commonly used pipe materials are given in Table 6.3.

TABLE 6.3: RECOMMENDED FRICTION FACTORS
IN DARCY-WEISBACH FORMULA

Sl. No.	Pipe Material	Diameter (mm)		Friction Factor	
		From	To	New	For Design Period of 30 Years
1	R.I.C.	100	2500	0.01 to 0.02	0.01 to 0.02
2	M.C.	100	600	0.01 to 0.02	0.01 to 0.02
3	H.D.P./P.V.C.	25	100	0.01 to 0.02	0.01 to 0.02
4	S.C.S.R.	100	900	0.01 to 0.02	0.01 to 0.02
5	C.I. (For corrosive waters)	100	1000	0.01 to 0.02	0.015 to 0.03
6	C.I. (For non-corrosive waters)	100	1000	0.01 to 0.02	0.01 to 0.02
7	Cement Mortar or Epoxy lined metallic pipes (Cast Iron, Ductile Iron, Steel)	100	2000	0.01 to 0.02	0.01 to 0.02
8	C.I.	15	150	0.014 to 0.03	0.015 to 0.06

(Reference may be made to I.S. 2951 for calculation of Head Loss due to friction according to Darcy-Weisbach formula)

6.2.3 HAZEN-WILLIAMS FORMULA

The commonly used Hazen-Williams formula has following inherent limitations:

- (i) The numerical constant of Hazen-Williams formula (1.318 in FPS units or 0.85 in MKS units) has been calculated for an assumed hydraulic radius of 1 foot and friction slope of $1/1000$. However, the formula is used for all ranges of diameter and friction slopes. This practice may result in an error of up to $\pm 30\%$ in the evaluation of velocity and $\pm 55\%$ in estimation of frictional resistance head loss.
- (ii) The Darcy-Weisbach formula is dimensionally consistent. The Hazen-Williams coefficient C is usually considered independent of pipe diameter, velocity of flow and viscosity. However to be dimensionally consistent and to be representative of friction conditions, it must depend on relative roughness of pipe and Reynold's number. A comparison between estimates of Darcy-Weisbach friction factor f , and its equivalent value computed from Hazen-Williams C for different pipe materials brings out the error in estimation of f (up to $\pm 35\%$) in using Hazen-Williams formula. It has been observed that for higher C values (new and smooth pipes) and larger diameters, the error is less, whereas it is appreciable for lower C values (old and rough pipes) and lower diameters at higher velocities.
- (iii) The Hazen-Williams formula is dimensionally inconsistent, since the Hazen-Williams C has the dimension of $L^{1.48} T^{-1}$ and therefore is dependent on units employed.

6.2.3.1 Discussion On Various Formulae For Estimation Of Frictional Resistance

- (i) With a view to avoid the limitations of the Hazen-Williams formula, the present trend is to use the Colebrook-White equation for estimation of friction factors and then use the Darcy-Weisbach's formula for estimation of head loss due to friction in the pipelines. This practice will yield correct results compared to the Hazen-Williams formula.

The estimation of Darcy's f for variations in velocity and diameter involves repetitive and tedious calculations. Further, there is a need for assuming a correct k value in the Colebrook-White equation for calculation of friction coefficient f in the Darcy-Weisbach formula. Conservative assumption of k values will also result in under-utilization of carrying capacity of the pipes. However it is recommended that frictional losses should be estimated with Darcy-Weisbach formula by changing f values for varying velocity and diameter combinations and assuming a correct k value in the Colebrook-White equation.

Recommended C_R values for use in Colebrook-White formula are shown in 6.21 (d).

- (iv) If there is a choice for use of pipe friction formulae, Darcy-Weisbach yields accurate results but involves extra computational effort and therefore Hazen-Williams (HW) formula is commonly used. The Modified Hazen Williams (MIHW) formula being an improvement, was suggested for use in lieu of HW formula. The MIHW formula shown in Para 6.2.4 is derived from Darcy-Weisbach (DW) and Colebrook-White equations. Since the friction coefficient depends on relative roughness of pipe and Reynolds number, C_R values also have to be varied for various diameter and velocity combinations to give correct estimation of the frictional resistance which also results in extra computational efforts. Average C_R values are given in Table 6.4 for use in the Modified Hazen Williams formula which will estimate f or C_R and resistance within $\pm 5\%$ accuracy as per Table 6.4. Darcy-Weisbach formula f or C_R or with Colebrook-White equation gives most accurate results followed by modified Hazen-Williams formula and Hazen-Williams formula.
- (v) It is significant to note that irrespective of the formula used for estimation of frictional resistance, it is necessary to adopt different roughness coefficient values for the various velocity-diameter combinations if the frictional resistance is to be accurately estimated involving changing the C values, k or C or C_R values for the same pipe material. In design, various velocity-diameter combinations are required.

6.2.4 MODIFIED HAZEN-WILLIAMS FORMULA

The Modified Hazen Williams formula has been derived from Darcy-Weisbach and Colebrook-White equations and obviates the limitations of Hazen-Williams formula.

$$V = 2.83 C_R d^{0.6375} (gs)^{0.5525} / \nu^{0.005} \quad (6.8)$$

Where:

- C_R = coefficient of roughness
- d = pipe diameter
- g = acceleration due to gravity
- s = friction slope
- ν = viscosity of liquid

For circular conduits, ν , for water = $10^{-6} \text{ m}^2/\text{s}$ and $g = 9.81 \text{ m/s}^2$

The Modified Hazen Williams formula derived as

$$V = 143.534 C_R d^{0.6375} s^{0.5525} \quad (6.9)$$

$$h = [1.1(Q/C_R)^{1.81} / 994.621]^{0.81} \quad (6.10)$$

in which,

- V = velocity of flow in m/s;
- C_r = pipe roughness coefficient: 140 for smooth pipes; 100 for rough pipes;
- r = hydraulic radius in m,
- s = friction slope;
- D = internal diameter of pipe in m;
- h = friction head loss in m;
- L = length of pipe in m; and
- Q = flow in pipe in m³/s.

A nomograph for estimation of head loss by Modified Hazen Williams formula is presented in the Appendix 6.3.

6.2.5 EFFECT OF TEMPERATURE ON COEFFICIENT OF ROUGHNESS

Analysis carried out to evaluate effect of temperature (20°C to 40°C) on value of C_r reveals that the maximum variation of C_r for a temperature range of 1°C to 1°C is 4% for a diameter of 250 mm at a velocity of 3.0 m/s. In the light of this revelation, C_r values are presented for average temperature of 20°C.

6.2.6 EXPERIMENTAL ESTIMATION OF C_r VALUES

The coefficients of roughness in various pipe formulae are based on experiments conducted over a century ago. The values of Hazen Williams C , Manning's n and roughness k values in Moody's Diagram have also been used on experimental data collected in early nineteenth century. There have since been major advances in pipeline technology. Both the manufacturing processes and jointing methods have improved substantially over the years and newer pipe materials have come into use. Continued usage of roughness coefficients estimated without recognition of these advances is bound to result in conservative design of water supply systems. Accordingly C_r values of commonly used commercial pipe materials have been experimentally determined in a study conducted within the country. This study covered pipe diameters 100 to 1500 mm over a wide range of Reynold's Numbers (1×10^5 to 1.62×10^6) encountered in practice. The results indicate that centrifugally spun CI , RCC, AC and HDPE pipes behave as hydraulically smooth when new and hence, $C_r = 140$ for these pipes.

The use of Hazen Williams C as per Table 6.1 results in under utilization of above pipe material when new. The extent of under utilization varies from 33 to 40 percent for CI pipes; 23 percent for RCC and AC pipes; and 8.4 percent for HDPE and PVC pipes.

6.2.7 REDUCTION IN CARRYING CAPACITY OF PIPES WITH AGE

The values of Hazen Williams C are at present arbitrarily reduced by about 20 to 25

percent to carrying capacity of pipes with age. Studies have revealed that chemical and bacteriological quality of water and velocity of flow affect the carrying capacity of pipes with age. The data on existing systems in some cities have been analyzed along with the experimental information gathered during the study to arrive at a rational approach to the selection of carrying capacity of pipes with age.

The C_R values obtained in such studies have shown that, except in corrosive (CO₂) and acid pipes where carrying capacity with water, the carrying capacity is arbitrary reduction in C_R values as per Sec. 6.2.2.2.2. In water mains, the carrying capacity of a pipe is reduced to the extent of 38 percent for CI pipes for a 20 year design period, 44 percent for AC pipes, 50 percent for 80 pipes, 56 percent for 80 and HDPE pipes.

6.7.6 DESIGN RECOMMENDATIONS FOR USE OF MODIFIED HAZEN-WILLIAMS FORMULA

The following design recommendations are made to ensure effective utilization of pipe carrying capacity:

- New CI, DI, steel, G.I., PVC and HDPE pipes behave as listed in Table 6.4 and hence C_R values are recommended.
- The design period of 30 years projection in which needs to be identified for CI, DI, PVC and HDPE pipes in respect of the quantity of water flow or capacity must be taken to assess self-cleaning velocity or prevent formation of slimes and consequent reduction in carrying capacity of these pipes with age.
- The design period of 20 years projection as required for unlined CI and DI pipes if non-corrosive water is to be transported. The design must also ensure self-cleaning velocity.
- While carrying corrosive waters, unlined CI, DI and steel pipes will lose 41 and 37 percent of their capacity respectively over a design period of 30 years. Hence, a cost trade-off analysis must be carried out between chemical and bacteriological content of water quality, provision of a protective lining to the pipe interiors and design of reduced C_R value for ascertaining the utility of CI, DI and steel pipe interiors in the transmission of corrosive waters.

Recommended C_R values are presented Table 6.4. The use of the recommended values in connection with Modified Hazen-Williams formula or the nomograph will permit better utilization of pipe materials.

TABLE 6.4

RECOMMENDED C_R VALUES IN MODIFIED HAZEN-WILLIAMS FORMULA (AT 20°C)

Sl. No.	Pipe Material	Diameter(mm)		Velocity(m/s)		C_R Value When New	C_R Value For Design Period of 30 Years
		From	To	From	To		
1	RC	100	2000	0.3	1.8	1.00	1.00
2	AC	100	500	0.3	2.0	1.00	1.00

		Diameter(mm)		Velocity(m/s)			
		50	100	1.5	1.8	1.91	1.96
3	HDPE and PVC	50	100	1.5	1.8	1.91	1.96
4	Cl/DI (for water with positive Langheis index)	100	200	1.5	1.8	1.96	1.96
5	Cl/DI (for water with negative Langheis index)	100	200	1.5	1.8	1.91	1.96
6	Alumic pipes lined with cement mortar or epoxy (for water with negative Langheis index)	100	200	1.5	2.1	1.91	1.96
7	SGSW	100	200	1.5	2.1	1.91	1.96
8	Cl (for water with positive Langheis index)	100	100	1.5	1.5	0.67	0.72

These are average K values which result in a maximum saving of 2.5% in installation or capital cost.

6.2.9 RESISTANCE DUE TO SPECIALS AND APPURTENANCES

Pipeline transitions and appurtenances add to the head loss, which is expressed as velocity head as $KV^2/2g$, where V and g are in m/s and $1.62m/s^2$ respectively or equivalent length of straight pipe. The values of K to be adopted for different fittings are given in Table 6.5 and equivalent length of pipe for different sizes of various fittings with $K=1$ are given in Table 6.6.

TABLE 6.5: K-VALUES FOR DIFFERENT FITTINGS

Type of Fitting	Value of K
Sudden contractions	0.5 - 0.5
Entrance shape well rounded	0.5
Elbow 90°	0.5 - 1.0
45°	0.4 - 0.75
22°	0.25 - 0.50
Tee 90° take off	1.5
Straight run	0.5

Type of Fitting	Value of K
Coupling	0.5
Gate valve (open)	$0.3^{*} + 0.4$
With reducer and increase	0.50
Globe	1.00
Angle	3.0
Swing check	2.5
Venturi Meter	0.5
Orifice	1.0

*Varying with area ratios.

**Varying with valve size.

TABLE 6.6 : EQUIVALENT LENGTH OF PIPE FOR DIFFERENT SIZES OF FITTINGS WITH K = 1

Size in mm	Equivalent length of pipe in metres	Size in mm	Equivalent length of pipe in metres
10	0.3	65	2.4
15	0.5	80	3.0
20	0.75	95	3.6
25	0.9	105	4.2
32	1.2	125	5.1
40	1.5	150	6.0
50	2.1		

6.2.10 GUIDELINES FOR COST EFFECTIVE DESIGN OF PIPELINES

The cost of transmission and distribution system constitutes a major portion of the project cost. It is desirable to adopt the following guidelines:

- (i) The design velocity should not be less than 1.0 m/s in order to avoid depositions and consequent loss of carrying capacity.
- (ii) In design of distribution systems, the design velocity should not be less than 0.6 m/s to avoid low velocity conditions which may encourage deposition and/or corrosion resulting in deterioration in quality. However, where inevitable due to minimum pipe diameter criteria or other hydraulic constraints, lower velocities may be adopted with adequate provision for scouring.
- (iii) In all hydraulic calculations, the actual internal diameter of the pipe shall be

adopted after accounting for the thickness of lining, if any, instead of the nominal diameter or outside diameter (OD).

- (v) In providing for head loss due to fittings, specials and other appurtenances, actual head loss calculations based on consideration included in specification 6.2.9 should be done instead of making an arbitrary provision.

6.3 PIPE MATERIALS

Pipelines are major investments in water supply projects and as such constitute a major part of the assets of water authorities. Pipes represent a large proportion of the capital invested in water supply undertakings and therefore are of particular importance. Therefore pipe materials shall have to be judiciously selected not only from the point of view of durability, life and over all cost which includes the pipe cost, the installation and maintenance costs necessary to ensure the required standards and performance of the pipeline throughout its designed life time.

6.3.1 CHOICE OF PIPE MATERIALS

The various types of pipes used are

- I. Metallic pipes : C.I., D.I., M.S., C.P.

 - (i) Unlined Metallic pipes
 - (ii) Metallic pipes lined with cement mortar or epoxy lining.

- II. Non-Metallic pipes

 - (i) Reinforced Concrete, Pre-stressed Concrete, Bar Wrapped steel Cylinder Concrete, Asbestos Cement.
 - (ii) Plastic Pipes : PVC, Polyethylene, Glass Reinforced Plastic, etc.

The determination of the suitability in all respects of the pipes and specials, for any work is a matter of decision by the Engineer concerned on the basis of requirements for the scheme.

Several technical factors affect the final choice of pipe material such as internal pressures, coefficient of roughness, hydraulic and operating conditions, maximum permissible diameter, internal and external corrosion problems, laying and jointing, type of soil, special conditions, etc.

Selection of pipe materials must be based on the following considerations

- (a) The initial carrying capacity of the pipe and its reduction with use, defined, for example, by the Hazen-Williams coefficient C .
Values of C vary for different conduit materials and their relative deterioration in service. They vary with size and shape to some extent.
- (b) The strength of the pipe as measured by its ability to resist internal pressures and

external loads.

- (8) The life and durability of pipe as determined by the resistance of cast iron and steel pipe to corrosion, of concrete and A.C. pipe to erosion and disintegration and plastic pipe to cracking and disintegration.
- (9) The ease or difficulty of transportation, handling and laying and jointing under different conditions of topography, geology and other prevailing local conditions.
- (10) The safety, economy and availability of manufacturing sizes of pipes and specials.
- (11) The availability of skilled personnel in construction and commissioning of pipelines.
- (12) The ease or difficulty of operations and maintenance.

The life and durability of the pipe depends on several factors including inherent strength of the pipe material, the manufacturing process along with quality control, handling, transportation, laying and jointing of the pipeline, surrounding soil conditions and quality of water. Normally, the design period of pipelines is considered as 50 years. Where the pipelines have been manufactured properly as per specifications, designed and installed with adequate quality control and strict supervision, some of them may last more than the designed life provided the quality of water is non-corrosive. However, pipeline failures for various pipe materials even before the expiry of the designed life have been reported probably due to lack of rigid quality control during manufacture and installation, improper design, presence of corrosive waters, corrosive soil environment, improper bedding and other relevant factors.

Some metallic pipelines are expected to last beyond the normal design life of 50 years. However, the relative age of such pipes depends on the thickness and quality of lining available for corrosion. The cost of the pipe material and its availability or design life are the two major governing factors in the selection of the pipe material. The pipeline may have very long life but may also be relatively expensive in terms of capital and recurring costs and, therefore, it is very necessary to carry out a detailed economic analysis before selecting a pipe material.

The metallic pipes are being provided with internal lining either with cement mortar or epoxy resins to reduce corrosion, increase smoothness and prolong the life.

Underground metallic pipelines may require protection against external corrosion depending on the soil environment and corrosive ground water. Protection against external corrosion is provided with cement mortar grouting or best applied coal-tar asphaltic enamel reinforced with fibreglass fabric yarn.

The determination of the suitability in all aspects of the pipeline for any work is a matter of decision by the engineer concerned on the basis of the requirements for the scheme. A checklist in Table 6.7 for selection of pipe material has been provided to facilitate the decision makers in selecting the economical and reliable pipe material for the given conditions.

TABLE 6.7: CHECK LIST FOR SELECTION OF PIPE MATERIAL

S.No	Attribute	Type of Pipes											Remarks if any		
		PVC	AC	CI	DI	MS	PSC	GRP	FRP	FRP/ME	GI	COPIERS			
1	Hydraulic smoothness (C value)														
2	Structural strength for external loads														
3	Strength to sustain internal pressure														
4	Easy in handling, transportation and storage														
5	Capacity to withstand damage at handling and installation														
6	Resistance to internal corrosion														
7	Resistance to external corrosion														
8	Resistance to heat/strength														
9	Resistance to rodent attack														
10	Sustainability in Black Cotton Soil														
11	Reliability and efficient joints														
12	Capable to absorb surge pressure														
13	Easy in maintenance and repair														
14	Low expense														
15	Easy to repair/replace/replace from maintenance														
16	Consistent performance														
17	Resistance to impact by any sharp element														
18	Economy														
19	Availability of spares														
20	Availability of skilled personnel for installation & maintenance														
21	Behaviour of pipe line - likelihood of interruptions due to leakage, bursting etc. and time for repairs														
	Recommended size range for														
	Rising Main														
	Gravity Main														
	Distribution Main														

Note: Weightage - 1 to 5 number/ 5 given to the significance of the attribute; 10 stands for highest quality; 00 & 01 stand for

Use of this checklist is strongly recommended for large and medium projects (more than 10 MLD). The checklist can be filled up based on the merits and demerits of relevant pipe materials. It is necessary that a quantitative and qualitative assessment is made to arrive at the most economical and reliable pipe material.

The project report should include provisions for addressing the less favourable attributes along with the cost estimates for the same. Risk factors should be identified and stated clearly in the project report. Risk analysis should be carried out to arrive at the correct decision in selecting the pipe material.

6.3.2 CHECK LIST FOR SPECIFICATIONS FOR MANUFACTURE, SUPPLY, LAYING, JOINTING, TESTING AND COMMISSIONING OF PIPELINES

6.3.2.1 GENERAL

Water utilities often procure pipes from one manufacturer/supplier under one contract, procure the valves and fittings from another manufacturer/supplier under another contract and have them installed under another contract rather than entrusting the entire work of Manufacture, Supply, Laying, Jointing, Testing and Commissioning of pipelines to a single agency. This procedure is resorted to on the plea that it results in economy and saves time.

It is seen that whenever single contracts are not awarded for the entire work of Manufacture, Supply, Laying, Jointing, Testing and Commissioning of pipelines to a single agency, the responsibility for performance of the pipelines could not be assigned to any particular agency. Time delays if any, in procurement of fittings and valves will also affect the completion of the contract and also results in cost overruns. Quite often, at the time of commissioning, deficiencies are noticed which might be due to faults at the manufacturing stage or due to transportation handling, or to commissioning defects or failure of fittings and valves.

Even if it is desirable that all pipeline contracts are awarded on a single contract responsibility so that quality assurance at various stages of manufacture, supply, delivery, laying, jointing and testing is taken care of by a single agency and the timely completion also rests with a single agency, this may result in receipt of competitive offers and hence results in economy. Further, the water utility's time and resources which otherwise are spent in monitoring the performance of several small contracts can be better utilised for quality management of the contract. This may ensure economy by timely completion and quality construction.

However it is necessary that the specifications for single contract responsibility have to be comprehensive and provide for penalty in delays so that the time and cost over runs can be avoided. There will be several site specific conditions and circumstances for the pipeline installations which vary to such an extent that it is very difficult to recommend a simple/ single all inclusive set of specifications for the pipeline contracts. A check list for drafting

specifications for Manufacture, Supply, Laying, Jointing, Testing and commissioning of pipelines for procurement through a single agency is furnished. Exhaustive selection of items which cover cross country or city installations is required.

6.3.3 CHECK LIST FOR SPECIFICATIONS FOR MANUFACTURE, SUPPLY, LAYING, JOINTING, TESTING AND COMMISSIONING PIPELINES

PART I - PROCUREMENT

Section 1 - General

- 1.1 Scope of work
- 1.2 Definitions of client, contractor, etc.
- 1.3 Drawings and documents referred to
- 1.4 Reference Standards
- 1.5 Penal clauses for failure to meet the time schedule & performance standards and requirements.
- 1.6 Basis for Prices: to include all pipes, fittings, valves, coating materials, including labour, cost of factory testing, lining, coating, marking and all other incidental expenses for manufacturing, transportation, insurance and delivery at site (any exclusions, additions may be clearly specified)

Section 2 - Detailed Requirements - Pipes

- 2.1 Material for pipes (standards for materials, manufacturing, production, testing and inspection)
- 2.2 Diameter of pipe
- 2.3 Wall thickness/other dimensions of the pipe
- 2.4 Class of pipe
- 2.5 Laying length
- 2.6 Pipe ends-flanged socket/spigot/plain
- 2.7 Special pipe lengths and special fittings
- 2.8 Working Pressures
- 2.9 Pipe lining and coating both for buried and exposed pipes

Section 3 - Transportation and delivery at site

- 3.1 Type of trucks used for transportation length/weight
- 3.2 Handling equipment for loading and unloading

Section 4 - Field Joints for Pipes

- 4.1 Requirements for machined couplings/ends
- 4.2 Flanged/joints, pitch circle, bolts type, gasket quality
- 4.3 Welded joints-runs-thickness

PART II - INSTALLATION

Section 1 - Instruction to Bidders

- 1.1 Procedure for invitation of bids
- 1.2 Instructions to bidders
- 1.3 Bidders proposal to include plan/programme for construction
- 1.4 Agreement and performance bonds

Section 2 - General Specifications

- 2.1 Definitions
- 2.2 Scope of Work
- 2.3 Payment conditions
- 2.4 Statutory Requirements- Payment of wages-Police-Environment control safety
- 2.5 Personnel

Section 3 - Detailed Specifications

- 3.1 Time Schedule
- 3.2 Construction facilities - Right of way - storage space - interference with other services
- 3.3 Work and materials
- 3.4 Concrete
- 3.5 Excavation - Bracing of excavation - Safety to public - Disposal of excess material from excavation
- 3.6 Maintenance, removal and reconstruction of other interfering facilities
- 3.7 Safeguarding of excavations and protection of property
- 3.8 Backfill
- 3.9 Resurfacing of roads within city limits

Section 4 - Pipes

- 4.1 Approval of drawings for pipes
- 4.2 Distribution along trench
- 4.3 Preparation of bedding
- 4.4 Lowering and laying
- 4.5 Joining

- 4.6 Inspection and tests
- 4.7 Bends, manholes, outlets
- 4.8 Joints- Flanged , bolting materials and gasket- machined ends - welded joints
- 4.9 Field touch up of site joints

6.4 CAST IRON PIPES

6.4.1 GENERAL

Most of the old Cast Iron pipes were cast vertically but this type has been largely superseded by centrifugally spun cast iron type manufactured upto a diameter of 1050 mm (IS- 1536-1989). Though the vertically cast iron pipe is heavy in weight, low in tensile strength, and liable to defects of inner surface, it is widely used because of its good lasting qualities. There are many examples of cast iron mains in this country which continue to give satisfactory service even after a century of use.

Cast iron pipes and fittings are being manufactured in this country for several years. Due to its strength and corrosion resistance, C.I. pipes can be used in corrosive soils and for waters of slightly aggressive character. They are well suited for pressure mains and laterals where tapings are made for house connections. It is preferable to have coating inside and outside of the pipe.

Vertically cast iron pipes shall conform to IS. 1537-1976. The pipes are manufactured by vertical casting in sand moulds. The metal used for the manufacture of this pipe is not less than grade 15. The pipes shall be stripped with all precautions necessary to avoid wrinkling or shrinking defects. The pipes shall be such that they could be cut, drilled or machined.

Cast iron flanged pipes and fittings are usually cast in the larger diameters. Smaller sizes have loose flanges screwed on the ends of double spigot-spun pipe.

The method of Cast Iron pipe production used universally today is to form pipes by spinning or centrifugal action. Compared with vertical casting in sand moulds, the spun process results in faster production, longer pipes with vastly improved metal qualities, smoother inner surface and reduced thickness and consequent lightweight (IS. 1536 --1989).

Centrifugally cast iron pipes are available in diameters from 80mm to 1050mm and are covered with protective coatings. Pipes are supplied in 3.66m and 5.5m lengths and a variety of joints are available including socket and spigot and flanged joints.

The pipes have been classified as L/A, A and B according to their thicknesses. Class L/A pipes have been taken as the basis for evolving the series of pipes. Class A allows a 10% increase in thickness over class L/A. Class B allows a 20% increase in thickness over class L/A.

The pipes are spigot and socket type. When the pipes are to be used for conveying potable water, the inside coating shall not contain any constituent soluble in water or any ingredient which could impart any taste or odour whatsoever to the potable water, after sterilization and suitable washing of the same.

Experiments in centrifugal casting of iron pipes were started in 1914 by a French Engineer which ultimately resulted in commercial production of spun pipes. Spun pipes are about 3/4 of the weight of vertically cast pipes of the same class. The greater tensile strength of the spun iron is due to close grain allowing use of thinner wall than for that of a vertically cast iron pipe of equal length. It is possible by this process to increase the length of the pipe whilst a further advantage lies in the smoothness of the inner surface.

6.4.2 LAYING AND JOINTING

Before laying the pipes, the detailed map of the area showing the alignment, sluice valves, service valves, air valves and fire hydrants along with the existing intercepting sewers, telephone and electric cables and gas pipes will have to be studied. Care should be taken to avoid damage to the existing sewer, telephone and electric cables and gas pipes. The pipeline may be laid on the side of the street where the population is dense. Pipes are laid and grouted with a minimum cover of 1 meter on the top of the pipe.

Laying of cast iron pipes for water supply purposes has been generally governed by the regulations laid down by the various municipalities and corporations. These regulations are intended to ensure proper laying of pipes paying due consideration to economy and safety of workers engaged in laying.

6.4.2.1 Excavation And Preparation Of Trench

The work may be done by hand or by machine. The trench shall be so dug that the pipe may be laid to the required gradient and at the required depth. When the pipeline is under a roadway a minimum cover of 1.0 m is recommended. The width of the trench at bottom shall provide not less than 200mm clearance on both sides of the pipe. Additional width shall be provided at positions of socket and flanges for jointing. Depths of pits at such places shall also be sufficient to permit finishing of joints.

6.4.2.2 Handling Of Pipes

While unloading, pipes shall not be thrown down but may be carefully unloaded on inclined timber skids. Pipes shall not be dragged over other pipes and along concrete and similar pavements to avoid damage to pipes.

6.4.2.3 Detection Of Cracks In Pipes

The pipes and fittings shall be inspected for defects and be rung with a light hammer, preferably with suspended, to detect cracks. Smearing the outside with chalk dust helps in

the location of cracks. If doubt persists further confirmation may be obtained by pouring a little kerosene on the inside of the pipe at the suspected spot. If a crack is present the kerosene seeps through and shows on the outer surface. Any pipe found unsuitable after inspection before laying shall be rejected.

6.4.2.4 Lowering Of Pipes And Fittings

All pipes, fittings, valves and hydrants shall be carefully lowered into the trench by means of derrick, ropes or other suitable tools and equipment to prevent damage to pipe materials and protective coatings and linings. Pipes over 300mm dia shall be hauled and lowered into trenches with the help of chain pulley blocks.

6.4.2.5 Cleaning Of Pipes And Fittings

All lumps, blisters and excess coating material shall be removed from socket and spigot end of each pipe and outside of the spigot and inside of the socket shall be wire-brushed and wiped clean and dry and free from oil and grease before the pipe is laid.

After placing a length of pipe in the trench, the spigot end shall be centered in the socket and the pipe forced home and aligned to gradient. The pipe shall be secured in place with approved back fill material packed on both sides except at socket.

The socket end should face the upstream when laying the pipeline on level ground; when the pipeline runs uphill, the socket ends should face the up gradient. When the pipes run beneath the heavy loads, suitable size of casing pipes or culverts may be provided to protect the casing of pipe. High pressure means need anchorage at dead ends and bends as appreciable thrust occurs which tend to cause draw and even "blow out" joints. Where thrust is appreciable concrete blocks should be installed at all points where movement may occur. Anchorages are necessary to resist the tendency of the pipes to pull apart at bends or other points of unbalanced pressure, or when they are laid on steep gradients and the resistance of their joints to longitudinal or shear stresses is either exceeded or inadequate. They are also used to restrain or direct the expansion and contraction of rigidly joined pipes under the influence of temperature changes. Anchor or thrust blocks shall be designed in accordance with I.S. 5330:1984.

6.4.3 JOINTS

Several types of joints such as rubber gasket joint known as Tyton joint, mechanical joint known as Screw Gland joint, and conventional joint known as Lead joint are used.

6.4.3.1 Categories Of Joints

Joints are classified into the following three categories depending upon their capacity for movement.

(a) Rigid joints

Rigid joints are those which admit no movement at all and comprise of flanged, welded and turned and bored joints. Flanged joints require perfect alignment and close fittings are

frequently used where a longitudinal thrust must be taken such as at the valves and meters. The gaskets used between flanges of pipes shall be of compressed fibre board or natural or synthetic rubber. Welded joints produce a continuous line of pipes with the advantage that interior and exterior coatings can be made properly and are not subsequently disrupted by the movement of joints.

(b) Semi Rigid joints

Semi rigid joint is represented by the spigot and socket with caulked lead joint. A semi rigid joint allows partial movement due to vibration etc. The socketed end of the pipe should be kept against the flow of water and the spigot end of the other pipe is inserted into the socket. A twisted sown yarn is filled into this gap and it is adjusted by the yarning tool and is then caulked well. A rope is then placed at the outer end of the socket and is made tight fit by applying wet clay, leaving two holes for the escape of the entrapped air inside. The rope is taken out and molten lead is poured into the annular space by means of a funnel. The clay is then removed and the lead is caulked with a caulking tool. Lead wool may be used in wet conditions. Lead covered yarn is of great use in repair work, since the leaded yarn caulked in a place will keep back water under very low pressure while the joint is being made.

(c) Flexible joints

Flexible joints are used where rigidity is undesirable such as work filling of granular medium and when two sections cannot be welded. They comprise mainly mechanical and rubber ring joints or tyton joints which permit some degree of deflection at each joint and are therefore able to stand vibration and movement. In rubber jointing special type of rubber gaskets are used to connect cast iron pipe which are cast with a special type of spigot and socket in the groove, the spigot end being lubricated with grease and slipped into the socket by means of a jack used on the other end. The working conditions of absence of light, presence of water and relatively cool uniform temperature are all conducive to the preservation of rubber and consequently the type of joint is expected to last as long as the pipe. Hence, rubber jointing is to be preferred to lead jointing.

6.4.4 TESTING OF THE PIPELINE

6.4.4.1 General

After laying and jointing, the pipeline must be pressure tested to ensure that pipes and joints are sound enough to withstand the maximum pressure likely to be developed under working conditions.

6.4.4.2 Testing Of Pressure Pipes

The field test pressure to be imposed should be not less than the maximum of the following:

- (a) 1 1/2 times the maximum sustained operating pressure.
- (b) 1 1/2 times the maximum pipeline static pressure.

- (c) Sum of the maximum sustained operating pressure and the maximum surge pressure.
- (d) Sum of the maximum pipeline static pressure and the maximum surge pressure, subject to a maximum equal to the work test pressure for any pipe fittings incorporated.

The field test pressure should wherever possible be not less than 2/3 work test pressure appropriate to the class of pipe except in the case of spun iron pipes and should be applied and maintained for at least four hours. If the visual inspection satisfies that there is no leakage, the test can be passed.

Where the field test pressure is less than 2/3 the work test pressure, the period of test should be increased to at least 24 hours. The test pressure shall be gradually raised at the rate of 1 kg/cm²/min. If the pressure measurements are not made at the lowest point of the section, an allowance should be made for the difference in static head between the lowest point and the point of measurement to ensure that the maximum pressure is not exceeded at the lowest point. If a drop in pressure occurs, the quantity of water added in order to re-establish the test pressure should be carefully measured. This should not exceed 0.1 litre per mm of pipe diameter per km of pipeline per day for each 30 metre head of pressure applied.

In case of gravity pipes, maximum working pressure shall be 2/3 work test pressure.

The hydrostatic test pressure at works and at field after installation and the working pressure for different classes of pipes are given in Appendix 6.4

The allowable leakage during the maintenance stage of pipes carefully laid and well tested during construction, however should not exceed:

$$ql = \frac{ND\sqrt{P}}{115} \tag{6.11}$$

Where,

- ql = Allowable leakage in cm³/hour
- N = No of joints in the length of pipe line
- D = Diameter in mm
- P = The average test pressure during the leakage test in kg/cm²

where any test of pipe laid indicates leakage greater than that specified as per the above formula, the defective pipe(s) or joint(s) shall be repaired/replaced until the leakage is within the specified allowance

The above is applicable to spigot and socket Cast Iron pipes and A.C. pressure pipes, whereas, twice this figure may be taken for steel and prestressed concrete pipes.

6.4.4.3 Testing Of Non-Pressure Conduits

In case of testing of non-pressure conduits, the pipeline shall be subject to a test for of 2.5 meters head of water at the highest point of the section under test for 10 minutes. The leakage or quantity of water to be supplied to maintain the test pressure during the period of 10 minutes shall not exceed 0.2 litres/mm dia of pipes per kilometer length per day.

6.5 STEEL PIPES

6.5.1 GENERAL

Steel pipes of smaller diameter can be made from solid bar sections by hot or cold drawing processes and these tubes are referred to as seamless. But the larger sizes are made by welding together the edges of suitably curved plates, the sockets being formed later in a press (IS 3589). The thickness of steel used is often controlled by the need to make the pipe stiff enough to keep its circular shape during storage, transportation and laying as also to prevent excessive deflection under the load of trench back filling. The thickness of a steel pipe is however always considerably less than the thickness of the corresponding vertically cast or spun iron pipe. Owing to the higher tensile strength of the steel, it is possible to make steel pipe of lower wall thickness and lower weight. Specials of all kinds can be fabricated without difficulty to suit the different site conditions. Due to their elasticity, steel pipes adopt themselves to changes in relative ground level without failure and hence are very suitable for laying in ground liable to subsidence. If the pipes are joined by a form of flexible joint, it provides an additional safeguard against failure. Steel pipes being flexible are best suited for high dynamic loading.

6.5.2 PROTECTION AGAINST CORROSION

It must be borne in mind, however, that steel mains need protection from corrosion internally and externally. Against internal corrosion, steel pipes are given epoxy lining or hot applied coal tar asphalt lining or rich cement mortar lining at works or in the field by the centrifugal process. The outer coating for under ground pipeline may be in cement sand grouting or hot applied coal tar asphaltic enamel reinforced with fibreglass fabric yarn.

6.5.3 LAYING AND JOINING

Small size mild steel pipes have got threaded ends with one socket. They are lowered down in the trenches and laid to alignment and gradient. The jointing materials for this type of pipes are white lead and spun yarn. The white lead is applied on the threaded end with spun yarn and inserted into socket of another pipe. The pipe is then turned to tighten it. When these pipes are used in the construction of tube wells, the socketed ends after positioning without any jointing material are welded and lowered down. Lining and out coating is done by different methods to protect steel pipes. While laying, the pipes already stocked along the trenches are lowered down into the trenches with the help of chain pulley block. The formation of bed should be uniform. The pipes are laid true to the alignment and gradient before jointing. The ends of these pipes are butted against each other, welded and a

coat of rich cement mortar is applied after welding. Steel pipes may be jointed with flexible joints or by welding but lead or other filler joints, hot or cold, are not recommended. The welded joint is to be preferred. In areas prone to subsidence this joint is satisfactory but flexible joints must be provided to isolate valves and branches.

When welding is adopted, plain ended pipes may be jointed by butt welds or sleeved pipes by means of fillet welds. For laying long straight lengths of pipelines, butt joint technique may be employed. The steel pipes used for water supply include hydraulic lap welded, electric fusion welded, submerged arc welded and spiral welded pipes. The latter are being made from steel strip. For laying of welded steel pipe IS 5822:1986 may be referred to.

For more details on different types of steel pipes used, reference may be made to the ISI codes indicated in Appendix 'C'.

For hydraulic testing of steel pipelines, the procedure described for cast iron spun pipes and ductile iron pipes may be followed.

6.6 DUCTILE IRON PIPES

6.6.1 GENERAL

Ductile iron is made by a metallurgical process which involves the addition of magnesium into molten iron of low sulfur content. The magnesium causes the graphite in the iron to precipitate in the form of microscopic (6.25 micron) spheres rather than the flakes found in ordinary cast iron. The spheroidal graphite in iron improves the properties of ductile iron. It possesses properties of high mechanical strength, excellent impact resistance and good casting qualities of grey cast iron. Ductile iron pipes are normally prepared using the centrifugal cast process. The ductile iron pipes are usually provided with cement mortar lining at the factory by centrifugal process to ensure a uniform thickness through out its length. Cement mortar lining is superior to bituminous lining as the former provides a smooth surface and prevents tuberculation by creating a high pH at the pipe wall and ultimately by providing a physical and chemical barrier to the water.

The Indian standard IS 8329-1994 provides specifications for the centrifugally cast ductile iron pipes (Similar to ISO:2531-1998 and EN:545-1994). These pipes are available in the range of 80 mm to 1000 mm diameter; in lengths of 3.5 to 6 m. These pipes are being manufactured in the country with ISO 9002 accreditation.

Ductile iron pipes have excellent properties of machinability, impact resistance, high wear and tear resistance, high tensile strength, ductility and corrosion resistance. DI pipes having same composition of CI pipe, it will have same expected life as that of CI pipes. The ductile iron pipes are strong, both inner and outer surfaces are smooth, free from lumps, cracks, blisters and scars. Ductile Iron pipes stand up to hydraulic pressure tests as required by service regulations. These pipes are approximately 30% lighter than conventional cast iron pipes.

Ductile iron pipes are lined with cement mortar in the factory by centrifugal process and unlined ductile iron pipes are also available. For more details reference may be made to IS 8329 - 1994 for Ductile Iron Pipes.

6.6.2 DUCTILE IRON FITTINGS

The ductile iron fittings are manufactured conforming to IS 9523-1980 for Ductile Iron fittings.

6.6.3 JOINTS

The joints for ductile iron pipes are suitable for use of rubber gaskets conforming to IS 5383.

6.6.4 LAYING AND JOINTING

Reference may be made to para 6.4.2 (laying and jointing of cast iron pipes)

6.6.5 TESTING OF DUCTILE IRON PIPELINES

The Ductile Iron pipelines are tested as per para 6.4.4 (testing of the pipeline). The test pressures shall be as per IS 8329 - 1994.

6.7 ASBESTOS CEMENT PIPES

6.7.1 GENERAL

Asbestos cement pipes are made of a mixture of asbestos paste and cement compressed by steel rollers to form a laminated material of great strength and density. Its carrying capacity remains substantially constant as when first laid, irrespective of the quality of water. It can be drilled and tapped for connecting but does not have the same strength or suitability for threading as iron and any leakage at the thread will become worse as time passes. However, this difficulty can be overcome by screwing the ferrules through malleable iron saddles fixed at the point of service connections as is the general practice. These pipes are not suitable for use in sulphate soils. Due to expansion and contraction of black cotton soil, usage of these pipes may be avoided as far as possible in Black Cotton soils, except where the depth of B.C. soil is clearly less than 0.9 metre below ground level.

The available safety against bursting under pressure and against failure in longitudinal bending, though less than that for spun iron pipes, is nevertheless adequate and increases as the pipe ages. In most cases, good bedding of the pipes and the use of flexible joints are of greater importance in preventing failure by bending, than the strength of pipe itself. Flexible joints are used at regular intervals to provide for repairing of pipes, if necessary.

AC pipes are manufactured from classes 5 to 25 and nominal diameters of 80mm to 600mm with the test pressure of 5 to 25 Kg/cm².

AC pipe can meet the general requirements of water supply undertakings for rising main as well as distribution main. It is classified as class 5, 10, 15, 20 and 25, which have test pressures 5, 10, 15, 20 and 25 Kg/cm² respectively. Working pressures shall not be greater

that 50% of test pressure for pumping mains and 67% for gravity mains.

For further details, refer to IS 1592-1989.

6.7.2 HANDLING

Utmost care must be taken while loading, transportation, unloading, stacking and retransporting to the site to avoid damage to the pipes.

6.7.2.1 Laying And Jointing

The width of the trench should be uniform throughout the length and greater than the outside diameter of the pipe by 300mm on either side of the pipe. The depth of the trench is usually kept 1 meter above the top of the pipe. For heavy traffic, a cover of at least 1.25 meter is provided on the top of the pipe.

The A.C. pipes to be laid are stacked along the trenches on the side or opposite to the spoils. Each pipe should be examined for any defects such as cracks, chipped ends, crushing of the sides etc. The defective pipes should be removed forthwith from the site as otherwise they are likely to be mixed up with the good pipes. Before use the inside of the pipes will have to be cleaned. The lighter pipes weighing less than 80kg can be lowered in the trench by hand. If the sides of the trench slip too much, ropes must be used. The pipes of medium weight upto 200kg are lowered by means of ropes looped at and both the ends. One end of the rope is fastened to a wooden or steel stake driven into the ground and the other end of the rope is held by men and is slowly released to lower the pipe into the trench. After their being lowered into the trench they are aligned for jointing. The bed of the trench should be uniform.

6.7.3 PIPE JOINTS

There are two types of joints for A.C. pipes.

- ◆ Cast iron detachable joint, J.D type;
- ◆ A.C. coupling joint.

(a) Cast Iron Detachable Joints

This consists of two cast iron flanges, a cast iron central collar and two rubber rings along with a set of nuts and bolts for the particular joint. At this point, the A.C. pipes should have flush ends. For jointing a flange, a rubber ring and a collar are slipped to the first pipe in that order; a flange and a rubber ring being introduced from the jointing of the next pipe. Both the pipes are now aligned and the collar centralized and the joints of the flanges tightened with nuts and bolts.

(b) A.C. Coupling Joint

This consists of an A.C. Coupling and three special rubber rings. The pipes for these joints have chamfered ends. These rubber rings are positioned in the grooves inside the coupling, then grease is applied on the chamfered end and the pipe and coupling is pushed

with the help of a jack against the pipe. The mouth of the pipe is then placed in the mouth of the coupling end and then pushed so as to bring the two chamfered ends close to each other. Wherever necessary, change over from cast iron pipe to A.C. pipes or vice versa should be done with the help of suitable adapters. IS 5633-1972 may be followed for laying A.C. pipes.

6.7.4 PRESSURE TESTING

The procedure for the test as adopted is as follows:

- (a) At a time one section of the pipeline between two sluice valves is taken up for testing. The section usually taken is about 500 meters long.
- (b) One of the valves is closed and the water is admitted into the pipe through the other, manipulating air valves suitably.
(If there are no sluice valves in between the section, the end of the section can be sealed temporarily with an end cap having an outlet which can serve as an air relief vent or for filling the line as may be required. The pipeline after it is filled, should be allowed to stand for 24 hours before pressure testing.)
- (c) After filling, the sluice valve is closed and the pipe section is isolated.
- (d) Pressure gauges are fitted at suitable intervals on the crown into the hauls main for the purpose.
- (e) The pipe section is then connected to the delivery side of a pump through a small valve.
- (f) The pump is then operated till the pressure inside reaches the designed value which can be read from the pressure gauges fixed.
- (g) After the required pressure has been attained, the valve is closed and the pump disconnected.
- (h) The pipe is then kept under the desired pressure during inspection for any defect, i.e. leakages at the joints etc. The test pressures will be generally as specified in 6.7.1 and Appendix 6.4. The water will then be emptied through scour valves and defects observed in the test will be rectified.

6.8 CONCRETE PIPES

6.8.1 GENERAL

Reinforced concrete pipes used in water supplies are classified as P1, P2 and P3 with test pressures of 2.0, 4.0, and 6.0 Kg/cm^2 respectively. For use as gravity mains, the working pressure should not exceed 2/3 of the test pressure. For use as pumping mains, the working pressure should not exceed half of the test pressure.

Generally concrete pipes have corrosion resistant properties similar to those of prestressed concrete pipes although they have their own features which significantly affect

corrosion performance. Concrete pipes are made by centrifugal spinning of vibratory process. Centrifugally spun pipes are subjected to high rotational forces during manufacture with improved corrosion resistance properties. The line of development most likely to bring concrete pressure pipes into more general acceptance is the use of P.S.C. pipes which are widely used to replace reinforced concrete pipes.

6.8.2 LAYING AND JOINTING

The concrete pipes should be carefully loaded, transported and unloaded avoiding impact. The use of inclined planes or chain pulley block is recommended. Free working space on either side of the pipe shall be provided in the trench which shall not be greater than 1/3 the dia of the pipe but not less than 15 cm on either side.

Laying of pipes shall proceed upgrade of a slope. If the pipes have spigot and socket joints the socket ends shall face upstream. The pipes shall be joined in such a way to provide as little unevenness as possible along the inside of the pipe. Where the natural foundation is inadequate, the pipes shall be laid in a concrete cradle supported on proper foundation or any other suitably designed structure. If a concrete cradle is used, the depth of concrete below the bottom of the pipes shall be at least 1/4 the internal diameter of pipe with the range of 10-30cm. It shall extend upto the sides of the pipe atleast to a distance of 1/4 the dia for larger than 300mm.

The pipe shall be laid in the concrete bedding before the concrete has set.

Trenches shall be back filled immediately after the pipe has been laid to a depth of 300mm above the pipe subject to the condition that the jointing material has hardened (say 12 hours at the most). The backfill material shall be free from boulders, roots of trees etc. The ramping shall be by hand or by other hand operated mechanical means. The water content of the soil shall be as near the optimum moisture content as possible. Filling of trench shall be carried on simultaneously on both sides of the pipe to avoid development of unequal pressures. The back fill shall be rammed in 150mm layers upto 300mm above the top of the pipe.

Joints may be of any of the following types

- (i) Bandage joint
- (ii) Spigot and socket joint (rigid and semi flexible)
- (iii) Collar joint (rigid and semi flexible)
- (iv) Flush joint (internal and external)

For more details of jointing procedure, reference may be made to IS 783-1985

In all pressure pipelines, the recesses at the ends of the pipe shall be filled with jute brading dipped in hot bitumen. The quantity of jute and bitumen in the ring shall be just sufficient to fill the recess in the pipe when pressed hard by jacking or any other suitable method.

The number of pipes that shall be jacked together at a time depends upon the dia of the pipe and the bearing capacity of soil. For small pipe upto 250mm dia, six pipes can be jacked together at a time. Before and during jacking, care should be taken to see that there is no offset at the joint. Loose collar shall be set up over the joint so as to have an even caulking space all round as in Fig. This caulking space shall be caulked a 1 : 1.5 mixture of cement and sand (as sufficiently moistened to hold together in the form of a cord when compressed in the hand). The caulking shall be so firm that it shall be difficult to drive the point of a pickaxe into it. The caulking shall be employed at both the ends in a slope of 1:1. In the case of non pressure pipes the recess at the end of the pipes shall be filled with cement mortar 1 : 2 instead of jute banding, which in the case of C.P. shall be kept wet for 10 days for maturing.

6.8.3 PRESSURE TEST

When testing the pipeline hydraulically, the line shall be kept filled completely with water for a week. The pressure shall then be increased gradually to full test pressure as indicated in 6.8.2.2. and maintained at this pressure during the period of test with the permissible allowance indicated therein. For further details reference may be made to I.S. 458-1971.

6.9 PRESTRESSED CONCRETE PIPES

6.9.1 GENERAL

While RCC pipes can cater to the needs where pressures are upto 6.0 kg/cm^2 and CI and steel pipes cater to the needs of higher pressures around 24 kg/cm^2 , the Prestressed Concrete (PSC) pipes cater to intermediate pressure range, while RCC pipes would not be suitable.

The strength of a PSC pipe is achieved by helically binding high tensile steel wire under tension around a concrete core thereby putting the core into compression. When the pipe is pressurized the stresses induced relieve the compression stress but they are not sufficient to subject the core to tensile stresses. The pre-tensioning wire is protected against corrosion by a surround of cementitious cover coat giving about 25mm thick cover.

The PSC pipes are suited for water supply mains where pressures in the range of 6 kg/cm^2 to 20 kg/cm^2 are encountered.

Two types of P.S.C. pipes are in use today

- (i) Cylinder type: Consists of a concrete lined steel cylinder with steel joint rings welded to its ends wrapped with a helix of highly stressed wire and coated with dense cement mortar or concrete.

Recommended specifications for above pipe are covered by Indian and foreign codes IS: 784-1978 AWWA C 301, EN 642 and EN 642.

- (ii) Steel Cylinder Prestressed Concrete Pipes are used in America and Europe. Confirming to AWWA C 301 and in Europe EN - 642.

Prestressed Concrete Cylinder pipe has the following two general types of construction : (1) a steel cylinder lined with a concrete core or (2) a steel cylinder embedded in a concrete core. In either type of construction, manufacturing begins with a full length welded steel cylinder. Joint rings are attached to each end and the pipe is hydrostatically tested to ensure water-tightness. A concrete core with a minimum thickness of one sixteenth times the pipe diameter is placed either by the centrifugal process, radial compaction, or by vertical casting. After the core is cured, the pipe is helically wrapped with high strength, hard drawn wire using a stress of 75 percent of the minimum specified tensile strength. The wrapping stress ranges between 150,000 and 180,000 psi (1034 and 1303 MPa) depending on the wire size and class. The wire spacing is accurately controlled to produce a predetermined residual compression in the concrete core. The wire is embedded in a thick cement slurry and coated with a dense mortar that is rich in cement content.

Size Range : AWWA C-301 covers prestressed concrete cylinder pipe 16 in. (406 mm) in inside diameter and larger. Lined cylinder pipe is commonly available in inside diameters to 100 in. from 16 to 48 in. (410 to 1,220 mm). Sizes up to 66 in. are available from some manufacturers. Unlined cylinder pipe has been manufactured larger than 250 in. (6,350 mm) in diameter and is commonly available in inside diameters of 48 in. (1,220 mm) and larger. Lengths are generally 16 to 24 ft (4.9 to 7.3 m), although long runs can be furnished.

The technology for manufacture of these pipes is now available with some of the Indian manufacturers.

- (ii) **Non cylinder type :** Consists of a concrete core which is pre-compressed both in longitudinal and circumferential directions by a highly stressed wire. The wire wrapping is protected by a coat of cement mortar or concrete.

Physical behaviour of PSC pipes under internal and external load is superior to RCC pipes. The PSC pipe wall is always in a state of compression which is the most favourable factor for impermeability. These pipes can resist high external loads. The protective cover of cement and mortar which covers the tensioned wire wrapping by its ability to create and maintain alkaline environment around the steel inhibits corrosion. PSC pipes are jointed with flexible rubber rings.

The deflection possible during laying of main is relatively small and the pipes cannot be cut to size to close gaps in the pipeline. Special closure units (consisting of a short double spigot piece and a plain ended concrete lined steel tube with a follower ring assembled at each end) are manufactured for this purpose. The closure unit (minimum length 1.27m) must be ordered specially to the exact length.

Specials such as bends, bevel pipes, flanged tees, taps and adapters to flange the couplings are generally fabricated as mild steel fittings lined and coated with concrete.

It is worth while when designing the pipeline to make provision for as many branches as are likely to be required in the future and then to install sluice valves or blank flanges on these branches. It is possible to make connections to the installed pipeline by emptying, breaking out and using a special closure unit but this is a costly item.

6.9.2 LAYING AND JOINTING

PSC pressure pipes are provided with flexible joints, the joints being made by the use of rubber gasket. They have socket spigot ends to suit the rubber ring joint. The rubber gasket is intended to keep the joint water tight under all normal conditions of service including expansion, contraction and normal earth settlement. The quality of rubber used for the gasket should be waterproof, flexible and should have a low permanent set. Refer to IS 784 -1978, for laying of PSC pipes.

6.9.3 PRESSURE TESTING

Testing of PSC pipe is the same as given in the para 6.4.4.2.

However the quantity of water added in order to re-establish the test pressure should not exceed 3 litres (instead of 10.1 litres) per mm dia. per km per 24 hours per 30m head for non-absorbent pipes as per the IS 783 (para 15.5.3 pages 28 & 29).

6.9.4 BAR WRAPPED STEEL CYLINDER CONCRETE PRESSURE PIPES

6.9.4.1 General

Bar Wrapped Steel Cylinder Concrete Pressure Pipes (confirming to AWWA C 303 and EN639 & EN 641) are reported to be manufactured in India. No Indian Standard is presently available for these pipes. Bar Wrapped Steel Cylinder Concrete Pressure Pipes are available in diameters of 250 mm to 1500 mm and higher diameter pipes can be obtained for working pressures upto 25 kgs per sq. cm. Standard lengths are generally 3 to 6m. Longer length pipes can also be custom made.

6.9.4.2 Manufacture

Manufacture of Bar Wrapped Steel Cylinder Concrete Pressure Pipes begins with fabrication of a thin steel pipe cylinder. Thicker steel joint rings are welded at both ends. Each pipe is hydrostatically tested. A cement mortar lining is placed by centrifugal process inside the cylinder. The lining varies from 12mm to 25 mm. After the lining is cured by steam or water, mild steel rod is wrapped on the cylinder using moderate tension in the bar. The wrapping is to be done under controlled tension ensuring intimate contact with the cylinder. The cylinder and bar wrapping are covered with a cement slurry and a dense mortar coating that is rich in cement. The coating is cured by steam or water.

6.9.4.3 Joints

The standard joint consists of steel joint rings and a continuous solid rubber ring gasket. The field joint can be overlapping/sliding, butt welded or with confined rubber ring as per the clients requirement. In the case of welded & rubber joints, the exterior joint recess is

normally grouted and the internal joint space may or may not be pointed with mortar. The AWWA C 303 provides for use of elastomeric sealing ring (rubber joints) and EN 643 provides both elastomeric sealing ring and steel end rings welded together on site. At present the pipes available in India use steel end rings welded at site.

6.10 PLASTIC PIPES

6.10.1 GENERAL

Plastic pipes are produced by extrusion process followed by calibration to ensure maintenance of accurate internal diameter with smooth internal bore. These pipes generally come in lengths of 6 meters. A wide range of injection moulded fittings, including tees, elbows, reducers, caps, pipe saddles, joints and threaded adapters for pipe sizes upto 200mm are available.

6.10.2 PVC PIPES

The chief advantages of PVC pipes are:

- ◆ Resistance to corrosion
- ◆ Light weight
- ◆ Toughness
- ◆ Rigidity
- ◆ Economical in laying, jointing and maintenance
- ◆ Ease of fabrication

The PVC pipes are much lighter than conventional pipe materials. Because of their lightweight, PVC pipes are easy to handle, transport, and install. Solvent cementing technique for jointing PVC pipe lengths is cheaper, more efficient and far simpler. PVC pipes do not become pitted or tuberculated and are unaffected by fungi and bacteria and are resistant to a wide range of chemicals. They are immune to galvanic and electrolytic attack, a problem frequently encountered in metal pipes, especially when buried in corrosive soils or near brackish waters. PVC pipes have elastic properties and their resistance to deformation resulting from earth movements is superior compared to conventional pipe materials specially AC. Thermal conductivity of PVC is very low compared to metals. Consequently water transported in these pipes remain at a more uniform temperature.

Rigid PVC pipes weigh only $1/3^{rd}$ of conventional steel pipes of comparable sizes. PVC pipes are available in sizes of outer dia. 21, 25, 32, 50, 63, 75, 90, 110, 140, 160, 200, 250, 290, and 315mm at working pressures of 2,5,4,6, 8 Kg/cm² as per IS 4985 - 1988.

Since deterioration and decomposition of plastics are accelerated by ultraviolet light and

frequent changes in temperature which are particularly severe in India, it is not advisable to use PVC pipes above ground. The deterioration starts with discoloration, surface cracking and ultimately ends with brittleness, and the life of the pipe may be reduced to 15-20 years.

6.10.3 PRECAUTIONS IN HANDLING AND STORAGE

Because of their lightweight, there may be a tendency for the PVC pipes to be thrown much more than their metal counterparts. This should be discouraged and reasonable care should be taken in handling and storage to prevent damage to the pipes. On no account should pipes be dragged along the ground. Pipes should be given adequate support at all times. These pipes should not be stacked in large piles, specially under warm temperature conditions, as the bottom pipes may be distorted thus giving rise to difficulty in pipe alignment and jointing. For temporary storage in the field, where racks are not provided, care should be taken that the ground is level, and free from loose stones. Pipes stored thus should not exceed three layers and should be so stacked as to prevent movement. It is also recommended not to store one pipe inside another. It is advisable to follow the practices mentioned as per IS 7634 – Part 1.

6.10.4 LAYING AND JOINTING PROCEDURE

6.10.4.1 Trench Preparation

The trench bed must be free from any such projections. The trench bottom where it is rocky and uneven a layer of sand or loam earth equal to 1/3 dia of pipe or 100mm whichever is less should be provided under the pipes.

The trench bottom should be carefully examined for the presence of hard objects such as flints, rock, projections or tree roots. In ordinary, relatively soft fine grained soils found to be free of such objects and where the trench bottom can readily be brought to an even finish providing a uniform support for the pipes over their lengths, the pipes may normally be laid directly on the trench bottom. In other cases, the trench should be cut correspondingly deeper and the pipes laid on a prepared under bedding, which may be drawn from the excavated material if suitable.

6.10.4.2 Laying And Jointing

As a rule, trenching should not be carried out in the ahead of pipe laying. The trench should be as narrow as practicable. This may be kept from 0.3m over the outside diameter of pipe and depth may be kept at 0.60 – 0.9m depending upon site conditions. Pipe lengths are placed end to end along the trench. The glued spigot and socket jointing technique as mentioned later is adopted. The jointed lengths are then lowered in the trench and when sufficient length has been laid, the trench is filled.

If tracks, beams, or other heavy on the full pipe across the pipeline, concrete slabs for 600 mm of suitable thickness and suitable width should be laid for at least 150 mm below the pipe to distribute the load. If the pipeline crosses a road, the pipe should be buried at least 200 mm below the level to protect the pipe.

For bending, the cleaned pipe is filled with sand and compacted by tapping with wooden stick and pipe ends plugged. The pipe section is heated with flame and the sand around bent is expanded. The bend is then cooled with water. The pipe can be joined and joined joints and the pipe (bend) cooled again. Heating is done as over the full length and gas or other heating devices are also preferred. Joints may be butt welded, or flanged or with rubber gaskets made with solvent cement. Threaded joints are also feasible but with a few standardized fittings of PVC pipe can be made in following ways:

- i) Solvent cement
- ii) Rubber ring joint
- iii) Flange joints
- iv) Threaded joint

For further details on laying & joining of PVC pipes, reference can be made to IS 4983 - 1988, IS 7634 - Part 1-7.

Socket and spigot joint is usually preferred for all PVC pipes upto 100 mm dia. The socket length should be at least one and half times the outer dia. for sizes upto 100 mm dia. and equal to the outer dia. for larger sizes.

For pipe installation, solvent gluing is preferable to welding. The glued joints of this connection has greater strength than can be achieved by welding. The surfaces to be glued are thoroughly scoured with dry cloth and preferably flamed or 30°. If the pipes have become heavily contaminated by grease or oil, methylene acetone is applied with a brush evenly to the outside surface of the spigot on one pipe and to the inside of the socket on the other. The spigot is then inserted immediately in the socket upto the shoulder and thereafter a quarter (25%) turn is given to evenly distribute the cement over the entire surface. The excess cement which is pushed out of the socket must be removed at once with a clean cloth. Laying must be carried out in all directions possible, care of making complete joint not being more than one minute. Joints should not be disturbed for at least 2 minutes. Full strength is attained in 24 hours and full service life. Care should be avoided in rainy or foggy weather, as the solvent glues with moisture and cloudy is a cause of water contamination.

6.10.4.3 Pre-Fabricated Connections

In laying long lengths of pipe, prefabricated rubber socketed connections are frequently used to join successive pipe lengths of either the same or one size different. The socket in this case must be formed over a size smaller. A short length of pipe is forced or forced over and used as the socket connection. The mandrel used is sized such that the internal dia. of the

flange corker matches the outer dia of the spigot to be connected. By proper sizing of the flange and corker, it is possible to achieve reduction for (variously) 10' pipe diameter in the connection.

6.10.4.4 Standard Threaded Connections

Normally PVC pipes need not be flanged. For connections of PVC pipes to metal piping, pipe or a special thick-walled PVC fitting, a rubber gasket at one end is used. The other end is connected to the normal PVC pipe by means of a glued spigot and socket joint. Before installation, the condition of the threads should be carefully examined for cracks and irregularities.

Clamp can be used for cranking joints. Cast iron and other materials generally used with metal pipe and fittings should not be used. Generally, it is advisable to use PVC as the spigot portion of the joint.

6.10.5 PIPE TESTING METHODS

The section which is to remain in service shall be pipe with water, taking care to avoid air in any part of it and slowly raising the water to a pressure to test pressure. The pressure testing may be followed as follows:

After the specified test time has elapsed, a definite, measured quantity of water is pumped into or forced into the pipe to the design test pressure, if there has been loss of pressure during the test. The pipe shall be judged to have passed the test satisfactorily if the quantity of water required to restore the test pressure of water for 24 hours does not exceed 1.5 times the difference of actual before and after test. (K-1)

6.11 POLYETHYLENE PIPES

Recent years and pipe made of polyethylene pipes have been used for water distribution systems mostly ranging from 10' diameter to considerably up to 300mm.

As long as the water level remains in the same or higher position in both the pipe, these pipes are made of low cost material and offer the flexibility and adaptability etc. to meet the requirements of 10' pipes as per IS 4726-1978. They can be joined with flexible joints and can be done for the same or stitching the pipe into forms or place to provide a tough material for many purposes for 10' pipes are light and tough, they can be done for residential and industrial use. The pipes are easy to lay and can be laid on ground or at trenches. They are available easily for joint with elbows, changing the size of spigots like joints, elbows etc., done by rubber ring fitting and installation. Also, PEHD pipes are easy and install. They are lighter in weight and can be done for bends as on hills. They can withstand the weight of water table. This could not cause damage to the pipes because of their flexibility except for PEHD has excellent flexing properties. They have non-adherent surface when in contact with any fluid. It can work without need to include the flow. PEHD pipes are anti-static and they are smooth inner surface. But there is a risk of friction and pressure loss in comparison with steel.

HDPE pipes can be jointed by welding.

For further details of PVC and HDPE pipes refer to:

IS 7831 - 1975 Parts 1-6

IS 8008 - 1976 Parts 1-7

IS 7631 - 1978 Parts 1-3

IS 7076 - 1985

IS 4984 - 1987

6.11.1 MEDIUM DENSITY POLYETHYLENE (MDPE) PIPES

The medium density Polyethylene Pipes (MDPE) are now being manufactured in India conforming to IS specifications (ISO 1127 and BS 6731 - 1986) for carrying particle water. However no BNS is available for these pipes. The MDPE pipes are being used for construction purposes as an alternative to CI pipes. The Polyethylene material used for making the MDPE pipes conforms to PE 80 grade and the MDPE pipes when used for conveying potable water do not constitute toxic hazard and does not support any microbial growth. Further, it does not impart any taste, odour on contact to the water.

The Polyethylene material conforms to PE 80 grade. The MDPE pipes are colour coded, black with blue strips in sizes ranging from 20 mm to 110 mm dia for pressure class of PN3.2, PN5, PN6.3, PN10 and PN16. The maximum admissible working pressure has worked out for temperature of 20 degrees centigrade as per IS 11497. The pipes are supplied in coils and maximum coil diameter is about 15 times diameter of the pipe.

HDPE compression fittings made of PE, ABS, UPVC are also available in India for use with MDPE pipes. The materials used for the fittings are also suitable for conveying particle water like HDPE pipes. The joining materials of fittings consists of the elastomeric inserts of Polyethylene resin, NBR, CR ring of Nitrile and clamp of Polypropylene, copolymer of 2, 2' zinc plated steel reinforcing ring, nuts and balls of special NBR gasket.

The MDPE pipes are lightweight, robust and non-corrosible and hence can be used as alternative material for construction. Since the pipes are supplied in coils, there will be no joints under the road and hence an excellent roadway in first, single and multi-lane country.

6.12 GLASS FIBRE REINFORCED PLASTIC PIPES (G.R.P. PIPES)

Glass fibre Reinforced Plastic (GRP) pipes are now being manufactured in India conforming to IS 12709. The diameter range is from 50 mm to 2400 mm. The pressure class is 3.6, 5.12 & 15 kg/sq cm (the field test pressure are 15.2, 18.5, 18.2, 15 kg/sq cm). The failure test pressures are 6.12, 18.2, 48.30 kg/sq cm. Depending on the type of installation, overburden above the crown of the pipe and the soil conditions, three types of reinforced glass pipes are available. Sizes are 6, 8, 12 mm. However custom made

height can also be made. The open ends are closed with fire clong pipe terminal (i.e. Glass-enclosed Rubberized Plug) (GEP).

The pipe can be made as per the technical drawing Double Bell coupling (GBC) for GRP to URP, Flange joint (GRP) by URP or as per technical drawing of flanged pipes.

Mechanism of coupling (flange for URP to GRP or steel pipe and Butt - strap joint (GRP) or GBC for GRP).

GRP pipes are corrosion resistant, have smooth surface and high strength to weight ratio. It is lighter in weight compared to metallic and concrete pipes. Longer lengths and hence narrower joints enable faster installation.

GRP pipes are widely used in other countries where corrosion resistant pipes are required in gas-mine areas. GRP can be used as a lining material for conventional pipes, which are subject to corrosion. These pipes can resist external and internal corrosion. The mechanism of corrosion is galvanic or chemical in nature.

6.12.1 PIPE INSTALLATION

GRP pipes being light in weight, can be easily lifted & hoisted by slings, plastic ropes or ropes. Large pipe can be lifted with only one support point or two support points, placed about 1.5m apart. Excavation of trench and back filling of materials is similar to that in the case of conventional pipes.

Installation of GRP pipe using double bell coupling in following manner:

1. Double bell coupling groove on both sides gasket ring should be thoroughly clean & free from dirt or debris.
2. Gasket ring should be made of suitable material of hard strap which is wrapped over both pipe at the groove with pressure.
3. Gasket ring is placed with both ends of the rubber gasket face the gasket groove of pipe and rubber gasket be pushed.
4. Apply a thin film of grease or oil on both ends of the pipe on the lock and attach strap.
5. Attach gasket on both ends of double bell coupling, and align with the pipe section.
6. If the pipe is placed on vehicle or on long pipe, for long distance, the coupling can be pushed on far end of the pipe on the coupling ring.
7. The pipe can then be pushed into the coupling, just as the end of the pipe is being pushed into the coupling.

When pipes are coupled together and both the gasket rings are used, working the joint is similar to that of a normal flange joint. In this case, no reinforced overlap and

mechanical types such as flanged, threaded, compressed air, and other commercial, proprietary joints are available.

6.13 STRENGTH OF PIPES

The stresses in a pipe are normally induced by internal pressure, external loading, surge forces and change of temperature of longitudinal and stresses can also be induced by pressure induced circumferential and longitudinal stresses. The latter due to longitudinal force change in size or direction, to have a closed end a pipe is usually designed so as to carry the circumferential stress without axial stretching or expansion but in the joints cannot safely transmit the longitudinal stress, and changes or some other means of joining. The load may be provided. Longitudinal stress is induced by forces be across the outside surface of the pipe and the material in which the line is buried.

A pipe must withstand the highest internal pressure it is likely to be subjected, the general provisions for which have been discussed in detail in 6.10, while seeping or water between is discussed in 6.17.

External loads generally arise from the weight of the pipe and its contents and that of the trench filling from superimposed loads, such as impact from traffic, from subsidence and from wind loads in the case of pipes laid above ground. If a pipe is laid on good and uniform continuous bed and the cover does not provide a sufficient amount of strengthening to resist external loading is generally better than a casting, likely to arise from subsidence is best dealt with by the use of flexible joint and steel pipes. External loading, however, is important usually when a line is laid on a bed not providing sufficient strength across a sewer, trench or in rock under deep cover or is subjected to heavy superimposed surface loads at less than normal cover. The necessity of stronger pipes can often be avoided by careful bedding and trench filling to give additional support. The imperfections of good bedding under and around the pipe pipe at least the horizontal diameter cannot be overemphasized and in some cases strengthening may be required.

Excess or distortion of a steel pipe may cause failure of its protective coating but can be limited by the use of strengthening rings. Distortion is only likely to arise in very large mains. Distortions at flexible joints can cause leakage.

When a pipeline has to be laid above ground over some obstruction, such as waterway or railway, it may either be carried on a pipe bridge or be supported on pillars. In the latter case, the pipe ends must be properly designed to resist shear, if the full strength of the pipe as a beam is to be realized. A small diameter pipe of small diameter or span over long by with its ends simply supported, but as diameter and lengths of spans increase, the problem becomes more complex and the ends are usually supported in saddles or restrained by ring girders. For pipes of more than 600mm, or at the large girth method will probably succeed, the most economical design. Structural design of buried pipes is discussed in detail in the companion volume "Manual on Sewerage and Wastewater Treatment".

The temperature of the water in a transmission main will vary from 5°C to 15°C if the water is

derived from underground sources the variation is relatively small, but if it is obtained from surface sources and is filtered through slow sand filters, the variation may be as much as 10°C during the year. Furthermore, the temperature changes may take place fairly quickly and for these and other reasons, long lengths of rigid mains are to be avoided. Provision of expansion joints to take care of these stresses is necessary. Thrust and anchor blocks are provided to keep the pipe curve in position. In small mains, i.e. the main with spigot and socket joint joints, the joints themselves allow sufficient movement, although some anchoring may be occasionally necessary. On large steel pipelines with welded joints expansion can be allowed to give a longitudinal stress in the pipe when first laid. In about four years or so, the ground normally consolidates sufficiently around the pipe so that the stress is transferred to the ground. Valves require to be bridged by steel or reinforced concrete heads so that the valve bodies are not stressed, as this could affect their water tightness.

In case of PVC pipelines, it should be noted that the coefficient of expansion of PVC is eight times greater than steel and considerable movement can take place in long lengths of rigid jointed pipelines.

6.13.1. STRUCTURAL REQUIREMENTS

Structurally, closed conduits must resist a number of different forces singly or in combination:

- (a) Internal pressure equal to the full head of water to which the conduit can be subjected (see Appendix 6.15).
- (b) Unbalanced pressures at bends, contractions, and closures which have been discussed in 6.16, 18.
- (c) Water hammer or increased internal pressure caused by sudden reduction in the velocity of the water, by the rapid closing of a gate or sluice door of a pump, for example, which has been discussed in 6.17.
- (d) External loads in the form of traffic, and their own weight is borne external supports (poles or supports). A reference may be made to the Manual on Sewerage and Sewage Treatment.
- (e) Temperature induced expansion and contraction, which is discussed in 6.13.3.

Internal pressure, including surge pressure, creates transverse stress or hoop tension, bends and closures at dead ends or gates produce unbalanced pressures and longitudinal stress. When conduits are not permitted to change length, variations in temperature likewise create longitudinal stress. External loads and foundation reactions (nature of support), including the weight of the full conduit, and atmospheric pressure (when the conduit is under vacuum) produce flexural stress.

6.13.4 DEPTH OF COVER

The traffic cover on pipeline is normal and generally sufficient to protect the Pipes from external damage. When heavy traffic is anticipated, depth of cover has to be arrived at taking into consideration the structural and other aspects as detailed in 6.13.2. Where freezing is anticipated, a 500 mm extra is normally added as extra cover in 6.13.2.

6.14 ECONOMICALLY SIZED CONVEYING MAIN

6.14.1 GENERAL CONSIDERATIONS

When the source is separated by a long distance from the area of consumption, the conveyance of the water over the distance involves the provision of a pressure pipeline or a free flow conduit including an appreciable capital outlay. The most economical arrangement for the conveyance is a discrete one of importance.

The available fall from the source to the town and the ground profile in between should generally help to decide if a free flow conduit is feasible. Once this is decided, the material of the conduit can be selected keeping in view the local costs and the nature of the terrain to be traversed. Even when a fall is available, a pumping or force main independently or in combination with gravity main could also be considered. Optimization technique may need to be adopted in such decisions. The most economical size for the conveyance main will be based on a power analysis of the following factors:

- (a) The period of design considered or the period of loan repayment if it is greater than the design period for the project and the quantities to be conveyed during different phases of such period.
- (b) The different pipe sizes against different hydraulic slopes which can be considered for the quantity to be conveyed.
- (c) The different pipe materials which can be used for the purpose and their relative costs as laid in position.
- (d) The rate, capacity and installed cost of the pumps set required against the corresponding sizes of the pipelines and the installation.
- (e) The recurring costs on:
 - (i) Energy charges for running the pump sets.
 - (ii) Staff for operation of the pump sets.
 - (iii) Cost of repairs and renewals of the pump sets.
 - (iv) Cost of miscellaneous consumable stores and
 - (v) Cost of replacement of the pumpsets installed to meet the immediate requirements by new sets at an intermediate stage of design period. The full design period or the repayment period may be 30 years or more while the

pumps are designed to serve a period of 15 years.

6.14.2 EVALUATION OF COMPARABLE FACTORS

Every alternative, when analyzed on the above lines, could be evaluated in terms of cost figures on a common comparable basis by

- (i) Capital cost of the most suitable pipe material as laid and jointed and ready for service, including cost of valves and fittings and all accessories to the pipeline.
- (ii) (a) Capital cost, as installed, of the necessary pump sets corresponding to the pipeline size in (i) above.
- (b) The amount which should be invested at present such as would yield with compound interest, the amount necessary to replace the pumps in (ii) (a) at the end of their useful life with bigger pumps for once or often to cater to the requirements during the design period or the loan repayment period.
- (iii) Energy charges: if the pumps in (ii) (a) are designed to serve for, say 15 years, the daily pumping will vary from the initial requirements to the intermediate demand after 15 years. The energy charges will be based on the average of these two daily pumpages, leading to an average annual expenditure on energy charges on such basis.

The replacing of pumps under (ii) (b) will, likewise, involve annual recurring energy charges for the average of the demands during the subsequent 15 years period for the project design or the loan repayment period whichever is greater.

The two annual recurring costs should be capitalized for inclusion as a part of the present investment. For this purpose it is necessary to derive:

- (a) The amount of the present investment which would yield an annuity for 15 years equal to the annual energy charges on the initial pump sets, and
- (b) The amount of present investment which would commence to yield, over the subsequent 15 years period, the annual energy charges for the replaced pumps in (ii) (a),
- (c) Apart from the energy charges, the other recurring annual charges composing the cost of operation and maintenance staff, ordinary repairs and miscellaneous consumable stores.

The present investment which would yield an annuity equal to such annual recurring charges throughout the design period, or loan repayment period (if it exceeds the former), would represent the capitalized cost, for inclusion as part of the total investment now required.

- (iv) The addition of the present investment figures as worked out under (i), (ii), (iii), (ii) (a), (ii) (b), (ii) (c) and (iv) would represent the total capital investment called for in

the cost of the water treatment process is a function of the population size and the existing pipe network. A large population leads to the construction of a large network and the second item, existing pipe network, has an impact on the cost of access of the water to the water supply network. Therefore:

- (i) water supply network is a function of the population size and the existing pipe network, and (ii) the cost of the water supply network is a function of the population size and the existing pipe network.

Table 5: Water supply network design

Water supply network design includes the design of the water supply network and the pipe network. The design of the water supply network is a function of the population size and the existing pipe network. The design of the pipe network is a function of the population size and the existing pipe network. The design of the water supply network and the pipe network is a function of the population size and the existing pipe network. The design of the water supply network and the pipe network is a function of the population size and the existing pipe network.

Table 6: Public Cost-User Benefit Analysis (CUBA)

There are three independent factors relating to the problem of the design of a water supply network. First, the population size, second, the pipe network, and third, the cost of the water supply network. The design of the water supply network is a function of the population size and the existing pipe network. The design of the water supply network and the pipe network is a function of the population size and the existing pipe network. The design of the water supply network and the pipe network is a function of the population size and the existing pipe network.

The water supply network design includes the design of the water supply network and the pipe network. The design of the water supply network is a function of the population size and the existing pipe network. The design of the pipe network is a function of the population size and the existing pipe network. The design of the water supply network and the pipe network is a function of the population size and the existing pipe network. The design of the water supply network and the pipe network is a function of the population size and the existing pipe network.

The water supply network design includes the design of the water supply network and the pipe network. The design of the water supply network is a function of the population size and the existing pipe network. The design of the pipe network is a function of the population size and the existing pipe network. The design of the water supply network and the pipe network is a function of the population size and the existing pipe network. The design of the water supply network and the pipe network is a function of the population size and the existing pipe network.

The design of the water supply network and the pipe network is a function of the population size and the existing pipe network. The design of the water supply network and the pipe network is a function of the population size and the existing pipe network. The design of the water supply network and the pipe network is a function of the population size and the existing pipe network. The design of the water supply network and the pipe network is a function of the population size and the existing pipe network.

for design variables and/or total cost (see Section 6.3.1).

Whether the pipe size is based on the flow, or pipe material, or the life cost of the pipe, or other factors, the comparison will be more complex after payments of the loan, since the influence of the taxable factor on the comparison will be less in the former case, the method is to be preferred.

6.3.4.5 RECURRING CHARGES-LESS THAN PRESENT VALUE PERIODICITY

Annual recurring charges (e.g., energy and operation and maintenance) are properties respectively of the design variable itself or of its pipe size. Their cost period is restricted to the design period or the loan repayment period, whichever is greater, when following the comparison method relevant to that period. If a design option involves a higher alternative (otherwise a possible modification) to be considered, a comparison can be made which would yield an interest to meet their recurring charges to justify it. It is better to make the loan and to consider capitalization of the recurring charges over the full service life, or over the period.

6.3.4.6 CAPITALIZATION VS ANNUITY METHODS

In tabularly, the comparison suggested above the loan or pipe or capitalized value. In the alternative, the capital is sufficient to cover the recurring charges concerned over the loan or the design period, or loan repayment period, whichever is greater, in the same way as a loan discharged through annuity and such a security added to the other amount recurring charges for a total comparison between the amount of

6.3.4.7 SELECTION

The method suggested in 6.3.4.5 will give a comparison between the total capital investment involved whereas the method suggested in 6.3.4.6 will judge the amounts involved in between the alternatives. A better concept is perhaps provided by the former method.

The most economical size of a pipe can be proved by evaluating the capital and maintenance cost (capitalized value) for different diameters. Other cost solutions are also possible. The objective function may be considered as a consequence of the system performance, because optimization techniques are available for minimizing a objective function. One of the simpler methods is one in which the design problem may be cast partial derivatives with respect to the several decision variables in an equal or one of the resulting system of equations is solved exactly or approximately to find the principal members of the determinant of second partial derivatives are investigated to determine whether a maximum or minimum is involved (see Appendix 6.5).

While determining the type of raw pipe material to be used, alternative payments, cost of cross-country works, cost of valves, manholes and other appurtenances, should all be

considered to determine the most economical site for the conveying shaft.

6.15 CORROSION

Causes of corrosion and the protective and preventive measures have been discussed in 9.8.

6.16 APPURTENANCES

To isolate and drain pipe sections for test, installation, cleaning and repairs, a number of appurtenances or auxiliaries are generally installed in the line.

6.16.1 LINE VALVES

Main line valves are provided to stop and regulate the flow of water in the course of ordinary operations and in an emergency. There are many types of valves for use in pipeline, the choice of which depends on the duty. The spacing varies principally with the terrain traversed by the line. In urban areas with connections in the distribution system, main aim is to start/raise the line in order to maintain reasonable service. In larger lines isolating valves are frequently installed at intervals of 1 to 3 km. The principal considerations in location of the valves are accessibility and proximity to special points such as branches, stream crossings etc. The spacing of valves is a function of economics and operating problems. Sections of the pipeline may have to be isolated to repair leaks. The volume of water which would have to be drained to waste would be a function of spacing of isolating valves.

These valves are usually placed at major points of pressure conduits. Surrants identify the sections of the line that can be drained by gravity, and pressures are least at these points permitting cheaper valves and easier operation. Gravity conduits are provided with valves at points strategic for the operation of supply points, at the two ends of sagg pipes and wherever it is convenient to drain the given section.

Normally valves are sized slightly smaller than the pipe diameter and installed with a reducer on either side. In choosing the size, the cost of the valve should be weighed against the cost of head loss through it, although in certain circumstances it may be desirable to maintain the full pipe bore (to prevent erosion or blockage).

It is sometimes advisable to install small diameter bypass valves around large diameter main valves to equalize pressures across the gate and thus facilitate opening.

6.16.1.1 Sluice Valves

Sluice valves or gate valves are the normal type of valves used for isolating or scouring. They seal well under high pressures and when fully open, offer little resistance to fluid flow. There are two types of spindles for raising the gate: a rising spindle which is attached to the gate and does not rotate with the hand wheel, and a non rising spindle which is rotated in a screwed attachment in the gate. The rising spindle is easy to fabricate.

The gate may be parallel sided or wedge shaped. The wedge gate seals best, but may be

damaged by grit. For low pressure, resilient or gummetal seating faces may be used. For high pressure, stainless steel seals are preferred.

Sluice valves are not intended to be used for continuous throttling, as erosion of the seats and body cavitation may occur. If small flows are required the bypass valve is more suitable for this duty.

Despite sluice valve's simplicity and positive action, they are sometimes troublesome to operate. They need a big force to raise them against high unbalanced pressure and large valves take many minutes to turn open or closed, for which power operated or manual operated actuators are also used. Some of these problems can be overcome by installing a valve with a smaller bore than the pipeline diameter.

In special situations variations of sluice valves suited to the needs are used, needle valves are preferred for fine control of flow, butterfly valves for ease of operation and cone valves for regulating the time of closure and controlling water hammer.

6.16.1.2 Butterfly Valves

Butterfly valves are used to regulate and stop the flow especially in large size conduits. They are sometimes cheaper than sluice valves for larger sizes and occupy less space. Butterfly valves with no sliding parts have the advantages of ease of operation, compact size, reduced chamber or valve house and improved closing and retarding characteristics.

These would involve slightly higher head loss than sluice valves and also are not suitable for continuous throttling. The sealing is sometimes not as effective as for sluice valves especially at high pressures. They also offer a fairly high resistance to flow even in fully open state, because the thickness of the disc obstructs the flow even when it is rotated to fully open position. Butterfly valves as well as sluice valves are not suited for operation in part open positions as the gates and seatings would corrode rapidly. Both types require high torques to open them against high pressure, they often have geared hand wheels or power driven actuators.

Butterfly Valves with loose seating ring are sometimes not effective, especially at higher pressures. Butterfly valves with fixed liner can overcome this shortcoming, further the butterfly valves with fixed liner needs no frequent maintenance for replacement of seating ring as in the case of butterfly valves with loose seating ring. The fixed liner design butterfly valves are now available in India suitable for working pressures up to 15 kg/cm² on. Presently there is no IS for the fixed liner Butterfly valves.

6.16.1.3 Globe Valves

Globe valves have a circular seat connected axially to a vertical spindle and hand wheel. The seating is a ring perpendicular to the pipe axis. The flow changes direction through 90° twice thus resulting in high head losses. These valves are normally used in small bore pipe work and as taps, although a variation is used as a control valve.

6.16.1.4 Needle And Cone Valves

Needle valves are more expensive than gate and butterfly valves but are well suited for throttling flow. They have a gradual throttling action as they close, whereas sluice valves and butterfly valves offer little flow resistance until practically shut and may suffer cavitation damage. Needle valves may be used with counter balance weights, springs, or actuators to maintain constant pressure conditions either upstream or downstream of the valve or to maintain a constant flow. They are resistant to cavitation at high flow velocities. The method of seating is to push an axial needle or spike through a seat. There is often a pilot needle which operates first to balance the forces before opening. The cone valve is a variation of the needle valve but the seal is achieved in a way from the pipe axis instead of being withdrawn axially.

The main disadvantage of these valves are that they are not normally used in water supply but are occasionally used as check valves when needed to be electric or hydraulic operated.

6.16.2 SCOUR VALVES

In pressure conduits, scumming or oil film formation, blow off or scum valves are provided at low points where line valves situated in the line with a slope such that such sections of the line between valves can be emptied and cleared completely. They discharge into natural drainage channel or empty into a sump from which water can be pumped to waste.

The main location of scum valves is the point indicated by opportunities to discharge off the water. Where a main crosses a stream or drainage structure, there will usually be a low point in the line but if the main goes under the stream or drain, it cannot be completely drained into the channel. In such a situation, it is better to locate a scum contraction at the lowest point that will drain by gravity and install for pumping out the part below the drain pipeline.

There should be no direct connections to sources of polluted watercourses except through a specially designed trap chamber, or via float valves. Any blow off valves are placed in series.

The outlet into the main should be above the high water line. If the outlet must be below high water a check valve must be placed to prevent back flow.

The size depends on local circumstances and is dependent upon the time in which a given section of line is designed to be emptied and upon the existing velocity of flow. Calculations are based upon either the time taken to fill the line or upon the difference in elevation of the water surface in the conduit and the blow off less the friction head. Frequency of operation depends upon the quality of the water and it is usually on all leads.

6.16.3 AIR VALVES

When a pipeline is filled air could be trapped in a pocket along the profile thereby increasing head losses and reducing the capacity of the pipeline. It is also undesirable to have air pockets in the pipe as they may cause air hammer or pressure fluctuations during operation of the pipeline. Other problems due to air include corrosion, reduced pump efficiency,

method (range of about 0.5 to 1.0) and the standard deviation (range of 0.1 to 0.2) are normally used to define a normal distribution. In practice, our estimates have a standard deviation of 0.1 or smaller. Additionally, we assume that about 95% of these any number of individuals will be within one standard deviation of the population mean operation.

When an activity is performed with a goal and the individual is able to adjust to it, it can be possible to do it better than normally.

As a result, we have to consider the possibility that variations in the degree of practice to perform a particular sign will cause the normal distribution. As a result, the "possibility" of a problem is not necessarily a design rule, and removal of it will be needed for accurate assessment of the overall quality of the product or system.

For all of these, it is also important to be aware of the fact that variations in the normality of other parts of the system can also cause variations in the overall quality of the product or system.

For the sake of a total quality management program, it is important to be aware of the fact that variations in the degree of practice to perform a particular sign will cause the normal distribution. As a result, the "possibility" of a problem is not necessarily a design rule, and removal of it will be needed for accurate assessment of the overall quality of the product or system. Additionally, we assume that about 95% of these any number of individuals will be within one standard deviation of the population mean operation. When an activity is performed with a goal and the individual is able to adjust to it, it can be possible to do it better than normally. As a result, we have to consider the possibility that variations in the degree of practice to perform a particular sign will cause the normal distribution. As a result, the "possibility" of a problem is not necessarily a design rule, and removal of it will be needed for accurate assessment of the overall quality of the product or system.

Special designs for activities are possible which can be performed with a high degree of accuracy. In general, these are used in order to be able to perform a task for the first time. In general, these are used in order to be able to perform a task for the first time.

For the sake of a total quality management program, it is important to be aware of the fact that variations in the degree of practice to perform a particular sign will cause the normal distribution. As a result, the "possibility" of a problem is not necessarily a design rule, and removal of it will be needed for accurate assessment of the overall quality of the product or system. Additionally, we assume that about 95% of these any number of individuals will be within one standard deviation of the population mean operation. When an activity is performed with a goal and the individual is able to adjust to it, it can be possible to do it better than normally. As a result, we have to consider the possibility that variations in the degree of practice to perform a particular sign will cause the normal distribution. As a result, the "possibility" of a problem is not necessarily a design rule, and removal of it will be needed for accurate assessment of the overall quality of the product or system.

As a result, we have to consider the possibility that variations in the degree of practice to perform a particular sign will cause the normal distribution. As a result, the "possibility" of a problem is not necessarily a design rule, and removal of it will be needed for accurate assessment of the overall quality of the product or system. Additionally, we assume that about 95% of these any number of individuals will be within one standard deviation of the population mean operation. When an activity is performed with a goal and the individual is able to adjust to it, it can be possible to do it better than normally. As a result, we have to consider the possibility that variations in the degree of practice to perform a particular sign will cause the normal distribution. As a result, the "possibility" of a problem is not necessarily a design rule, and removal of it will be needed for accurate assessment of the overall quality of the product or system.

valves in the streets, it being the routine duty of a turncock in the area to pit the mains, to minimize the risk of serious contamination, is yet another practice.

The following ratios of air valves to conduit diameter provide common but rough estimates of needed sizes:

For release of air only 1:12

For admission as well as release of air 1:8

An analysis of air-inlet valves for steel pipelines, Parnakian takes the compressibility of air into account and combines equations for safe differential pressures of cylindrical steel pipe, pipeflow, and air flow, in the following approximate relationships:

$$d_v/d = 1.99 \times 10^{-2} \sqrt{\frac{\Delta V}{C}} \left[1 - \frac{P_2}{P_1} > 0.288 \right]^{-0.25} \quad (6.15)$$

for $P_2 > 0.53 P_1$ and as

$$d_v/d = 3.91 \times 10^{-2} \sqrt{\frac{\Delta V}{C} \frac{P_2/P_1}{P_1/P_2}}^{0.18} \quad (6.16)$$

for $P_2 \leq 0.53 P_1$, because air flow cannot increase beyond a critical differential of 0.488 Kgf/cm².

In these equations, d_v and d are respectively the diameter of the air orifice and pipe, ΔV is the difference in the velocities of flow on each side of the inlet valve, C is the coefficient of discharge of the valve, and P_2 and P_1 are the pressures inside and outside the pipe respectively, with $P_1 - P_2$ not exceeding one half the collapsing pressure as a matter of safety.

The equations apply strictly only to elevations of 304.8 m above mean sea level at 40 degrees latitude ($g = 9.81$ mps²) temperatures of 25.32°C, 20% humidity, an adiabatic expansion for which $p_2 v_2^{\gamma} = p_1 v_1^{\gamma}$, the air occupying a volume of 0.87 cum/Kgf.

6.16.3.1 Air Release Valves

Air Release valves are designed specifically to vent, automatically and when necessary, air accumulations from lines in which water is flowing. Such accumulations of air tend to collect at high points in the pipeline. Air which accumulates at such points, reduces the useful cross sectional area of the pipe, and therefore induces a friction head factor that lowers the pumping capacity of the entire line. The use of air release valves eliminates the possibility of this air binding and permits the flow of water without damage to pipeline.

Small orifice air valves are designated by their inlet connection size, usually 12 to 50 mm diameter. This has nothing to do with the air release orifice size which may be from 1 to 13 mm diameter. The larger the pressure in the pipeline, the smaller need be the orifice size. The volume of air to be released will be a function of the air entrained which is on the

average 2% of the volume of water (at atmospheric pressure).

The small orifice release valves are sealed by a floating ball, or needle which is attached to a float. When a certain amount of air has accumulated in the connection on top of the pipe, the ball will drop or the needle valve will open and release the air. Small orifice release valves are often combined with large orifice air vent valves on a common connection on top of the pipe. The arrangement is called a double air valve. An isolating sluice valve is normally fitted between the pipe and the air valves.

Double air valves should be installed at peaks in the pipeline, both with respect to the horizontal and the maximum hydraulic gradient. They should also be installed at the ends and intermediate points along a length of pipeline which is parallel to the hydraulic grade line. It should be borne in mind that air may be dragged along in the direction of flow in the pipeline and may even accumulate in sections falling slowly in relation to the hydraulic gradient. Double air valves should be fitted every 1/2 to 1 KM along descending sections, especially at points where the pipe dips sharply.

Air release valves should also be installed all along ascending lengths of pipeline where air is likely to be released from solution due to the lowering of the pressure, again especially at points of decrease in gradient. Other places where air valves are required are on the discharge side of pumps and at high points on large mains and upstream of orifice plates and reducing tapers.

Air Relief devices are provided at the first summit of the line to remove air that is mechanically entrained as water is drawn into the entrance of the pipeline.

6.16.3.2 Air Inlet Valves

In the design and operation of large steel pipelines, where gravity flow occurs, considerations must be given to the possibility of collapse in case the internal pressure is reduced below that of atmosphere. Should a break occur in the line at the lower end of a slope, a vacuum will in all probability be formed at some point upstream from the break due to the sudden rush of water from the line. To prevent the pipe from collapsing, air inlet (vacuum breaking) valves are used at critical points.

These valves, normally held shut by water pressure, automatically open when this pressure is reduced to slightly below atmospheric, permitting large quantities of air to enter the pipe, thus effectively preventing the formation of any vacuum. In addition to offering positive protection against extensive damage to large pipelines, by prevention of vacuum, they also facilitate the initial filling of the line by the expansion of air whenever the valves are installed.

Air inlet valves should be installed at peaks in the pipeline, both relative to the horizontal and relative to the hydraulic gradient. Various possible hydraulic gradients, including reverse gradients during scouring, should be considered. They are normally fitted in combination with an air release valve.

6.16.8 PRESSURE-REDUCING VALVES

These are used to automatically maintain a reduced pressure within reasonable limits in the downstream side of the pipeline. This type of valve is always in movement and requires scheduled maintenance on a regular basis. This work is facilitated if the valve is fitted on a bypass with isolating valves on either side to proceed without taking the route out of service. If the pressure-reducing valve is fitted on the main pipeline, a bypass can be provided for emergency use. Needle-type valves which can be hydraulically controlled or easily operated with a pressure regulator are used for large aqueducts etc.

6.16.9 PRESSURE SUSTAINING VALVES

Pressure sustaining valves are similar in design and construction to pressure-reducing valves and are used to maintain automatically the pressure on the upstream side of the pipeline.

6.16.10 BALL VALVES OR BALL FLOAT VALVES

Ball valves or ball float valves are used to maintain a constant level in a service reservoir or elevated tank or standpipe. The equilibrium type of valve is the most effective and it is designed to ensure that the forces on each side of the piston are nearly balanced. For severe operating conditions, a more expensive needle-type valve will give better service.

In both cases the float follows the water level in the reservoir and permits the valve to admit additional water on a falling level and less water on a rising level and to close entirely when the overflow mark is reached. The disadvantage of this system is that the valve may operate for long periods in a closed condition, but this can be avoided by arranging for the float to float in a small auxiliary cylinder or a tank. When the water reaches the top of the auxiliary tank, the ball will rise fairly quickly from the fully open position to the closed position without shock. The valve will not open again until the water level in the reservoir reaches the base of the auxiliary tank, at which point the water will drain away and the ball valve will move to the fully open position. With this method the valve is not in a state of almost continuous movement and through and across of the seats are avoided.

6.16.11 AUTOMATIC SHUT-OFF VALVES

These are used on the main to close automatically when the velocity in the main exceeds a predetermined value in case of accident in the line.

6.16.12 AUTOMATIC BURST CONTROL

With large steel mains suitably protected against corrosion and laid properly, particularly a change of direction and the ground is not liable to subsidence, the possibility of a major burst is reduced.

The simplest arrangement to explain in 6.16.12 is to insert an interrupter joint in the main and to arrange that the final quarter inch of a check valve occurs in slow steps to the point of danger. The costlier arrangement will be insertion of a smaller power-operated

bypass valve alongside the main valve and provision of automatic control arrangements for the main valve to close first at a fairly rapid rate, followed by the smaller bypass valve at a much lower speed.

6.16.13 VENTURIMETERS

These are used to measure the flow in line and are discussed in 4.3.1.1.

6.16.14 SPACING OF VALVES AND INTERCONNECTIONS

The pipeline should be divided into sections by valves to avoid the necessity of emptying the whole pipeline in case of repair, each section being provided with an air valve and scouring facilities. The need for scour should be particularly borne in mind when layout of the pipeline and siting of the valves is finalized, as they cannot always be arranged in the best position due to likely difficulty in disposing of the discharge. They are necessary for scouring the mains and hence should be in proportion to the size of the main.

It is desirable to have valves close together in more densely built up areas. Ease of access to the valves is also important as the time taken in shutting off a valve in an emergency may be mostly spent in reaching it. In gravity mains, automatic valves, self-closing if pipe bursts, may also be provided for protection to property as well as to prevent excessive wastage of water.

Where there is more than one pipeline, they should be interconnected at each site of main valves, so that only shortest possible length of one pipeline need be put out of commission at a time. The interconnection will entail only negligible loss of head if its area is not less than two-thirds that of the largest main.

Also, when two or more mains are connected in parallel, the mains may be interconnected so that either main can be filled from the other while the other valve is shut. Chopping through a sewer can be done steadily with less risk than chopping over a scratch, the danger of surging from trapped air being much reduced.

Bypasses around the main valves are convenient for regulating the flow during the changing or emptying of a pipeline and may be a part of the main valve itself, or arranged as a connecting between trees on each side of the valve. Bypasses may also be provided in order to allow a pump suction on each side of the main valve before attempting to open it up.

6.16.15 MANHOLES

Access manholes are spaced 300 to 600m apart on large conduits. They are helpful during construction and serve later on for inspection and repairs. Their most useful positions are at junctions, discharges, and flow reversal of main valves. They are less common on cast iron and asbestos-cement lines than on steel and concrete lines.

6.16.16 INSULATION JOINTS

These are used to introduce resistance to the flow of stray electric currents along metallic pipelines and may help in the control of electrolysis. Modern insulation joints make use of

rubber gaskets or rings and of rubber covered sections of pipe if they are sufficiently long to introduce appreciable resistance.

6.16.17 EXPANSION JOINTS

Expansion joints are not needed if the pipe joints themselves take care of the pipe movements induced due to temperature changes, which is mostly the case for long buried pipes without any bend or dip. Steel pipes laid with rigid transverse joints particularly in the open, must either be allowed to expand at definite points or its motion be rigidly restrained by anchoring the line.

6.16.18 ANCHORAGES

Anchorages are necessary to resist the tendency of the pipes to pull apart at bends or other points of unbalanced pressure, or when they are laid on steep gradients and the resistance of their joints to longitudinal (shearing) stresses is either exceeded or inadequate. They are also used to restrain or direct the expansion and contraction of rigidly joined pipes under the influence of temperature changes. The unbalanced static pressure at ends computed by the expression $1/2 \pi d^2 p \sin \alpha/2$ with the two component pressures in the direction of each pipe leg being $1/4 \pi d^2 \alpha p$ (where d = dia of pipe, α = degree of bend and p the water pressure in the pipeline) is compared with the magnitude of the resistance of the pipe joint (which is 14.3% Kg/cm^2 for lead joint) and anchorages are designed to resist the balance force. Horizontal thrust F at Bend = $2 A \beta \sin \alpha/2$, where β = internal pressure in Kg/cm^2 , A area of pipe in sq cms, and α is angle of deviation of pipe in degrees.

Anchorages take many forms. For bends, both horizontal and vertical they may be designed as concrete buttresses or "kick blocks" that resist the unbalanced pressure by their weight, in much the same manner as a gravity dam resists the pressure of the water that it impounds. The resistance offered by the pipe joints themselves, by the friction of the pipe exterior and by the bearing value of the soil in which the block is buried may be taken into consideration if the cost of the block is to be a minimum. Steel straps attached to heavy boulders or to bedrock are used in place of buttresses where it is possible and convenient to do so.

The unbalanced thrust may be counteracted by longitudinal tension in an all-welded pipeline, or by a concrete thrust block bearing against the foundation material. In the case of a jointed pipeline the size of the block may be calculated using soil mechanics theory. In addition to frictional resistance on the bottom of the thrust block and the circumference of the pipeline, there is a lateral resistance against the outer face of the pipe and block. The maximum resisting pressure a soil mass will offer is termed the passive resistance and is given by

$$f_p = \gamma_s \cdot h \left[\frac{1 + \sin \theta}{1 - \sin \theta} \right] + 2c \sqrt{\frac{1 + \sin \theta}{1 - \sin \theta}} \quad (6.17)$$

The lateral resistance of soil against the thrust block

$$F_p = \gamma_s \frac{H^2}{2} l \left[\frac{1 - \sin \theta}{1 + \sin \theta} \right] + C \cdot H l \left[\frac{1 - \sin \theta}{1 + \sin \theta} \right] \quad (8.16)$$

This maximum possible resistance will only be developed if the thrust block is able to move into the soil mass slightly. The corresponding maximum soil pressure is termed the passive pressure. The minimum pressure which may occur on the thrust block is the active pressure, which may develop if the thrust block acts free to yield away from the soil mass.

$$F_a = \gamma_s \frac{H^2}{2} \left[\frac{1 + \sin \theta}{1 - \sin \theta} \right] + C \cdot H \left[\frac{1 + \sin \theta}{1 - \sin \theta} \right] \quad (8.17)$$

F_p = lateral resistance of soil against the thrust block in tons,

F_a = lateral resistance of soil against the projection of pipe in tons/ft²,

γ_s = soil density in T/m³,

H = depth in m,

θ = angle of friction in degrees,

C = cohesion of soil in N/cm²,

C = 0 for gravel and sand, 0.02 for silt, 0.03 for dense clay or 0.12 for soft saturated clay,

H = height of thrust block in m,

l = the length of thrust block in m,

The active pressure is considerably less than the passive pressure and will only be developed if the force on which it is acting is free to move away from the soil exerting the pressure.

A thrust block should be designed so that the line of action of the resultant of the resisting forces coincide with the line of thrust of the pipe. This will prevent occurrence of unbalanced stresses. This may best be done graphically or by taking moments about the centre of the pipe. Anchor blocks for expansion joints can also be designed on the basis of

✓ S.S.5330-1984

Thrust blocks are needed not only at changes in vertical or horizontal alignment of the pipeline, but also at fittings that may not be able to transmit longitudinal forces such as flexible couplings.

When laying a pipe parallel to an existing pipe, the trench excavation for a bend would deprive the existing pipe of the needed support. The simplest solution is to stop the flow in the original pipe while the work is carried out and a new thrust block is constructed, but




FIGURE 6.1 : THRUST AT A BEND & THRUST BLOCK

6.17.2 COMPUTATIONS

Maximum water hammer pressure (which occurs at the critical time of closure t_c or any time less than T_c) is given by the expression,

$$P_{max} = \frac{\rho \cdot V \cdot C}{g} \quad (6.17)$$

Where,

P_{max} = maximum pressure rise in the closed main due to the normal pressure in psi

C = velocity of pressure wave travel in m/s,

g = acceleration due to gravity in m/s

V = normal velocity in the pipeline, before sudden closure in m/s

$$C = \frac{1425}{\sqrt{\frac{1}{E} + \frac{k}{B C_1}}} \quad (6.18)$$

Where,

k = bulk modulus of water (2.07×10^9 kg/cm²)

d = diameter of pipe in m,

C_1 = wall thickness of pipe in m and

E = modulus of elasticity of pipe material in kg/cm²

Table 6.7 gives values of E that may be adopted for different materials:

TABLE 6.7: VALUES OF E FOR DIFFERENT MATERIALS

Material	E (Kg/cm ²)
Polyethylene - soft	1.2×10^7
Polyethylene - hard	2×10^7
P.V.C	3×10^7
Concrete	2.8×10^8
Asbestos Cement	3×10^8
Reinforced Cement Concrete	3.1×10^8
Prestressed Concrete	3.3×10^8
Cast Iron	7.5×10^8
Ductile Iron	1.7×10^9
Wrought Iron	1.8×10^9
Steel	2.1×10^{10}

the flow of gas of course, but it is not in the direction of the flow of gas, and the rate of flow is not constant, and it is not in the direction of the flow of gas.

The flow of gas is not constant, and it is not in the direction of the flow of gas, and the rate of flow is not constant, and it is not in the direction of the flow of gas.

of the flow of gas of course.

The flow of gas is not constant, and it is not in the direction of the flow of gas, and the rate of flow is not constant, and it is not in the direction of the flow of gas.

The flow of gas is not constant, and it is not in the direction of the flow of gas, and the rate of flow is not constant, and it is not in the direction of the flow of gas.

The flow of gas is not constant, and it is not in the direction of the flow of gas, and the rate of flow is not constant, and it is not in the direction of the flow of gas.

The flow of gas is not constant, and it is not in the direction of the flow of gas, and the rate of flow is not constant, and it is not in the direction of the flow of gas.

The flow of gas is not constant, and it is not in the direction of the flow of gas, and the rate of flow is not constant, and it is not in the direction of the flow of gas.

The flow of gas is not constant, and it is not in the direction of the flow of gas, and the rate of flow is not constant, and it is not in the direction of the flow of gas.

supply of water into the receiving pipes. In case of sudden power failure, the flow rate up to the possible flow rate through the discharge pipe is likely to increase and may cause the discharge pipe to burst through the pipe. In such a case, the discharge pipe should be checked.

6.17.3.1 *Kamudhar* (Water Hammer) and *Kamudhar* (Water Hammer)

The flow of water in a pipe is stopped suddenly when the pump is stopped. The flow of water in the pipe is stopped suddenly when the pump is stopped. The flow of water in the pipe is stopped suddenly when the pump is stopped. The flow of water in the pipe is stopped suddenly when the pump is stopped.

6.17.3.2 *Kamudhar* (Water Hammer) (Continued)

Water hammer is a phenomenon which occurs when the flow of water in a pipe is stopped suddenly. The flow of water in the pipe is stopped suddenly when the pump is stopped. The flow of water in the pipe is stopped suddenly when the pump is stopped. The flow of water in the pipe is stopped suddenly when the pump is stopped.

6.17.3.3 *Kamudhar* (Water Hammer) for Sudden Shut Off of Pump

When the power supply to the pump is suddenly cut off, the water in the pipe is stopped suddenly. The flow of water in the pipe is stopped suddenly when the pump is stopped. The flow of water in the pipe is stopped suddenly when the pump is stopped.

(a) *Start-Up Effects on Discharge Line*

When the pump is started, the water in the pipe is stopped suddenly. The flow of water in the pipe is stopped suddenly when the pump is started. The flow of water in the pipe is stopped suddenly when the pump is started.

In some cases a surge relief, called for, is to be near the outlet end of the line. Depending on the size of the line and the pressures involved, it may be an air chamber, a relief valve, or an open overflow which lets the encroaching water spill out of the pipeline above some pre-determined elevation. Although provision to surge at the outlet end of the line will not, in most cases, prevent all surges of flow, it does tend to cushion shock there and at the same time decreases the magnitude of the returned flow that is thrown back toward the pump.

Two devices are commonly used for cushioning shock in the discharge line at a pump. The first concerns the situation where flow is non-reversible at the pump. The ordinary swing check valve tends to shut off on reversal of flow, thus causing, unnecessarily, severe shock pressure. This trouble can be avoided by using a non-flow filling disc check valve, or some form of counter-pressure valve which is controlled by a relay actuated from the power circuit or discharge pressure of the pump. Immediately on power interruption, the relay acts to start closing the valve so as to permit gradual closure to be reached to complete closure before reversal of flow can take place. In some cases a spring loading device can be used successfully on a swing-check valve to cushion during the opening before the valve is closed.

Although the size and design change the amount to be expected with an ordinary swing check, they cannot prevent a considerable rise in pressure when reversal of flow is stopped at the check valve. Hence, a surge device in the nature of a accumulator is required which may take the form of an air chamber or a relief valve of ample size. Air chambers sometimes perform so effectively when damped with orifices or check valves to the connecting pipe.

The necessity of replenishing the air in air chambers should be recognized in considering high pressure water hammer suppressors. In some cases, restricting the passages between the pipeline and the air chambers increases the effectiveness of a given size of air chamber suppressors as a general rule, do not eliminate shock entirely but will reduce it by 30% to 40%, which often is sufficient to remove the clanking sound.

A pressure vessel with air cushion can serve as an automatic water accumulator. The effective volume that can be obtained from the vessel depends on the switching on and switching off pressures. Owing to the fact that water absorbs some of the compressed air that forms the air cushion, fresh air has to be introduced into the vessel from time to time. This can be done by means of a small compressor or, in the case of small units, a self-priming pump which is capable of dealing with water and air, the latter entering through a screw adjustable orifice in the pump suction branch.

The effective capacity of a pressure reservoir necessary for an automatic pumping plant is governed by the permissible switching frequency of the electric equipment and by the pump capacity. As a rule, the pump capacity must be such as to cover, by itself, the highest consumption expected.

Pumps with steep head/flow characteristics often induce high starting pressures when the power is switched on. This is because the flow is small (or zero) when the pump is switched on, so a wave with a head equal to the closed valve head is generated.

By partly closing the pump delivery valves during starting, the starting pressures can be

reduced.

If the pumps supplying an unprotected pipeline are stopped suddenly, the flow will also stop. If the pipeline profile is relatively close to the arithmetic grade line, the sudden deceleration of the water column may cause the pressure to drop to a value less than atmospheric pressure. The lowest value to which pressure could drop is vapour pressure. Vaporization or even water column separation may thus occur at peaks along the pipeline. When the pressure is once again restored as a positive value the water column will collapse giving rise to water hammer over pressure.

Unless some method of water hammer protection is installed, a pumping pipeline system will normally have to be designed for a water hammer head. This is often done with high pressure lines where water hammer heads may be small in comparison with the pumping head. For similar lines this may be an economic solution. Other methods for various water hammer protection levels are shown in Fig. 6.1.

The philosophy behind the design of most methods of protection against water hammer is similar. The objective is to reduce the down surge by the pipeline caused by stopping the pumps. The upsurge will then be correspondingly reduced, or may even be entirely eliminated. The most common method of limiting the downsurge is to install a valve in the pipe system as the pressure tends to drop.

The sudden deceleration change of the water column beyond the valve is prevented so the classic water hammer phenomenon is converted to a slow motion surge phenomenon. Part of the original kinetic energy of the water column is converted into potential energy in form of elastic energy. The water column gradually decelerates under the effect of the difference in heads between the ends. If it is allowed to decelerate the water column would prefer to move in the reverse direction and impact against the pump to cause water hammer over pressure. If however, the water column is arrested at a point of maximum potential energy, which is incident with the point of minimum kinetic energy, there will be no sudden change in momentum and consequently no severe transient overpressure. The reverse flow may be stopped by installing a reflux valve or throttling device at the entrance to the discharge tank or at the pipeline. A small orifice type valve to the return line would limit the pressure fluctuations to gradually varying.

Charts are available for the design of air vessels and for the selection of the pipe diameter effects, so that a water hammer analysis is unnecessary (p. 223, 224). Rigid body dynamics theory may be employed for the analysis of surge tanks, surge and return vessels, or discharge tanks.

If the pipeline system incorporates a line of low values or a pump by pipe system, a water hammer analysis is usually necessary. An analysis may be done graphically on the basis of solutions of similar systems and envisaged a computer program could be developed. Normally the design size and discharge characteristics of a protective device, such as a discharge tank have to be determined by trial and error. The location and type of valve or reflux valves may similarly have to be determined by trial. In the construction of a computer program is usually the most economical method of solution, as a general program could be developed and by varying the design parameters on the handle, an optimum solution arrived at.




FIG. 3 - PIPELINE PROFILE ILLUSTRATING SUITABLE LOCATION FOR VARIOUS DEVICES FOR WATER HAMMER PROTECTION




FIGURE 1: FRONT VIEW WITH BYPASS BEARING VALUE

If the rotational inertia of a centrifugal pump and motor continue to rotate the pump for while after power failure, water hammer pressure transients may be reduced. The rotating pump, motor and entrained water will continue to feed water into the potential vacuum on the delivery side, thereby alleviating the sudden deceleration of the water column. The effect is most noticeable on low head, short pipeline:

After the power supply to the motor is cut off, the pump will gradually slow down until it can no longer deliver water against the delivery head existing at the time. If the delivery head is still higher than the suction head it will then force water through the pump in the reverse direction, with the pump still spinning in the forward direction, provided there is no reflex or control valve on the delivery side of the pump. The pump will rapidly decelerate and gain momentum in the reverse direction, and will act as a turbine under these conditions. The reverse speed of the pump will increase until it reaches runaway speed. Under these conditions there is a rapid deceleration of the reverse flow and water hammer overpressures will occur.

If there is a reflex valve on the delivery side of the pump, the reverse flow will be arrested, but water hammer overpressures will still occur. The pressure changes at the pump following power failure may be calculated graphically or by computer.

The surge age could be reduced considerably if reverse flow through the pump was prevented. If the reflex valve was prevented, the maximum head-rise above operating head (H_1) would be approximately equal to the lowest head-drop below H_1 .

A simple rule of thumb for ascertaining whether the pump inertia will have an effect in reducing the water hammer pressure is:

If the inertia parameter $I = (MN^2/WALH)$ exceeds 0.01, the pump inertia may reduce the pressure surge by at least 10%. Here M is the moment of inertia of the pump, N is the speed in rev/min, W is the volume of water in the pipe.

Some people may have a finished fixed to the pump to increase the moment of inertia. In most cases the flywheel would have to be impractically heavy, since it should be borne in mind that starting currents may thereby be increased. The effect of pump inertia can be ascertained and the pumps assumed to stop instantaneously.

(c) Pump Bypass Reflex Valve

One of the simplest arrangements for protecting a pumping main against water hammer is a reflex valve installed in parallel with the pump (Fig. 6.3). The reflex or non-return valve would discharge only in the same direction as the pumps. Under normal pumping conditions the pumping head would be higher than the suction head and the pressure difference would maintain the reflex valve in a closed position. On stopping the pumps, the head on the delivery pipe would tend to drop below the suction head, in which case water would be

drawn through the bypass valve. The pressure would therefore only drop to the suction pressure less any friction loss in the bypass. The return wave over pressure would be reduced correspondingly. Fig. 5.4. gives the maximum and minimum head at pump after power failure.

This method of water hammer protection cannot be used in all cases, as the delivery pressure will often never drop below the suction pressure. In other cases there may still be an appreciable water hammer overpressure (equal in value to the initial drop in pressure). This method is used only when the pumping head is considerably less than vcv/g . In addition, the initial drop in pressure along the entire pipeline length should be tolerable. The suction reservoir level should also be relatively high or there may still be column separation in the delivery line.

Normally the intake pipes draw directly from a constant head reservoir. However, there may be cases where the intake pipe is fairly long and water hammer could be a problem in it too. In these cases a bypass reflux valve would, in a similar way to that described above, prevent the suction pressure exceeding the delivery pressure.

Water may also be drawn through the pump during the period that the delivery head is below the suction head, especially if the machine was designed for high specific speeds, as is the case with through flow pumps. In some cases the bypass reflux valve could even be omitted, although there is normally a fairly high head loss through a stationary pump. A constant bleed-off line led off to the suction reservoir with a smaller diameter pipe can also be connected to the pump outlet after the gate valve to reduce the water hammer effects. This may result in wastage of energy.

(ii) Surge Tanks

The water surface in a surge tank is exposed to atmospheric pressure, while, the bottom of the tank is open to the pipeline. The tank acts as a balancing tank for the flow variations that may occur, discharging in case of a head drop in the pipe, or filling in case of a head rise. Surge tanks are used principally at the head of turbine penstocks, although there are cases where they can be applied in pumping systems. It is essential that the hydraulic grade line of a pumping line is low enough to enable an open tank to be used. It may be possible to construct a surge tank at a peak in the pipeline profile and protect the pipeline between the pumps and the tank against water hammer by some other means. If the surge tank is relatively large, it could be treated as the discharge end of the intermediate pipeline length and this section could be treated as an independent pipeline shorter in length than the original pipeline.

The fluctuations of the water surface level in a surge tank following power failure may be studied analytically. The fluctuations in tank level may be dampened with a throttling orifice. In this case the pressure variations in the line may be more extreme than for the unrestricted orifice. The maximum heads at pump after power failure is presented in Fig. 5.4. A differential surge tank includes a small diameter riser in the middle of the tank. The tank may have a varying cross section or multiple shafts. Such variations are more applicable to hydro-power plant than pumping systems as they are useful for dampening the surges in cases of rapid load variation on turbines.




FIG. : 6.4 MAXIMUM AND MINIMUM HEADS AT PUMPS AFTER POWER FAILURE




FIG. 6.5 : DISCHARGE TANK

(iii) Discharge Tanks

In situations where the pipeline profile is considerably lower than the hydraulic grade line it may still be possible to use a tank, but one which under normal operating conditions is isolated from the pipeline. The tank water surface would be subjected to atmospheric pressure but would be above the hydraulic grade line, as opposed to that of a surge tank.

A discharge tank would generally be situated on the first rise along the pipeline and possibly on subsequent and successively higher rises. The tank will be more efficient in reducing pressure variations, the nearer the level in the tanks is to the hydraulic grade line. It should be connected to the pipeline via a reflux valve installed to discharge from the tank into the pipeline if the pipeline head drops below the water surface elevation in the tank. Normally the reflux valve would be held shut by the pressure in the pipeline. A small bore bypass to the reflux valve, connected to a float valve in the tank, should be provided to fill the tank slowly after it has discharged. Fig. 6.5 depicts a typical discharge tank arrangement.

The function of a discharge tank is to fill any low pressure zone caused by pump stoppage, thus preventing water column separation. The water column between the tank and the discharge end of the pipeline (or a subsequent tank) will gradually decelerate under the action of the head differences between the two ends. It may be necessary to prevent reverse motion of the water

column which might cause water hammer over pressures by installing a reflux valve in the line.

A discharge tank will only operate if the water surface is above the lowest level to which the head in the pipeline would otherwise drop following pump stoppage. For very long pipelines with a number of successively higher peaks, more than one discharge tank may be installed along the line. The tanks should be installed at the peaks where water column separation is most likely. The lowest head which will occur at any point beyond a tank as the down surge travels along the line is that of the water surface elevation of the preceding tank.

The best position for discharge tanks and inline reflux valves is selected by trial and error and experience. In a case with many peaks or major pipelines with large friction heads, a complete analysis should be carried out, either graphically or by computer. In particular, a final check should be done for flows less than the maximum design capacity of the pipeline.

Even though a number of tanks may be installed along a pipeline, vaporization is always possible along rising sections between the tanks. Provided there are no local peaks, and the line rises fairly steeply between tanks, this limited vaporization should not lead to water hammer overpressures.

6.17.4 AIR VESSELS

If the profile of a pipeline is not high enough to use a surge tank or discharge tank to protect the line, it may be possible to force water into the pipe behind the low-pressure wave by means of compressed air in a vessel. The pressure in the vessel will gradually decrease as water is released until the pressure in the vessel equals that in the adjacent line. At this stage the decelerating water column will tend to reverse. However, whereas the outlet of the air vessel should be unrestricted, the inlet should be throttled. A suitable arrangement is to have the water discharge out through a reflux valve that shuts when the water column reverses. A small orifice open bypass would allow the vessel to refill slowly. (Fig 6.6)

A rational design of air vessel involves calculation of the dimensionless parameters, as follows:

$$\text{Pipeline parameter} = \rho = CV_0 / 2gH_0 \quad (6.22)$$

$$\text{Air vessel parameter} = \rho \frac{2K_c C}{Q_0 L} \quad (6.23)$$

K_c = Coefficient of Head Loss such that $K_c H_0$ is the total head loss for a flow of Q_0 into air vessel. (Ref to Fig. 6.7 to 6.10) C is water hammer wave velocity, V_0 is initial velocity and H_0 is absolute head (including atmospheric head), C_0 is the volume of Air, L is the length of pipeline.




FIGURE 6.6 : AIR VESSEL

6.17.4.1 Design Of Air Vessel

The pipeline parameter, C , is calculated from the maximum likely line velocity and pumping head, and the corresponding chart selected from Figs. 6.7 to 6.10 for an assumed K_f value i. e. 0.0, 0.3, 0.5 or 0.7. The value of Air Vessel parameter corresponding to the selected line is used to read off the maximum head envelope along the pipeline from the same chart.

The volume of air, V_o , is calculated once the air vessel parameter is known. The vessel capacity should be sufficient to ensure no air Where escapes into the pipeline, and should exceed the maximum air volume. This is the volume during minimum pressure conditions and is $S(H_o/H_{min})^{2/3}$.

The outlet diameter is usually designed to be about one-half the main pipe diameter. The outlet should be designed with a bellmouth to suppress vortices and entrainment. The air in the vessel will dissolve in the water to some extent and will have to be replenished by means of a compressor.




FIGURE 6.7 SURGES IN PUMP DISCHARGE LINE, $K_0 = 0$

The required effective capacity of the vessel is also calculated from the expression:

$$V_e = 1200 \text{ to } 1500 Q / Z_p \quad (6.26)$$

Where:

V_e = effective volume in litres

Q = discharge of pumps in lps and

Z_p = permissible number of switching operations per hour for three-phase motor:

10-15 for squirrel-cage motors direct in line,

6-10 for squirrel cage motors with star delta starter,

6-10 for motors with rotor starter,

Permissible number of starts for motors as per IS 325 is 3.

A worked out example is at Appendix 6.7)

6.17.4.2 In-Line Reflux Valves

In-line reflux valves would normally be used in conjunction with surge tanks, discharge tanks or air vessels. Following pumps shutdown, the tank or vessel would discharge water into the pipe either side of the reflux valve. This would alleviate the violent pressure drop and convert the phenomenon into a slow motion effect. The reflux valve would then arrest the water column at the time of reversal, which coincides, with the point of minimum kinetic energy and maximum potential energy of the water column. There would therefore be little momentum change in the water column when the reflux valve is shut and consequently negligible water hammer pressure rise.

There are situations where water column separation and the formation of vapour pockets in the pipeline following pump stoppage would be tolerable, provided the vapour pockets did not collapse resulting in water hammer pressures. Reversal of the water column beyond the vapour pocket could in fact be prevented with an in-line reflux valve at the downstream extremity of the vapour pocket. The water column would be arrested at its point of minimum momentum, so there would be little head rise.

Vaporization would occur at peaks in the pipeline where the water hammer pressure drops to the vapour pressure of the water. If the first rise along the pipeline was higher than subsequent peaks, the vaporization would be confined to the first peak.

In locating the reflux valve, allowance should be made for some lateral dispersion of the vapour pocket. The valve should be installed at a suitable dip in the pipeline in order to trap the vapour pocket and to ensure proper functioning of the valve doors when the water column returns.




FIGURE 6.8 : SURGES IN PUMP DISCHARGE LINE, $K_c = 0.3$

A small diameter bypass to the reflux valve should be installed to permit slow refilling of the vapour pocket otherwise over pressures may occur on restarting the pumps. The diameter of the bypass should be of the order of one-tenth of the pipeline diameter. An air release valve should be installed in the pipeline at the peak to release air which would come out of solution during the period of low pressure.

It is common practice to install reflux valves immediately downstream of the pumps. Such reflux valves would not prevent water hammer pressures in the pipeline. They merely prevent return flow through the pump and prevent water hammer pressure reaching the pumps.

Normally a reflux valve installed on its own in pipe-line will not reduce water hammer pressures, although it may limit the lateral extent of the shock. In fact, in some situations indiscriminate positioning of reflux valves in a line could be detrimental to water hammer pressures. For instance if a pressure relief valve was installed upstream of the reflux valve the reflux valve would counteract the effect of the other valve. It may also amplify reflections from branch pipes or collapse of vapour pockets.

In some pumps installations, automatically closing control valves, instead of reflux valves, are installed on the pump delivery side.

6.17.4.3 Release Valves

There are a number of sophisticated water hammer release valves (often referred to as surge relief valve or surge suppressors) available commercially. These valves have hydraulic actuators which automatically open, then gradually close after pumps tripping. The valves are normally the needle type, which discharge into a pipe leading to the suction reservoir, or else sleeve valves, mounted in the suction reservoir. The valves must have a gradual throttling effect over the complete range of closure. Needle and sleeve valves are suitably designed to minimize cavitation and corrosion associated with the high discharge velocities which occur during the throttling process.

The valves are usually installed on the delivery side of the pump reflux valves and discharge directly to the suction reservoir. They should not discharge into the suction pipe as they invariably draw air through the throat, and this could reach the pumps.

The valves may be actuated by an electrical fault or by a pressure sensor. The valve should open fully before the negative pressure wave returns to the pumps as a positive pressure wave. As the pressure on the top of the piston increases again the valve gradually closes, maintaining the pressure within desired limits. The closing rate may be adjusted by a pilot valve in the hydraulic circuit.

If no over pressure higher than the operating head is tolerable, the valve would be sized to discharge the full flow at a head equal to the operating head, where reliability is of importance, and if water hammer is likely to be a problem during a partial shutdown of the pumps, two or more release valves may be installed in parallel. They could be set to operate at successively lower delivery heads.




FIGURE 6.9 : SURGES IN PUMP DISCHARGE LINE, $K_c = 0.5$




FIGURE G.10 : SURGES IN PUMP DISCHARGE LINE, $K_c = 0.7$

could be disengaged to prevent their operation.

The types of control valves available as release valves for pumping lines normally cannot open in less than about five seconds. Their use is therefore limited to pipelines over two kilometers in length. This method of water hammer protection is normally most economical for cases when the pumping head greatly exceeds CV_w/g , since the larger the pumping head, the smaller the valve needed.

A less sophisticated valve than the control valves described above, which has been used on small pumps installation, is the spring-loaded release valve. The valve is set to open when the pressure reaches a prefixed maximum. Some over pressure is necessary to open the valve and to force water out.

Where a relief valve is power operated and actuated by a relay so as to open before reversal of flow takes place, over pressures can be held down so as not to rise more than 10 to 20% above normal operating pressure, although there may be an initial drop in pressure at the pump down to atmosphere or below. With the surge relief valve open, however, all succeeding reversals are dissipated through the open valve. The pipeline then assumes a penstock condition and the surge relief valve must be closed very slowly to prevent penstock surge. With large diameter lines for low pressure water service the economic justification for rather elaborate protective devices is obvious since without them the lines would have to be designed for shock pressures considerably in excess of the normal working pressure. This is particularly true in the case of concrete pipes, or of thin-walled steel pipes. With thin-walled steel pipes where the pressure may fall below atmospheric under shock conditions, it may be necessary to provide vacuum breakers to prevent collapsing of the pipe.

6.17.4.4. Shut-Off Effects On Suction Line

The effect of power interruption on the pump suction line depends on the arrangement of the suction piping. Nothing of much consequence will occur where the suction line is short and considerable suction lift has to be developed by the pump in order to get water flow to it. In the case of a booster pump, however, where water flows to the pumps suction through a long line under pressure, the result of a power interruption is much like what takes place in a discharge line and the measures taken to cushion shock are similar. To be most effective, a suppressor in such a booster pump suction should be placed close to the pumps. The booster pumps problem is frequently encountered in connection with the intermittent filling of standpipes such as overhead sprinkler tanks, pressure tanks in tall buildings and locomotive filling tanks in railroad yards. In cases where frequent fillings are required, the shock-pressure problem may be most annoying and corrective measures are clearly called for, especially if the pumps suction is taken from a branch line off a distribution network which may be adversely affected for large distances back from the pump. As an alternative to installing suppressors in such cases, consideration should be given to providing automatic means for slowly closing a valve in the pump discharge before power is cut off.

Another pump-suction problem involving surge on a large scale is encountered in water works intakes where the pumps may be fed through a conduit extending for several kilometers from some lake or reservoir in the mountains. In order to look after surge in the case of a sudden power interruption, it may be necessary to provide ample relief valves of gravity overflow, discharging to a receiving basin of generous proportions.

6.17.4.5 Reciprocating Pumps Or Hydraulic Rams

Reciprocating pumps cause pulsation problem not encountered with the continuous action of centrifugal pumps. Owing to the irregularity of flow through a reciprocating pump, more or less water hammer develops in the suction and discharge lines and cannot be suppressed entirely with vacuum or air chambers. For this reason it is advisable to design the suction and discharge lines of reciprocating pumps for something like 50% in excess of the normal working pressure and to provide ample air chambers at the pumps. Shock conditions obtaining with hydraulic rams are decidedly worse than with reciprocating pumps and generous provision should be made in the design of their piping. An allowance of at least 21 kg/cm² extra beyond the working pressure is called for with rams.

6.18 SPECIAL DEVICES FOR CONTROL OF WATER HAMMER

The philosophy is (i) to minimize the length of the returning water column causing water hammer (ii) to dissipate energy of the water column length by air cushion valve and (iii) to provide a quick opening pressure relief valve to relieve any rise in pressures in critical zones. These objectives are achieved by the following three valves.

6.18.1 ZERO VELOCITY VALVE

The principle behind the design of this valve is to arrest the forward moving water column at zero momentum i.e. when its velocity is zero and before any return velocity is established.

The valve fitted in the pipeline consists of an outer shell and an inner fixed dome leaving a streamlined annular passage for water. A closing disc is mounted on central and peripheral guide rods and is held in the closed position by one or more springs when there is no flow of water. A bypass connects the upstream and downstream sides of the disc. The springs are so designed that the disc remains in fully open position for velocity of water equal to 25% of the designed maximum velocity in the pipeline.

With sudden stoppage of pumps the forward velocity of water column goes on decreasing due to friction and gravity. When the forward velocity becomes less than 25% of the maximum, the flap starts closing at the same rate as the velocity of water. The flap comes to the fully closed position when forward velocity approaches zero magnitude, water column on the upstream side of the valve is thus prevented from acquiring a reversed velocity and taking part in creating surge pressures. The bypass valve maintains balanced pressures on the disc and also avoids vacuum on the downstream side of valve if that column experiences

The main advantages of zero velocity valves are:

- Controlled closing characteristics, and
- Low loss of head due to streamlined design.

6.18.2 AIR CUSHION VALVE

The principle of this valve is to allow large quantities of air in the pumping main during separation, enter the air compress it into a returning air column and expel the air under controlled pressure so as to dissipate the energy of the returning water column. An effective air cushion is thus provided.

The valve is mounted on TEE-joint on the rising main at locations where water column separation is likely. The valve has a spring loaded inlet port, an outlet normally closed by a float, a spring loaded outlet poppet valve and an adjustable needle valve control orifice.

When there is sudden stoppage of pump due to power failure, partial vacuum is created in the main. With differential pressure, the spring loaded port opens and admits outside air into the main. When the pressure in the main becomes near atmospheric, the inlet valve closes under spring pressure. The entrapped air is then compressed by the returning water column till the poppet valve events. With flow in depressed position, the air is expelled through poppet valve and controlled orifice under predetermined pressure thus dissipating the energy of the returning water column.

6.18.3 OPPOSED POPPET VALVE

As the name implies, the valve has two poppets of slightly different areas mounted on the same stem. The actual load on the stem is less the difference in loads on the two poppets and is thus light. A weak spring is heretofore able to keep the valve closed under normal working pressure. If pressure in the water main increases beyond a certain limit, the increase in differential pressure overcomes the holding pressure of the spring, opens the valve and allows water to discharge through both the poppets.

On account of the light spring, the valve is able to open quickly and thus reduce the peak surge pressure to the desired level.

6.19 WORKING OF THE SPECIAL DEVICES AS A SYSTEM

Every valve has a different function to perform for limiting water surge after power failure. Location of the valves have therefore to be based on the results of the analysis of water column separation. Air cushion valves are located where separation of water column is indicated. Zero velocity valves are so placed that the entire length of water column is suitably divided in spite of differing gradients and undulations. More than one valve may be required in such cases.

Opposed Poppet pressure relief valves are generally placed near the air cushion valves or

on the upstream side of the Zero Velocity Valves, if further limiting of peak surge pressure is required for the safety of the pipeline.

6.19.1 CHOICE OF PROTECTIVE DEVICE

The best method of water hammer protection for a pumping line will depend on the hydraulic and physical characteristics of the system. The accompanying Table 6.8 summarizes the ranges over which various devices are suitable. The most influential parameter in selecting the method of protection is the pipeline parameter $\rho = (CV_0/gL)$. When the pipeline parameter is much greater than 1, a reflux valve by passing the pumps may suffice. For successively smaller values of ρ it becomes necessary to use a surge tank, a discharge tank in combination with an inline reflux valve, an air vessel, or a release valve. The protective devices listed in Table 6.8 are arranged in approximate order of increasing cost. Thus, to select the most suitable device, one proceeds down the table until the variables are within the required range.

It may be possible to use two or more protective devices on the same line. This possibility should not be ignored as the method of installation often involves more than one method of protection. In particular the rotational inertia of the pump often has a slight effect in reducing the required capacity of a tank or air vessel. A comprehensive water hammer analysis would be necessary if a series of protection devices in combination is envisaged.

TABLE 6.8
SUMMARY OF METHODS OF WATER HAMMER PROTECTION

Method of protection (In approximate order of increasing cost)	Required range of Pipe value	Remarks
Inertia of pump	$(CV_0 / \rho g L) \geq 10^3$	Approximate
Pump bypass reflux valve	$(CV_0 / \rho g L) \geq 1$	Some water may also be drawn through pump
Inline reflux valve	$(CV_0 / \rho g L) \geq 1$	Normally used in conjunction with some other method of protection. Water column separation possible

Method of protection (In approximate order of increasing cost)	Required range of Variables	Remarks
Surge tank	If small	Pipeline should be near hydraulic grade line so height of tank is practical
Automatic release valve	$(Cv_p / \rho H_0)^2 < 1$ $(L/c)^2 > 5 \text{secs}$	Pipeline profile should be convex downwards. Water column separation likely.
Discharge tanks	$(Cv_p / \rho h)^2 > 1$	h = pressure head at tank / Pipeline profile should be convex upwards
Air vessel	$(Cv_p / \rho L_0)^2 < 1$	Pipeline profile preferable convex downwards.

The example in App. 6.7 gives the methods of analysis and calculations for water column separation and computation of Air Vessel size

- M = Moment of inertia of rotating parts of pump, motor and entrained water (mass x radius of gyration²)
- N = Pump speed in rpm
- W = Wt. of water per unit volume
- A = Pipe cross section Area
- L = Pipeline length
- H_0 = Pumping head
- h = Pressure head
- c = Water hammer wave velocity
- v_0 = Initial velocity
- j = Pump parameter,
- f = Pump rated efficiency (expressed as a fraction).

CHAPTER 7 WATER TREATMENT

7.1 METHODS OF TREATMENT AND FLOW SHEETS

The aim of water treatment is to produce a safe quantity of water that is hygienically safe, aesthetically pleasing, and palatable, and is of a required standard through the treatment of water which achieves the desired quality. The treatment process as a quality standard is defined by the extent of the treatment facilities that are available to the point of consumption.

The method of treatment is determined by the quality of the source water, water constraints, and the desired standard of water quality. The most common processes of treatment include filtration, flocculation, rapid and slow sanding, and disinfection. Filtration, coagulation, sedimentation, flocculation, disinfection, and water softening and other different combinations of these processes are required to produce different quality standards as presented in Fig. 7.1. The choice of the process for a particular source of water is not only dependent on the quality of the raw water, but also on the treated water desired for the purpose, the comparison of an array of alternative treatment options available.

In the case of ground water, and surface water, the water is normally well aerated, which means water has a higher dissolved oxygen content than fine filtered air and a lower point distribution by chlorination is adopted but a rapid disinfection (Fig. 7.1 (b)) and (c).

When ground water contains excessive iron, manganese, hydrogen sulphide and odorous gases, aeration followed by flocculation, rapid sanding and reduction to a rapid gravity or pressure filtration and disinfection may be necessary in Fig. 7.1 (d). In case of water with turbidity and odorous gases, aeration followed by disinfection may be sufficient. In surface water with turbidity and odorous gases, aeration followed by disinfection may be sufficient. In surface water with turbidity and odorous gases, aeration followed by disinfection may be sufficient. In surface water with turbidity and odorous gases, aeration followed by disinfection may be sufficient.

Conventional treatment including prechlorination, aeration, flocculation, rapid and slow sanding, and sedimentation, rapid gravity filtration, and post-chlorination are adopted for highly polluted surface water bodies with dissolved iron and manganese.

Some times conventional flow sheet may be adopted for waters containing turbidity below 100 mg/l and containing excessive iron content of 100 mg/l or above 50 mg/l as in Fig. 7.1 (e). Such raw water may require going rapid sand filtration with pre-aeration which may or may not be necessary followed by slow sanding for a short period (10 minutes).

Slow sand filtration can also be used to remove iron from rapid sand filtration plant. Water with excessive hardness needs either 100 mg/l or 100 mg/l or more Ca^{2+} and Mg^{2+} and

solids, demineralisation by ion-exchange may form a part of the domestic or industrial water treatment units as in Fig. 7.1 (6).

7.2 AERATION

Aeration is necessary to promote the exchange of gases between the water and the atmosphere. In water treatment, aeration is practised for three purposes.

- To add oxygen to water for imparting freshness e.g. water from underground sources devoid of or deficient in oxygen.
- Expulsion of carbon dioxide, hydrogen sulphide and other volatile substances causing taste and odour e.g. water from deeper layers of an impounding reservoir and
- To precipitate impurities like iron and manganese in certain forms e.g. water from some underground sources.

7.2.1 LIMITATIONS OF AERATION

The unit operation of aeration requires significant head of water. The water is rendered more corrosive after aeration when the dissolved oxygen content is increased though in certain circumstances it may be otherwise due to removal of aggressive carbon dioxide. The designer should carefully consider the merits or other alternatives because of the additional cost of lining which may be involved in aeration. Iron taste and odour removal by aeration is not highly effective but can be used in combination with chlorine or activated carbon to reduce their doses.


7.2.2 AERATION PROCESS

Gases are dissolved in or blotted from water until the concentration of the gas in the water has reached its saturation value. The concentration of gases in a liquid generally obeys Henry's law which states that the concentration of each gas in water is directly proportional to the partial pressure (product of the volume per cent of the gas and the total pressure of the atmosphere) or concentration of gas in the atmosphere in contact with water. The saturation concentration of a gas decreases with temperature and dissolved salts in water. Aeration tends to accelerate the gas exchange.

The rate of exchange of a gas is governed by the area of interface between the gas and the liquid, the thickness of the interlayers, time of contact, the partial pressure of the gas in the overlying atmosphere and the degree of under-saturation or over-saturation of the gas in the liquid.

To ensure proper aeration, it is necessary:

- To increase the area of water in contact with the air i.e. if the water is sprayed, the smaller the droplets produced, the greater will be the area available. Similarly, if the water is being made to fall as a film over packing material in a tower, the smaller the size of the packing material, the greater will be the area available.



1. STORAGE

6. SEDIMENTATION

2. CHLORINATION (PRE)

7. SLOW SAND FILTRATION

3. AERATION

8. RAPID SAND FILTRATION

4. RAPID MIXING

9. SOFTENING

5. FLOCCULATION - SLOW MIXING

10. CHLORINATION (POST)

11. DEMINERALISATION

FIG. 7.1 : UNIT OPERATIONS IN WATER TREATMENT

- b) To keep the surface of the liquid continuously agitated so as to reduce the thickness of the liquid film which would increase the resistance offered to the rate of exchange of the gas, and
- c) To increase the time of contact of water droplets with air to increase the time of flow which can be achieved by increasing the height of jet in spray aerator and increasing the height of bed in the case of packed media.

Where oxygen is to be dissolved in water the concentration or partial pressure of the oxygen may be increased by increasing the air pressure of the gases in contact with water. For this reason air injected into a main under pressure is a reasonably efficient method of increasing the amount of dissolved oxygen.

The exchange of gases from water to air or from air to water which takes place at the air-water interface can be described by the following formulae:

$$C_t = C_s + (C_s - C_0) \exp\left[-k \frac{A}{V} t\right] \quad (7.1)$$

(Gas absorption)

and

$$C_t = C_s + (C_0 - C_s) \exp\left[-k \frac{A}{V} t\right] \quad (7.2)$$

(Gas release)

Where,

- C_t = actual concentration of the gas in the water after a given period 't'.
- A/V = ratio of exposed area to the volume of water;
- C_s = gas saturation concentration;
- k = gas transfer coefficient (has a dimension of velocity),
- C_0 = concentration of gas initially present in the water; and
- t = aeration period.

The gas saturation values of H₂S and CO₂ are generally 2 and 0.5 mg/l when exposed to normal atmosphere having partial pressures of the gases of 0 and 0.03 percent respectively. Because of the low saturation values, removal of H₂S and CO₂ by aeration is practicable.

If the initial concentration of the gas to be removed from water is much above the saturation limit, sizeable reduction in the concentration of the gas by aeration is possible.

7.2.3 TYPES OF AERATORS

There are two main types of aerators depending upon the mechanics of aeration:

- those forming drops or thin sheets of water exposed to the atmosphere, i.e. water is exposed to come in contact with the ambient air, and
- those forming small bubbles of air which rise in the water, i.e. air is brought in contact with the water.

Spray, water-fall or multiple tray, cascade and mechanical aerators can be considered under type (a), while diffusion aerators fall under type (b).

7.2.3.1 Spray Aerators

Water is sprayed through nozzles upward into the atmosphere and broken up into either a mist or droplets. Water is directed vertically or at a slight inclination to the vertical. The installation consists of trays and fixed nozzles on a pipe grid with necessary carrier arrangements.

Nozzles usually have diameters varying from 3 to 40 mm spaced in the pipe at intervals of 0.5 to 1 m or more. Special (patented) types of corrosion resistant nozzles and sometimes plain openings in pipes, acting as orifices, are used. The pressure required at the nozzle head is usually 7 m of water but practice varies from 2 to 9 m and the discharge ratings per nozzle vary from 18 to 36 m³/hr. Usually aerator area of 0.5 to 0.02 m²/m³/hr of design flow is provided.

The time of exposure of the droplets, the head required and the flow from each nozzle can be calculated from the following formulas:

$$v = C_v \sqrt{2gh} \quad (7.3)$$

$$q = C_d a \sqrt{2gh} \quad (7.4)$$

$$t = 2C_v \frac{\sqrt{2h}}{g} \text{ Sec} \quad (7.5)$$

where,

- h = Total head of water at the nozzle;
- g = Acceleration due to gravity;
- v = Initial velocity of drop emerging from the nozzle;
- C_v = Coefficient of velocity;
- C_d = Coefficient of discharge;
- q = Discharge rate from each nozzle.

- a = Area of cross-section of nozzle opening; and
- c = Time of travel or exposure and α is the angle of inclination of the tray from the horizontal.

The vertical jet gives the longest exposure time for a given value of h (2 seconds for a head of 6 m), while the inclined jets can have less interference between falling drops. Wind can influence the path of the trajectory of each drop and allowance must be made for its effect. The dimensions of the tray must take into account the velocity and direction of the wind to ensure that no water is lost by carry-away. The size, number and spacing of nozzles, aeration time and interference between adjacent arrays, as already explained are also factors governing the aeration efficiency. Spray aerators are usually quite efficient with respect to gas transfer and can be expected to remove 40 to 95% of CO_2 and 90 to 99% H_2S and add to the appearance of a water treatment plant. They require large area and consequently difficult to be housed readily and pose operating problems due to corrosion and choking of the nozzles particularly during freezing weather.

The diameters of the pipe, grid and nozzles should be so designed as to ensure a uniform discharge (with a maximum variation of 5 percent) through all the nozzles in the grid. The loss of head at the pipe is kept low compared to the loss of head in the nozzle. Alternatively numerous small nozzles capable of producing atomized water could be used. However, however extremely small nozzles are to be avoided because of clogging and consequent excessive maintenance needed. Common friction formulas are used in the estimation of loss of head, excepting that the pipe with nozzles has to be considered as carrying uniformly decreasing flow.

7.2.3.2 Waterfall Or Multiple Tray Aerators

Water is discharged through a race pipe and distributed on to a series of trays or steps from which the water falls either through small openings to the bottom or over the edges of the trays. Water is caused to fall into a collection basin at the base. In most aerators, coarse media such as coke, stone or ceramic balls, ranging from 50 to 150 mm in diameter are placed in the trays to increase the efficiency. Iron removal (see 9.5.2) thus may be beneficial. The trays about 4 to 9 in number (with a spacing of 300 mm to 750 mm) are arranged in a structure 1 m to 3 m high. With the media, good turbulence is created and large water surface is exposed to the atmosphere. By the addition of more trays, the time of contact can be increased. The space requirements vary from 0.013 to 0.042 m^3 per m^3 of flow. Natural ventilation or forced draft is provided. Removal efficiencies varying from 65 to 90 percent for CO_2 and 60 to 70 percent for H_2S have been reported.

7.2.3.3 Cascade Aerators

In cascade aerators water is allowed to flow downwards after spreading over inclined surface in thin sheets and the turbulence is secured by allowing the water to pass through a series of steps or baffles. The number of steps is usually 4 to 6. Exposure time can be increased by increasing the number of steps and the area to volume ratio improved by adding baffles to produce turbulence. Head requirements vary from 0.5 to 3.0 metres and the space requirements vary from 0.015 to 0.045 m^3 per m^3 of flow. In cold climates, these aerators must be

housed with adequate provision for ventilation. Corrosion and slime problems may be encountered. The gas transfer efficiency is less compared to the spray type. Removal of gas varies from 20 to 45 percent for CO_2 and up to 35 percent for H_2S .

7.2.3.4 Diffused Air Aerators

This is an alternate of waterfall type aerator. This type of aerator consists of a basin in which perforated pipes, porous tubes or plates are used for release of fine bubbles of compressed air which then rise through the water being aerated. As the rising bubbles of air have a lower average velocity than the falling drops, a diffused air type provides a longer aeration time than the water fall type for the same power consumed. These have higher initial costs and require greater recurring expenditure. Tanks are commonly 3 to 4.5 m deep and 3 to 9 m wide. Compressed air is injected through the system to produce fine bubbles which on rising through the water produce turbulence resulting in a continual change of exposed surface. Ratios of width to depth should not exceed 2:1 for effective mixing and the desired detention period varies from 30 to 50 minutes. The amount of air required ranges from 0.06 to 1m^3 of air per m^3 of water treated. The air diffusers are located on one side of the tank. The power requirements of blower vary from 3 to 13 $\text{w}/\text{m}^3/\text{hr}$.

The air should be filtered before passing through porous diffusers. Oil trap is also provided before diffusers. Diffused aerators require less space than spray aerators but more than tray aerators. Cold weather operating problems are not encountered. The aerators can also be used for mixing of chemicals.

Compressor power requirements may be estimated from the air flow, discharge and inlet pressures and air temperatures, using the following equation, which is based upon the assumption of adiabatic conditions:

$$P = \frac{wRT_1}{(8.41)\epsilon} \left[\left(\frac{p_2}{p_1} \right)^{1.41} - 1 \right] \quad (7.6)$$

where,

- P = Power required in KW;
- p_1 = Absolute inlet pressure in atm. (normally 1 atm);
- p_2 = Absolute outlet pressure in atm;
- R = Gas constant (8.314 $\text{J}/\text{mole} \cdot ^\circ\text{K}$);
- w = Air mass flow in Kg/s ;
- ϵ = Efficiency of the machine, (usually 0.7 to 0.8); and
- T_1 = Inlet temperature in degrees $^\circ\text{K}$.

7.2.3.5 Mechanical Aerators

These are not normally used in water treatment because of the availability of more economical alternatives but find application in waste water treatment.

7.3 CHEMICALS HANDLING HANDLING AND FEEDING

The chemicals are introduced into the water for the purposes of zooplankton and filtration, infection softening, turbidity control, algae control and fluoridation. In general, chemicals are added as solutions or dilute suspensions. The treatment is a continuous process, the flow of chemicals is regulated and measured continuously through chemical meters which can be either submersible or type of the dry feed type. The installation of chemical feeders obviously promotes the uniform distribution of chemicals and also reduces waste. Every chemical feeder should be designed and constructed in such a way that the rate of dosing rate can be made accurate, in order to verify the discharge rate.

7.3.1 Solution Tank:

The preparation of the solution of the chemicals in water in desired strength is the first step in the solution of the chemical. The material added to the use water through controlled feeders is added in gravity to pass through the solution of the proper type of tank and the point of application or injection. For example, when mixing is done in a chamber, it should be done in a way of view in the most uniform of maximum turbulence. Also as different chemicals are to be fed at different points, the location at which the chemicals are fed is important to derive maximum efficiency.

7.3.1.1 Solution Tanks

There should be at least two tanks for each chemical feed. The capacity of each tank should generally be such as to fulfil 8 hours requirement at the maximum demand or demand to the design flow at minimum free head of 0.3 m is necessary. Dissolving trays or racks and also adequate facilities for charging the solution tanks should be provided.

The solution tank may be constructed either of concrete, plain or reinforced concrete or non-ferrous with bituminous paint or of square for zinc tanks while for tanks for handling dilute solution of chemicals, small volume of rubber, PVC or epoxy resin may be desirable in case of corrosion.

The chemical solution tanks should be kept as near as near the chemical storage godown as possible to avoid unnecessary lifting and handling of chemicals. These tanks should preferably be located at a suitable distance to facilitate gravity feed of the chemical solution.

Lifting facilities for lifting the chemicals to the elevated tanks should be provided. Each tank should have a platform which should be at least 0.75 m wide to allow the workers sufficient space for handling the chemicals and preparing the solution, wherever necessary, the platforms should be arranged upon a minimum height of 0.75 m. The platforms should be fixed in a convenient to have a clear height of 2.0 m from the ceiling. The top of the solution tank should not be higher than 1.0 m from the floor of the platforms.

7.3.1.2 Dissolving Trays Or Boxes

The trays or boxes for weighing chemicals should be placed near the dissolving tanks which are provided for the purpose of the maximum safety. The trays or boxes may be constructed

of wood, cast iron, or cast steel or coated steel, or with slots or perforations both at the sides and at the bottom. These may be placed either inside or just above the solution tanks.

For small tanks, a pipe perforated with small holes to provide a spray of water to help dissolve the chemicals, may be placed above the trays. For plants of medium and large size, dissolving boxes should preferably be constructed of concrete with a pipe manifold having holes either at bottom or at sides for dissolving chemicals.

7.3.1.3 Preparation Of Solutions

It is essential to ensure that all the chemicals are dissolved before the solution is put into operation and the homogeneity of the prepared chemical solution is maintained. This can be achieved by proper mixing either by compressed air or recirculating the solution or by mechanical agitation. For plants having capacities not exceeding 2500 m³/d manual mixing may be adopted ensuring proper mixing.

A knowledge of the solubility characteristics of the chemical as well as the solution strength that are used in normal practice will assist in the choice of feed equipment. The solution strength of 40m which is the most widely used equivalent shall not be more than 5% for manual operations and 10% for other operations with efficient mixing. It may be desirable to dilute down to 2% prior to addition. For other chemicals, reference may be made to Appendix 7.10 which gives the strengths to be used with mechanical mixing. With manual operation, lower strengths are recommended.

The chemical solution is conveyed from the solution tanks to the point of application by means of chemical feed lines. There should be as short and straight as possible.

Liquid Alum

Liquid alum contains 53 to 85% water soluble alumina as against 17% for crystalline alum, but is lower priced. Since its use also assists construction of solution tanks, it may be economical in large plants especially if the waterworks are within a reasonable trucking distance of alum producing works. Acid proof equipment such as rubber-lined or stainless steel tanks and piping is necessary for transport, handling and storage.

7.3.1.4 Solution Feed Devices

Solution feed devices are used to regulate the doses of chemical fed into water. The rate of flow of the chemical solution of known strength prepared in the solution tank is measured by means of either an orifice rotameter, positive displacement pump or by weirs. The solution feed equipment should be simple in operation and corrosion resistant.

The constant head orifice is the most commonly device used for measuring the rate of flow of solution. It is usually contained in a unit consisting of corrosion resistant, constant level box with a float valve and an orifice. The orifice can be of either variable size or constant size, the adjustment in the latter being made by using the required size to give the desired rate of flow. The unit should also be capable of adjustment to allow setting for various strengths of solution in the box.

In large systems, an automatic control of chemical feed could be practiced which assures that the quantity of chemical measured is not prone to human errors. The principle must be

based upon the measurement of some attributes of the water such as the rate of flow, pH, colour, conductivity, chlorine residual.

Since the flow of water can fluctuate, it is necessary to maintain the flow of chemical in a fixed proportion to the flow of water for which a proportional feed device is necessary. Measurement of the water can be done in a number of ways, the simplest possibly being the dipping bucket or a pump with positive meter which provides a positive method of measurement but is applicable to the smaller installations only. The more common measuring device is a weir, venturi tube or orifice plate described in Chapter 4.

Another method is based on the operation of a flow regulator directly or through a relay from the primary measuring unit. The latter involves the empirical calibration of some link in the system and care must always be taken to see that such arrangements are properly adjusted for they do not depend on a state of equilibrium.

The most satisfactory method of control is one that depends upon the matching of two beams, one of which is associated with the primary measuring unit (control) and the other with the flow of chemical. For example, a venturi tube will produce a differential pressure bearing known relationship to the flow of water through it. If it is desired to control the flow of a chemical solution, then some similar measurement associated with the flow of a chemical solution must be compared with the differential pressure and means provided for adjusting the flow of chemical so that the two factors so compared are mutually in equilibrium. Such a system is basically stable.

7.3.1.5 Solution Feeders

There are several types of solution feeders, some of which are discussed below.

(a) Pot Type chemical feeders

The pot type chemical feeder is a simple type of equipment for feeding alum or alkali into water. The chemical, in large crystal or lumps form, is charged into the feeding pot. A special orifice fitting, placed in the raw water line, contains an orifice plate which creates a pressure differential at pipes which connect the chemical pot into the orifice fitting.

This pressure differential causes a small stream of water to flow from the high pressure side of the orifice plate through a pipe and a regulating valve, into the bottom of the chemical feeding pot and this forms an equivalent stream of the chemical solution, formed in the pot, to flow out of the top of the pot, into the raw water line on the low pressure side of the orifice plate.

Since the same pressure differential acts across the regulating valve as across the orifice, the flow through the regulating valve, at any setting, is a definite fraction of the flow through the orifice. Consequently, the rates of flow of the small stream of chemical fed to the raw water are directly proportional to the rates of flow of the raw water. These find use in small plants because they do not permit a uniform feed rate and the feed rate cannot be checked. Sediment tanks are usually employed with these feeding lines.

(b) Pressure Solution Chemical Feeders

Pressure solution chemical feeders are more accurate than the pot type chemical feeders. In these chemical solutions of a definite strength are made by dissolving a weighed amount of chemical in a specified volume of water in the chemical solution tank. This batch of chemical solution, when required, is drawn into the displacement tank through the bottom. As the specific gravity of the chemical solution is higher than that of water, the water in the displacement tank is displaced upward to waste through a float.

A sight glass at the side of the feed tank has in it a glass float, which is so constructed that it floats in the heavy chemical solution or in water. This float indicates, at all times, the level of the chemical solution thus notifying the operator when recharging is necessary.

A special orifice fitting placed in the raw water line consists of aifice plate which creates a pressure differential in the pipes connecting the displacement feed tank to the orifice fitting. This pressure differential causes a small stream of water to flow from one side of the orifice plate. The greater part of this stream flows through a secondary orifice and the smaller through an adjustable needle valve in the top of the displacement feed tank, where it displaces downwardly an equivalent stream of the heavier chemical solution.

This small stream of chemical solution is diluted when it discharges on the other side of the secondary orifice into the water flowing through the orifice and this diluted chemical solution is fed into the raw water line on the other side of primary orifice. This dilution serves to make the density of the effluent solution approach the density of the influent water thus assuring a greater degree of accuracy, at varying flow rates, than is possible with a single orifice control.

Since the same pressure differential acts across the primary orifice as across the needle valve, the flow through the needle valve at each setting, is a constant fraction of the flow through the primary orifice. As the rates of flow of the chemical solution are directly proportional to the rates of flow of the raw water, this type of feed is applicable to water supplies of varying flow rates and pressure. Sediment tanks are usually equipped with pressure solution chemical feeders to keep sediment out of the feeding line. In cases where toxicive chemical are handled, special pressure solution chemical feeders are employed.

(c) Electro-chemical Feeders

The water flows through an integrating or water meter causing an electrical circuit to stop the feed control unit through a time switch. The feed control unit is a mechanism designed to lower the swing drawoff pipe at a rate which is proportional to the rate of flow of raw water. It consists of a meter, a speed reducing mechanism, two drums on which separate tapes are wound, a manual rewinding mechanism, a switch for operating an alarm for stopping the feed at low level in the solution tank and a dial for indicating directly the length of run removed from the tank.

(d) Gravity Orifice Chemical Feeders

The gravity orifice chemical feeder is limited in application to those cases where the flow rate of the water being treated is constant. The solution from the chemical solution tank flows by gravity through a strainer and through a float valve, into the orifice or a

The float valve keeps the chemical solution in the orifice box always at the same level so that the adjustable orifice operates under constant head. By gravity, the chemical solution flows from the orifice box through the adjustable orifice to the point of application.

To stop and start the chemical and water simultaneously, a float switch may be used in the settling basin to operate a solenoid-operated valve on the orifice box discharge and an electrically controlled valve on the raw water line. Thus the flows of raw water and chemical solution are stopped whenever the level of the water in the basin has reached a certain height. When the level has fallen a certain distance, the float switch closes an electric circuit thus starting simultaneously the flows of raw water and chemical solution.

Instead of being connected to an electrically controlled valve in the raw water line, the float switch may be connected so as to start or stop a raw water pump simultaneously with the starting or stopping of the chemical feeder.

The amount of chemical solution fed to the raw water may be varied over a wide range by means of the adjustable orifice located in the orifice box.

Instead of the chemical solution flowing by gravity to the point of application, it may be discharged into a pump suction box from which it is pumped to the point of application.

(e) Reciprocating Pump chemical Feeders

This method of feeding chemical employs a motor driven reciprocating chemical pump. The pump withdraws a chemical solution or suspension of suitable strength, from a tank and discharges the solution or suspension to the point of application under any desired pressure. The feeding pump may be designed to deliver either a variable or a constant flow of water.

The chemicals to be fed are prepared in solution tanks. If the chemical to be fed is relatively insoluble, a high speed motor-driven system maintains uniform suspension throughout the full depth of the tank. If the chemical forms a clear solution, a dissolving basket is furnished and the mechanical agitator is omitted.

(1) Variable rate proportional feeders

If the rate of flow of water being treated varies, proportional feeding of chemicals is necessary. This is carried out by accurately measuring the amount of chemical fed by the pump. This pump is a proportioning and metering device which delivers a definite volume of chemical with each stroke. A water meter with an electrical contactor is placed in the raw water line. The contactor closes a circuit each time a given volume of water flows through the meter. The closing of the circuit energizes the motor of the reciprocating pump, which then operates to deliver a given volume of chemical until an electric time switch breaks the circuit, thereby stopping the pump. The cycle repeats itself approximately every thirty seconds at maximum flow, with the pump operating for approximately twenty seconds after each contact. The amount of chemical fed is thus accurately proportioned to the flow of water regardless of variations in the rate of flow, because both the volume of water treated between meter contacts and the volume of chemical which is used to treat the water are accurately measured. However this suffers from the draw-back that, particularly when used with alkali solutions, the water is subject to an excessive and no dose sequence. It is better to have the

chemical pump run continuously and to modulate the stroke of the pump either manually or with a mechanical device.

For a number of chemicals fed simultaneously, one motor control serves to operate any number of pumps.

(2) Constant rate feeding for uniform flow

If the flow of water being treated is constant, the chemical pump operates continuously at the set dosage. When the flow of water ceases, the chemical pump is stopped automatically so as to shut off the flow of chemicals. When the flow of water begins again, the chemical feeding is automatically resumed.

(3) Adjustment of feeding rates

Two methods are available for adjusting the rate of chemical feeding. First, the length of the pump stroke can be changed to vary the rate of feeding of a given strength of solution over a wide range. Secondly, the strength of the chemical solution or suspension in the chemical tank can be changed when a new chemical charge is made up so as to provide a different chemical dosage for the same setting of the chemical pump.

The method of adjustment of the chemical feeding rate varies with the type of proportioning pump used. The single feed pump varies the feeding rate by a simple screw adjustment, which changes the length of the plunger stroke. The duplex pump varies its feeding rate by screwing the adjusting coupling toward the liquid end of the pump to increase the capacity or away from the end to decrease the capacity.

The reciprocating chemical pumps can be provided with ball check valves on both suction and discharge, thus assuring maximum efficiency, no displacement, non-clogging and self-cleaning features, elimination of air locking and the minimising of wire drawing of valve seats. The check valves are readily opened to inspect the ball checks and seats, without disconnecting either suction or discharge pipes.

7.3.2 DRY FEED

Dry chemical feeders incorporate a feed hopper which sometimes serves as a storage hopper also mounted above the feeding device. This device may consist of a rotating table and scrapers, a vibrating trough or an oscillating displacer or some equivalent method of moving the chemical from the point where it leaves the feed hopper to the point of discharge. The rate of movement of the chemical determine the quantity to be discharged on a volumetric basis. Gravimetric feeders are also available in which the quantity discharged in a unit of time is continuously weighed and the speed of operation automatically controlled to maintain a constant weight. The feeder may be designed for constant rate operation or for feeding chemicals in proportion to the rate of flow of water. The dry feeders with a completely enclosed feeding mechanism have many advantages over the solution feeder like accuracy of feeding, reproducibility of feeding rate for any feeder setting with a stepless adjustment of dosage in a wide feeding range, a single feeder serves as a spare for a group of feeders handling different materials and the height of chemical in standard or expansion hopper has no effect on feeding rate. When small rates of chemical feeding are desired, one hopperful of chemical will allow the feeder to operate for several days unattended.

Chemicals stored in a steep sided hopper flow downwards to a discharge opening at the bottom of the hopper. Chemicals which have a tendency to arch or stick, such as lime and soda ash, are made free flowing by a vibrator mounted on the side of the hopper at a point where it produces the most effective abrasion. Exact volumes of chemicals are freed off and discharged from the bottom of the discharge opening by an endless belt with rubber lugs in the form of equally spaced paddles.

Mixers, or paddles on both sides and above the lugs insure that each pocket is filled with an exact volume of chemical. As the belt moves forward it passes over a pulley where each pocket is stretched open as the belt goes over and then under this pulley so that all the chemical is dropped into a mixing or dissolving chamber. A jet of water admitted tangentially to a motor driven paddle in the mixing chamber provides the agitation needed for mixing or dissolving the chemical. This chemical solution or suspension then overflows or is pumped to service.

Where the quantity to be handled is large a storage hopper is usually constructed above the relatively small feed hopper. The capacity of the storage hopper is usually arranged for recharging once a day or once a shift. Because of the height of such hoppers, it is almost inevitable that storage of chemicals has to be in an elevated place to obviate the need of lifting of the chemicals every time.

7.3.3 CHEMICALS

7.3.3.1 Chemicals Used And Their Properties

Appendix 7.10 gives the list of chemicals commonly used in water treatment and their properties.

7.3.3.2 Chemical Storage

The chemical store should be of sturdy pipe construction, properly drained. Special precautions against freezing should also be taken.

For chemicals purchased in bags, storage by piling on the floor of the store room may be arranged. A height of stack not exceeding 2 m is recommended. Hygroscopic chemicals should be obtained in moisture-proof bags and stored in air-tight containers.

All plants, particularly small ones, should keep on hand at all times, a supply of chemicals sufficient to provide a safety factor. A storage of 3 months is advisable but this again depends upon the location of the plant as well as the source of supply, transport facilities and the arrangement made with the suppliers for the supply of chemicals.

In cases where the major storage is provided at a place away from the feed equipment, a weeks storage spare should be provided near the plant.

Dampness may cause severe caking even in chemicals such as aluminium sulphate which is usually not free from such troubles. Quick lime gradually expands on prolonged storage and may even burst the containers if kept too long.

Chemicals such as powdered activated carbon which are likely to cause caking problems should preferably be stored in separate rooms.

Storage of acid materials near alkalis is undesirable as their contact generates considerable heat resulting in combustion. This is also true of oxidising elements such as chlorine, if time mixed with activated carbon. Hence they should be isolated. It is advisable to store chlorine cylinders separately or gaseous chlorine in contact with activated carbon tanks or secure fire barrels.

7.3.3.3 Handling Of Chemicals

Ordinarily a 50 kg container can be handled by a single person when aided by an oil hand cart. Heavy containers should be handled with the aid of mechanical equipment such as cranes, manual pulley, cranes and other special equipments.

Chemicals such as chlorine, ferric chloride, sodium hydroxide, sulphuric acid, ammonium chloride, ammonia, sulphur dioxide and sodium bisulphite should be handled by equipment, specially designed to reduce the hazards in their handling to a minimum. Care should be taken to prevent the dropping or bumping of the containers of these chemicals. For safe lifting, chains should be preferred to ropes.

Sufficient space with access should be provided for handling bulk storage allowing for negotiating of vessels and cranes likely to be used.

Rolling of cylinders, barrels and drums on the floor should be avoided.

Chlorine, ammonia and sulphur dioxide are toxic gases when present even in small concentrations in the air. Hence special care must be exercised in their handling. Sodium bisulphite may give off sulphur dioxide and may cause corrosion when spilled. Calcium sulphate mixed with lime is likely to generate enough heat to start combustion. When such chemicals are used, special care needs to be given to ventilation arrangements (IS: 3103-1965). In the case of chlorination tanks, ventilation is specially necessary at the bottom and should be provided by exhaust fans.

7.4 COAGULATION AND FLOCCULATION

The terms 'Coagulation' and 'Flocculation' are often used indiscriminately to describe the process of removal of turbidity caused by fine suspensions, colloids and organic carbon.

'Coagulation' describes the effect produced by the addition of a chemical to a colloidal dispersion, resulting in particle destabilization. Operationally, this is achieved by the addition of appropriate chemical and rapid intense mixing for obtaining uniform dispersion of the chemical.

'Flocculation' is the second stage of the formation of settleable particles (or flocs) from destabilised colloidal sized particles and is achieved by gentle and prolonged mixing.

In modern terminology, this combination of mixing (rapid) and stirring or agitation (slow mixing) that produces aggregation of particles is designated by the single term 'flocculation'. It is a common practice to provide an initial rapid or flash mixing for dispersal of the coagulant or other chemicals into the water followed by slow mixing where growth of floc takes place.

7.4.1 INFLUENCING FACTORS

Both these stages of flocculation are greatly influenced by physical and chemical factors such as electrical charges on particles, exchange capacity, particle size and concentration, pH, water temperature, electrolyte concentrations and mixing.

7.4.1.1 Coagulant Dosage

Although there is some relation between turbidity of the raw water and the proper coagulant dosage, the exact quantity can be determined only by trial. Even thus determined, the amount will vary with other factors such as time of mixing and water temperature. The use of the minimum quantity of coagulant determined to be effective in producing good flocculation in any given water, will usually require a fairly long stirring period varying from 15 to 30 minutes in summer and 30 to 60 minutes in the colder months, as water temperatures approach the freezing point.

Addition of coagulants in excess of the determined minimum quantity may increase bactericidal efficiency. It is, however, usually more economical to use the minimum quantity of coagulant and to depend on disinfection for bacterial safety.

Very finely divided suspended matter is more difficult to coagulate than coarse particles, necessitating a larger quantity of coagulant for a given turbidity. The cation-exchange capacity of the particles of turbidity bears a significant relationship to the success of flocculation.

7.4.1.2 Characteristics of Water

The characteristics of water especially pH have considerable influence on the coagulation. Some natural waters require certain adjustments in acidity or alkalinity of water.

7.4.1.2.1 Optimum pH Zone

There is at least one pH zone for any given water at which good flocculation occurs in the shortest time with a given dose of coagulant, or in a given time with the required minimum dose of coagulant. Coagulation should be carried out within this optimum zone using alkalis and acids for correction of pH wherever necessary. For many waters, mostly those which are low in colour and well buffered and having pH in the optimum zone, no adjustment of pH is necessary. However, in waters of low mineral content, or in the presence of interfering organic matter, constant attention is needed for pH adjustment. Failure to operate within the optimum zone may be a waste of chemicals and may be reflected in the lowered quality of the plant effluent. As a result of studies of the effect of pH on coagulation, it has been found that "the narrower the water in total dissolved solids and the less the alum added, the narrower becomes the pH zone".

In the case of coagulation with alum, the control over the alkalinity is very important. Not only should the water contain sufficient alkalinity to completely react with the aluminium sulphate, but there should be a sufficient residual to ensure that the treated water is not corrosive. A consideration of the reaction involved shows that one molecule of "clear alum"

(molecular weight of $Al_2(SO_4)_3 \cdot 16 H_2O = 666$ requires three molecules of calcium bicarbonate $[Ca(HCO_3)_2] \times 3 = 486$ for complete reaction.

If the alkalinity is expressed in terms of calcium carbonate, the theoretical requirement of 666 parts of "filter alum" works out to 300 parts of alkalinity, i.e. approximately in the ratio of 2:1. This reduction of alkalinity should be taken into consideration and sufficient alkalinity should be added to the water, if necessary. For this purpose, hydrated lime $Ca(OH)_2$ is usually added, or "soda ash" (Na_2CO_3) may be used when the increase of hardness is to be avoided.

When ferrous sulphate is used as a coagulant, the pH should be maintained above 9.5 to ensure complete precipitation of the iron. This is done by the addition of hydrated lime. For this reason, the process is sometimes known as "iron and lime process".

7.4.1.3 Coagulant Aids

Coagulant aid is a chemical, which when used along with main coagulant, improves or accelerates the process of coagulation and flocculation by producing quick-forming, dense and rapid settling flocs.

Finely divided clay, fuller's earth, bentonites and activated carbon are the most commonly used materials as nuclei to floc formation. The particles may become negatively charged making them subject to attraction by the positively charged aluminium ion.

Activated silica, i.e. sodium silicate, activated with aluminium sulphate, sulphuric acid, carbon dioxide or chlorine, when applied to water, produces a stable solution having a high negative charge which unites with the positively charged alum or other flocc to make it denser and tougher. It is especially useful for clear water that does not coagulate well with the usual processes. It has a wider range of use in water softening.

Polyelectrolytes which are polymers containing ionisable units have been used successfully as both coagulant aids and coagulants but care should be taken to guard against their toxicity. They are soluble in water, conduct electricity and are affected by the electrostatic forces between their charges. Cationic, anionic and amphoteric polyelectrolytes have been used; the cationic being able to serve as both a coagulant and coagulant aid while the other two as coagulant aids primarily. Polyelectrolytes create extraordinarily slippery surfaces when spilled on floor and are difficult to clean up.

Toxicity of any polyelectrolyte has to be checked before it can be used as coagulant or coagulant aid.

7.4.1.4 Choice of Coagulant

In selecting the best coagulant for any specific treatment problem, a choice has to be made from among various chemicals, each of which may offer specified advantages under different conditions. The common coagulants used in water works practice are salts of aluminium; viz. filter alum, sodium aluminate and liquid alum and iron salts like ferrous sulphate (Copperas), ferric sulphate, ferric chloride and chlorinated copperas which is an equimolecular mixture of ferrous sulphate and ferric chloride being obtained by chlorinating

of a wastewater treatment plant depend on natural products such as NH_4^+ and SO_4^{2-} from (Robert, 1981).

Solubility of a substance in water largely depends on the stability of a complex and its own solubility. Both filter cake and bulk solution have certain specific examples. Most of them can be interpreted with known quantity of theory, such as concentration of complex, solubility product, and its relation to concentration of the free ions of ions etc. The dissolving of KNO_3 and $CaSO_4$ has different mechanism of behavior. The solubility of iron ion is not related to a complex, and iron ion may be the main species in solution used with water. High oxygen content in the water and ferric iron is denser than alum iron and is more completely precipitated than water pH range. Also good correlation with above mentioned statements.

The choice of the reagent to be used for any particular water should preferably be based on a series of reasons, as planned rate it will permit accurate comparison of the results to any studied water and experimental conditions. The reagent data in the table should be particularly considered in the light of the particular uses.

Table 1. The main reagents used in analysis of water (collected by Veprek, 1986)

3.4.2 Reagents:

Many reagents are available to which the reagent is supplied and initially, in case of a problem, their names are written on the label, i.e., their homogeneity of supply, a supplier's name, and the percentage of solution contained. In addition, the label should also contain the name of the reagent, the percentage of concentration, the purity, and the name of the manufacturer. It is important to note that the reagent should be used in the form of powder for rapid analysis. The dissolved reagent should be used immediately after its preparation.

The reagent is prepared by the manufacturer and is available in a variety of forms. It is important to note that the reagent should be used in the form of powder for rapid analysis. The dissolved reagent should be used immediately after its preparation.

The reagent is prepared by the manufacturer and is available in a variety of forms. It is important to note that the reagent should be used in the form of powder for rapid analysis. The dissolved reagent should be used immediately after its preparation.

$$C = \frac{W}{V} \quad (3.4.1)$$

where

C = concentration of reagent in N or n equivalent/l;

W = weight of reagent in grams in water volume;

V = volume of water in liters (1000 ml = 1 liter) and

V_{in} = Volume of water to which power is applied, m^3 .

When head loss through the plant is to be conserved as much as possible and where the flow exceeds $330 m^3/hr$, mechanical mixing also known as flash mixing, is desirable. Multiple units may be provided for large plants. Normally a detention time of 30 to 60 seconds is adopted in the flash mixer. Head loss of 0.2 to 0.6 m of water, which is approximately equivalent to 1 to 3 watts per m^3 of flow per hour is usually required for efficient flash mixing. Gravitational or hydraulic devices are simple but not flexible, while mechanical or pneumatic devices are flexible, but require external power.

7.4.2.1 Gravitational Or Hydraulic Devices

In these devices, the required turbulence is obtained from the flow of water under gravity or pressure. Some of the more common devices are described below.

(a) Hydraulic pump mixing

This is achieved by a combination of a chute followed by a channel with or without a sill. The chute creates super critical flow (velocity 3 to 4 m/s), the sill defining the location of the hydraulic jump and the gently sloping channel induces the jump. Standing wave flumes specially constructed for measurement of flow can also be used in which the hydraulic jump takes place at the throat of the flume. In this hydraulic jump mixing, loss of head is appreciable (0.7 to 0.8 m) and the detention time is brief. This device though relatively inflexible, is simple and free from moving parts. This can be used as a standby in large plants to the mechanical mixers while for small plants, this can serve directly as the main unit. Typical residence time of 2 seconds and G value of $630 s^{-1}$ have been reported. overflow weirs have also been used for rapid mixing. A head loss of 0.3 to 0.6 m across the weir has been reported.

(b) Baffled Channel Mixing

In this method, the channel section (neglecting the baffle) is normally designed for a velocity of 0.6 m/s .

The angle subtended by the baffle in the channel is between 40° to 90° with the channel wall. This angle should ensure a minimum velocity of 1.5 m/s while negotiating the baffle.

The main walls of the channel are constructed of brick masonry, steam concrete or reinforced cement concrete finished smooth to avoid growing of weed etc. The baffles are made of concrete or brick, finished in the same manner as the channel. A minimum free board of 150 mm is normally provided.

(c) Other Type of Hydraulic Mixing

Sudden drop in hydraulic level of water over a weir can cause turbulence and chemicals can be added at this "plunge" point with the aid of diffusers. Similarly in pressure conduits, the chemicals can be added at the throat of a venturi or just upstream of or far located within the pipe. In this system, no effective control is possible even though mixing takes place. Rapid mixing can also be obtained by injection of chemicals preferably at the suction end or delivery end of low lift pumps where the turbulence is maximum. In this system also, the detention time is brief while the cost is low.

7.4.2.2 Mechanical Devices

There are two devices, the usual one being the rapid rotation of impellers or blades in water and the other mixing with the aid of a jet or impingement over a plate. Propeller type impellers are commonly employed in flash mixers, with high revolving speeds ranging from 100 to 1400 rpm or more. The blades are mounted on vertical or inclined shaft and generate strong axial currents. Turbine types and paddle types are also used. In the design of a mechanical flash mixer unit, a detention time of 30 to 60 sec. is provided. The relatively high powered mixing devices should be capable of creating velocity gradients of 300 s^{-1} or more. Power requirements are such only 1 to 3 w/gal. per million of flow. Usually, the flash mixers are deep, circular or square tanks. The ratio of impeller diameter to tank diameter is 0.2 to 0.4 and the shaft speed of propeller greater than 100 rpm imparting a tangential velocity greater than 3 m/s and $\frac{1}{3}$ of the blade. The ratio of tank height to diameter of 1.1 to 2.1 is preferred for proper dispersal.

Several strips or baffles, projecting 1 to 6% of tank diameter, at minimum of four places, along the walls of the tank should be provided to reduce vortex formation or rotational movement of water about the vertical shaft. The mixing chamber can be placed below the chemical feed floor ensuring safe chemical feedings. The usual mechanical agitator drive is an electric motor with synchronous drive, operating through a reduction gear. Good results are achieved by adding the chemical just near the tip of the blade or the propeller at the tank. Mechanical type requires very little head of water and permits flexibility of operation. When there is possibility of frost occurring in the tank, one may, if required, heat or steam be provided. This requires more attention power input and needs constant attention and maintenance.

In the impingement type, water is forced out through a nozzle, impinging on a plate, where the chemical is added. An auxiliary pump is used to create the jet current. The rapid mixing takes place at the point of impingement, where turbulence occurs. The power requirement of the auxiliary pump should be provided in accordance with Table 7.1. Rapid mixing chamber may be substituted by pipe mixing manifold with orifice (instead of venturi) or with a mechanical impeller through a self-cleaning horizontal pipe.

7.4.2.3 Pneumatic Devices

When air is injected or diffused into water after suitable compression, it normally expands isothermally and the resultant work done by the air can be used for necessary agitation. They are not common in water works practice. The typical range of velocity gradients and contact times are in the range of 200 to 5000 s^{-1} and 0.2 to 1.0 sec. respectively.

Taking into account the various types of rapid mixing devices, velocity gradients and the detention times, the following equation is proposed:

$$Gt = 7790 \text{ (min)}^{-1} \quad (7.8)$$

where,

G = Velocity gradient, s^{-1}

t = Detention time, S

In the field, it has been observed that the detention time reduces much faster with increase in the value of G . Hence the Gt curve instead of remaining constant reduces with increase in G value. Equation 7.8 is based on this field experience. Variation in the value of G could be from 300 s^{-1} to 5000 s^{-1} .

7.4.3 SLOW MIXING OR WEIRING

Slow mixing is the hydrodynamic process which results in the formation of large and readily settleable flocs (or flocculation) by bringing the finely divided matter into contact with the microflocs formed during rapid mixing. These can be subsequently removed in settling tanks and filters.

TABLE 7.1
RECOMMENDED DETENTION TIME AND NET POWER REQUIRED

Detention Time s	Velocity gradient s^{-1}	Net Power input per unit volume watts/m ³ of volume	Net Power input per unit discharge watts/m ³ of flow/hr
60	300	72	1.2
50	500	104	1.4
40	600	162	1.8
30	600	288	2.4
25	720	415	2.9
20	900	648	3.6

Note: Power calculations are based on water temperature of 20°C ($\mu = 0.88 \times 10^{-3}\text{ kg/m}^2\text{ s}$).

7.4.3.1 Design Parameters

The rate at which flocculation processes depends on physical and chemical parameters such as charges on particles, exchange capacity, particle size and concentration, pH, water temperature, electrolyte concentration, time of flocculation, size of mixing basin and nature of mixing device. The influence of these and other unknown factors which vary widely for different waters, is not yet fully understood. Information on the behaviour of the water to be treated can be had by examination of nearby plants treating similar water and by laboratory testing using jar Test.

The physical forces of slow mixing of the effluent feed water and adhesion, controlled by chemical and electrical forces are respectively, in a large extent influencing the flocculation processes.

Slow mixing is meant to bring the particles to collide and then agglomerate. The rate of collision among the particles is dependent upon the number and size of particles in suspension and the intensity of mixing in the mixing chamber.

Since flocculation is a time rate process, the time provided for flocculation to occur is also significant factor in addition to the intensity of agitation and the total number of particles. The number of collisions is proportional to Gt where t is the detention time of the

flocculation basin. The product Gt is non-dimensional and is a useful parameter for the design and operation of flocculation.

The desirable values of G in a flocculator vary from 20 to 75 s^{-1} and Gt from 10^4 to 6×10^4 for aluminum coagulants and 1 to 1.5×10^5 for ferric coagulants. The usual detention time, provided, varies from 10 to 30 minutes. Very high G values tend to shear flocs and prevent them from building up size that will settle rapidly. Low G values may not be able to provide sufficient agitation to ensure complete flocculation.

Another useful parameter is the product of Gt and the flow volume concentration C_0 (M^3/m^3 of flow per unit volume of water). This parameter GtC_0 reflects to a certain extent the correct proportion of the particles but the usefulness of this parameter is not yet fully established. The values are of the order of 100.

To ensure maximum economy in the input of power and to reduce possible shearing of particles (i.e. formation), tapered flocculation is sometimes practised. The value of G in a tank is made to vary from 100 in the first stage to 50 or 60 in the second stage and then brought down to 20 s^{-1} in the third stage in the direction of flow.

7.4.3.2 Types Of Slow Mixers

Similar to rapid mixing units, these can be categorised under gravitational or hydraulic, mechanical and pneumatic. The hydraulic type uses the kinetic energy of water flowing through the plant created usually by means of baffles, while mechanical type uses the external energy which produces agitation of water.

(i) Gravitational or Hydraulic Type Flocculators

Several types of gravitational or hydraulic flocculators are used in practice.

(a) Horizontal Flow Baffled Flocculator

Fig. 7.3 shows the plan of a typical horizontal flow baffled flocculator. This flocculator consists of several around the end baffles with in between spacing of not less than 0.45 m to permit cleaning. Clear distance between the end of each baffle and the wall is about 1.5 times the distance between the baffles, but never less than 0.6m. Water depth is not less than 1.0 m and the water velocity is in the range of 0.10 to 0.30 m/s. The detention time is between 15 and 20 minutes. The flocculator is well suited for very small treatment plants. It is easier to drain and clean. The head loss can be changed as per requirement by altering the number of baffles. The velocity gradient can be achieved in the range $10-100s^{-1}$.

(b) Vertical Flow Baffled Flocculator

Fig. 7.3 shows the cross section of typical vertical flow baffled flocculator. The distance between the baffles is not less than 0.45 m. Clear space between the upper edge of the baffles and the water surface or the lower edge of the baffles and the basin bottom is about 1.5 times the distance between the baffles. Water depth varies between 1.5 to 3 times the distance between the baffles and the water velocity is in the range 0.1-0.2m/s. The detention time is between 10-30 minutes. This flocculator is mostly used for medium and large size treatment plants.





FIGURE 7.5 : ALABAMA TYPE FLOCCULATOR



(a) FLOCCULATOR WITH HORIZONTAL FLOW



(b) VERTICAL FLOCCULATOR

FIGURE 2.6: MECHANICAL TYPE FLOCCULATORS WITH PADDLES




FIG. 7.3 VERTICAL FLOW BAFFLED FLOCCULATOR




FIGURE 7.4 : JET FLOCCULATOR

of unit chamber = 0.75 to 1.50 m; width = 0.50 to 1.25 m, depth = 2.50 to 3.00 m; and detention time = 15 to 25 min.

(e) Tangential Flow Type

Water is introduced tangentially at an inclination in a square tank with chamfered corners to induce a circulatory motion, thus resulting in turbulence and mixing. Chances of short circuiting are high and adequate mixing may not be obtainable.

(f) Pipe Flocculators

The turbulence during the flow through a pipe can create velocity gradients leading to flocculation. The mean velocity gradient is calculated from

$$G = \frac{1}{Vol} \left(\frac{Q h_f}{f l} \right) \quad (7.9)$$

in which Q = flow rate, m^3/s ; Vol = Volume of pipe of length l , in m^3 , and h_f = headloss in pipe of length l , $h_f = \frac{f l v^3}{2gd}$

where v = Velocity, m/s ; f = friction factor for the pipe; d = diameter of pipe, in m .

(2) Mechanical Type flocculator

Paddle flocculators are widely used in practice. Fig. 7.6 shows two types of mechanical type flocculator with paddles. The design criteria are: depth of tank = 3 to 4.5 m; detention time, t = 10 to 40 min, normally 30 min; velocity of flow = 0.2-0.8 m/s (normally 0.5 m/s); total area of paddles = 10 to 25% of the cross-sectional area of the tank; range of peripheral velocity of blades = 0.2-0.6 m/s ; 0.3-0.4 m/s is recommended; range of velocity gradient, G = 10 to 75 s^{-1} ; range of dimensionless factor Gt = 10^4 - 10^5 and power consumption; 10.0 to 30.0 kw/m^3 ; water velocity to settling tank where water has to flow through pipe or channel = 0.15 to 0.25 m/s to prevent settling or breaking of flocs. For paddle flocculator, the velocity gradient is given by

$$G = \left(\frac{1}{2} \frac{C_D A_p \rho (V_p - V_w)^2}{\mu Vol} \right)^{1/2} \quad (7.10)$$

In which C_D = coefficient of drag (0.8 to 1.2), A_p = area of paddle (m^2), Vol = volume of water in the flocculator (m^3), V_p = velocity of the tip of paddle (m/s), V_w = Velocity of the water adjacent to the tip of paddle (m/s).

The optimum value of G can be calculated

$$G_{opt}^{2.8} t = 44 \times 10^5 \quad (7.11)$$

In which G = optimum velocity gradient, s^{-1} ; t = time of flocculation, min, and c = alum concentration (mg/l).




FIGURE 7.7 : SURFACE CONTACT FLOCCULATOR

In large plants, it is desirable to provide more than one compartment in a row to lessen the effect of short circuiting. While translating laboratory jar test data to plant scale, it must be borne in mind that the good mixing conditions available in the laboratory cannot be simulated in the plant.

The paddles can be driven by electric motors or by turbines rotated by water fall when sufficient head is available. The direction of flow is usually horizontal moving parallel or at right angles to the paddle shafts. The shape of the container also affects the process of flocculation. For the same volume and height of water in the containers of several shapes such as circular, triangular, square, pentagonal and hexagonal, it was observed that the pentagonal shape gave the best performance.

Introduction of struts in the flocculator helps to improve the performance of flocculation.

(3) Pebble Bed Flocculator

The pebble bed flocculator contains pebbles of size ranging from 1 mm to 50 mm. Smaller the size of the pebbles, better is the efficiency, but faster is the build up of the headloss and vice versa. The depth of the flocculator is between 0.3 to 1.0 m.

The velocity gradient is given by

$$G = \left[\frac{180(h_f)^{-1}}{\alpha \mu} \right] \quad (7.12)$$

In which

h_f = Head loss across the bed (m);

α = Porosity of bed;

A = Area of flocculation (m²); and

L = Length of the bed (m)

The main advantage of the pebble bed flocculator is that it requires no mechanical devices and electrical power. The operation and maintenance cost is also low. The drawback of this flocculator is that there is gradual build up of the head loss across the pebble bed and therefore needs periodical cleaning by simultaneous draining and hosing.

(4) Fluidized Bed Flocculator

In a fluidized flocculator the sand bed is in the fluidized form. Even a 10% expansion of the sand bed is enough to create the required turbulence without choking the media. The sand size is between 1.2 to 0.6 mm and depth of sand bed is between 0.3 to 1.6 m. The flow of water is upwards. This flocculator also does not require any mechanical equipment or electrical power. Further, there is no build up of the head loss across the bed.

(b) Pneumatic Flocculator

In a pneumatic flocculator, air bubbles are allowed to rise through a suspension. This creates velocity gradient useful for flocculation. The velocity gradient can be calculated from

$$G = 0.236 \frac{g^{0.5} \rho^{0.5} (Vd_a)^{0.5}}{\mu} \quad (7.13)$$

In which


D_a = diameter of air bubbles (m), and $(Vd_a)^{0.5}$ = volume of air supplied per unit water volume.

The flocculator needs air compressor and the problem of clogging of diffuser is quite common. It is less efficient than the paddle flocculator and therefore not commonly used.

(b) Surface Contact Flocculator

The surface contact flocculator was studied experimentally in India to overcome the inherent problem of choking which increases the head loss over a period of time in pebble bed flocculators.

The surface contact flocculators consist of studled plates, placed in a zigzag form along the direction of flow. An experimental flocculator, shown in Fig. 1.7, comprised of 55 mild steel plates, 140 mm x 69 mm in size, arranged in 11 rows of 5 plates each. These plates were fixed at 45° to a base plate in zigzag fashion. The flocculator was tested in a continuous



LEGEND

- | | |
|-----|----------------------|
| RWL | RAW WATER LEVEL |
| CW | CLEAR WATER |
| SBL | SLUDGE BLANKET LEVEL |
| SWP | SLUDGE WASTE PIPE |

FIGURE 7.8(a) : SLUDGE BLANKET CLARIFIER

blanket so that the newly formed insoluble salts precipitate directly on the sludge particles already present. In this manner a completely flocculated system is constantly maintained and a type of sludge is produced which settles very rapidly and results in completely "cracked" water. At the same time, the filtering action of the blanket traps the finer particles.

The clarification zone extends from the top of the sludge blanket to the surface of the liquid. Upon emergence from the sludge blanket, the water passes through this clarification zone and is collected for use.

From time to time the excess sludge is withdrawn either by gravity or by pumping. For larger tanks, it is advisable to provide mechanical scrapers for removal of the settled solids.

Several designs of the "Solids Contact Units" are available and they are fundamentally similar in design in that they combine solids contact mixing, flocculation, solids liquid separation and continuous removal of sludge in a single basin. The general design features are:

- Rapid and complete mechanical mixing of chemicals, raw water and suspension of solids;
- Provision of mechanical means for constant circulation of large volumes of liquid containing the solids being used for contact. This is achieved either inside the tank by an impeller in the inner compartment or in the outer compartment used for settlement. In other types, the solids from the clarification zone are removed and mixed with the raw water in a chamber located outside. Rapid sludge recirculation ensures quick mixing with incoming water; and
- Operation at higher flow rates than conventional flow rates.

As the efficiency of this type depends on the formation of a sludge blanket, skilled and delicate operation for control is needed. Its suitability of raw water that can be applied to the Solids Contact Unit is limited to 70° to 30.0° N: C. These are not advisable for the high algae laden water. A typical sketch of the unit is shown in Fig. 7.8 (a). The different problems involved in the conventional clarifier are in connection with the dosing and mixing, desludging and the stability of the blanket. An attempt was made in India to overcome these inherent defects, through a modified sludge blanket clarifier, shown in Fig. 7.8 (b).

The velocity gradient of the sludge blanket can be calculated from:

$$G = \frac{2g(S_s - 1)(1 - \alpha)h}{Q} \quad (7.4)$$

In which S_s = specific gravity of flocs; α = porosity of blanket; h = depth of blanket (m); Vol = capacity of clarifier (m^3), and Q = rate of flow (m^3/s).

(9) Tapered Velocity Gradient Flocculator

In a tapered velocity gradient flocculator, the water is initially subjected to a high velocity gradient and finally to a low velocity gradient, thus generating dense, large size and tough flocs which in turn settle more quickly.




FIGURE 7.7(a) : MODIFIED SLUDGE BLANKET CLARIFIER

Recent studies indicated that the efficiency of a tapered water pipe clarifier increases when (a) the cross-section of the top of the velocity profile is not uniform (b) there is greater disturbance in velocity profile and (c) smaller change of velocity gradient along the direction of flow and (d) side tapping, especially near outlet end as well as time of the column is achieved, i.e. highest velocity gradient in the downer zone followed by the lower velocity zones in upward part, i.e. in the upflow zone and so on, so that, velocity and the value of the velocity gradient is the least with the maximum time of detention.

7.5 SEDIMENTATION

Sedimentation is the separation from water of gravitationally settling of suspended matter that is heavier than water. It is one of the most common advanced unit operations in the design of conventional water treatment. Sedimentation is used for settling of coarse suspended matter and primary clarification. It is also used to remove readily settling solids such as sand and silt, suspended impurities, iron, manganese and turbidity and precipitated flocs, such as ferric hydroxide flocs, which are removed with

1. The first step in the process of creating a business plan is to conduct a market analysis. This involves identifying the target market, understanding the needs and preferences of the target audience, and assessing the competitive landscape. A thorough market analysis provides valuable insights into the viability of the business idea and helps to shape the overall strategy.

1. Conduct a market analysis.
2. Determine the business structure.
3. Develop a marketing plan.
4. Create a financial plan.
5. Write the business plan.
6. Obtain financing.
7. Launch the business.


2.4.1. Market Analysis

Market analysis is a critical component of the business planning process. It involves a systematic evaluation of the market environment, including the size and growth of the market, the behavior of consumers, and the actions of competitors. By conducting a market analysis, entrepreneurs can identify opportunities, assess risks, and make informed decisions about their business strategy. The market analysis should cover both the current market and potential future trends, providing a comprehensive view of the business landscape.

There are several key elements to consider in a market analysis. First, it is essential to define the target market and understand the demographics and psychographics of the target audience. This helps to tailor the business offering to the specific needs and preferences of the target market. Additionally, a thorough analysis of the competitive landscape is necessary to identify the strengths and weaknesses of existing competitors and to determine the unique value proposition of the business.

2.4.2. Business Structure

The choice of business structure is a significant decision that can have long-term implications for the business. The most common structures are sole proprietorship, partnership, and corporation. Each structure has its own advantages and disadvantages, and the choice should be based on the specific needs and goals of the business.



Why? (4 marks)

2 marks for each of the following questions. (4 marks)

1. Why is the classification of organisms important? (2 marks)

2. Why is the classification of organisms important? (2 marks)

1. Why? (2 marks)

2. Why? (2 marks)

3. Why? (2 marks)

4.

2. (4)

- Why is the classification of organisms important? (2 marks)
- Why is the classification of organisms important? (2 marks)
- Why is the classification of organisms important? (2 marks)
- Why is the classification of organisms important? (2 marks)
- Why is the classification of organisms important? (2 marks)
- Why is the classification of organisms important? (2 marks)

$$\frac{1}{2} \times \frac{1}{2} \times \frac{1}{2} \times \frac{1}{2} = \frac{1}{16}$$

(4 marks)

3. Why is the classification of organisms important? (2 marks)

4. Why is the classification of organisms important? (2 marks)

$$\frac{1}{2} \times \frac{1}{2} \times \frac{1}{2} \times \frac{1}{2} \times \frac{1}{2} = \frac{1}{32}$$

10. Why is the classification of organisms important? (2 marks)

11. Why is the classification of organisms important? (2 marks)

12. Why is the classification of organisms important? (2 marks)

13. Why is the classification of organisms important? (2 marks)

where \mathbf{r} is the unit vector in the direction of the flow, $\mathbf{r} = \mathbf{r}(\theta, \phi)$, and $\mathbf{r}(\theta, \phi)$ is the unit vector in the direction of the flow, $\mathbf{r} = \mathbf{r}(\theta, \phi)$, and $\mathbf{r}(\theta, \phi)$ is the unit vector in the direction of the flow, $\mathbf{r} = \mathbf{r}(\theta, \phi)$.

The velocity vector \mathbf{v} is given by $\mathbf{v} = \mathbf{v}(\mathbf{r}, \mathbf{r})$, and the velocity vector \mathbf{v} is given by $\mathbf{v} = \mathbf{v}(\mathbf{r}, \mathbf{r})$.

$$\mathbf{v} = \mathbf{v}(\mathbf{r}, \mathbf{r}) = \mathbf{v}(\mathbf{r}, \mathbf{r}) \quad (11)$$

where \mathbf{v} is the velocity vector, $\mathbf{v} = \mathbf{v}(\mathbf{r}, \mathbf{r})$, and $\mathbf{v} = \mathbf{v}(\mathbf{r}, \mathbf{r})$.

The velocity vector \mathbf{v} is given by $\mathbf{v} = \mathbf{v}(\mathbf{r}, \mathbf{r})$, and the velocity vector \mathbf{v} is given by $\mathbf{v} = \mathbf{v}(\mathbf{r}, \mathbf{r})$.

The velocity vector \mathbf{v} is given by $\mathbf{v} = \mathbf{v}(\mathbf{r}, \mathbf{r})$, and the velocity vector \mathbf{v} is given by $\mathbf{v} = \mathbf{v}(\mathbf{r}, \mathbf{r})$.

The velocity vector \mathbf{v} is given by $\mathbf{v} = \mathbf{v}(\mathbf{r}, \mathbf{r})$, and the velocity vector \mathbf{v} is given by $\mathbf{v} = \mathbf{v}(\mathbf{r}, \mathbf{r})$.

$$\mathbf{v} = \mathbf{v}(\mathbf{r}, \mathbf{r}) = \mathbf{v}(\mathbf{r}, \mathbf{r}) \quad (12)$$

The velocity vector \mathbf{v} is given by $\mathbf{v} = \mathbf{v}(\mathbf{r}, \mathbf{r})$, and the velocity vector \mathbf{v} is given by $\mathbf{v} = \mathbf{v}(\mathbf{r}, \mathbf{r})$.

The velocity vector \mathbf{v} is given by $\mathbf{v} = \mathbf{v}(\mathbf{r}, \mathbf{r})$, and the velocity vector \mathbf{v} is given by $\mathbf{v} = \mathbf{v}(\mathbf{r}, \mathbf{r})$.

7.5.3. FLOW CHARACTERISTICS

The flow characteristics are given by $\mathbf{v} = \mathbf{v}(\mathbf{r}, \mathbf{r})$, and the flow characteristics are given by $\mathbf{v} = \mathbf{v}(\mathbf{r}, \mathbf{r})$.







FIGURE 6. Relationship between water and solids percentages.

3.4.13.3. Variation of Flow Profile

In the study, a series of experiments were conducted to study the effect of the inlet flow velocity on the flow profile. The inlet flow velocity was varied by changing the flow rate in the settling zone. The results of the study are shown in Figure 6. The flow profile is represented by the curves shown in the figure. The flow profile may be characterized

- (a) In the flow profile, the water content is higher in the center of the tank and lower at the periphery. This is due to the fact that the water content is higher in the center of the tank and lower at the periphery. The flow profile is characterized by the curves shown in the figure. The flow profile is characterized by the curves shown in the figure. The flow profile is characterized by the curves shown in the figure.
- (b) In the flow profile, the water content is higher in the center of the tank and lower at the periphery. This is due to the fact that the water content is higher in the center of the tank and lower at the periphery. The flow profile is characterized by the curves shown in the figure. The flow profile is characterized by the curves shown in the figure.



WASTEWATER TREATMENT PLANT




FIG. 1. Schematic diagram of the power plant.




Fig. 2. Schematic diagram of the control system.

The diameter of the circular tanks is governed by the structural requirement of the truss structure with the supporting horizontal members. Circular tanks upto 90 m in diameter are in use but are generally upto 5 m to reduce wind effects. Square tanks are generally smaller usually with sides upto 20 m. Square tanks with hopper bottom having vertical flow have sides generally less than 10 m and total height depths.

The depth of the settling basin depends on the character of sludge handled, storage capacity required and cost. In water treatment and where the sludge is likely to contain considerable organic matter it is not advisable to store sludge for long periods, otherwise, its decomposition will be undesirable. Hence the settling process. Depths commonly used in practice vary from 2.5 to 5 m with 4 m being a preferred value. Bottom slopes may range from 1:6 m rectangular tanks to about 1:10 in circular tanks. The slopes of sludge hoppers range from 1:20 to 2:1 (vertical to horizontal).

2.5.6 COMMON SURFACE LOADINGS AND DETENTION PERIODS

The removal of particles of varying size and settling velocities is solely a function of surface overflow rate also called 'surface loading' and is independent of the depth of the basin for discrete particles and unbalanced settling. However, certain opportunities among particles leading to aggregation, increase with increasing depth for flocculent particles having tendency to agglomerate with scaling, such as alum and iron flocs. The range of surface loadings and detention periods for average design flow for different types of sedimentation tanks are as follows:

Tank type	Surface loading, $m^3/m^2/d$		Detention period, hr		Particles normally removed
	Range	Typical value for design	Range	Typical value for design	
Plain Sedimentation	upto 6000	15-30	3.0-15	3-4	Sand, silt and clay
Horizontal flow, Circular	25-75	5-40	2-8	2-2.5	Alum and iron floc
Vertical flow, Circular/Square		10-50		1-1.5	Flocculent

(at average design flow)

2.5.7 INLETS AND OUTLETS

Inlet structures must efficiently distribute the solid and suspended particles over the cross section at right angle to flow within individual tanks and into various tanks in parallel (i) minimize large-scale turbulence and (ii) initiate longitudinal or radial flow, if high removal efficiency is to be achieved. For uniform distribution of flow, the flow being divided must be counter radial flow, i.e. the head loss between inlets on inlet openings must be small in

component of the unit vector \hat{r} is only $\cos \theta$ in the direction of \hat{r} . The length of the field due to the positive charge q is $\frac{1}{4\pi\epsilon_0} \frac{q}{r^2}$ in the direction of \hat{r} . The field due to the negative charge $-q$ is $\frac{1}{4\pi\epsilon_0} \frac{q}{r^2}$ in the direction of $-\hat{r}$. The total field is the vector sum of these two fields.

$$\vec{E} = \frac{1}{4\pi\epsilon_0} \frac{q}{r^2} \hat{r} - \frac{1}{4\pi\epsilon_0} \frac{q}{r^2} \hat{r} = \frac{1}{4\pi\epsilon_0} \frac{q}{r^2} (2\cos\theta) \hat{r} \quad (1)$$

The magnitude of the electric field is $E = \frac{1}{4\pi\epsilon_0} \frac{2q}{r^2} \cos\theta$. The direction of the field is along the line joining the two charges, away from the positive charge and towards the negative charge.

$$E = \frac{1}{4\pi\epsilon_0} \frac{2q}{r^2} \cos\theta$$

$$E = \frac{1}{4\pi\epsilon_0} \frac{2q}{r^2} \frac{z}{r}$$

$$E = \frac{1}{4\pi\epsilon_0} \frac{2qz}{r^3} \quad (2)$$

The electric field is directed along the line joining the two charges, away from the positive charge and towards the negative charge. The magnitude of the field is $E = \frac{1}{4\pi\epsilon_0} \frac{2qz}{r^3}$. The direction of the field is along the line joining the two charges, away from the positive charge and towards the negative charge. The electric field is directed along the line joining the two charges, away from the positive charge and towards the negative charge. The magnitude of the field is $E = \frac{1}{4\pi\epsilon_0} \frac{2qz}{r^3}$. The direction of the field is along the line joining the two charges, away from the positive charge and towards the negative charge.

The electric field is directed along the line joining the two charges, away from the positive charge and towards the negative charge. The magnitude of the field is $E = \frac{1}{4\pi\epsilon_0} \frac{2qz}{r^3}$. The direction of the field is along the line joining the two charges, away from the positive charge and towards the negative charge. The electric field is directed along the line joining the two charges, away from the positive charge and towards the negative charge. The magnitude of the field is $E = \frac{1}{4\pi\epsilon_0} \frac{2qz}{r^3}$. The direction of the field is along the line joining the two charges, away from the positive charge and towards the negative charge.

The electric field is directed along the line joining the two charges, away from the positive charge and towards the negative charge. The magnitude of the field is $E = \frac{1}{4\pi\epsilon_0} \frac{2qz}{r^3}$. The direction of the field is along the line joining the two charges, away from the positive charge and towards the negative charge. The electric field is directed along the line joining the two charges, away from the positive charge and towards the negative charge. The magnitude of the field is $E = \frac{1}{4\pi\epsilon_0} \frac{2qz}{r^3}$. The direction of the field is along the line joining the two charges, away from the positive charge and towards the negative charge.

$$\vec{E} = \frac{1}{4\pi\epsilon_0} \frac{2qz}{r^3} \hat{r} \quad (3)$$

where \hat{r} is the unit vector in the direction of \vec{r} . The electric field is directed along the line joining the two charges, away from the positive charge and towards the negative charge. The magnitude of the field is $E = \frac{1}{4\pi\epsilon_0} \frac{2qz}{r^3}$. The direction of the field is along the line joining the two charges, away from the positive charge and towards the negative charge.

$$E = \frac{1}{4\pi\epsilon_0} \frac{2qz}{r^3} \cos\theta$$

$$E = \frac{1}{4\pi\epsilon_0} \frac{2qz}{r^3} \frac{z}{r} = \frac{1}{4\pi\epsilon_0} \frac{2qz^2}{r^4}$$

$$E = \frac{1}{4\pi\epsilon_0} \frac{2qz^2}{r^4} \quad (4)$$

$$E = \frac{1}{4\pi\epsilon_0} \frac{2qz^2}{r^4}$$


$$E = \frac{1}{4\pi\epsilon_0} \frac{2qz^2}{r^4} \quad (5)$$

The electric field is directed along the line joining the two charges, away from the positive charge and towards the negative charge. The magnitude of the field is $E = \frac{1}{4\pi\epsilon_0} \frac{2qz^2}{r^4}$. The direction of the field is along the line joining the two charges, away from the positive charge and towards the negative charge. The electric field is directed along the line joining the two charges, away from the positive charge and towards the negative charge. The magnitude of the field is $E = \frac{1}{4\pi\epsilon_0} \frac{2qz^2}{r^4}$. The direction of the field is along the line joining the two charges, away from the positive charge and towards the negative charge.

$$\vec{E} = \frac{1}{4\pi\epsilon_0} \frac{2qz^2}{r^4} \hat{r} \quad (6)$$



11. The block diagram of the control system.



12. The block diagram of the control system.



13. The block diagram of the control system.



14. The block diagram of the control system.

15. The block diagram of the control system.



15. The block diagram of the control system.

16. The block diagram of the control system.

There is a primary trend towards the use of elliptical basins or troughs covering a good part of the surface of the settling basins. There are special arrangements of tank layout between the troughs. The use of numerous troughs with lengths increasing from the outlet towards the inlets means greater compensation of hydraulic currents. Another advantage is the difficulty in levelling, which is not faced with perforated pipe launchers. Perforated launchers with ports commonly submerged to 500 mm below the surface are used to varying the water level in the basin during operation and process, allowing water flowing to the filters.

7.5.8 WEIR LOADINGS

Weir length relative to surface area depends on the nature of the material. Common slotted weir loadings are up to 30 m³/day/m. For slotted flap weirs, the proper design will slotted weirs can be obtained at weir loadings of up to 40 m³/day/m.

7.5.9 SLUDGE REMOVAL

Sludge is normally removed under hydrostatic pressure through pipes. The size of the pipe will depend upon the flow and the quantity of suspended matter. It is advisable to provide telescopic sludge discharge arrangements for easy operation and for minimizing the wastage of water. For non-mechanised units, pipe diameters of 75 mm are normally recommended. Pipe diameters of 100 mm or more are preferred for the reasons mentioned. Continuous removal of sludge with mechanical scrapers is common and, where mechanical scrapers are provided, the flow should be controlled so that the sludge is continuously and properly collected. For manual cleaning, the scraper should be about 1 in 10.

The power required for driving the scrapers is dependent on the diameter of the scraper, the area to be scraped and the design of the scraper. The scraper should move slowly to complete one revolution in about 30 to 60 minutes. The peripheral velocity of the scraper should be around 0.3 m/min or below. Power requirements are about 0.5 kw/m² of tank area.

Sludge and wash water should be properly disposed of to avoid causing any pollution if discharged into water courses.

For sludge blanket type vertical flow settling tanks, the slopes of the hopper should not be less than 55° to horizontal to ensure efficient sliding and removal of sludge. In such tanks special slurry weirs are provided with their crests at level with the top of the sludge blanket to ensure continuous bleeding of the excess sludge.

Special types of consolidation tanks with a capacity of 30 m³ are sometimes provided to consolidate the sludge and recover water from it.

In non-mechanised horizontal flow (conventional) settling tanks, the basin floors should slope about 1/2% from the sides towards the longitudinal central line, indicating a longitudinal slope of at least 5% from the shallow outlet end towards the deeper inlet area where the drain is normally located. Manual cleaning of basins is normally done hydraulically, using high pressure hoses. Admitting settled water through the basin outlet helps this function. 17

sludge will be withdrawn continuously or nearly continuously from the bottom of the basin by gravity return mechanism. Equipment required for this system has to be used with slope of not less than 55° to the horizontal.

Removal of water from the sludge removed from the settling basin should be encouraged. The various methods listed disposal of sludge on land or on sludge drying beds.

2.5.10 Settling Tank Efficiency

The efficiency of basin is reduced by currents caused by inertia of the incoming water, wind, and other flow, density and temperature gradients. Such currents short circuit the flow. The efficiency of such basins affected by currents induced short circuiting may be approximately expressed as

$$\frac{P}{P_0} = 1 - \alpha \frac{H}{L} \quad (7.21)$$

where

- P = efficiency of removal of suspended particles
- P_0 = efficiency that maintains basin performance
- α = coefficient of current for ideal plug basin
- H = height of surface overflow rate for real basin to achieve an efficiency of P/P_0 for given basin performance.

The values of α are assumed 0 for best possible performance, 1/8 for very good performance, 1/4 for good performance, 1/2 for average performance 1 for very poor performance. Mathematical analysis of longitudinal mixing in settling tanks indicates that the value of α can be approximated by the ratio of the difference between the mean and modal flow through periods to the mean flow through period.

The short circuiting characteristics of basins are usually measured by addition of a slug of dye, electrolyte or tracer and observing the emergence of this tracer substance with passage of time. A frequency distribution plot of the concentration with respect to time is plotted. The t_{50} , median and mean flow-through periods identify the central tendency of the time concentration distribution and percentiles reflect its variance. The ratio of the median time to the mean time or the ratio of the difference between the mean and the modal (or mean and median) to the mean indicate the stability or efficiency of the basin. The lower the first ratio is from unity or the higher the second value, the lesser the efficiency and the more the short circuiting. A well designed tank should be capable of having a volumetric efficiency of at least 70%.

To achieve better clarification, the flow regime in settling basin should be as close as possible to ideal plug flow. A narrow and long rectangular tank approximates plug flow conditions better than wide shallow rectangular tank, peripheral feed circular tank and centre feed radial flow tank.

feeding rate of about 100 g dry weight per day per animal for a 100 g dry weight fish (Brett, 1972).

2.2.2.2. *Temperature and salinity effects*

The model of growth rate of rainbow trout, *Salmo gairdneri*, in relation to temperature and salinity is based on the relationship between the maximum length of fish (L_{∞}) and growth rate. The maximum length of fish is a function of the maximum growth rate, and the maximum growth rate is a function of temperature and salinity. The maximum growth rate is a function of temperature and salinity, and the maximum length of fish is a function of the maximum growth rate. The maximum growth rate is a function of temperature and salinity, and the maximum length of fish is a function of the maximum growth rate.

The model of growth rate of rainbow trout, *Salmo gairdneri*, in relation to temperature and salinity is based on the relationship between the maximum length of fish (L_{∞}) and growth rate. The maximum length of fish is a function of the maximum growth rate, and the maximum growth rate is a function of temperature and salinity. The maximum growth rate is a function of temperature and salinity, and the maximum length of fish is a function of the maximum growth rate. The maximum growth rate is a function of temperature and salinity, and the maximum length of fish is a function of the maximum growth rate.

2.2.2.3. *Food quality effects*

Feeding rate of rainbow trout, *Salmo gairdneri*, in relation to food quality is based on the relationship between the maximum length of fish (L_{∞}) and growth rate. The maximum length of fish is a function of the maximum growth rate, and the maximum growth rate is a function of food quality. The maximum growth rate is a function of food quality, and the maximum length of fish is a function of the maximum growth rate. The maximum growth rate is a function of food quality, and the maximum length of fish is a function of the maximum growth rate. The maximum growth rate is a function of food quality, and the maximum length of fish is a function of the maximum growth rate.

The model of growth rate of rainbow trout, *Salmo gairdneri*, in relation to food quality is based on the relationship between the maximum length of fish (L_{∞}) and growth rate. The maximum length of fish is a function of the maximum growth rate, and the maximum growth rate is a function of food quality. The maximum growth rate is a function of food quality, and the maximum length of fish is a function of the maximum growth rate.

Table 8.1: Analysis of the Fourier series

Table 8.1 shows the Fourier series coefficients for the periodic function $f(x)$ defined in (8.1).

$$f(x) = \frac{1}{2} \sum_{n=-\infty}^{\infty} \left(\frac{1}{|n|} + (-1)^n \right) e^{inx} \quad (8.2)$$

where

(i) $\frac{1}{2} \sum_{n=-\infty}^{\infty} \frac{1}{|n|} e^{inx}$ is the periodic extension of the function $\frac{1}{2|x|}$,

(ii) $\frac{1}{2} \sum_{n=-\infty}^{\infty} (-1)^n e^{inx}$ is the periodic extension of the function $\frac{1}{2}$.

Figure 8.1 shows the periodic extension of the function $\frac{1}{2|x|}$.

Figure 8.2 shows the periodic extension of the function $\frac{1}{2}$.

Let $f_1(x)$ and $f_2(x)$ be the periodic functions defined in (8.2).

Figure 8.3 shows the periodic extension of the function $f(x)$ defined in (8.1). The function $f(x)$ is the sum of the periodic functions $f_1(x)$ and $f_2(x)$. The function $f(x)$ is a periodic function with period 2π . The function $f(x)$ is a periodic function with period 2π .

Figure 8.4 shows the periodic extension of the function $f(x)$ defined in (8.1). The function $f(x)$ is a periodic function with period 2π . The function $f(x)$ is a periodic function with period 2π . The function $f(x)$ is a periodic function with period 2π . The function $f(x)$ is a periodic function with period 2π . The function $f(x)$ is a periodic function with period 2π .

Figure 8.5 shows the periodic extension of the function $f(x)$ defined in (8.1). The function $f(x)$ is a periodic function with period 2π . The function $f(x)$ is a periodic function with period 2π . The function $f(x)$ is a periodic function with period 2π .

$$f(x) = \frac{1}{2} \sum_{n=-\infty}^{\infty} \left(\frac{1}{|n|} + (-1)^n \right) e^{inx} \quad (8.3)$$

where $f(x)$ is the periodic extension of the function $f(x)$.

Table 8.2: Analysis of the Fourier series

Table 8.2: Analysis of the Fourier series

Table 8.2 shows the Fourier series coefficients for the periodic function $f(x)$ defined in (8.1). The function $f(x)$ is a periodic function with period 2π . The function $f(x)$ is a periodic function with period 2π . The function $f(x)$ is a periodic function with period 2π . The function $f(x)$ is a periodic function with period 2π . The function $f(x)$ is a periodic function with period 2π .

Filters can be classified according to (1) the direction of flow (2) type of filter media and beds (3) the driving force (4) the method of flow rate control and (5) the direction of flow. Depending upon the direction of flow through them, these are designated as down flow, upflow, biflow, radial flow and horizontal flow filters. Based on filter media and beds, they have been categorized into (a) granular media filters and (b) fabric and membrane micro-strainers. The granular media filters include simple sand, dual media and multi-media (usually tri-media) filters. Sand, coal, crushed oyster shell, clam shells, etc. and activated or granular activated carbon have been used as filter media but sand filter has been most widely used as sand is widely available, cheap and effective in removing suspended solids. The force to overcome the frictional resistance is generated by the gravity water head in either the force of gravity or applied pressure. In the former case, they are accordingly referred to as gravity filters and pressure filters. In the latter category, the flow rate and direction of flow are mostly dependent upon the flow rates, the filters are designated as slow or rapid sand filters.

Utilization of municipal water supply system has an emphasis on using

- (a) slow sand filters, or
- (b) rapid sand filters

Both of these types of filters are covered by granular media and/or fine mesh gravity filters. The rapid sand filters have been more extensively employed at commercial scale of filtration.

7.6.2 SLOW SAND FILTERS

7.6.2.1 General

slow sand filters can provide a single step treatment for polluted surface waters of low turbidity (< 20 NTU) when land, labor, sand filter sand are readily available, a low cost, chemicals and equipments are difficult to procure and skilled personnel to operate and maintain are not available locally.

When raw water turbidity is high, simple pre-treatment such as storage, sedimentation or primary filtration will be necessary to reduce it to within desirable limits. Coagulant application and decantation may also be successfully used to effectively protect water bodies without adverse effect on filtrate quality by slow sand filtration.

7.6.2.2 Description

A slow sand filter consists of an open box about 3.0 m deep rectangular or circular in shape and made of concrete or masonry (Fig. 7.1). The box contains a supernatant water layer, a bed of filter medium, an underdrainage system and a set of control valves and appurtenances.

The supernatant provides the driving force for the water to flow through the sand bed and to overcome frictional resistance in other parts of the system. It can also provide a storage of several hours to the incoming water before it reaches the sand surface.

The filter bed consists of natural sand with an effective size (E.S.) of 0.25 mm to 0.35 mm and uniformity coefficient (U.C.) of 3 to 5. For best efficiency, the thickness of filter bed should be not less than 0.4 to 0.5 m. As a layer of 10-20 mm sand will be removed every time the filter is cleaned, a new filter should be provided with an initial sand depth of about 1.0 m. Recharging will then become necessary only about 2-3 times.

- | | |
|---------------------------------|--------------------------------|
| A — RAW WATER INLET VALVE | B — SUPERNATANT DRAINOUT VALVE |
| C — RECHARGE VALVE | D — FILTER SCOUR VALVE |
| E — FILTERED WATER OUTLET VALVE | F — FILTER TO WASTE VALVE |
| | G — FILTERED WATER VALVE |




FIGURE 7.14 : BASIC ELEMENTS OF SLOW SAND FILTER (SCHEMATIC)

The underdrainage system supports the sand bed and provides unobstructed passage for filtered water to leave the underside of the filter. The underdrains may be made of unjointed bricks laid to form channels, perforated pipes or porous tiles laid over drains. Graded gravel to a depth of 0.2-0.3 m is placed on the underdrains to prevent the sand from entering the underdrains and ensure uniform abstraction of filtered water from the entire filter bed.

A system of control valves facilitates regulation of filter run and adjustment of water level in the filter at the time of cleaning and backwashing when the filter is put back into operation after cleaning.

7.6.2.3 Purification in a Slow Sand Filter

In a slow sand filter, water is subject to various purifying influences as it percolates through the sand bed. Impurities are removed by a combination of straining, sedimentation, bio-chemical and biological processes. Shortly after the start of filtration, a thin slimy layer called the 'schmutzdecke' is formed on the surface of sand bed. It consists of a great variety of biological organisms which feed on the organic matter and convert it into simple,

(f) Filter slope and layout

Rectangular filters offer the advantage of ease in installation and may be preferred except for very small installations where circular types may be more useful. Arranging filters in a row maximizes the number of connections with and between rows, easing work of erection and maintenance. Filters can also be set out in a staggered or checker-board pattern about a central pipe gallery. The layout can be determined by taking particular note of placement of pumps or sump storage units for backflow.

(g) Depth of Filter Bed

The designer must determine the depth of the filter bed and the storage tank depth and free board (0.2 m) separation water column (pressure filter and float) or gravel depth (0.3 m) and or the drainage system (0.3 m) with regard to the depth of the filter bed. The use of greater depths in these elements can reduce the cost of the filter but can adversely affect the adversely affect performance.

(h) Filter material choice

Under normal the size and configuration of sand for filters. This is number of circular or rectangular filter plates, and total quantity of sand. The sand should be uniformly rounded gravel, which is often quite expensive and difficult to obtain, can be replaced by hard, broken limestone or other cost.

7.6.2.5 Construction Aspects

(a) General

The construction of slow sand filters should be based on sound engineering principles. Some of the important considerations that need attention are: (i) the type of sand used; (ii) bearing capacity; (iii) the ground water table and its character; and (iv) the availability and cost of materials, man power and labour. Water tight construction of the filter has to be guaranteed, especially when the ground water table is high. This will prevent leakage of water through the filter and contamination of the sand water. The top of the filter should be atleast 0.5 m above the ground level in order to allow for free flow of air and debris. The danger of denitrification of raw water may be prevented by rough aeration of the filter bed. The drainage system should be carefully laid so that it is unobstructed, cleaned or repaired without the necessity of removal of the filter bed material.

(b) Inlet

The inlet structure is an important component of a slow sand filter and should be well designed and constructed to cause minimum disturbance to the filter bed while allowing raw water and to facilitate routine operation and maintenance. A filter needs to be cleaned periodically and this is done by lowering the water level a few centimeters below the filter bed and scraping the top layer of 10-20 mm of sand. It is found to be more than digging the water through the filter bed on a regular basis, at times it is better to only clean the surface. This difficulty, a support structure can be used to hold the filter bed in place and prevent it from being disturbed. By a proper design, the filter inlet can be constructed to be made of concrete or steel combined in a single structure (Fig. 7.15).




FIGURE 7.15 : INLET CUM SUPERNATANT DRAINOUT BOX




FIGURE 7.16 : OUTLET CHAMBER

(c) Outlet

The outlet structure incorporates means for removing the filter flow rate backfilling with clean water after sand scraping and recommissioning of the filter.

In small filters, the outlet chamber is usually constructed in two parts separated by a wall with a weir. The sill of the weir is fixed to the highest sand level in the filter bed. This makes filter operation independent of fluctuations in the clear water storage level and prevents occurrence of negative head across filter. It also permits the filter to operate at a rising water level, thus raising its oxygen content. To facilitate removal of accumulated operating pebbles, a sump is provided in the chamber. (Fig. 7.16)

(ii) Sump and overflow outlet

To facilitate drainage of surplus water entering the filter and when this may accumulate on the supernatant water, an overflow pipe will should be provided in the filter.

The equation for b , when rearranged, shows that $2nb = (n + 1)l$, or the condition for minimum filter cost is to have the sum of the lengths equal to the size of the headloss. It can be shown that this is true whether filter units are arranged in a single row or in blocks on each side of a central gallery. The general expression for the minimum cost is found by substituting Eqs. 7.26 and 7.27 for Eqn. 7.24:

$$C = K_p l + 2K_s l_y / (n + 1) \quad (7.28)$$

The values of K_p and K_s can be worked out for any place based on prevailing prices for construction materials. For Nagpur India ($C = 85$),

$$C = 500l + 1660 \left[\frac{2.45n}{n + 1} \right] \quad (7.29)$$

(b) Economy of Scale

A general cost model for any filter bed is written as

$$C = K/V^b \quad (7.30)$$

Where V is the total area of the filter beds, K is the cost per unit area of filter bed construction including scale, and b is the exponent that represents the economy of scale factor.

The cost data obtained from Eq. 7.29 for various values of A can be used to determine the parameters K and b of the function by the method of least squares. The resulting equation for Nagpur ($C = 85$) is given by

$$C = 16.17 V^{0.27} \quad (7.31)$$

Large economies of scale are associated with small values of the exponent. If the exponent is close to about 0.6 or 0.7, there is no economic incentive for overdesign. Thus, cost saving is accomplished by increasing the size of the project in order to provide economies of scale and into the future.

(c) Cost of Slow Versus Rapid Sand Filters

There is a general misconception that slow sand filters, because of their relatively larger mean are expensive. However, this is not always true. Comparative cost analysis for slow and rapid filter has shown that slow sand filters are cost effective, especially for rural and small community water supplies. The economic capacities have to be determined for specific situations using local cost data before deciding on the choice between the two types of filter.

TABLE 7.3
SUMMARY GUIDELINES FOR DESIGN OF SLOW SAND FILTERS

Description	Recommended Design value	Description	Recommended Design value
Design period	50 years	Depth of tap water	1.0m
Filtration rate		Free Board	0.2m
Normal Operation	1.5m/hr	Depth of filter and tank	1.0m
Max. overload rate	0.2m/hr	Level (Maximum)	0.5m
Number of filter tank Minimum	2	size of sand effective size	0.5-0.5mm
Areas upto 300 m ²	2	Uniformity coefficient (U.C)	2
Areas upto 300-2400 m ²	3	Gravel (3-4 layers) depth	0.3m
Areas upto 2400-6000 m ²	4	Windrows made of bricks or reinforced pipes	0.5m
Areas upto 6000-12000 m ²	5	Depth of filter box	2.7m
Areas upto 12000-20000 m ²	6	Diffuser level above sand bed	200mm

7.6.3 RAPID SAND FILTERS

7.6.3.1 Filtration Process

The rapid sand filter comprises of a bed of sand resting on a single medium granular matrix supported on gravel overlying an underdrainage system. The distinctive features of rapid sand filtration as compared to slow sand filtration include careful pretreatment of raw water to effectively flocculate the colloidal particles, use of higher filtration rates and coarser but more uniform filter media to allow greater depths of filter media to trap influent solids.

specified by the uniformity coefficient which is the ratio between the sieve size (no. 60) and the effective size.

Shape, size and quality of filter sand should meet the following norms:

- Sand shall be of hard and resistant quartz or quartzite and free of clay, fine particles, soft joints and dirt etc. as per specification.
- Effective size shall be 0.45 mm or thereon.
- Uniformity coefficient should not be more than 1.7 nor less than 1.3.
- Specific gravity shall not exceed 2.65 per cent by weight.
- Soluble fraction soluble in dilute acid shall not exceed 5.0% by weight.
- Shrinkage should be not less than 10%.
- Specific gravity shall be in the range between 2.55 to 2.65.
- Wearing loss shall not exceed 1%.

IS: 419 (Part 1) 1973 (Revised) Filter Sand and Gravel may be referred to for details.

7.6.3.7 Depth Of Sand

Usually the sand layer has a depth of 0.60 to 0.75 m, but for higher rate filtration when the coarse medium is used deeper sand beds are suggested. The standing depth of water over filter varies between 1 and 2m. The usual sand above the water level should be at least 0.5 m so that when air loading problems are encountered, it will facilitate the additional levels of 0.15 to 0.30 m of water being provided to overcome the trouble.

7.6.3.8 Preparation Of Filter Sand

The stock to be used for the filter is specified in terms of effect of size and uniformity coefficient. From a stock analysis of the stock sand, the coarse and fine portion of stock sand that must be removed in order to meet the size specifications, can be computed in terms of p_1 , the percentage of stock sand that is smaller than the desired effective size d_1 , which is also equal to 10% of the usable sand and p_2 , the percentage of the stock sand that is smaller than the desired 60 percentile size d_2 .

The percentage of suitable stock sand p_3 is then $= 2(p_2 - p_1)$ because the sand lying between the d_1 and d_2 sizes will constitute half the specified sand.

To meet the specified composition, the sand must contain 0.1 p_3 of a sand below d_1 size. Hence the percentage p_4 below which the stock sand is too fine to use is

$$p_4 = p_1 + 0.1(p_2 - p_1) = 0.2(p_2 - p_1) + 0.1p_2 \quad (7.1)$$

Likewise, the percentage p_5 above which the stock sand is too coarse for use is

$$p_5 = p_2 + 0.9(0.1 \text{ of usable sand}) \\ = p_2 + 0.4 \times 2(p_2 - p_1) = p_2 + 0.8(p_2 - p_1) = 1.8p_2 - 0.8p_1$$

From the cumulative frequency curve, the grain sizes of soil d_{10} and d_{60} corresponding to q_{10} and q_{60} are determined (d_{10} and d_{60}). The size d_{10} and d_{60} will have to be separated out from the rock sand to bring it to the desired specification. This may be done by sieving. The finer portion can also be removed by a sand washer equipped to clean up the particles of size smaller than d_{10} by maintaining velocity in the upward flow water slightly less than the bulk rate subsidence value corresponding to d_{10} size, since this will permit only that d_{10} size to float out with the flowing water.

7.6.3.9 Filter Bottoms And Strainer Systems

The water drainage system of the filter is intended to collect the filtered water and to distribute the wash water as such a system that all portions of the filter may perform nearly the same amount of work and when washed receive nearly the same amount of cleaning. Since the rate of wash is several times higher than the rate of filtration, the d_{10} must be the governing factor in the hydraulic design of filter which are created by backwashing.

The most common type of filter bottom is a cast iron manifold with laterals either perforated or ribbed bottom or having gridlike type strainers. A cast filter type such as Wheeler type or false bottom type strainers, formed for the entire area in several intervals or a perforated plate floor supported on numerous pipes, are all satisfactory when properly designed and constructed. However, plates, however, are likely to be clogged by minute quantities of sludge which can penetrate through the ribs. A clog might lead to a pipe.

In the case of cast iron manifold with laterals either the manifolds, headers and laterals are to cast from purple, asbestos cement, concrete or other material. The velocity of air issuing from perforated pipes or nozzles is destroyed by directing the quantities downwards against the filter bottom and into the frame grates surrounding the pipes. The air flow, therefore, will be equal to the downward flow during the wash. To prevent this, sometimes man holes are set lateral to manifold or nozzles under drain system a preferable way is to water has a low pH and is corrosive and when the corrosion the pH has to adjust the alkalinity. However, AS 14 is used to have a tendency to rise in pH at the presence of low pH than tap water.

The following values may be used in the design of a manifold system consisting of central manifold and laterals.

The lateral may vary from 100 to 150 mm diameter and should be supported at a slight angle from the vertical. The spacing between the laterals may vary from 800 mm to perforated metal floor is 200 mm for pipes and 150 mm.

Between the frame of perforated ribs in the manifold, the spacing in cross section and row of lateral should not exceed 500 mm for pipes and 400 mm for grates, to allow for perforations of 5 mm.

Between the area of perforations to the frame of the section may be about 0.5" with a range of length or diameter of the lateral, not to exceed 0.100 spacing of laterals close to perforations the spacing of ribs and shall be 50 mm.

The cross-sectional area of the manifold should be preferably 1.5 to 2 times the cross-section of the lateral, to minimize frictional losses and to give the best distribution. It is noted that the design of manifold and distribution of wash water is critical to the under drain.

The cast iron manifold with lateral type of distribution system is shown in fig. 118.





FIGURE 7.17 ORIENTATION SKETCH FOR OPERATION OF DOWNFLOW GRANULAR MEDIA WATER FILTER



DETAIL OF LATERAL DRILLING

FIGURE 7.18 - A PERFORATED PIPE UNDERDRAIN

The troughs are designed as free falling weirs or culverts. For free fall of rectangular troughs with level inlets, the discharge capacity Q in m^3/s can be computed from the formula

$$Q = 1.486 b h^{3/2} \quad (7.32)$$

Where b is the width of the trough in m and h is the water depth in m .

7.6.3.12 High Rate Backwash

Back wash should be arranged at such a pressure that sand should expand to about 130-150% of its undisturbed volume. The pressure at which the wash water is applied is about 5m head of water as measured at underdrains.

Normally, the rate at which wash water is applied, where no other agitation is provided, is 36 m³ (60 lpm/m²) for a period of 10 minutes. The tendency in design is toward higher rates of washing, primarily because of the larger sizes of sand being used, which require a faster application of water for equal expansion unless surface agitation by auxiliary means is provided. The maximum fraction that may be washed free to move and expand in water is their submerged weight in water. Beyond this time, any further increase in flow may lead to the carryover of fine grains along with the wash water. For high rate wash, the pressure in the underdrainage system should be 6 to 8 m with the wash water requirement being 40-50 m³/hr for a duration of 6 to 10 minutes.

The supply of wash water can be made through an overhead storage tank or by direct pumping or by tapping the rising main of the treated water if the clean water meters are not overloaded. The capacity of the storage tank must be sufficient to supply wash water to two filter runs, one time, when the units are in service.

7.6.3.13 Surface Wash

The upper layer of the filter bed because of the most rapid expansion washing will lead to the formation of mud balls, cracks and clugged spots in the filters. These troubles can be overcome by using the surface wash which can be accomplished by using the expanded filter bed mechanically with rakes, by circulating jets of water directed into the sand and sand or pneumatically with air, oil or diaphragm type compressors. The latter two methods being common and desirable.

(a) Hydraulic System

1. The fixed type surface washing system shall consist of pipes not less than 25 mm in diameter arranged vertically at intervals of 0.6 to 0.9 m. The lower ends of the pipes are to be situated so that they project evenly over the sand surface and nozzles shall be located on the lower ends of pipes. An alternate fixed type may consist of piping horizontally arranged at intervals of 0.6 m approximately at a height of 1.0 to 0.1 m over the sand surface. The horizontal pipes shall be perforated at intervals of 0.3 m approximately and provided with non-clogging outlet ports to prevent entry of the filter media.
2. The rotary type shall consist of rotating pipes suspended at a height of 50 to 75 mm at adequate intervals over the bed to provide adequate coverage jet nozzles

shall be located to side and bottom of frame and act as support for wash water and shall be at a pressure of 0.12 MPa.

(b) Air Wash System

In the air wash system, compressed air is used to remove effective sanding agent with a smaller volume of wash water. The air wash is passed through the frame and above the wash water, is mixed with air through a special pipe with a diameter of 200 mm and the sand layer. Through the frame, more than one washing, the sand is likely to be disturbed. With the former procedure, the amount of air is 0.16 m³/min for a 2000 g/m² of the filter area; or 0.35 kg/m² is mixed through air under the same time, the sand is thoroughly agitated for a duration of 10 min. The rate follows the which, wash water is introduced through the side and bottom of the frame to 30 mm to 40 mm (height of the area). On the other hand, with the lance pipe, the wash water is forced down to the center drain, about the same volume of air is forced straight through through a separate piping, in the practice of backwashing creating comparative air and water wash, air is usually applied at a rate of 0.50 m³/min and 0.12 MPa.

2.6.3.14 Operation Of Filters

Before starting, a filter is washed clean and the sand bed has been stratified vertically by the air jet water which is passed in alternate directions through it. The filter rate of rapid gravity filter depends on several attendant factors. It is necessary to maintain the sand bed of head or backwash. It is given at the pump capacity and piping height of backwash water and air. The sand bed is covered with a thin layer composed of sand less it contains a micro-bubble system. Use of incoming piping of the filter is a good water gutter with a pipe to under the frame. The use of sand filter can be done if a washing should not exceed 10 min. The time that use of the greater the rate of filtration, the greater the initial head loss. The initial head loss of the filter grows only during a time. It is usual to allow a time head loss of 1.5 m to 2 m before cleaning each filter. Under the 100 distance, a head loss of 1.5 m to 2 m is not to be allowed.

The duration of the washing process can be different in a case of cleaning of the filter, sand and sludge material, sludge, sand, and the sludge should not be allowed to settle in a long time after filtration.

In a gravity operated filter, the clean sand bed wash used should be covered 20% of the initial sand of a filter. It is convenient and possible when large quantities of wash water is involved and water is scarce. Generally, the backwash of a gravity wash water filter is the treatment has not to be applied, including the washing process, it is used to be backwash in the first few minutes of time through the filter, must be cleaning of the filter, effluent immediately stop using. It is not recommended by a variety of methods, it is also caused by an economic assessment, is the best choice in the stability of effluent of a high quality filter. The test is concerned to advantage in most parts.

The water running on the head of the cover of the wash should be clear with a turbidity not exceeding 10 NTU. In a well designed and maintained filter, there should be no air binding when during filtration. A damage wash of time should be to carry away of sand with the wash water and the sand bed should settle more firmly and more without undulations.

formation of sand balls and their retention in the bed even after washing, indicates poor performance. At the commencement of the filtration (or after a wash), the initial loss of head should not exceed 0.3 m.

7.5.3.15 Hydraulics Of Filtration

The head loss h_f through a clean filter bed of depth L can be computed using Kozeny's equation

$$h_f = \frac{k}{g} \frac{\mu}{\rho} \frac{v_f^2 (G \cdot f)^2 L}{f^3} \left(\frac{1}{\sigma} \right) \quad (7.33)$$

k = resistive dimensionless coefficient, about 5 under most conditions of water filtration,

μ = absolute viscosity of water, ($N \cdot s$)

ρ = density of water, (Kg/m^3)

v_f = macroscopic velocity of filtration, (m/s)

f = porosity of clean sand bed, dimensionless

G = surface area of the grains (m^2)

V = volume of the grains (m^3)

σ = ratio of spheric medium particles or diameters d

$$\sigma = \frac{d_1}{d_2}$$

For non-spherical grains, sphericity is defined as the surface area of the equivalent volume sphere to actual surface of non-spherical particles. The sphericity, σ assumes values of 1.0 for spherical grains, 0.98 for rounded grain, 0.94 for worn grains, 0.81 for sharp grains, 0.78 for angular grains and 0.40 for crushed grains for sand medium.

In a stratified beds as obtainable in rapid sand filters after back washing, the head loss in a given bed will be sum of the head losses in successive sand layers. If n is the fraction of medium of sieved size m , the head loss is given by

$$h_f = \frac{k}{g} \frac{\mu}{\rho} \frac{v_f^2 (G \cdot f)^2 L}{f^3} \left(\frac{1}{\sigma} \right) \sum_{m=1}^n \frac{p_m}{\sigma_m^2} \quad (7.34)$$

For unstratified beds e.g. slow sand filter, the head loss becomes

$$h_f = \frac{k}{g} \frac{\mu}{\rho} \frac{v_f^2 (G \cdot f)^2 L}{f^3} \left(\frac{1}{\sigma} \right) \sum_{m=1}^n \frac{p_m}{\sigma_m^2} \quad (7.35)$$

7.6.3.16 Hydraulics Of Backwashing

High rate granular filters are backwashed to remove the impurities lodged in the medium matrix. The hydraulics of backwashing concerns with the determination of head loss across the filter bed during backwashing and to estimate backwash velocity at any required level of bed expansion and concomitant porosity of expanded bed.

As the water is applied in upflow mode to a granular medium or media, frictional resistance is offered by the filter grains due to skin friction and form drag. The initial effect at low velocities of flow is to result in concentration of the particles to minimize frictional resistance. At low backwash velocities, the filter bed does not expand and its porosity does not change. The head loss or pressure drop is a linear function of upward flow velocity at low velocities. As the water velocity is increased, the frictional resistance also increases till it reaches a value equal to the gravitational force acting upon the filter grains. Any further increase in the velocity of water fluidizes the filter bed resulting in bed expansion and increasing porosity of filter bed.

(a) Head loss across filter bed

The maximum frictional resistance that can be offered by the filter grains in fluidized state is their submerged weight. The head loss across the filter bed in fluidized condition is given by the equation

$$h_f = \frac{(\rho_m - \rho) L}{\rho} (1 - \epsilon) \quad (7.36)$$

Where,

h_f = head loss across filter bed during backwashing (m)

L = height of the expanded bed, (m)

ρ_m = mass density of the filter grains (kg/m^3)

ρ = mass density of water, (kg/m^3)

ϵ = porosity of expanded bed, dimensionless

Since the grain volume does not change before and during backwashing,

$$L(1 - \epsilon) = (L + l)(1 - \epsilon')$$

l is given by eqn (7.37) using eq (7.36)

$$h_f = \frac{(\rho_m - \rho) L}{\rho} (1 - \epsilon) \quad (7.38)$$

(b) Estimation of Backwash Velocity

Several approaches are available for computation of backwash velocity to achieve a desired degree of bed expansion and attendant expanded bed porosity or to estimate bed expansion and expanded bed porosity at a given backwash velocity.

According to one of the approaches, first minimum fluidization velocity (v_{mf}) which is the superficial fluid velocity required to initiate fluidization of the bed is computed from the empirical Carman-Kozeny equation:

$$V_{\text{eff}} = \frac{1}{2} \rho_{\text{eff}} \omega_{\text{eff}}^2 \left(\frac{1}{2} \rho_{\text{eff}} \omega_{\text{eff}}^2 \right)^{-1} \left(\frac{1}{2} \rho_{\text{eff}} \omega_{\text{eff}}^2 \right)^{-1} \left(\frac{1}{2} \rho_{\text{eff}} \omega_{\text{eff}}^2 \right)^{-1} \quad (2.201)$$

and

(i) $\rho_{\text{eff}} = \rho_{\text{eff}}(\omega_{\text{eff}})$ is the effective density of the medium.

(ii) $\omega_{\text{eff}} = \omega_{\text{eff}}(\omega)$ is the effective angular frequency.

(iii) $\rho_{\text{eff}} = \rho_{\text{eff}}(\omega_{\text{eff}})$ is the effective density of the medium.

(iv) $\omega_{\text{eff}} = \omega_{\text{eff}}(\omega)$ is the effective angular frequency.

where

$$\rho_{\text{eff}} = \frac{1}{2} \rho_{\text{eff}} \omega_{\text{eff}}^2 \left(\frac{1}{2} \rho_{\text{eff}} \omega_{\text{eff}}^2 \right)^{-1} \left(\frac{1}{2} \rho_{\text{eff}} \omega_{\text{eff}}^2 \right)^{-1} \left(\frac{1}{2} \rho_{\text{eff}} \omega_{\text{eff}}^2 \right)^{-1} \quad (2.202)$$

(i) $\rho_{\text{eff}} = \rho_{\text{eff}}(\omega_{\text{eff}})$ is the effective density of the medium.

(ii) $\omega_{\text{eff}} = \omega_{\text{eff}}(\omega)$ is the effective angular frequency.

(iii) $\rho_{\text{eff}} = \rho_{\text{eff}}(\omega_{\text{eff}})$ is the effective density of the medium.

(iv) $\omega_{\text{eff}} = \omega_{\text{eff}}(\omega)$ is the effective angular frequency.

The effective density of the medium is given by the effective density function ρ_{eff} .

$$\rho_{\text{eff}} = \frac{1}{2} \rho_{\text{eff}} \omega_{\text{eff}}^2 \quad (2.203)$$

It is important to note that the effective density function ρ_{eff} must be applied as follows:

$$\rho_{\text{eff}} = \rho_{\text{eff}}(\omega_{\text{eff}})$$

The effective density of the medium is given by the effective density function ρ_{eff} is then given by the following equation:

$$\rho_{\text{eff}} = \rho_{\text{eff}}(\omega_{\text{eff}}) \quad (2.204)$$

The effective density of the medium is given by the effective density function ρ_{eff} is then given by the following equation:

$$\rho_{\text{eff}} = \frac{1}{2} \rho_{\text{eff}} \omega_{\text{eff}}^2 \quad (2.205)$$

The effective density of the medium is given by the effective density function ρ_{eff} is then given by the following equation:

$$\rho_{\text{eff}} = \rho_{\text{eff}}(\omega_{\text{eff}}) \quad (2.206)$$

The effective density of the medium is given by the effective density function ρ_{eff} is then given by the following equation:

$$\rho_{\text{eff}} = \frac{1}{2} \rho_{\text{eff}} \omega_{\text{eff}}^2 \quad (2.207)$$

The expected total porosity, $\bar{\mu}_p$, can be determined from the equation $\bar{\mu}_p = \bar{\mu}_p \mu_p$ in equation 7.10.

The experiment of graded filter sands at different compaction conditions that can be used to excellent degree for the above calculation of $\bar{\mu}_p$ within the apparatus of Figure 7.10 is given in Table 7.1 for the graded filter sand produced by the manufacturer.

It is noted that the given information also includes the head loss, h_f , for the filter sand expressed as $h_f = \lambda L v$ in eq. 7.11.

$$L = \frac{(\lambda v)^{-1}}{(\lambda v)} \quad (7.11)$$

Where, λ is the undrained settling velocity of the filter sand, $\mu_p = \bar{\mu}_p / \mu_p$ is the porosity of the sand.

7.6.3.12 Optimum Backwashing

It is noted that efficient maintenance of filters can be achieved by using the optimum backwash duration, backwash and the principal factor of design is to determine them. Theoretically, supported with experimental evidence, it is shown that the optimum maximum hydraulic head loss control at expense of total porosity is $h_f = 0.0015$ m.

According to Camp and Stein's equation, the head loss can be expressed as

$$\frac{h_f}{L} = \frac{1}{2} \rho v^2 \beta \quad (7.12)$$

- When $\frac{dh_f}{dt}$ = velocity gradient within pores
- v^2 = velocity within pores
- $\frac{dh_f}{L}$ = head loss per unit length

It is noted that head loss is given by

$$h_f = \frac{dh_f}{L} \left(\frac{dh_f}{dt} \right) \quad (7.13)$$

combining equations (7.12) and (7.13)

$$h_f = \left[\frac{1}{2} \rho \frac{v^2}{v} \frac{dh_f}{dt} \right] L \quad (7.14)$$

The velocity within pores can be expressed as

$$v^2 = \frac{1}{L} \lambda v h_f \quad (7.15)$$

$$\text{and } \frac{dh}{dt} = \left(\frac{\rho_s - \rho}{\rho} \right) f_v \quad (7.50)$$

$$\gamma = K [f_v^{n-1} - f_v^n] \quad (7.51)$$

where $K = [\mu g K_c (\rho_s - \rho)^{n-1}]$

Differentiating Eq. 7.51 and equating to zero

$$\frac{d\gamma}{df_v} = K \left[\frac{1}{2} f_v^{n-1} - f_v^n \right] = \left[\frac{1}{2} (n-1) f_v^{n-2} - n f_v^{n-1} \right] = 0$$

Optimization of the equation for γ can be made by differentiating the equation and equating to zero yields the following expression for the porosity of maximum hydrodynamic shear:

$$f_v = \frac{n-1}{n} \quad (7.52)$$

According to this equation, the maximum hydrodynamic shear occurs in a fluidized bed at porosities of 0.68 to 0.71 for typically sized filter sands which corresponds to an expansion of 80 to 100%. However, the curve of the hydrodynamic shear versus porosity is quite flat, indicating that washing at porosities different from the theoretical optimum does not result in a major decrease in the efficiency of cleaning process. Optimal cleaning has been observed in some cases at expansion of 16-18% only.

It has been found that there is lack of abrasion during water backwash and therefore a backwashing with water alone is inherently a weak cleaning process. For effective cleaning, abrasion resulting from collision, between grains is achieved by auxiliary process like surface wash or air scour (Section 7.6.3.13).

7.6.3.18 Appurtenances

Filter appurtenances include manually, hydraulically or electrically operated shut-off valves on the influent, effluent, drain and wash water lines; measuring devices such as venturi meters, rate controllers activated by measuring device, loss of head and rate of flow gauges, sand expansion indicators, wash water controllers and indicators, operating tables and wash sampling devices; and ejectors and sand washers; wash water tanks and pumps.

(a) Rate of Flow Controllers

The primary purpose of rate of flow controllers is to regulate the flows of liquids in the lines and specifically, in filter plant, to maintain at all times a uniform rate of filtration through each filter unit. Without these control features in the filter effluent lines, raw water will pass through the sand bed at different velocities, higher when the sand bed is clean and lower when coagulated deposit has accumulated on its surface.

Sudden change of rate of flow also must be avoided if the filter medium is to be maintained in an unbroken and efficient condition. Any changes in rate must be gradual and predetermined maximum must not be exceeded. Such unfavorable operating conditions may be eliminated by the use of rate of flow controllers.

The flow can also be controlled by means of a Venturi or a venturi-like water control valve.

Rate of flow controllers may be classed as double-beam type or venturi type. The beam type consists of a main section, diaphragm chamber arrangement, valve mechanism and counter-weighted scale-beam group and receiver outlet section. By virtue of the arrangement of the parts, straight line flow through the unit is facilitated.

Water flowing through the venturi section produces different pressures at the main and throat, due to the difference of velocities at these points. Since connections from the main and throat lead to the upper and lower halves, respectively, of the diaphragm chamber, these differential pressures are reflected directly on the piston, moving it a certain distance depending on the difference between the pressures being exerted. Since downward pressure on the top of the piston is greater than upward pressure from below, a downward pull is balanced by the counter weight on the long arm of the beam as transmitted to the scale beam. This balance of counter weight and piston load regulates the valve opening and hence the maximum rate of discharge through the controller.

In filter operation, the controller, by virtue of its throttling action, uses up all the sand due to the difference in raw and filtered water which is not required to overcome friction loss to sand, piping, velocity head, etc., and as the loss of head through the sand increases, the head consumed by the controller diminishes by a corresponding amount. During the entire operation, therefore, the rate of filtration remains practically constant.

However, it must be emphasized that rate of flow controllers require proper operation and maintenance to ensure that filtration is done at constant rate. These devices are used only where feeding rate of filtration is adopted.

(b) Filter Gauges

Filter gauges are essential to the operation of the modern filter plant to indicate and to accurately the rate of flow through each filter box and to determine the loss of head occurring at any given time during the filter run. Gauges are available in various combinations of rate of flow and loss of head, both indicating and recording or as single recording or indicating units.

These gauges use the float and mercury principle for the conversion of differential pressure into measurement of loss of head or rate of flow. The primary pressure differential producing device required for the rate gauge usually is the venturi section of the efficient rate controller, connections to the high and low pressure sides of the gauge valve or being made to the main and throat sections of the controller. The differential pressure for the gauge is the difference between the water level in the filter box and the pressure head in the effluent pipe, pressure connections being led from these sources to the high and low pressure gauge cylinder taps.

Particulates can also be used for filtration, though they derive from one stream and the flow rate is dependent on their particle size, their porosity, and sensitivity and fouling exposure to the different chemical types of contaminants.

7.6.3.18 Sand Filtration (Gravity)

Properly designed and constructed sand filtration systems can remove 90 percent of turbidity, 90 percent of iron, and 90 percent of manganese. This form of gravity operation by means of a sand bed filter.

The sand bed filter has a minimum depth of 1.5 feet. The specific gravity of the filter media must operate with a minimum rate up to the surface of the media. It is exposed. The filter's performance and yield (actual) will depend on filter media depth, particle size, and filter rate. The filter media, that is, sand, is clean.

In some plants, the suspension of sand in the water is replaced, and the sand is replaced by a bed of granular activated carbon. This is a type of sand filter. The sand is replaced by a bed of granular activated carbon. This is a type of sand filter. The sand is replaced by a bed of granular activated carbon.

7.6.3.19 Fine Filtration

The efficiency of fine filtration is dependent on the type of filter media used. The efficiency of fine filtration is dependent on the type of filter media used. The efficiency of fine filtration is dependent on the type of filter media used.

7.6.3.20 Dual-Media and Multi-Media Filtration

The dual-media and multi-media filtration systems are designed to remove turbidity and suspended solids. The dual-media and multi-media filtration systems are designed to remove turbidity and suspended solids. The dual-media and multi-media filtration systems are designed to remove turbidity and suspended solids.

Various applications have been recommended to overcome the above limitations of the conventional sand filter. These include up-flow filtration, backwash flow filtration and dual-media and multi-media filtration. Central to the development of these concepts is the principle of counterflow filtration. The counterflow filtration system consists of filter media having maximum pore size and porosity to remove the largest impurities. As water travels deeper into the filter bed, it comes in contact with filter bed layers containing smaller pore sizes resulting in removal of even very fine flow particles. This leads to better-quality filtrate and greater utilization of lower layers to remove impurities. The dual-media and multi-media filters which are being increasingly used can be operated at higher rates of filtration with

production of higher quantities of filtered water of good quality per plant area compared to rapid sand filters.

7.6.4 RAPID-GRAVITY FILTER MEDIA FILTERS

The rapid gravity filter media filters are those containing two or more non-uniform coarse sand and fines suspended in downward direction under gravity.

7.6.4.1 Construction and Description

The enclosure of a gravity filter media is usually a rectangular box made of concrete or masonry. The plan area of these filter may range between 45 and 206 m² with depths between 2.5 m to 3 m. The filter media is supported on gravel bed over top of the under-drainage system connected to the under-drainage system used for collecting filtered water and discharging it. Backwash water is brought to the troughs spanning across the width of each filter for distribution of water to be filtered and for collection of wash water. The troughs remain submerged during filtration and their top edge is normally kept 150 mm above the filter media to prevent loss of media during backwash and to minimize the amount of dirty water that flows to filter basin, the area of the wash.

The filters are commonly arranged in rows parallel to the direction of supply water. The filters receive the influent directly, whereas for gravity wash water is being pumped and other appurtenances including gate of flow control. The receiving pipes to distribute wash water to the structure or into the filter can be an also located above and/or below the gallery floor.

7.6.4.2 Filtration Media

With a view to maintain uniformity in the gradation of pore sizes and pore volume with increasing depth of filter bed, two media of different density and size are chosen. The top layer consists of a lower density material like coal having larger particle size over a layer of higher density material like silica sand having smaller diameter particles. Since the media comprising coal is not easily available, the coarse medium may consist of high grade bituminous coal or crushed coconut husk which have been recommended for use after laboratory and field trials. The effective size (d₁₅) of coal (specific gravity 1.4) is usually from 3.8 to 6 mm range with uniformity coefficient (U.C.) of 1.3 to 1.5. Coefficients of 0.3 to 0.4 have been reported to be satisfactory, whereas excessive head loss built up and fines losses can be occlude particles besides requiring large backwash requirements. The finer media generally consists of 0.5 to 0.6 mm thick silica sand (specific gravity 2.65) with effective size of around 0.5 mm (0.45 to 0.6 mm range) and uniformity coefficient of 1.3 to 1.5.

The basic principle in designing the dual media bed is to have coal as coarse as is consistent with solids removal to prevent surface hardening but to have the sand as fine as possible to provide maximum solids removal subject to the constraint that the finer sand should not be present in the upper layers after backwashup in appreciable quantity.

In addition to high grade bituminous coal, crushed cocoma shell has been effectively used as coarse media in dual media filters. The size ranges from 1.0 to 2.0 mm with depths of 0.3-0.4 m. The uniformity coefficient is below 1.5 and specific gravity 1.4. The sand used in conjunction with crushed cocoma shell has effective size varying between 0.4 to 0.55 mm with uniformity coefficient below 1.5. The sand depths may vary between 0.30 and 0.4 m. Water treatment plants with capacities ranging between 5 to 20 mld have been constructed employing dual media filter using crushed cocoma shell and sand.

Anthracite coal has been extensively used in dual media filters. It is recommended that 0.2 to 0.75m of anthracite coal of effective size of 1.0 to 1.6 mm (specific gravity 1.45-1.55) be used above a sand layer of 0.15 to 0.30 m. The effective size of sand may vary between 0.45 to 0.8 mm with 0.45 mm being preferred. The sand should have a specific gravity of 2.65.

7.6.4.3 Design Of Media Depth And Media Sizes

a) Design of Media Depth

The efficiency of removal of suspended particles is a function of the surface area of the media grains. For a filter of depth L comprising of N particles of average size d and sphericity ψ

$$A = \frac{100}{\pi} \left(\frac{L}{d} \right) \left(\frac{\psi}{\psi_0} \right) \left(\frac{V}{V_0} \right) \quad (7.58)$$

$$L = \frac{6(1-f)(V)}{\psi \pi (d)} \quad (7.59)$$

The equation can be employed to design the depths of filter. For example, for typical high rate filters ($\tau=0.45$, $\psi=0.8$ and $\left(\frac{1}{d}\right) = 680$, $V = 290 \text{ m}^3$). Since the effective size of sand is normally specified, $\left(\frac{1}{d}\right) = 680$ corresponds to $(d_{10}) = 0.15$ when d_{10} is the effective size. Figures can be developed for predetermined values of A , based on pilot data, between the effective size of medium and filter medium depth for different values of N . These figures can be used to estimate depths of various combinations of dual media.

(b) Design of Media Sizes

The dual media filters, consisting of coarse but lighter medium particles on top of finer but heavier particles, must remain free stratified character during backwashing and resetting. Equal expansion during backwashing for dual media comprising of coal and sand with the equal fluidization velocity for both media. It can be shown that

$$\frac{d_m}{d_s} = \left(\frac{\psi_s}{\psi_m} \right) \left(\frac{\rho_s}{\rho_m} \right)^{1/2} \quad (7.55)$$

Where d_1 and d_2 respectively denote the largest grain within the upper layer (coal) and the smallest grains within the lower layer (sand). It follows that mixing during settling as well as during expansion determines the convenient allowable ratio of the grain sizes in the two layers.

For sharp interface and no intermixing, the ratio of maximum diameter of coal to the minimum diameter of sand that will ensure both equal expansion and equal settling can be computed using above mentioned equation for d_1 density of coal of 1.5 and its sphericity 0.79 and sphericity and density of sand of 0.85 and 2.65, this ratio is

$$\frac{d_1}{d_2} = \frac{0.85}{0.79} \cdot \left(\frac{2.65 - 1}{1.5 - 1} \right)^{1/3} = 2.26 \text{ or } 2.3$$

If partial intermixing is to be achieved the size of the coarsest coal must be more than 2.3 times the minimum diameter of sand for characteristics of coal and sand given.

7.6.4.4 Filtration Rates And Filtrate Quality

Dual-media and multimedia filters have been successfully operated at rates of filtration ranging from 15 to 20 $\text{m}^3/\text{m}^2/\text{hr}$ with acceptable filtrate quality. Field trials in India using high grade bituminous coal indicate that even with inadequate pretreatment of filter influents as obtainable in Indian conditions, filtration rates of 16 $\text{m}^3/\text{m}^2/\text{hr}$ could be recommended with filter run of at least 32 hours, though much higher rates of filtration upto 24 $\text{m}^3/\text{m}^2/\text{hr}$ could be employed if proper pretreatment is available. Filtrate turbidity are generally less than 1 NTU and coliform removal is around 95.

In general, it may be recommended to operate dual media filters at higher rates of 7.5 to 12 $\text{m}^3/\text{m}^2/\text{hr}$. The backwash rates of 42 to 54 $\text{m}^3/\text{m}^2/\text{hr}$ (700-900 mm/min^2) have been employed to clean the filters.

7.6.5 MULTIMEDIA FILTERS

The multimedia filters normally contain three media such as anthracite coal, silica sand and garnet sand with specific gravities being around 1.4, 2.65 and 4.2. The size of media may vary from 2 mm at the top to 0.15 mm at the bottom. A typical trimedium filter may contain 0.45 m of coal with an effective size of 1.4 mm, followed by 0.25 m of silica sand of effective size of 0.5 mm and 0.08 m of garnet sand having an effective size of 0.3 mm.

Media of polystyrene, anthracite, crushed flint sand, garnet and magnetite whose specific gravities are 1.04, 1.40, 2.65, 3.83 and 4.90 respectively are being tried.

7.6.6 PRESSURE FILTERS

7.6.6.1 General

Based on the same principle as gravity type rapid sand filters, water is passed through the filter under pressure through a cylindrical tank, usually made of steel or cast iron, wherein the

underdrain, gravel and sand are placed. They are compact and can be prefabricated and moved to site. Economy is possible in certain cases by avoiding double pumping. Pretreatment is essential. The tank axis may be either vertical or horizontal.

7.6.6.2 Disadvantages

Pressure filters suffer from the following disadvantages:

- (a) The movement of water under pressure seriously complicates effective flocculation, mixing and flocculation of water to be filtered.
- (b) In case of direct supply to an on-site filter, it is not possible to provide adequate contact time for chlorine.
- (c) Since water under filtration and the sand and amount of kg/m^3 and it is not possible to observe the effectiveness of the back wash or the degree of regularity during washing process.
- (d) Because of the inherent shape of the pressure filters it is difficult to provide wash water pattern effectively designed so that the material washed from the sand is discharged to waste and not flushed back to other portions of the sand bed.
- (e) It is difficult to inspect, clean and replace the sand, gravel and underdrains of pressure filters.
- (f) Because the water is under pressure at the delivery end, on a occasion when the pressure on the discharge main is reduced suddenly, the entire sand bed might be disturbed violently with disastrous results to the filter effluent.

In view of these disadvantages, pressure filters are not recommended for community water supplies, particularly for large ones. They may be used for industrial needs and swimming pools.

7.6.7 DIATOMACEOUS EARTH FILTERS

Diatomaceous filters, are not advertised for public water supplies. Their utility is restricted to temporary and emergency water supplies of a limited nature where other arrangements are not easy or desirable.

The medium consists of diatomaceous earths which are skeletons of diatoms mined from deposits laid down in seas.

The filtering medium is a layer of diatomaceous earth built up on a porous septum by recirculating a slurry of diatomaceous earth until a thin layer is formed on the septum. The product thus formed is used for straining the turbidity in water. For this, diatomaceous earth is applied at 0.5 to 2.5 kg/m^2 of septum. Some times, when the turbidity is very high, the diatomaceous earth will have to be added to the incoming water as body feed. Body feed is added at three times the solids when organic slimes etc. present. Filtration rates range from 7.2 to 18 $\text{m}^3/\text{m}^2/\text{hr}$.

7.6.8 ADDITIONAL MODIFICATIONS OF CONVENTIONAL RAPID GRAVITY FILTERS

7.6.8.1 Constant And Declining Rate Filtration

(a) Constant Rate Filtration by Influent Flow Splitting

In conventional rapid sand filters, constant rate of flow is maintained by installing a rate of flow controller on the effluent line. This rate of flow controller can be quite complex and highly material and maintenance cost. Alternative systems have been proposed which are easier to operate, install, operate and maintain.

One of the simplest methods is rate control by influent flow splitting, which is depicted in Fig. 7.19. The filter influent is divided equally among all the operating filters in series by means of a weir in each filter inlet. The level of the filter influent weir is kept relatively constant so that the head loss is not significant and the water level does not vary significantly along the length of the conduit. This helps in maintaining nearly same head on each of the units and flow rate is equally split among all the operating filters. The filtration rate is controlled just for all the filter units by the inflow feeding rate. At the beginning of filter run, clean and washed filter to put into service, the level of water in that filter is maintained. As the filtration process and head loss builds up, the water level rises in the filter till it reaches the maximum permissible level above the filter bed, which may be, for example, equal to the level of influent weir. The filter is then taken out of service for backwashing.

The advantages of this system include elimination of rate controllers and slow and costly change-over rates due to gradual rise and fall of water level above filter bed with loss




FIGURE 7.19 : GRAVITY FILTER ARRANGEMENTS FOR RATE CONTROL BY INFLUENT FLOW SPLITTING

harmful effects on filtrate quality in comparison to filters having rate of flow controllers. It completely eliminates the possibility of negative head in the filter, the effluent control valve must be located above filter media as shown in the Figure.

The only disadvantage of the influent flow splitting system is the additional depth of the filter box which is 1.5 to 2 m more than in conventional filters.

(b) *Declining Rate Filtration*

This is also referred to as variable declining rate filtration. In this system, the filter influent enters below the low water level of the filters and not above as in the case of influent flow splitting system described in section 7.6.8.1 (a). A relatively large influent header (pipe or channel) serves all the filters and a relatively large influent valve is used for each individual filter. This results in relatively small head losses in the influent header and influent valve and water level is essentially the same in all operating filters at all times. The essential features for variable declining rate filtration system are shown in Fig. 7.20. No rate of flow controllers are used in this system also.

During the course of filtration by a series of filters being served by a common header, as the filters get clogged, the flow through the cleanest filters decreases most rapidly. This causes redistribution of head among all of the filters increasing the water level according to the additional head needed by the clogged filters for handling additional flow. Therefore, the capacity lost by the dirty filters is picked up by the clean filters.

The advantage claimed for this system include significantly better filtrate quality than obtained with constant-rate filtration, and less available head needed than that required for constant-rate operation.

Another type of declining rate filtration is called "controlled-head" operation. In this type of filters, the filter effluent lines are connected to a common header. A fixed orifice is built into the effluent piping for each filter so that a clogged filter, after washing, will take an undue share




FIGURE 7.20 : GRAVITY FILTER ARRANGED FOR VARIABLE DECLINING RATE OF FILTRATION

of the flow. The filtered water header pressure may be regulated by a throttle valve which discharges to a filtered water reservoir. Costly rate controllers are replaced with fixed orifices and, therefore, would make the units even more practical particularly in large water works involving hundreds of filters. The quality of water produced by the declining rate filters and filters controlled by conventional rate controllers are reported to be almost the same. For equal durations of filter runs the total output per day from a declining rate filter is higher than that by the conventional one. In a group of filters operating at an average rate of $6 \text{ m}^3/\text{m}^2/\text{hr}$, fixed orifice will be so designed that a recently cleaned filter will begin operation at $7 \text{ m}^3/\text{m}^2/\text{hr}$ while the filter next in line for backwashing will have slowed down to about $3 \text{ m}^3/\text{m}^2/\text{hr}$. Usually the depths of filter boxes for declining rate filters are more than those for the conventional ones. These would permit longer filter runs and consequent reduced wash water requirements. The possibility of "break through" resulting in increased concentration of suspended solids in the effluent in filters with rate controllers is avoided in this system.

7.6.9 UP-FLOW FILTERS

In up-flow filtration, the water is passed under pressure in an upward direction through the coarse medium followed by finer medium. Thus larger size suspended solid particles are first retained in the larger interstices of the lower part of bed and as the water proceeds upwards it receives a progressive polishing until it emerges in a fully filtered condition at top of the filter bed. Thus the entire depth of media is made effective in removal of suspended solids and as a result low head loss and longer filter run could be expected. Besides many other advantages are claimed for up flow filtration such as elimination of the rate controller and absence of negative head. Unfiltered water can be used for washing filter since the first few minutes of flow through the filter after washing has to be necessarily run to waste. Filter depths as low as 0.6 m and as high as 1.8 m have been successfully used. Although wash water rate and consumption are greater per wash cycle than the conventional filter, wash water used as a percentage of treated water is much less because of low loss of head and long filter runs. But mainly compared air scouring is desirable to dislodge the impurities collected in the lower portions of the filter. The only disadvantage is fluidization of the top fine layers of the sand bed which results in the deterioration of the treated quality. Complete bed fluidization occurs when the headloss equals the depth of bed. Control of headloss is much more significant than the upward velocity through the filter. It is desirable that the hydraulic gradient through the upflow sand bed is restricted to 0.6.

7.6.10 GRID OR IMMIDIUM TYPE FILTERS

The problem of bed fluidization in an upflow filter is eliminated in this type by providing a grid. The grid is a system of parallel vertical plates placed within the bed a few centimeters below the top of the media. This grid provides a friction resistance to prevent expansion of the bed and breakthrough or channeling at relatively higher rates of filtration. The exact mechanism of how this plate grid restrains sand expansion has not been proved but it is believed that the upward flow of water causes formation of inverted arches of sand which bridges the gap between the adjacent vertical plates. Being a compressive force, arches are strong enough to resist the upward force of liquid being filtered ending to break through the bed, thus preventing fluidization of sand. Generally the grid spacing is 100-150 times the size

of fine sand at the top of the bed. They operate at the rate of 1.13 m³/m² hr and deliver 6.1 m³ of the filtered water per m² of down flow filter of the same size. Recent experience indicates that higher rates of 1.32 m³/m² hr would be possible. The operating rate, however, depends on quality of water to be filtered and the effluent quality desired.

7.6.11 RI-FLOW FILTERS

The possibility of flocculation of the finest sand may be avoided if a means is selected to ensure the effluent collecting pipe is in an upper layer of sand bed and filter is substantially free to flow through the beds of the media and from there through top layers of sand. With the same hydraulic head applied on top and bottom of the filter, the headloss across with the upper to lower beds in the centers of effluent pipe is the same and hence the effluent pipe is hydraulically balanced. The two principal hydraulic problems are the top 2 m of pipe near flocculation. The inlet or filter's case head of depth 1.5 m (5 ft) for an effluent collection system being provided is 2.5 m below the top and bottom of the filter is 1.5 m (5 ft) below the top and bottom of the filter. The headloss is 1.5 m (5 ft) less than conventional filter. The air scouring pipes and controls are more complicated.

7.6.12 SUBMERGED FILTERS

These filters have a 100% covered case. They are used primarily for pumping to use an automatic adjustment of treatment plant operation at high level pumping to meet the city's, and states as demands of a large city. These filters operate under vacuum, with a filtered water and through the use of a slow closing butterfly valve, the filter can run and be changed without deterioration of water quality. The butterfly valve also is closed over a period of time usually 3 to 10 minutes. The filters have proved satisfactory as a plant work.

7.6.13 RADIAL FLOW FILTERS

In these filters, flow comes in radially and washing is done continuously. The filter media is sand, contained in the annular space between a horizontal cylindrical shell. Chemically treated water enters into a central hollow column and permeates radially through sand, and is collected through peripheral holes and flows out of the shell. The dirty sand is continuously drawn from the bottom and filled in a compartment at the top of the filter where it is washed. The sand rising to the clouds while the washed water carrying air escapes out through an overflow device.

7.6.14 AUTOMATIC VALVELESS GRAVITY FILTERS

These filters operate without butterfly valves, pilot mechanism, flow controllers, gauges and air compressors. They have two compartments, the filtering section and with water storage compartment. As the incoming water is admitted to the filter, a head gets built up on the top of the sand and causes the water level to rise in the backwash pipe. When the water level reaches the top of the hop, usually designed with a 2 meters differential, syphon action is started and backwashing begins at the treated rate of 30 to 40 m³/m² hr. Wash water flows from the storage tank up through the sand bed and is discharged through the back

wash pipe. A siphon breaker ends the wash cycle. The filter washes itself automatically at the proper time at a given loss of head, without any mechanical arrangement or operating tables. There is no maintenance from a mechanical standpoint of view. These filters are useful for low turbidity waters and for small installations.

7.7 DISPOSAL OF WASTES FROM WATER TREATMENT PROCESSES

Disposal of wastes from the water treatment plants has become increasingly important with the availability of technology and the need for protection of the environment. Treatment of waste adds to the cost of construction and operation of treatment plants.

Wastes from water treatment plants comprise of:

- (a) sludge from sedimentation of particulate matter in raw water, flocculated and precipitated material resulting from chemical coagulation, or residuals of excess chemical dosage, plankton etc.;
- (b) wastes from rinsing and backwashing of filter media containing debris, chemical precipitates, scumings of organic debris and plankton and residuals of excess chemical dosage etc.; and
- (c) wastes from regeneration processes of ion exchange softening treatment plant containing cations of calcium, magnesium and unused sodium and anions of chlorides and sulphates originally present in the regenerant.

7.7.1 DISPOSAL METHODS

In continuous sludge removal, the feasibility of discharging of water treatment plant sludge to existing sewers nearby should be considered. For line softening plant sludge, the reclamation by aching and reuse can be explored [8.4.2.1 (a) (5)]. Sludge from clarification tanks using iron and aluminium coagulants can be dewatered by vacuum filter using lime as the conditioner, to a cake that can conveniently be trucked for landfill. The material will be still greasy and sticky. Recovery of alum from sludge by treatment with sulphuric acid offers possibilities of reducing the quantity of sludge to be handled and drying beds are an acceptable method for dewatering certain types of sludge from settling tanks or clarifiers for further disposal by landfill. Simple lagooning of sludge does bring about a reduction in the bulk of the sludge to be handled and further dewatered as landfill is necessary. Backwash water from filters can sometimes be recycled back to the plant tank which can possibly improve settling and filtration. Reclamation of backwash water from filters can be adopted in areas of water scarcity. Simultaneously this reduces the disposal problem of the waste.

7.8 PERFORMANCE CAPABILITIES

7.8.1 SLOW SAND FILTERS

The following standards of performance for slow sand filters are recommended:

- (a) The filtrate should be clear with a turbidity of 1 NTU or less.
- (b) The filtrate should be free from colour or loss in clarity should be less than 10 pcu.

12. The average number of people in a room is 30. Find the probability that the number of people in a room is less than 20, given that the number of people in a room is less than 40.
13. The probability of a person being a member of a club is 0.2. Find the probability that a person is a member of a club, given that the person is a member of a club or a member of a club.

14. (a) Find the probability that

- (i) a card drawn from a pack of 52 cards is a red card or a king or a queen or a jack or a 10 or a 9 or an 8 or a 7 or a 6 or a 5 or a 4 or a 3 or a 2 or an ace.
- (ii) a card drawn from a pack of 52 cards is a red card or a king or a queen or a jack or a 10 or a 9 or an 8 or a 7 or a 6 or a 5 or a 4 or a 3 or a 2 or an ace, given that the card is a red card.
- (iii) a card drawn from a pack of 52 cards is a red card or a king or a queen or a jack or a 10 or a 9 or an 8 or a 7 or a 6 or a 5 or a 4 or a 3 or a 2 or an ace, given that the card is a king or a queen or a jack or a 10 or a 9 or an 8 or a 7 or a 6 or a 5 or a 4 or a 3 or a 2 or an ace.

CHAPTER 8 DISINFECTION

8.1 INTRODUCTION

Water treatment processes such as sedimentation, flocculation, coagulation, filtration, aeration and water softening are primarily designed to remove suspended solids, to improve the appearance of water, to reduce the turbidity and to remove undesirable tastes and odours. However, these processes are not sufficient to protect drinking water from disease-causing microorganisms. The main objective of disinfection is to reduce the number of living organisms to a level where they are considered safe for consumption. Disinfection is the process of killing or inactivating microorganisms. Disinfection can be achieved by physical, chemical and biological means. Physical disinfection systems normally use ultraviolet light, gamma rays or high pressure ultrasonic radiation. Although chlorine, ozone, sodium hypochlorite and ozone are biological, such as chlorine is responsible for waterborne diseases. The most commonly used disinfecting process is chlorination. Chlorination of water must be well controlled and monitored to meet the required disinfection standards.

Chlorination of drinking water is the most common and effective disinfection method. The main objective of disinfection is to reduce the number of microorganisms to a level where they are considered safe for consumption. The main objective of disinfection is to reduce the number of living organisms to a level where they are considered safe for consumption.

- Physical methods such as ultraviolet light, gamma rays, etc.
- Chemical disinfection such as chlorine, ozone, sodium hypochlorite, etc.
- Biological disinfection such as ozone, etc.

The main objective of disinfection is to reduce the number of microorganisms to a level where they are considered safe for consumption. The main objective of disinfection is to reduce the number of living organisms to a level where they are considered safe for consumption.

8.2 CRITERIA FOR A GOOD DISINFECTANT

The criteria for a good disinfectant are as follows:

- It should be effective against all types of microorganisms, including bacteria, viruses, protozoa, and fungi.
- It should be stable and easy to handle.
- It should be safe for use and not produce any harmful by-products.
- It should be economical and easy to apply.

- (i) Possess the property of leaving residual concentrations to deal with possible recontamination.
- (ii) Be amenable to detection by practical, rapid and simple analytical techniques in the small quantities of samples to permit the control of disinfection process.

8.3 MECHANISMS OF DISINFECTION

The mechanism of killing the pathogens depends largely on the nature of the disinfectant and on the type of microorganisms. In general three mechanisms are proposed to explain the action of a disinfectant on a microorganism:

- (i) Damage to cell wall.
- (ii) Alteration of cell permeability.
- (iii) Altering the colloidal nature of the cell protoplasm.
- (iv) Inactivation of crucial enzyme systems responsible for metabolic activities.

Damage to cell wall leads to cell lysis and death. Alteration of cell permeability refers to the destruction of selective permeability of cytoplasmic membrane and causes outflow from cell cells of such vital nutrients, as nitrogen and phosphate. Denaturation of cell proteins, by acids and bases leads to destruction of cells. Inactivation of crucial enzyme activity vital to cell growth and survival is normally brought about by oxidizing chemicals.

General mechanism normally proceeds in at least two steps:

- (i) Penetration of the disinfectant through the cell wall and
- (ii) Action on vital enzyme system in cell.

8.4 FACTORS AFFECTING EFFICIENCY OF DISINFECTION

The efficiency of the disinfectant is influenced by the following factors:

- a) Nature and amount of water in the environment of organisms to be destroyed.
- b) Form and concentration of disinfectant.
- c) Nature and physical characteristics of material to be treated.
- d) Amount of time available for disinfection.
- e) Temperature of water.

8.4.1 TYPE, CONDITION AND CONCENTRATION OF ORGANISMS TO BE DESTROYED

The disinfectant has to diffuse through the cell wall before it can react with the enzymic system. Since the different types of organisms have different cell structures and different enzyme systems, the action of the disinfectant must necessarily vary. Amongst intestinal organisms, protozoa are less resistant than the rod-form group and hence the latter can survive in residual water of the effluent of disinfection.

Viruses appear to be more resistant than bacteria and require longer periods of contact as well as higher concentration of disinfectant. Spores are relatively resistant but fungicide is not of such significance as pathogens. Clostridia are extremely resistant. The conditions in which the organisms occur may also affect the efficiency of disinfection. Thus, when the bacteria are clumped together, the cell surface area is protected against the action of disinfectant. The density of the organism affects its efficiency only when its number is so high that there is a deficiency of available disinfectant. Such a condition may occur in disinfection of sewage, but is not usual in water works practice.

8.4.2 TYPE AND CONCENTRATION OF DISINFECTANT

The efficiency of disinfection will obviously depend on the nature of the disinfectant. The added chemical undergoes several transformations so that the disinfectant activity is affected by the end products of reaction. The course of these reactions is largely influenced by the character of the water and its conditions. These reactions that occur under different conditions will determine the type and proportion of the active disinfectant. Higher the concentration of a chemical disinfectant, the higher is the destruction of organisms.

8.4.3 CHEMICAL AND PHYSICAL CHARACTERISTICS OF WATER TO BE TREATED

Organic matter and certain oxidizing substances in water reduce the availability of the active products for disinfection. Undissolved solids or suspended materials in water may be sheltered from the action of disinfectant.

8.4.4 TIME OF CONTACT AVAILABLE FOR DISINFECTION

The destruction of organisms increases with contact time available for disinfection. In practice, the contact period is limited by the design of the plant and is usually not less than 30 minutes.

Adequate period of contact is available in most plants because the chlorinated water has a considerable detention in the clear water reservoirs before it is supplied. However, in small plants where such storage is not provided, the contact period is determined by the time taken for the water to flow from the point of application of chlorine to the point of draw-off of water by the first consumer. If the minimum contact time is not available, the dose of disinfectant should be suitably increased.

8.4.5 TEMPERATURE OF THE WATER

Rates of chemical reactions are speeded up as the temperature of the reaction is increased. The higher the temperature, the more rapid is the destruction of organisms.

8.5 MATHEMATICAL RELATIONSHIPS GOVERNING DISINFECTION VARIABLES

The kinetics of disinfection is affected by several variables as enumerated in Section 8.4. The effect of some of these disinfection variables can be quantified by empirical

a convenient relationship (where k_1 is a constant) between the rate of denaturation, namely to the zero of curvature, y_0 , or concentration of the curable resin, and the denaturation of water.

3.2.1. Rate and Time

The initial rate is a quantity which characterizes the rate of initiation of a reaction. In the present model, the initial rate is a function of the curing temperature. The number of experiments for a given temperature is small, so that it is not possible to find a unique value of k_1 (No. 1) that is true.

$$\ln \frac{y_0}{y_0 - k_1} = k_1 t \quad (6.1)$$

where t is the reaction time (min. or sec.).

Experiments were conducted by measuring the rate of cure of DGEBA by a dilatometer (see section 2.1.1) with time intervals ranging from 10 to 100 min. The results are shown in Figure 1. The dependence of the initial rate on the curing temperature is given by (6.1):

$$\ln \frac{y_0}{y_0 - k_1} = k_1 t \quad (6.2)$$

where k_1 is a constant that is a function of rate of all denaturation, k_1 , and if m is given then k_1 is a function of k_1 by means of a mathematical analysis and subsequent numerical calculations, resulting in a unique value for k_1 for a given m .

3.2.2. Effect of Temperature on the Reaction Rate

Reaction rate is affected by the curing temperature, concentration of initiator, etc. The relationship was examined in this section, and a procedure for determining a desired amount of initiator is given in Appendix B. The equilibrium constant

$$K = \frac{[A][B]}{[A][B]} \quad (6.3)$$

where K is the equilibrium constant, $[A]$ and $[B]$ are the concentrations of the reactants, k_1 is the rate constant of the reaction, k_2 is the rate constant of the reverse reaction, k_3 is the rate constant of the reaction, and k_4 is the rate constant of the reaction. The efficiency of the reaction is reduced if m is less than 1. The rate of the reaction is a function of m and k_1 (eq. 6.1). In addition, the efficiency of the reaction is a function of the concentration of the initiator, k_1 , but k_1 is a function of m and k_1 (eq. 6.1). The overall reaction rate is

$$\begin{aligned} R &= k_1 [A] - k_2 [B] - k_3 [A] - k_4 [B] \\ &= k_1 [A] - k_2 [B] - k_3 [A] - k_4 [B] \\ &= k_1 [A] - k_2 [B] - k_3 [A] - k_4 [B] \\ &= k_1 [A] - k_2 [B] - k_3 [A] - k_4 [B] \end{aligned}$$

The overall rate of the reaction is a function of the curing temperature, the concentration of initiator, and the concentration of the reaction. The overall reaction rate is

the manufacturer's instructions, and the use of the product is restricted to that of a DDD made according to the instructions of the manufacturer.

5.3.3 THERMAL CHARACTERIZATION

The thermal properties of the polymer were determined by the use of DSC under non-isothermal conditions. The thermal stability of the polymer was determined by thermogravimetric analysis (TGA) under non-isothermal conditions. The results are shown in Table 5.3.1.

$$\frac{dW}{dT} = \frac{dW}{dA} \cdot \frac{dA}{dT} \quad (5.3.1)$$

The results of the TGA analysis are shown in Figure 5.3.1. The results show that the polymer is stable up to 300°C. The weight loss is due to the degradation of the polymer. The results of the DSC analysis are shown in Figure 5.3.2. The results show that the polymer has a glass transition temperature of approximately 150°C. The results of the TGA analysis are shown in Figure 5.3.3. The results show that the polymer is stable up to 300°C. The weight loss is due to the degradation of the polymer.

5.6 CONCLUSIONS


5.6.1 CHARACTERIZATION OF THE POLYMER

The results of the characterization of the polymer are shown in Table 5.6.1. The results show that the polymer has a glass transition temperature of approximately 150°C. The results of the DSC analysis are shown in Figure 5.6.1. The results show that the polymer has a glass transition temperature of approximately 150°C. The results of the TGA analysis are shown in Figure 5.6.2. The results show that the polymer is stable up to 300°C. The weight loss is due to the degradation of the polymer.


8.6.2. CHLORINE-WATER-REACTIONS

8.6.2.1 Free Available Chlorine

Chlorine reacts with water to form hypochlorous acid (HOCl) and Hydrochloric acid (HCl) according to the equation:



The hydrolysis reaction is reversible. The hypochlorous acid dissociates into hydrogen ions (H⁺) and hypochlorite ions (OCl⁻) according to the equation:




This reaction is also reversible. Free available chlorine may be defined as the chlorine existing in water as hypochlorous acid and hypochlorite ions. The undissociated HOCl is about 90 to 100 times more potent as a disinfectant than the OCl⁻ ion.


Both the above reactions are dependent upon the pH of the water. When the pH value of the chlorinated water is above 7, which is normally the case, the hydrolysis reaction is almost complete and the chlorine exists entirely in the form of HOCl. The influence of pH on the disinfection action, therefore is governed by the second reaction as waters with pH value below 7 are very rare. From a consideration of the second equation, it is evident that as the pH increases, more and more HOCl dissociates to form OCl⁻ ion. At pH values of 5.5 and below it is practically 100% undissociated HOCl while above pH 9.5, it is all OCl⁻ ions. Between pH 6.0 to 8.0, there occurs a very sharp change from undissociated to completely dissociated hypochlorous acid with 90% to 10% of HOCl, with equal amounts of HOCl and OCl⁻ being present at pH 7.5 (Fig. 8.1). The addition of chlorine does not produce any significant change in the pH of the natural waters because of their buffering capacity.

8.6.2.2 Combined Available Chlorine


The free chlorine can react with compounds such as ammonia, proteins, amino acids and phenols that may be present in water to form chloramines and chloro-derivatives which constitute the combined chlorine. This combined available chlorine possesses some disinfecting properties though to a much lower degree than the free available chlorine. Theoretically some free available chlorine can exist along with combined available chlorine since these reactions do not go to 100% completion. The reactions with ammonia are



(Monochloramine)



(Dichloramine)



The monochloramine (NH_2Cl) and the dichloroams (NHCl_2) have disinfectant properties, though twenty five times less than that of free chlorine, while the trichloramine has no disinfectant properties at all. The pH of the water generally determines the ratio between the amount of mono and dichloramines formed which have nearly equal bactericidal powers. Below pH 4.4, trichloramine is found. Between pH 4.4 to 5.5, only dichloramine exists and in the range of 5.5 – 8.4, both mono and dichloroams prevail in a ratio fixed by the pH. At pH 7.0, equal quantities of mono and dichloroams are present and above pH 8.1 only mono chloramines are formed.

8.6.2.3 Chlorine Demand

Chlorine and chlorine compounds by virtue of their oxidizing power can be consumed by a variety of inorganic and organic materials present in water before any disinfection is achieved. It is, therefore, essential to provide sufficient rate and dose of chlorine to satisfy the various chemical reactions and leave some amount of unreacted chlorine as residual either in the form of free or combined chlorine adequate for killing the pathogenic organisms.

The difference between the amount of chlorine added to water and the amount of residual chlorine after a specified contact period is defined as the chlorine demand. The chlorine demand of any given water varies with the amount of chlorine applied, the time of contact, pH, temperature, and type and quantity of residual desired.

8.6.2.4 Estimation Of Chlorine

The usual tests practised for estimating the residual chlorine in water are the orthotolidine test (OT) and orthotolidine ascrite test (O.T.A.). The former is used for total residual chlorine concentration and the latter for free available chlorine. When orthotolidine reagent is added to water containing chlorine, a greenish yellow colour develops, the intensity of which is proportional to the amount of residual chlorine present. Soluble tablets of DPD (diethyl-p-phenylene diamine) have also been used successfully in place of orthotolidine reagent.

O.T AND O.T.A. METHODS

The orthotolidine test procedure does not overcome errors caused by the presence of iron, copper, iron and manganese, all of which produce a yellow colour with orthotolidine reagent. It is unable to discriminate between "Free Chlorine" and "Combined Chlorine". The O.T.A. method permits these differentiations. The principle of the method is that chlorine either free or combined is destroyed on addition of sodium ascrite whereas the colour produced by the reaction of chlorine with orthotolidine as well as the interfering agents is unaffected. The reaction of orthotolidine with free chlorine is instantaneous while with combined chlorine it is very slow and does not begin until about 10 seconds. This property is used for distinguishing free from combined chlorine. The test is carried out as follows:

- a) Take three tubes marked to hold 10 ml and label them 'A', 'B' and 'C'.
- b) To tube 'A' add 0.5 ml. of orthotolidine solution. Then add 10 ml. of water sample and mix. Add 0.5 ml. of 0.5% sodium ascrite (NaAsCl_2) immediately. Mix and compare with standards as rapidly as possible. Record the result (A).




FIG. 8.1 RELATIVE DISTRIBUTIONS OF TOTAL AND FREE Cd AT DIFFERENT pH VALUES

- c) To ensure the availability of an effective search mechanism, the following measures shall be adopted and implemented and shall be continuously monitored, reviewed and improved with regard to procedure, as far as it is possible. Revised on reading, (B) is a copy of the document and shall be available to the members of the judicial body. It may also be made available to the public.
- d) To ensure the availability of the following documents and records of the court: copies of the court files, court records, and the court records of support filed in the court, shall be available on request.
 - i) Court records:
 - Court records of the High Court of Jharkhand
 - Court records of the District Court
 - Court records of the District Court, Patna

3.6.3 CHIEF JUSTICE'S ORDERS

3.6.3.1 Case Records And Continued Availability of Records

The copy of the file shall be made available to the public on the determination of the court on request and during the process of the trial. It shall be available. Moreover, the court shall, in respect of the final judgment, records, proceedings and records available to the public. The final orders and judgments of the court shall be made available to the public on request. The records of the files shall be made available to the public on request. The records shall be made available to the public on request. The records shall be made available to the public on request.

(a) Free available records of judgments

(1) Plain or Simple Judgments

This new set of judgments shall be made available to the public on request. The records shall be made available to the public on request. The records shall be made available to the public on request. The records shall be made available to the public on request.

- (i) Clarity and readability of the records shall be a priority in the records of the court.
- (ii) Records shall be made available to the public on request.
- (iii) Records shall be made available to the public on request.
- (iv) Records shall be made available to the public on request.

(2) Super-Citations

This is a new set of judgments shall be made available to the public on request. The records shall be made available to the public on request. The records shall be made available to the public on request. The records shall be made available to the public on request.

- (i) Plain or Simple Judgments shall be made available to the public on request.


- (ii) The water is coloured; or
- (iii) Iron and manganese have to be oxidized

It may be resorted to on special occasions when available contact time is limited at the pre-chlorination stage. Super chlorination can effectively destroy the relatively resistant organisms such as viruses and protozoic cysts. The dose of chlorine may be as high as 10 to 15 mg/l with contact periods of 10 to 30 minutes. Excess chlorine will have to be dechlorinated.

(3) Dechlorination:



When superchlorination is employed, the water usually contains excess of free available chlorine which must be removed before it becomes acceptable to consumer. Dechlorination is the partial or complete reduction of undesirable excess chlorine in water by any chemical or physical treatment.

Prolonged storage and absorption on charcoal, granulated carbon and activated carbon are effective. Also reducing compounds like sulphur dioxide, sodium thiosulphate and sodium bisulphate are frequently used as dechlorinating agents. Dechlorination by sulphur dioxide and its derivatives is feasible, rapid and precise. About one part of SO_2 (by weight) is required for each part of chlorine to be removed, the exact amount to be determined by the Stoichiometric relationship:



(4) Breakpoint Chlorination:

As already explained in section 8.6.2.2, the addition of chlorine to ammonia in water produces chloramines which do not have the same efficiency as free chlorine. If the chlorine dose in this water is increased, a reduction in the residual chlorine occurs, due to the destruction of chlorine by the added chlorine. A few possible schemes are as below:



The end products do not represent any residual chlorine. This fall in residual chlorine will continue with further increase of chlorine dose and after a stage the residual chlorine begins to increase in proportion to the added dose of chlorine. This point at which the free residual chlorine appears after the entire combined chlorine residual has been completely destroyed is referred to as breakpoint and corresponding dosage is the breakpoint dosage. Breakpoint chlorination achieves the same results as superchlorination in a rational manner and can therefore be construed as controlled superchlorination.

(b) Combined Available Residual Chlorination

This method involves the application of chlorine to water to produce with natural or added ammonia, a combined available chlorine residual and to maintain the residual through part or all of a water treatment plant or distribution system. They are less effective

disinfectants and oxidants thus free available chlorine forms. The residual, however, will persist much longer than free available chlorine which has a tendency to diffuse and be lost. A minimum of 30 to 60 minutes contact time must be provided before delivery to the consumer. Depending upon the characteristics of water this can be accomplished as follows:

- (i) application of chlorine only, if sufficient ammonia is present in the water;
- (ii) addition of both chlorine and ammonia if it contains little ammonia; or
- (iii) addition of ammonia if free available residual chlorine is already present in water.

In order to control chlorine ammonia treatment effectively the optimum ratio of chlorine to ammonia has been found to be 3:1 or more to ensure the presence of an excess of ammonia.

This practice is useful after filtration for controlling algae and bacterial growths, for reducing red water troubles in distribution systems at dead ends and for providing and maintaining a stable residual throughout the distribution system.

(c) Points of Chlorination

The use of chlorine at various stages of water supply system right from raw water collection to the distribution network is a common practice and terms like pre post and re-chlorination have come into common usage depending upon the points at which chlorine is applied.

(i) Prechlorination

Prechlorination is the application of chlorine to water prior to any unit treatment process. The point of application as well as dosage will be determined by the objectives viz., control of bryozoa growths in raw water conduits, promotion of improved coagulation, prevention of mud ball and slime formation in filters, reduction of taste, odour and colour and minimizing the post-chlorination dosage when dealing with heavily polluted water.

(ii) Postchlorination

Postchlorination is the application of chlorine to water before it enters the distribution system to maintain the required amount of free chlorine specified in 2.2.9 (c).

(iii) Rechlorination

When the distribution system is long and complex, it may be difficult to maintain the minimum chlorine residual of 0.2 mg/l at the farthest end. To achieve this if a very high dosage is applied at the postchlorination stage, it would, apart from being costly, make the water unpalatable at the reaches close to the point of chlorination. The maintenance of the required residual, in such cases can be accomplished by a stagewise application of chlorine in the distribution system which is called rechlorination. Rechlorination is carried out in service reservoirs, booster pumping stations or at points where the main supply to distribution zones.

8.6.4 CHLORINE RESIDUAL

Residual chlorine is measured by pouring 100 ml of water into a glass beaker and adding 10 ml of 0.1% potassium dichromate solution. The water is then allowed to stand in the plant effluent for 30 min. At night or in the dark at least 0.1 mg/l is required for complete disinfection of water. The residual chlorine should be 0.2 mg/l at 100°C.

The amount of chlorine required in the water works depends on various factors, generally measured by the amount of chlorine gas or amount of residual chlorine. The amount of chlorine of water depends on the amount of bacteria and other micro-organisms in the water.

Chlorine is used in the form of calcium hypochlorite, sodium hypochlorite, or calcium hypochlorite. The amount of chlorine required depends on the pH of the water. The pH of the water should be maintained between 7.0 and 8.0. The amount of chlorine required is also dependent on the amount of organic matter in the water.

Chlorine is supplied in the form of calcium hypochlorite. The amount of chlorine required is also dependent on the amount of organic matter in the water. The amount of chlorine required is also dependent on the amount of organic matter in the water.

8.7 APPLICATION OF CHLORINE

Chlorine is applied to water in the following ways:

- (a) by the addition of a weak solution of chlorine to the water.
- (b) by the addition of a weak solution of chlorine to the water.
- (c) by the addition of chlorine in the form of calcium hypochlorite to the water.

The amount of chlorine applied depends on the amount of organic matter in the water. The amount of chlorine applied depends on the amount of organic matter in the water. The amount of chlorine applied depends on the amount of organic matter in the water.

The amount of chlorine applied depends on the amount of organic matter in the water. The amount of chlorine applied depends on the amount of organic matter in the water. The amount of chlorine applied depends on the amount of organic matter in the water.

even if the program is available on a local computer, it may be a good solution to store a copy of the program on a floppy disk to protect the program and application of the program from damage due to computer hardware problems and bad viruses.

4.1.1.1. **Hardware:** The basic computer system needed in this program is a computer with 1024 bytes of RAM, 1000 bytes of secondary storage, and a monitor. It may be better to have more than the minimum. The basic computer system is a personal computer and a hard disk drive. The basic computer system is a personal computer with a hard disk drive. The basic computer system is a personal computer with a hard disk drive. The basic computer system is a personal computer with a hard disk drive.

4.1.1.2. **Software:** The software needed for this program is the software system of the computer. It is a large program that will apply the two basic methods of solving a maze and use of advanced combinatorial computer search algorithms.

3.7.1.1. **Hardware: PRIMER**

3.7.1.1.1. **Using Solving Maze**

4.1.1.1.1. **Hardware:** The hardware needed for this program is a personal computer with a monitor, a keyboard, and a mouse. The hardware needed for this program is a personal computer with a monitor, a keyboard, and a mouse. The hardware needed for this program is a personal computer with a monitor, a keyboard, and a mouse. The hardware needed for this program is a personal computer with a monitor, a keyboard, and a mouse.

4.1.1.1.2. **Software:** The software needed for this program is the software system of the computer. It is a large program that will apply the two basic methods of solving a maze and use of advanced combinatorial computer search algorithms. The software needed for this program is the software system of the computer. It is a large program that will apply the two basic methods of solving a maze and use of advanced combinatorial computer search algorithms. The software needed for this program is the software system of the computer. It is a large program that will apply the two basic methods of solving a maze and use of advanced combinatorial computer search algorithms.

4.1.1.1.3. **Hardware:** The hardware needed for this program is a personal computer with a monitor, a keyboard, and a mouse. The hardware needed for this program is a personal computer with a monitor, a keyboard, and a mouse. The hardware needed for this program is a personal computer with a monitor, a keyboard, and a mouse. The hardware needed for this program is a personal computer with a monitor, a keyboard, and a mouse.

3.7.1.2. **Using Solving Maze**

4.1.1.2.1. **Hardware:** The hardware needed for this program is a personal computer with a monitor, a keyboard, and a mouse. The hardware needed for this program is a personal computer with a monitor, a keyboard, and a mouse. The hardware needed for this program is a personal computer with a monitor, a keyboard, and a mouse. The hardware needed for this program is a personal computer with a monitor, a keyboard, and a mouse.

To withdraw gas from a cylinder or ton container, the liquid chlorine must be vaporized. The flow rate is a function of the vaporization rate, which, in turn, is dependent on the rate of heat transfer to the liquid.

8.7.1.3 Connecting And Disconnecting Containers

The design and operation of facilities should be such as to minimize all hazards associated with connecting emptying and disconnecting chlorine containers. These operations should be performed in well lighted places by authorised personnel equipped with gas masks or other suitable respiratory protection devices. Container valve protection caps should always be in place when the container is not in use. Valves should not be left open when operating personnel are not available to maintain proper surveillance of the operations.

Connections to valve outlets on cylinder and ton containers can be made by either a clamp and adapter or a union connector; the former is preferred. In making connections it should be ascertained that the outlet valve is closed before the outlet cap is removed. Gasket surfaces should be thoroughly inspected and cleaned and a new gasket of standard material should be used. Connections that do not fit should never be forced.

Cylinder and ton container valves should be slowly opened by using a special wrench, not more than 150 mm long, for this purpose. One complete turn of the stem in a counter clockwise direction opens the valve sufficiently to permit maximum discharge. An auxiliary cylinder or ton container valve should be installed adjacent to the container valve between it and the chlorine feeder or gas header on manifold systems. Such a valve serves as an emergency shut off if the container valve should leak. Moreover, it prevents chlorine gas from escaping from the supply line when the container is removed from service. In the interests of safety, the ventilation system should be operating whenever containers are being placed into or removed from service and at all times in which an emergency exists or adjustments and repairs are being made.

Specifications and manufacturing of chlorine cylinders/containers, its transportation, handling, filling, possession and safety shall be governed as per Gas Cylinder Rules, 1981 of Central Government.

8.7.2 CHLORINATORS

A chlorinator is a device designed for feeding chlorine to a water supply. Its functions are:

- (a) To regulate the flow of gas from the chlorine container at the desired rate of flow.
- (b) To indicate the flow rate of gas feeding.
- (c) To provide means of properly mixing the gas either with an auxiliary supply of water or with the main body of the liquid to be disinfected.

8.7.2.1 Types Of Feeders

Chlorinators are used for control and measurement of chlorine in the gaseous state and to supply chlorine as a gas or an aqueous chlorine solution. The principle of operation of these equipments depends on the regulation of flow by establishing a pressure relationship

between the upstream and downstream in which the flow is steady and laminar and the velocity profile is parabolic. A small amount of the flow $Q_1 = \rho_1 \bar{u}_1 A_1$ is taken off at the tap. The pressure difference ΔP is the driving force for the flow. The coefficient of discharge C_d is defined as the ratio of the actual flow Q_2 to the theoretical flow Q_1 .

Types of orifices are of two types based on the location of the orifice in the vessel.

(a) Pressure Type Orifice (Head Orifice)

In this type of liquid discharge, the liquid is kept in a vessel under a constant pressure above the orifice. The vessel is rigid and the liquid level is constant. The pressure above the orifice is the same as the pressure in the vessel. The flow is steady and laminar. The velocity profile is parabolic. The pressure difference ΔP is the driving force for the flow. The coefficient of discharge C_d is defined as the ratio of the actual flow Q_2 to the theoretical flow Q_1 .

(b) Vacuum Type Orifices

Orifices are also used in the vacuum type of discharge. The pressure above the orifice is less than the atmospheric pressure. The flow is steady and laminar. The velocity profile is parabolic. The pressure difference ΔP is the driving force for the flow. The coefficient of discharge C_d is defined as the ratio of the actual flow Q_2 to the theoretical flow Q_1 .

(i) Vacuum type orifices (head orifices)

(ii) A differential pressure measurement device

(iii) A device for measuring the pressure difference between two points in a pipe or duct

(iv) A device for measuring the pressure difference between two points in a pipe or duct

(v) A device for measuring the pressure difference between two points in a pipe or duct with a small quantity of flow (e.g. in a microfluidic system)

(vi) A vacuum pressure breaker (pressure regulator) for use in a vacuum system to protect the vacuum from backflow of air

(vii) A vacuum breaker (e.g. in a vacuum system) to prevent backflow of air

8.7.3 ENGINEERING CONTROL OF LIQUIDS

Careful consideration should be given to methods of handling liquids in pipe contracts. Carriage high enough to prevent leaks and to avoid spillage is essential. A handling mechanism should be used to store and discharge liquids and be properly installed so as to minimize possible leakage. The design of the system should be based on their previous noted characteristics. Flows should be controlled by valves and possible with a minimum number of parts. It should be well supported, protected against temperature extremes and adequately supported to avoid vibration.

Long pipelines for liquid discharge and low velocity flow are not recommended. It is advised to shut off the head ends, particularly in high pressure systems, to avoid expansion chamber to avoid possible failure. The design of the system should be based on their previous noted characteristics. Flows should be controlled by valves and possible with a minimum number of parts. It should be well supported, protected against temperature extremes and adequately supported to avoid vibration.




FIG. 8.2 CHLORINATOR WITH ABSORPTION TOWER




FIG. 8.3 CHLORINATOR WITH INJECTOR

the various processes equally, but standards have become more precise in order to enable provision of a consistent performance to the various parts of the machine. The maintenance of a high standard of performance is vital to the health and performance of the machine, and the performance of the machine will be affected if a high standard of maintenance is not observed. It is important to note that there is no one correct method of maintenance, and the maintenance should be planned to produce the maximum of machine life and efficiency.

Improvements in the way in which the machine is used, and the way in which it is maintained, are essential to the success of the machine, and the adequate maintenance for the safe performance of the machine should be provided. It is essential to provide the equipment with an adequate standard of maintenance, and the maintenance of the machine should not be undertaken if the machine is to be used in a safe manner. It is essential to provide the machine with a high standard of maintenance, and the machine should be used in a safe manner. It is essential to provide the machine with a high standard of maintenance, and the machine should be used in a safe manner. It is essential to provide the machine with a high standard of maintenance, and the machine should be used in a safe manner.

3.3.4 Piping Systems

When a piping system is designed, it is essential to provide a high standard of maintenance, and the machine should be used in a safe manner. It is essential to provide the machine with a high standard of maintenance, and the machine should be used in a safe manner. It is essential to provide the machine with a high standard of maintenance, and the machine should be used in a safe manner. It is essential to provide the machine with a high standard of maintenance, and the machine should be used in a safe manner. It is essential to provide the machine with a high standard of maintenance, and the machine should be used in a safe manner.

The piping system should be designed to provide a high standard of maintenance, and the machine should be used in a safe manner. It is essential to provide the machine with a high standard of maintenance, and the machine should be used in a safe manner. It is essential to provide the machine with a high standard of maintenance, and the machine should be used in a safe manner. It is essential to provide the machine with a high standard of maintenance, and the machine should be used in a safe manner.

The piping system should be designed to provide a high standard of maintenance, and the machine should be used in a safe manner. It is essential to provide the machine with a high standard of maintenance, and the machine should be used in a safe manner. It is essential to provide the machine with a high standard of maintenance, and the machine should be used in a safe manner. It is essential to provide the machine with a high standard of maintenance, and the machine should be used in a safe manner.

The piping system should be designed to provide a high standard of maintenance, and the machine should be used in a safe manner. It is essential to provide the machine with a high standard of maintenance, and the machine should be used in a safe manner. It is essential to provide the machine with a high standard of maintenance, and the machine should be used in a safe manner. It is essential to provide the machine with a high standard of maintenance, and the machine should be used in a safe manner.




FIG. 8.4 MANUALLY OPERATED VACUUM TYPE CHLORINE FEED

8.7.3.2 Number Of Cylinders Or Containers

Normal chlorine dosage required on disinfected water supplies not subject to significant pollution would not exceed 2mg/l. The actual chlorine dosage has to be determined on the basis of chlorine demand tests. The chlorine feed rate is then computed by dividing the expected maximum dosage of chlorine by maximum flow rate.

Total daily chlorine requirements can be estimated from the daily average consumption or maximum daily flow peak and the minimum rate requirements should be taken into consideration when designing a chlorine supply and feeder system and not merely the total daily requirements of chlorine.

When chlorine gas is withdrawn from a cylinder containing the liquefied gas, the pressure drops and the liquid 'boils' liberating more gas till the pressure is restored. This boiling also is heat continuously, thus producing a cooling effect in the liquid region. If the withdrawal is continued, the liquid may freeze and no more gas will be evolved. It is therefore, essential to keep the apparatus and the containers in service warm and to ensure that there is not an abnormal rate of withdrawal from a single container with heavy demand of gas.

The recommended discharge rates are approximately 6.5 to 7.5 kg/hr from a one-ton container and 0.8 kg/hr from cylinders. Equipment should have sufficient capacity to exceed highest expected demand at any time and to provide continuous effective discharge under all prevailing hydraulic conditions. It is good practice to provide for duplicate equipment since disinfection process cannot be stopped at any time.

When the gas discharge rate from a single container will not meet the requirements, two or more can be connected to a manifold and discharge simultaneously. It is advisable not to connect more than four containers to a manifold. When discharging through a manifold, care must be taken that all the containers are at the same temperature, particularly when connecting a new cylinder to the manifold. When more than 3 or 4 cylinders are used, the connections would be arranged in groups so that one complete group can be changed at a time. Storage of chlorine lasting a month or so should be provided. It is advisable to keep the full cylinders in the same room as the cylinders in service.

8.7.3.3 Maintenance

Every chlorinator is supplied with an instruction book that will include specific steps to follow in servicing. However, following are four areas most often associated with maintenance requirement and cause of trouble.

(a) Moisture

Moisture in chlorine is corrosive to ferrous and most nonferrous metals. Most chlorinators use elastic materials in the sections where gas is handled under vacuum. Metal parts or fittings, which are generally external to the chlorinator, are header valves, header pipe and flexible connections. When any connection is broken, even for a short time, the openings should be plugged immediately to exclude moisture. Corrosion is internal and not

evidence upon external inspection until failure occurs. A good rule to follow is to exclude moisture from any part of the equipment that is normally exposed to dry chlorine only.

Corrosion products, primarily ferric chloride, are a major cause of chlorinator malfunctioning.

(b) Impurities in Chlorine

Even trace amounts of impurities can cause problems if they accumulate. Two compounds are frequently found in chlorine: ethyl acrylonitrile and ethyl ferrocyanide, one is present in the chlorine containers or may reach them if careless operation allows moisture to enter the system. The compound is recognizable as a dark brown, syrupy liquid and is soluble in water. After chlorinator operation is over to remove impurity, it must be dried thoroughly before reassembly.

The other material, hexachloroethane, is a white, waxy solid, classified as a volatile solid. It tends to deposit in gas lines at points of stress or temperature change. This material is not soluble in water, but can be dissolved in methanol to form a common industrial solvent.

(c) Flexible Connections

Flexible connections (comprising steel clamps or metal tubing), used to connect two cylinders or two containers, need special attention. Because they are flexible every time a cylinder is changed, they are subject to metal fatigue. These connections should be changed once a year.

Each time a connection is made either to a chlorine container or to the chlorinator, a new gasket must be used.

(d) Gaskets

Elastomers (flexible) materials used for gaskets and O-rings generally become brittle in time. If a gasketed joint is not broken, the gasket will last ten years. A regular program of replacement is desirable but guidelines are difficult. A very recommended spare parts list includes spare gaskets. If swelling or buckling of a gasket is noted, it should be replaced. Old non-dur hardened gaskets cannot be properly reused.

8.7.4 CHLORINE HOUSING

The chlorine cylinders and feeders should be housed in an isolated room, easily accessible, close to the point of application and convenient for truck loading, and safe container handling. The floor should be at least 15 cm above the surrounding ground and drainage should have at least two exit doors or building should have at least two exit doors for gross ventilation that allows an approximate air change in 10 minutes. For small installations, provision of ventilator opening at the bottom, one opposite the other is adequate.

Separate and reasonably gas tight enclosures opening to the outdoors should be provided for housing the chlorine feeding equipment in large installations and in buildings occupied by persons. These enclosures should be vented to the upper atmosphere and equipped with positive means of exhaust from the floor level, at the center of the room or opposite to the

the process of the water being heated. The amount of steam that is produced is controlled by the amount of water that is heated. The amount of water that is heated is controlled by the amount of steam that is produced. The amount of steam that is produced is controlled by the amount of water that is heated.

The amount of steam that is produced is controlled by the amount of water that is heated.

STEP 2: HEATING THE WATER

The amount of steam that is produced is controlled by the amount of water that is heated. The amount of water that is heated is controlled by the amount of steam that is produced. The amount of steam that is produced is controlled by the amount of water that is heated.

The amount of steam that is produced is controlled by the amount of water that is heated. The amount of water that is heated is controlled by the amount of steam that is produced. The amount of steam that is produced is controlled by the amount of water that is heated.

The amount of steam that is produced is controlled by the amount of water that is heated. The amount of water that is heated is controlled by the amount of steam that is produced. The amount of steam that is produced is controlled by the amount of water that is heated.

The amount of steam that is produced is controlled by the amount of water that is heated. The amount of water that is heated is controlled by the amount of steam that is produced. The amount of steam that is produced is controlled by the amount of water that is heated.

The amount of steam that is produced is controlled by the amount of water that is heated. The amount of water that is heated is controlled by the amount of steam that is produced. The amount of steam that is produced is controlled by the amount of water that is heated.

- 4. Electrical safety devices, such as a thermocouple gas safety heater, can add cost to a water heating rate component.
- 5. Water level gauges, as a means of controlling the amount of water in the water tank, may be used.
- 6. A water level sensor may be used to detect a low water level in the pressure vessel.
- 7. A high water temperature gauge may be used to detect a high water temperature, particularly the pressure vessel.
- 8. Water level and temperature gauges may be used to detect a low water level.
- 9. A high water temperature gauge may be used to detect a high water level, which may indicate a leak in the water supply system. The gauge may be used to detect a high water level and a low water level, which may indicate a leak in the water supply system. The gauge may be used to detect a high water level and a low water level, which may indicate a leak in the water supply system.
- 10. High water temperature switches, which are used to detect a high water level, may be used to detect a high water level. The switches may be used to detect a high water level and a low water level, which may indicate a leak in the water supply system. The switches may be used to detect a high water level and a low water level, which may indicate a leak in the water supply system.
- 11. A low water level switch, which is used to detect a low water level, may be used to detect a low water level. The switch may be used to detect a low water level and a high water level, which may indicate a leak in the water supply system. The switch may be used to detect a low water level and a high water level, which may indicate a leak in the water supply system.
- 12. A magnetic float switch, which is used to detect a low water level, may be used to detect a low water level. The switch may be used to detect a low water level and a high water level, which may indicate a leak in the water supply system. The switch may be used to detect a low water level and a high water level, which may indicate a leak in the water supply system.
- 13. Cathodic protection, which is used to detect a low water level, may be used to detect a low water level. The protection may be used to detect a low water level and a high water level, which may indicate a leak in the water supply system. The protection may be used to detect a low water level and a high water level, which may indicate a leak in the water supply system.
- 14. A vent pipe, which is used to detect a low water level, may be used to detect a low water level. The vent pipe may be used to detect a low water level and a high water level, which may indicate a leak in the water supply system. The vent pipe may be used to detect a low water level and a high water level, which may indicate a leak in the water supply system.
- 15. Liquid chlorine expansion tanks, which are used to detect a low water level, may be used to detect a low water level. The tanks may be used to detect a low water level and a high water level, which may indicate a leak in the water supply system. The tanks may be used to detect a low water level and a high water level, which may indicate a leak in the water supply system.

Some or all of the above mentioned devices, gauges and accessories may be supplied with an operation.

8.7.6 ANCHORAGE REQUIREMENTS

8.7.6.1 Lifting Machines

Lifting machines are necessary to reduce the weight of lifting loads to 24 hours which would require a check of the any crane operator and also enable the cylinders to be changed without the person.

8.7.6.2 Personal Protection Equipment

It is an exposure and potential health hazard, even whenever toxic compressed gas and other respiratory irritants are handled, or used. An approved gas mask should be provided for every employee involved with handling these. A minimally suitable protective equipment for emergency use should be available, located in an area where hazardous materials are located near the entrance, away from areas of likely contamination. Such equipment might be provided in some facilities as a large size of mask.

Canister type gas masks with a full face piece and specific or all purpose commodity canister should be used only for relatively short exposure periods and only if it has been clearly established that sufficient oxygen is present (not less than 10% in air) and that contamination does not exceed the filterable level of 1% of chlorine. Canister masks might not be used in emergency situations where they might not be readily maintained, especially if suitable stored ventilation systems are not provided. Regular replacement of covers, canisters, and high level filter is recommended.

Self contained breathing apparatus with a diaphragm and a canister of air or oxygen carried on the back, or with a canister that produces oxygen chemically, is suitable for high contaminant concentrations and is the preferred means of respiratory protection. Protection is provided for a period that varies with the amount of air, oxygen or oxygen producing canister carried.

Respiratory protective equipment should be carefully maintained, inspected and cleaned after each use and at regular intervals. Detection of respiratory equipment is worse than none at all. All such equipment should be used and maintained in strict accord with the manufacturer's instructions. No entry should enter contaminated areas unless attended by an observer who can rescue him in the event of respiratory failure or other emergencies.

It is good practice to provide eye protection devices for masks with full face piece and other protective clothing for workers exposed to hazardous materials. Emergency showers, eye baths or other suitable water flush systems should be provided in convenient locations for use by acutely exposed personnel. Installation of an automatic chlorine leak detector with a visible or audible alarm should be considered.

8.7.6.3 Chlorine Detectors

Continuous monitoring of atmospheric air areas where chlorine is stored and used is an important aspect of any safety program. Instruments for this purpose are called chlorine

detectors, which are not necessarily the detectors used for measuring actual chlorine in water.

Concentrations are expressed as parts per billion (ppb), not as parts per million parts by weight, as the expression is used to describe concentrations in water. If one cup (8 oz.) of water of chlorine by volume in air is equivalent to 8 ounces of air. The threshold of colour perception is 50 to 5 ppm.

Two types of detectors are available. The first type to be sampled is attached to a rotating drum covered with a strip of sensitive paper. The paper is white and light is reflected from it to a photoelectric cell. The amount from the cell is amplified and used to keep an electric relay open in an alarm circuit. If the air sample from the drum was chlorine, the paper darkens, the light is absorbed, the current from the photoelectric cell drops below that required to keep the relay open and then the alarm circuit is energized.

In the second type, air from the point or points of sampling is drawn to the detector by an air pump through a filter and flow meter that indicates the sample flow rate. The air sample is directed to an electrochemical sensing cell the output of which increases with the presence of chlorine. A meter measures it to indicate visually the strength of the chlorine in air and an alarm which is included to provide a coded closure for remote control. Visual alarms are not advised for

8.7.6.4 Automatic Changeover Systems

Increased emphasis on the need for uninterrupted chlorine can lead to the use of automatic changeover systems, particularly at outdoor stations. The basic concept of these systems is to switch from a depleted source of chlorine to a stand-by source automatically without the presence of an operator. Several methods have been used to accomplish this. One system consists of currently operated chlorine shut-off valves, actuated by a chlorine pressure switch that senses the loss of chlorine pressure due to empty cylinders. Another system uses two pressure-reducing valves, each attached to its own source of chlorine and manifold on the downstream side. The pressure settings of the two valves are adjusted so that the valves control at maximum approximately 2 psig apart. Since a pressure-reducing valve will not open until the downstream pressure is lower than its setting, the valve with the higher setting opens first, allowing gas to flow through the valve from its source. This process continues until the first source is depleted and the downstream pressure drops to the setting of the second valve, at which point it opens and chlorine flows from the standby source.

The recent development of small cylinder compressed chlorine has also added more types of automatic changeover systems to the market place. It is not necessary to detail the operation of each, but merely to state that they may now have need of permitting continuous chlorine feeds in a remote, unattended, manual or even fully automatic gas chlorination facilities.

8.7.7 SAFETY CONSIDERATIONS

- (a) Only trained personnel should be permitted to handle chlorine cylinders and chlorinating equipment. They should be made aware of the hazards involved, the

- (g) Protect cylinders or the containers for low gas instead of liquid azides. The containers may be insulated with such materials to decrease absorption of heat and the decomposition.
- (h) Apply appropriate emergency equipment wherever available.
- (i) Call the supplier or nearest producer for emergency assistance.
- (j) If practical, reduce pressure in the system by removing the gas to process or suitable disposal system. Calcium chloride, soda ash or other suitable alkali absorption system should be provided for disposing of chlorine from leaking cylinders and tall containers (100 kg of Cl₂ can be neutralized with 125 kg of caustic soda).
- (k) In some cases it might be desirable and possible to move the contents to an isolated spot where it will not be a hazard.

8.7.9 PERSONNEL TRAINING

Safety in handling hazardous materials depends to a great extent, upon the effectiveness of employee education, proper safety instructions, intelligent supervision, and the use of safe equipment. Training for both new and old employees should be considered periodically to maintain a high degree of safety in handling procedures. Employees should be thoroughly informed of the hazards that may result from improper handling. They should be encouraged to prevent leaks and thoroughly instructed regarding proper action to take in case leaks do occur. Each employee should know what to do in an emergency and should be fully alerted to the first aid measures.

In addition, employee training should include the following:

- (a) Instruction and periodic drill or quiz regarding the location, purpose and use of emergency fire fighting equipment, alarm, shut down, emergency cross shut down equipment such as valves and switches.
- (b) Instruction and periodic drill or quiz regarding the location, purpose and use of personal protective equipment.
- (c) Instruction and periodic drill or quiz regarding the location, purpose and use of safety showers, eye washes, first aid kit, first aid kit, and the closest source of water for use in emergencies.
- (d) Instruction and periodic drill or quiz of second employees regarding the location, purpose and use of respiratory protective equipment.
- (e) Instruction to avoid inhaling of toxic vapors and all other contents with corrosive agents.
- (f) Instruction to report to the proper authority all leaks and equipment failures.

8.8 CHLORINE COMPOUNDS

Chlorine may also be applied to the form of compounds such as bleaching powder or calcium or sodium hypochlorite which can be analyzed gravimetrically when they contain

contact with water. These are used for disinfection of surface water supplies having capacities up to 5 mld.

(a) Bleaching Powder

Bleaching powder is a variable mixture of calcium hypochlorite, calcium chloride and calcium hydroxide. The calcium hypochlorite, the main constituent, is therefore, similar to that of gaseous chlorine in water. Bleaching powder is characterized by its content of available chlorine, i.e. the chlorine which can be liberated by or combine directly with water. Commercial brands have an available chlorine of 20 to 30% i.e. 20 to 30 parts by weight of chlorine per 100 parts by weight of bleaching powder.

Bleaching powder is sparingly soluble in water and is separated, which contains the chlorine in solution, is expelled by the water by a variable ferrugineous mechanism such as a float operated gravity tank. In conventional systems, the solution may be applied through a drip-feed mechanism. However, for low capacity systems, a feed can be easily fabricated. In the case of well supplies, bleaching powder solution may also be introduced on the suction side of the pump. An application by the free discharge on the pump discharge is such the solution of the distribution system to the flow of water, a very simple method involving the use of pipes, valves, tanks, and floats can be suspended in wells has been developed in the country. The cost of chlorine is always a prime consideration of each water supplier where cost and technical skill factors to be kept in mind.

Since bleaching powder contains only about 35% available chlorine, its use involves the extra expense of transporting and storing the same amount. The cost is further increased because the material is sold in non-volatile drums which have no valve for use. Furthermore, bleaching powder is an unstable compound and it is not suitable for long storage. All these considerations make its use impractical except in very small quantities or for special cases such as disinfection of surface water.

(b) Hypochlorites

The chemicals used are Sodium hypochlorite and Calcium Hypochlorite. Specially fortified brands of Calcium Hypochlorite such as Perchlorin and Hyd. Dis. (Type 1) can have 60-70 per cent available chlorine. Calcium Hypochlorite can be fed either in the dry or solution form, with calcium hypochlorite in dry solution. The solution form is usually preferred. Certain resistant materials such as concrete, glass, plastic or special rubber would be required while handling hypochlorite solutions. Generally 1 to 7% chlorine solutions are prepared and fed directly through a variable head gravity device with adjustable orifices or used in dose chlorine delivery in the tanks. These can be fed through mechanical transporting pumps and can be handled under pressure, but possibly require less ventilation in the tanks.

(c) Chlorine Dioxide

Chlorine dioxide is an unstable gas, is formed by reacting a strong solution of sodium chlorate with H_2O_2 at pH 8.5 with sodium chlorate.

- (iii) Alkalies and Acids
- (iv) Surface active chemicals.

8.9.2.1 Halogens Other Than Chlorine

Halogens are oxidizing agents and include fluorine being the strongest and iodine the weakest oxidizing agent. However, disinfecting efficiency does not correlate directly with oxidizing capacity of a disinfectant. As Fluorine can oxidize water, it cannot be used for disinfecting water.

Bromine is a heavy, dark reddish brown liquid which upon addition to water forms hypobromous acid (HOB), the dissociation of the acid resulting in formation of hypobromite ion (OBr). Bromine also reacts with ammonia in water to form mono-bromamine and dibromamine. No stable tri-bromamine is formed. Monobromamine is a strong bactericide almost as strong as free chlorine in contrast to mono-chloramines. Bromine has been used for disinfection of swimming pool waters on a limited scale. However, because of its higher cost and its effectiveness, its use for public water supply has not found acceptance.

Iodine is a bluish black solid and its addition to water yields Hypoiodous acid (HOI) and Hypoiodite (IO). Iodine reacts less with organic matter compared to chlorine and is relatively stable in water. At pH 7-7.5, the percentage of iodine, Hypoiodous acid and Hypoiodite ion have been reported to be 24, 75 and 1 for a total iodine residual of 0.5 mg/l. Both iodine and Hypoiodous acids are equally good disinfectants. Iodine does not react with ammonia to form iodamines but oxidizes ammonia. It also oxidizes phenols. Because of these reasons, less iodine is required to obtain free iodine residual.

Iodine has been used for disinfection of swimming pool waters and small quantities of water in field. Iodine tablets (e.g. of tetraglycyl hydroperiodide) have been used by the Army. Iodine is less dependent on pH, temperature, and of certain and numerous impurities than chlorine and not as liable to form toxic by-products which chlorine does not. It has the same disinfecting power as chlorine. Because of certain advantages over chlorine, iodine is better for post disinfection than chlorine providing longer lasting protection against pathogens and reduced offensive tastes and odours. However, it is more costly than chlorine.

8.9.2.2 Ozone

It is a faintly blue gas of pungent odour. Being unstable it breaks down to normal oxygen and nascent oxygen. This nascent oxygen is a powerful oxidizing and germicidal agent. Ozone is produced by the corona discharge of oxygen or high electricity intensity air. Ozone, being unstable, has to be produced onsite.

Ozone possesses more superior bactericidal properties than chlorine and is highly effective in removal of tastes, odours, colour, iron and manganese. As ozone reacts with chemical impurities prior to attacking the microorganisms, it produces essentially no disinfection unless ozone demand of water has been satisfied but much more rapid kills are achieved, once free ozone residuals are available. Studies have reported 92-99% kills of *E. coli*

• the development of a code when the government is not able to regulate. In the case of the UK, the lack of a fully functioning regulatory system has led to a number of major public health problems, such as the BSE and mad cow disease, and the contamination of the water supply in the UK. The lack of a fully functioning regulatory system has led to a number of major public health problems, such as the BSE and mad cow disease, and the contamination of the water supply in the UK.

According to the authors, the following are the main reasons for:

- (i) the high cost of water treatment
- (ii) the high cost of providing water to rural areas
- (iii) the high cost of providing water to urban areas
- (iv) the high cost of providing water to industrial areas

However, the authors also note that the high cost of water treatment is not the only reason for the high cost of water supply.

8.3.2.3 Potassium Permanganate

Potassium permanganate is a powerful oxidizing agent and is used in a number of applications, including water treatment. It is used to oxidize iron and manganese in water, and to oxidize organic matter in wastewater. It is also used to oxidize hydrogen sulfide in water, and to oxidize nitrite in water. The authors note that the use of potassium permanganate in water treatment is becoming increasingly common.

8.3.2.4 Metal Ions

Several metals, including lead, copper, zinc, and iron, are found in natural waters. Some of these metals are toxic to humans and animals, and can cause a number of health problems. The authors note that the presence of these metals in water is a major concern for public health. They also note that the use of metal ions in water treatment is becoming increasingly common. For example, lead is used in the production of lead-acid batteries, and copper is used in the production of brass. The authors note that the use of metal ions in water treatment is becoming increasingly common.

8.3.2.5 Acids and Bases

Acids and bases are important components of natural waters. They are involved in a number of chemical reactions, and can affect the pH of the water. The authors note that the presence of acids and bases in water is a major concern for public health. They also note that the use of acids and bases in water treatment is becoming increasingly common.

The distribution of water is affected by a number of factors, including population density, climate, and topography. The authors note that the distribution of water is becoming increasingly uneven, and that this is a major concern for public health. They also note that the use of water treatment is becoming increasingly common.

Intensity of ultraviolet rays is expressed in terms of germicidal unit which is an intensity of 100 mW per sq. cm. at wave length of 253.7 nm. It has been reported that *Escherichia Coli* (kds) of 10^9 , 10^8 , and 10^7 can be inactivated by ultraviolet rays of 3000, 1500 and 750 mW sec. per sq. cm. Typically a 30 watt lamp could achieve 99.9% kill for water flows of approximately 25 to 100 m³/hr in a water depth ranging from 125 to 180 cm; approximately assuming 2% absorption coefficient.

The advantages of ultraviolet radiation as a disinfectant is that exposure is for short periods, no foreign matter is actually introduced and no toxic residue produced. Over exposure does not result in any harmful effects. The disadvantages are that no residual effect is available and there is lack of a rapid field test. In a way, the treatment efficiency. Moreover, the apparatus needed is expensive.

CHAPTER 9

SPECIFIC TREATMENT PROCESSES

9.1 INTRODUCTION

Water treatment involves physical, chemical and biological changes that transform raw water into potable water. The treatment process used in any specific instance must depend on the quality and nature of the raw water. Quality requirements for industrial uses are frequently more stringent than for domestic supplies. Additional treatment may be required by the industry like demineralization of boiler feed water to prevent scale deposit.

Water treatment processes may be simple like sedimentation, or may involve complex physico-chemical changes, as with coagulation. The specific treatment processes include control of algae, control of taste and odour in water, removal of colour, softening, removal of iron and manganese, defluoridation of water, demineralization of water and disinfection.

9.2 CONTROL OF ALGAE

9.2.1 GENERAL

Algae give rise to a variety of trouble in water supplies. They impart odour and taste to the water. *Synura* causes a perceptible odour. *Volvoxella*, *Microcystis* and *Tabellaria* produce aromatic odour. Algae like *Dinobryon*, *Peridinium*, *Trigonopsis*, *Asterionella* and *Tabellaria* produce fishy odour. Grass odour is caused by *Aphanizomenon*, *Anabaena*, *Gomphosphaeria*, *Cylindrocapsa* and *Rivularia*. Soapy odour is caused by *Chlorella*, *Hydrodictyon*, *Ceratium*, *Aphanizomenon*, *Anabaena* and *Cylindrocapsa*. When algae like *Microcystis*, *Anabaena* and *Aphanizomenon* die in mass and decay, they produce foul odours.

Some algae impart sweet or bitter or sour tastes to water. Algae like *Nitzschia*, *Ceratium* and *Synura* give rise to bitter taste, while algae such as *Chara*, *Fragilaria*, *Aphanizomenon*, *Microcystis*, *Cryptomonas* and *Gomphosphaeria* impart sweet taste to water.

Algae interfere in the process of flocculation and sedimentation. Algae like *Asterionella* and *Senedelia* prevent floc formation. Water containing *Gomphosphaeria* and *Anabaena* need to be agitated for proper floc formation. They come up the lines and clog into the filters. They choke the filters and as a result reduce the filter runs. Algae associated with filter clogging are *Asterionella*, *Fragilaria*, *Nitzschia*, *Synura*, *Cymbella*, *Dinobryon*, *Oscillatoria*, *Rivularia*, *Trachelomonas* and *Chlorella*. Algae like *Synura* and *Oscillatoria* can get through rapid sand filter. Algae such as *Coelastrum*, *Phacus*, *Navicula*, *Nitzschia* and *Trachelomonas* get through slow sand filter. These algae in distribution system cause biological corrosion.

There is a strong possibility that the above-mentioned conditions are not met, and the results of the analysis will be biased. In order to avoid this, the following steps should be taken:

1. The data should be checked for normality. This can be done by plotting the data on a normal probability plot. If the data points fall on a straight line, the data are normally distributed. If not, the data may be transformed to make them normally distributed. For example, the square root transformation can be used for count data, and the log transformation can be used for data that are skewed to the right.

3.2.3.3. Choice of statistical test

The choice of statistical test depends on the type of data and the research question. The following table provides a guide to the choice of test:

3.2.3.4. Software

There are many software packages available for statistical analysis. The choice of software depends on the user's needs and preferences. Some of the most commonly used software packages are:

- Microsoft Excel: A spreadsheet program that includes basic statistical functions.
- Minitab: A statistical software package that is easy to use and provides a wide range of statistical tests.
- SPSS: A statistical software package that is widely used in social sciences research.
- R: A free and open-source statistical software package that is highly flexible and powerful.

3.2.3.5. Interpretation

The results of a statistical analysis should be interpreted in the context of the research question. It is important to remember that statistical significance does not necessarily imply practical significance. For example, a small difference between two groups may be statistically significant, but it may not be important in practice. Therefore, the results should be interpreted in terms of the magnitude of the effect and the confidence interval.

3.2.3.6. Effect of Hawthorne

The Hawthorne effect is a phenomenon that occurs when individuals change their behavior because they are being observed. This effect can be a confounding factor in research. To minimize the Hawthorne effect, researchers should use a control group and should not tell the participants that they are being observed. Additionally, the researchers should use a double-blind design to avoid bias.

you will follow. The same applies to the type of maintenance activities you will be doing, such as the amount of work and the number of employees.

It is very important to be open to change. The maintenance plan is not a blueprint that you have to follow. The plan is a guide that you can use to help you make decisions. The plan is a living document that you can update as you learn more about your system and as you learn more about your organization's needs.

9.2.2.1. Scouting

Scouting is the process of identifying potential problems before they become major problems. It is a proactive approach to maintenance that involves regular inspections and testing of the system to detect and prevent problems before they occur.

9.2.2.2. Characteristic and Resonance

Characteristic and resonance are two important concepts in vibration analysis. Characteristic frequencies are the frequencies at which a system naturally vibrates. Resonance occurs when the system is excited at one of these frequencies, causing the amplitude of the vibration to increase significantly.

9.2.2.3. Temperature Effects

Temperature effects can have a significant impact on the performance of a system. Changes in temperature can cause changes in the physical properties of the system, such as the expansion and contraction of materials, which can lead to changes in the system's behavior.

9.2.3. Reliability Method (RF)

9.2.3.1. Parameter Methods

Parameter methods are a class of reliability methods that use statistical analysis to estimate the reliability of a system. These methods are based on the assumption that the failure rate of a system is constant over time. The most common parameter method is the exponential distribution, which is used to model the time to failure of a system. Other parameter methods include the Weibull distribution and the log-normal distribution. These methods are used to estimate the mean time to failure (MTTF) of a system, which is the average time that the system is expected to operate before failing.

9.2.3.2. Critical Element Approach (CEA)

The critical element approach (CEA) is a reliability method that focuses on identifying the most critical elements of a system. These elements are the ones that are most likely to fail and that have the greatest impact on the system's performance. The CEA method is used to estimate the reliability of a system by focusing on these critical elements.

9.2.3.3. Management Evaluation

Management evaluation is a reliability method that focuses on evaluating the management practices of a system. This method is used to identify areas where the management practices are weak and to develop strategies to improve them. The management evaluation method is used to estimate the reliability of a system by focusing on the management practices that are most likely to affect the system's performance.

examination is especially necessary during the season in which algal eruptions may be expected.

(b) Time for Treatment

Generally, the practice has been to apply algicides when the total count reaches or exceeds 5000 cells/ml. Algae which are known to be especially troublesome should be eradicated even though the total count is much less than 5000 cells/ml. For example, algal treatment is indicated as soon as forming a type that causes severe snail troubles is encountered, irrespective of the total count.

(c) Types of Algicide

A large variety of algaecides are available and a number of new algaecides are being synthesized. Many of these are complex organic compounds and are endowed with specific action against particular species. Chemicals such as formalin, aldehydes, organic acids, and organic cyanide compounds, silver ions, Cu^{++} and organotin compounds have also been tried as algaecides, however, their use is difficult and harmful to some extent in general use. The most widely used algaecide is copper salts and chlorine but both cause pollution of stream and sea water supplies. The chemical to be used as an algaecide should be species selective, non-toxic to aquatic life particularly fish, harmless to snails, large, have no other effect on water quality and be inexpensive and easy to apply.

(i) Copper Salts

The most common algaecide is copper sulphate. Its action is due to the copper ion which acts as a direct protozoic poison. The action is a function of the concentration of the chemical and the time of exposure of the algae to the action of the copper.

(i) Copper Sulphate

The copper sulphate reacts with the bicarbonates in the water to form a basic copper carbonate which further decomposes to form copper hydroxide. The basic copper carbonate is somewhat soluble especially if the water is not very hard and if it contains carbon dioxide. The copper hydroxide is also insoluble in water. It remains in a colloidal form for sometime before it precipitates out. This reaction is retarded by low temperature and organic matter in the water, while temperature and suspended particles accelerate it, thus, follows that the efficacy of copper sulphate as an algaecide is influenced by the temperature of the water, its hardness, its content of organic matter and suspended matter.

The added copper sulphate is rapidly removed in a short while. This is both an advantage and a disadvantage. It is an advantage because the content of the copper in the water rapidly gets reduced to levels below those at which copper is toxic to human beings in mere efflux of time and without the need for any elaborate treatment for removal of the excess copper. Tendency of copper to get out of the solution is a disadvantage because the algaecidal effect is rendered purely temporary. With the disappearance of the copper from the field of action, another crop of algae can come up necessitating a repetition of the treatment.

(a) Dosage

Doses of copper sulphate required to kill algae are generally expressed in terms of concentration in mg/l of the salt $\text{CuSO}_4 \cdot 5\text{H}_2\text{O}$. Some authorities express the doses in terms

of the equivalent of copper. The values may be determined on the basis of the following equation:

$$100 \text{ parts of copper sulphate } (CuSO_4 \cdot 5H_2O) = 22.32 \text{ parts of copper}$$

The quantity of copper sulphate required has to be calculated on the basis of the volume of water in the reservoir. A factor of 25 at the time of the algae present, quantity of food of multiplication and a normal succession is necessary to reach the dose to be applied. The table dose for different types of algae is given in Table 3. These apply for a temperature of 15°C and may be decreased by about 25 percent for each degree rise of temperature above 15°C.

TABLE 3.

COPPER SULPHATE REQUIRED FOR CONTROL OF DIFFERENT ALGAE

Algae	Copper sulphate concentration, mg/l.
1. Cyanophyta	
1. Anabaena	0.12-0.18
2. Aphanizomenon	0.12-0.19
3. Chlorella	0.12-0.15
4. Coelastrum	0.20-0.35
5. Microcystis	0.20
6. Oscillatoria	0.20-0.30
7. Chlorophyta	
1. Chlorella	0.30
2. Chlamydomonas	0.30
3. Coelastrum	0.60-0.75
4. Desmidiaceae	0.30
5. Emericella	0.30
6. Volvox	0.25
7. Hydrocoleum	0.10
8. Microspora	0.10
9. Scenedesmus	0.30
10. Springera	0.12
11. Ulothrix	0.20
12. Zygnema	0.30
13. Diatomaceae	
1. Achnanthes	0.12-0.20
2. Fragilaria	0.25
3. Amphioxys	0.20
4. Tabellaria	0.12-0.30
5. Navicula	0.30
6. Surirella	0.30-0.35
7. Stephanodiscus	0.30

5. Page no.	
1. Abstract	670
2. Introduction	671
3. Method	672
4. Materials	673
5. Results	673-674

6. Discussion	674-675
7. Conclusion	675-676
8. Bibliography	676-677

© 2011, All rights reserved. www.ijerph.in

3. Method of Application

The study is a qualitative method in which the pages containing the articles had to be scanned to get a better understanding of the same. The data was carefully studied and only articles were selected which had a clear and concise methodology to be followed by the specific researcher and the data was analysed to get the best outcome of the study. The data should be given in proper form and the researcher should get the general idea of the study.

The primary objective of the study is to study the factors responsible for the development of the system. This study is the first of its kind in the field of the study. The objective of the study is to study the factors responsible for the development of the system. The study is the first of its kind in the field of the study. The objective of the study is to study the factors responsible for the development of the system. The study is the first of its kind in the field of the study. The objective of the study is to study the factors responsible for the development of the system.

The study is a qualitative method in which the pages containing the articles had to be scanned to get a better understanding of the same. The data was carefully studied and only articles were selected which had a clear and concise methodology to be followed by the specific researcher and the data was analysed to get the best outcome of the study.

10. Abstract of Cyberbullying

The study is a qualitative method in which the pages containing the articles had to be scanned to get a better understanding of the same. The data was carefully studied and only articles were selected which had a clear and concise methodology to be followed by the specific researcher and the data was analysed to get the best outcome of the study.

TABLE 3.3
CORRELATION OF CYBERBULLYING TO FISEL

Factor	Value
Age	10
Gender	10
Income	10
Education	10
Occupation	10

Dist.	mp./i
Acid	170°
amide	120°
Blau's base	110°

Chemical analysis gave results which showed that the acid was a monomer and that the base was a dimer. The molecular weight of the acid was 170 and that of the base 340.

The acid was found to be a dimer of the acid which was formed by the reaction of two molecules of the acid. The acid was found to be a dimer of the acid which was formed by the reaction of two molecules of the acid. The acid was found to be a dimer of the acid which was formed by the reaction of two molecules of the acid. The acid was found to be a dimer of the acid which was formed by the reaction of two molecules of the acid.

Chemical Properties of Oxidation and Reduction

The acid was found to be a dimer of the acid which was formed by the reaction of two molecules of the acid. The acid was found to be a dimer of the acid which was formed by the reaction of two molecules of the acid. The acid was found to be a dimer of the acid which was formed by the reaction of two molecules of the acid.

The acid was found to be a dimer of the acid which was formed by the reaction of two molecules of the acid. The acid was found to be a dimer of the acid which was formed by the reaction of two molecules of the acid. The acid was found to be a dimer of the acid which was formed by the reaction of two molecules of the acid.

Other Compounds

The acid was found to be a dimer of the acid which was formed by the reaction of two molecules of the acid. The acid was found to be a dimer of the acid which was formed by the reaction of two molecules of the acid. The acid was found to be a dimer of the acid which was formed by the reaction of two molecules of the acid.

(i) Other Compounds

The acid was found to be a dimer of the acid which was formed by the reaction of two molecules of the acid. The acid was found to be a dimer of the acid which was formed by the reaction of two molecules of the acid.

crucial for the chemical is much better than copper sulphate. By using a complex of copper with streptomycin in conjunction with chlorine type chlorination process, the algaloid effect of copper is minimized. The use of more persistent compounds of copper sulphate, however, is more rigidly controlled over the treatment so as to ensure that the water is not supplied to a level which for copper content goes well below the standard.

(2) Chlorine

Chlorine is normally a bactericide but also used as an algicide. Whereas copper sulphate is more commonly applied to water in reservoirs, chlorine is generally added to the water as it passes the control point.

Chlorine has specific toxic effect and causes death and disintegration of some species of algae. The essential ions present in the algae are thus liberated and may cause tastes and odours. Occasionally these essential ions as well as the organic matter of the dead algae may combine with chlorine to form very objectionable odours and tastes. Such mineralization of excretions make the control of algae by chlorine a problem which challenges the ingenuity of the operators.

(3) Dosage

The lethal dose of chlorine for the more common types of algae are given in Table 9.3

TABLE 9.3

AMOUNT OF CHLORINE REQUIRED TO DESTROY MICROSCOPIC ALGAE

Algae	Chlorine Dose mg/l
Volvox, Monas	3.85
Cyathella	1.00
Nelostoma	2.00
Dinobryon	0.5
Chlorella	0.5
Scenedesmus	0.5

(ii) Methods of Application

Chlorine may be applied either as a store of bleaching powder or as a strong solution of chlorine from a chlorinator. The latter is preferable.

Small reservoirs may be treated by applying a store of bleaching powder at the influent end or by using trays containing the bleaching powder in the water. Chlorination for algal growth is more commonly adopted in the pretreatment part of the water works. The point of application is generally at the point of entry of raw water into the treatment plant or just ahead of the coagulant feed. Algal growth in raw water conduits can be got rid of by heavy doses of chlorine. Addition of chlorine along with coagulant is sometimes practiced, but this

is to be discouraged since the experience would result in the absorption and storage of chlorine.

(iii) Microstrainer

A special process, known as microstraining is being used in some water treatment plants. The microstrainer is an open drum. The water is passed through a finely woven fabric of stainless steel. The size of the openings in the mesh determines the size of the plaiton removed from the water.

9.2.3.3 Relative Merits of Chlorine and Copper Sulphate Treatment

Each plant should conduct experiments and decide on the type and dose of the algaicide on the basis of local conditions. To a certain extent the method will depend on the facilities available for dosing the water with chemicals, the general arrangements of the works, as well as on the costs. There are, however, certain special conditions where the use of copper sulphate is not possible and chlorination has to be preferred. For example, when the point of application is too near the point of entry into a pipe, copper sulphate cannot be used as the copper will plate out on the metal and become inactive. Similarly, when the surface is so prevent that growth in a stagnant stream, copper sulphate cannot be used as it will be drawn out of solution almost immediately. This is where the seep current is short if it is periodically sufficient to cause a reduction of the copper content. In such cases, however, chlorination has to be preferred.

When chlorination causes an intermediate control of the algal masses and becomes applicable in heavy cases of algaenae followed by a heavy algal bloom, it can be useful, even under the difficulty.

The growth of plaiton in reservoirs can be controlled by copper sulphate treatment. Generally satisfactory results have been secured, but this element has not always been effective as an algaicide. The doses required for this purpose differ with each organism, so economy in the use of copper sulphate and its dissipation can be observed warrants careful examination of appropriate samples collected in different locations, to determine the types of organisms and their relative numbers. The recommended doses are 0.3 mg/l or less, so this dose may be used in the absence of laboratory control. On the other hand, many troublesome organisms may be killed with doses of 0.12 mg/l, ensuring the economy possible when microscopic examinations can be made.

The required dose is influenced by temperature, alkalinity and carbon dioxide content of water.

If effective control of micro-organisms is required, but is not obtained by the treatment as application of copper sulphate to the water entering reservoirs, the microorganisms may be controlled before heavy growths occur, avoiding the necessity of remedial treatment. Furthermore, the prevention of growing algaenae, the subsequent destruction of heavy quantities of organisms, which would result in the reduction of the dissolved oxygen content of the water, and hence protect fish life by using the covering of the oxygenometer is frequently responsible for fish kills, produced, either directly or indirectly, by copper sulphate. The economy in application of copper sulphate, however, reduces the available supply of dissolved oxygen.

can be a treatment should be a separate collection and collection of the water supply.

It is more certain that the amount of pollution of the water supply is a direct result of the available equipment of the water supply system. In addition, the amount of pollution is a direct result of the available equipment of the water supply system. In addition, the amount of pollution is a direct result of the available equipment of the water supply system. In addition, the amount of pollution is a direct result of the available equipment of the water supply system.

The amount of water treatment should be a direct result of the available equipment of the water supply system. In addition, the amount of pollution is a direct result of the available equipment of the water supply system. In addition, the amount of pollution is a direct result of the available equipment of the water supply system.

The amount of water treatment should be a direct result of the available equipment of the water supply system. In addition, the amount of pollution is a direct result of the available equipment of the water supply system. In addition, the amount of pollution is a direct result of the available equipment of the water supply system.

The amount of water treatment should be a direct result of the available equipment of the water supply system. In addition, the amount of pollution is a direct result of the available equipment of the water supply system. In addition, the amount of pollution is a direct result of the available equipment of the water supply system.

3.0 CONTROL OF TASTE AND ODOUR IN WATER

3.1 GENERAL

The amount of water treatment should be a direct result of the available equipment of the water supply system. In addition, the amount of pollution is a direct result of the available equipment of the water supply system. In addition, the amount of pollution is a direct result of the available equipment of the water supply system.

acceptable limits. Using ammonia with chlorine in combined residual chlorination can partly mask or delay chlorophenol tastes in water.

Chlorine Dioxide which is 2.5 times more powerful than chlorine as an oxidizing agent has been found extensively efficient and the general dosage values range from 0.3 to 2.0 mg/l. This is a specialized form of chlorine treatment used for taste and odour control when large doses of chlorine are to be avoided. Chlorine dioxide gas is released in water on site by the reaction of a solution of sodium chlorite (NaClO_2) with a strong chlorine solution of 60 to 7500 mg/l.



Though the theoretical ratio of chlorine to sodium chlorite is 1 : 2.0, values between 1:2 and 1:1 are employed in practice. Chlorine dioxide is more expensive and is used for taste and odour control only. It is applied at the first stage of the treatment plant. Thereafter, the total residual chlorine may be adjusted by simple chlorination after filtration. Some studies suggest that long contact period gives good results. Chlorination is useful in the removal of phenolic tastes.

Another method of treatment for taste and odour removal is activated carbon. Activated carbon is made from hydrocarbon or other volatile sources, the principal requirement being that the carbon residue left after destruction of distribution has a porous structure. Odour producing substances which cannot be removed by oxidation are physically adsorbed on to the surface. This treatment is usually applied before filtration. The contact time varies from 10 to 30 minutes. Adsorbed carbon particles well at lower pH values. A bed of carbon or a suspension kept in circulation could be used. The active surface must be preserved from coating by other elements. Application of carbon can be before sedimentation if taste and odour is severe and frequent and in certain cases after sedimentation. The approximate dosage for routine continuous application is suspension of 2 to 8 mg/l, for emergency treatment of 20 to 40 mg/l. Carbon beds are generally 1.5 to 3 m deep with the size of 0.2 to 4 mm with loadings of about 48 mg/l of adsorbable organic carbon. Filtration rates range from 7.7 to 15 m³/hr/m² with expected efficiencies of 60 to 90%. As many variables are involved, pilot plant tests are indicated. Carbon can also be used as a polishing agent to remove residual odour after ozonation.

Variables such as pH, temperature, quantity and type of organic matter in the influent water and detention time have a marked effect on the efficiency of removal of odours mainly.

9.4 REMOVAL OF COLOUR

9.4.1 CAUSES OF COLOUR

Colour in water may be due to natural causes or as a result of human activity. Water containing in part soils acquire colour because of the presence of colloidal organic matter. Colour is also due to mineral matter in solution, as a colloid or in suspension as in the case of ground water in certain areas. Waters containing oxidized iron and manganese impart characteristic reddish or black colour. Excessive growth of algae may also impart colour to the water. Discharge of industrial effluents or heavy pollution may discolouring in colour.

9.4.7.6 Treatment by Activated Carbon

Treatment with activated carbon is often a good choice for the removal of odor-causing compounds. Under the right conditions, it can remove a wide range of pollutants from effluents (11, 12, 18).

9.5 SCOURING

9.5.1.7.1 NBRM

As a result of the increasing quantities of industrial effluents, the amount of available chlorine has decreased. This has a detrimental effect on the efficiency of the treatment process.

Chlorination, however, is still used to disinfect effluents from the pulp and paper mills. Chlorination is also used to remove the odor-causing compounds from effluents and to oxidize the residual chlorine. The main problem is the formation of chlorinated hydrocarbons.

The chlorination of effluents is often a problem because of the high amount of organic matter. The chlorination process is often a problem because of the possibility of chlorination of the effluent. The chlorination process is often a problem because of the high amount of organic matter. The chlorination process is often a problem because of the high amount of organic matter.

Chlorination of effluents is often a problem because of the high amount of organic matter. The chlorination process is often a problem because of the high amount of organic matter. The chlorination process is often a problem because of the high amount of organic matter.

Chlorination of effluents is often a problem because of the high amount of organic matter. The chlorination process is often a problem because of the high amount of organic matter.

Alkaline dosing		Chlorination dosing		Acidity dosing
Chemical	Formula	Chemical	Formula	
NaOH	NaOH	CaO	CaO	None
Na ₂ CO ₃	Na_2CO_3	Ca(OH) ₂	Ca(OH)_2	None
Na ₂ SO ₄	Na_2SO_4	Na ₂ CO ₃	Na_2CO_3	None
Na ₂ SiO ₃	Na_2SiO_3	Na ₂ SO ₄	Na_2SO_4	None
		Na ₂ CO ₃	Na_2CO_3	None
		Na ₂ SO ₄	Na_2SO_4	None

Water is obtained with a total hardness of 1000 mg/l.

Classification	Total hardness as mg/l of CaCO ₃
Soft	0
Very Soft	0-100
Hard	100-300
Very hard	300

When hardness is less than 15 mg/l, softening for domestic purposes is not usually needed.

9.5.2 METHOD OF SOFTENING:

The two methods used are: (i) lime-soda softening and (ii) coagulation.



9.5.2.1 Lime and Soda-Soda Softening:

Softening with lime is the most usual one, especially for water with high mineral hardness. However, lime softening is suitable for water containing calcium, magnesium and iron salts. Increase these ions in hardness by increasing calcium carbonate hardness. The amount of lime is generally better by 200 mg/l, however, it varies with hardness. The chemical reaction is as follows:

(i) Pure Soda

(a) Chemical Reactions

When pure soda solution is added to water containing calcium and magnesium salts, the following reactions take place:



Note: In reaction (4), carbon dioxide

where $\mu_{\text{eff}} = \mu_{\text{eff}}(\Delta_{\text{eff}}^{(1)})$ is the effective chemical potential.

Repeating the above calculation with $\mu_{\text{eff}} = \mu_{\text{eff}}(\Delta_{\text{eff}}^{(1)})$ instead of μ in terms of an average of $\mu_{\text{eff}}(\Delta_{\text{eff}}^{(1)})$ and $\mu_{\text{eff}}(\Delta_{\text{eff}}^{(2)})$ would lead to an equation for $\Delta_{\text{eff}}^{(1)}$ which is the solution of a transcendental equation. The necessity of solving such an equation for $\Delta_{\text{eff}}^{(1)}$ is removed if $\mu_{\text{eff}}(\Delta_{\text{eff}}^{(1)})$ is approximated by $\mu_{\text{eff}}(\Delta_{\text{eff}}^{(2)})$. This approximation is $\Delta_{\text{eff}}^{(1)} \approx \Delta_{\text{eff}}^{(2)}$ according to equation (11) since $\Delta_{\text{eff}}^{(1)}$ is small relative to $\Delta_{\text{eff}}^{(2)}$ in the case of $\Delta_{\text{eff}}^{(1)} \ll \Delta_{\text{eff}}^{(2)}$ and $\Delta_{\text{eff}}^{(1)} \approx \Delta_{\text{eff}}^{(2)}$ in the case of $\Delta_{\text{eff}}^{(1)} \approx \Delta_{\text{eff}}^{(2)}$. The approximation $\mu_{\text{eff}}(\Delta_{\text{eff}}^{(1)}) \approx \mu_{\text{eff}}(\Delta_{\text{eff}}^{(2)})$ is also valid in the case of $\Delta_{\text{eff}}^{(1)} \approx \Delta_{\text{eff}}^{(2)}$ since $\mu_{\text{eff}}(\Delta_{\text{eff}}^{(1)}) \approx \mu_{\text{eff}}(\Delta_{\text{eff}}^{(2)})$ in the case of $\Delta_{\text{eff}}^{(1)} \approx \Delta_{\text{eff}}^{(2)}$. In the case of $\Delta_{\text{eff}}^{(1)} \approx \Delta_{\text{eff}}^{(2)}$, the approximation $\mu_{\text{eff}}(\Delta_{\text{eff}}^{(1)}) \approx \mu_{\text{eff}}(\Delta_{\text{eff}}^{(2)})$ is also valid in the case of $\Delta_{\text{eff}}^{(1)} \approx \Delta_{\text{eff}}^{(2)}$ since $\mu_{\text{eff}}(\Delta_{\text{eff}}^{(1)}) \approx \mu_{\text{eff}}(\Delta_{\text{eff}}^{(2)})$ in the case of $\Delta_{\text{eff}}^{(1)} \approx \Delta_{\text{eff}}^{(2)}$.

In calculating the chemical potential of the n th order of the expansion, the terms of the following order can be neglected since they are of the order of the next order of the expansion. The approximation $\mu_{\text{eff}}(\Delta_{\text{eff}}^{(1)}) \approx \mu_{\text{eff}}(\Delta_{\text{eff}}^{(2)})$ is also valid in the case of $\Delta_{\text{eff}}^{(1)} \approx \Delta_{\text{eff}}^{(2)}$ since $\mu_{\text{eff}}(\Delta_{\text{eff}}^{(1)}) \approx \mu_{\text{eff}}(\Delta_{\text{eff}}^{(2)})$ in the case of $\Delta_{\text{eff}}^{(1)} \approx \Delta_{\text{eff}}^{(2)}$.

Using the above results, the following equations are obtained by using the above results in the chemical equations (1) and (2):

$$(1) \quad \Delta_{\text{eff}}^{(1)} = \Delta_0 - \mu_{\text{eff}}(\Delta_{\text{eff}}^{(2)}) - \Delta_{\text{eff}}^{(2)} \quad (12)$$

$$(2) \quad \mu_{\text{eff}}(\Delta_{\text{eff}}^{(2)}) = \mu_{\text{eff}}(\Delta_{\text{eff}}^{(2)}) + \mu_{\text{eff}}(\Delta_{\text{eff}}^{(2)})$$

$$(3) \quad \mu_{\text{eff}}(\Delta_{\text{eff}}^{(2)}) = \mu_{\text{eff}}(\Delta_{\text{eff}}^{(2)}) \quad (13)$$

$$(4) \quad \mu_{\text{eff}}(\Delta_{\text{eff}}^{(2)}) = \mu_{\text{eff}}(\Delta_{\text{eff}}^{(2)}) + \mu_{\text{eff}}(\Delta_{\text{eff}}^{(2)}) \quad (14)$$

$$(5) \quad \mu_{\text{eff}}(\Delta_{\text{eff}}^{(2)}) = \mu_{\text{eff}}(\Delta_{\text{eff}}^{(2)}) + \mu_{\text{eff}}(\Delta_{\text{eff}}^{(2)}) \quad (15)$$

$$(6) \quad \mu_{\text{eff}}(\Delta_{\text{eff}}^{(2)}) = \mu_{\text{eff}}(\Delta_{\text{eff}}^{(2)}) + \mu_{\text{eff}}(\Delta_{\text{eff}}^{(2)}) \quad (16)$$

$$(7) \quad \mu_{\text{eff}}(\Delta_{\text{eff}}^{(2)}) = \mu_{\text{eff}}(\Delta_{\text{eff}}^{(2)}) + \mu_{\text{eff}}(\Delta_{\text{eff}}^{(2)}) \quad (17)$$

Using the above results, the following equations are obtained by using the above results in the chemical equations (1) and (2):

$$\Delta_{\text{eff}}^{(1)} = \Delta_0 - \mu_{\text{eff}}(\Delta_{\text{eff}}^{(2)}) - \Delta_{\text{eff}}^{(2)} \quad (18)$$

$\text{AsO}_4^{3-} + 2\text{H}^+ \rightleftharpoons \text{H}_2\text{AsO}_4^- \quad K_1 = 10^{-3.5}$

$\text{H}_2\text{AsO}_4^- + \text{H}^+ \rightleftharpoons \text{HAsO}_4^{2-} \quad K_2 = 10^{-6.9}$

$\text{HAsO}_4^{2-} + \text{H}^+ \rightleftharpoons \text{H}_3\text{AsO}_4 \quad K_3 = 10^{-11.5}$

$\text{pH} = 7.00 \quad \text{pH} = 7.00 \quad \text{pH} = 7.00$

Figure 10.10. Speciation of arsenic in natural waters. The distribution of arsenic species is highly dependent on the acidity but also on the total arsenic concentration. The species distribution is shown for a typical natural water with a total arsenic concentration of 10^{-5} mol/L.

Asides happen in natural waters, particularly in natural waters, which are rich in arsenic. In natural waters, arsenic is present as arsenate (AsO_4^{3-}) and arsenite (AsO_3^{3-}) species. The distribution of arsenic species is highly dependent on the acidity but also on the total arsenic concentration. The species distribution is shown for a typical natural water with a total arsenic concentration of 10^{-5} mol/L.

10.1.2.2. Methods Applied

The arsenic concentration in natural waters is determined by various methods. The most common method is the arsenic reduction method, which involves the reduction of arsenate to arsenite and the subsequent measurement of the arsenite concentration. Other methods include the arsenic reduction method, which involves the reduction of arsenate to arsenite and the subsequent measurement of the arsenite concentration.

(a) Chemical Methods

The arsenic concentration in natural waters is determined by various methods. The most common method is the arsenic reduction method, which involves the reduction of arsenate to arsenite and the subsequent measurement of the arsenite concentration. Other methods include the arsenic reduction method, which involves the reduction of arsenate to arsenite and the subsequent measurement of the arsenite concentration.

(b) Rapid As and Heterotrophic Assays

Rapid arsenic assays are available for the detection of arsenic in natural waters. These assays are based on the reduction of arsenate to arsenite and the subsequent measurement of the arsenite concentration. The most common method is the arsenic reduction method, which involves the reduction of arsenate to arsenite and the subsequent measurement of the arsenite concentration. Other methods include the arsenic reduction method, which involves the reduction of arsenate to arsenite and the subsequent measurement of the arsenite concentration.

The arsenic concentration in natural waters is determined by various methods. The most common method is the arsenic reduction method, which involves the reduction of arsenate to arsenite and the subsequent measurement of the arsenite concentration. Other methods include the arsenic reduction method, which involves the reduction of arsenate to arsenite and the subsequent measurement of the arsenite concentration.

Volume of exchange material to be used in cubic metres (Q) is calculated by the formula

$$Q = \frac{Q_1 H}{1000C}$$

Where,

Q_1 = Volume of water to be treated below Q_1 capacity unit, in m^3

H = Hardness of water in mg/l

C = Exchange capacity of the material kg/m^3

Generally, ion exchange beds are designed to be long, shallow (uniform) and bed depth being adjusted to maintain a uniform rate of flow in the range of 0.5 to 1.0 m/min. The vertical unit is 1.2 to 1.8 metres in diameter while the horizontal unit is 3 to 4 metres and 5 to 2 m long. The ion exchange bed has a depth of 0.6 m usually and is placed over supporting gravel (or depending upon the position of the exchange material but with similar classification as that for rapid gravity sand filters) of 0.30 to 0.47 m depth with an underdrain system at the bottom for collecting softened water. After the softening cycle, the softener should be backwashed for 3 to 5 minutes to loosen the exchange resin and remove particulate matter. The rate of backwash should cause atleast 50% bed expansion. After regeneration of the bed is carried out with brine solution. The brine distribution manifold is placed immediately above the softener bed.

Exchange capacities and the common salt requirements of Cation exchangers are presented in Table 2.1

TABLE 2.1
EXCHANGE CAPACITIES AND COMMON SALT REQUIREMENTS OF
CATION EXCHANGERS

Cation Exchanger	Capacity Eq/m^3	Common Salt kg/kg exchanged
Green sand	7-14	3.5-7
Synthetic Silica or Zeolite (natural)	17-37	2.5-3.5
Synthetic Organic	-	-
Impregnated Coal	13-35	2-4
Resin Polystyrene	20-300	2-3

The optimum concentration of brine for restoration of maximum exchange capacity in any resin is about 10 to 15% and the contact time for regeneration varies from 20 to 45 minutes. A dosage of salt of 15 kg/ mm^3 of resin using 1% brine solution is usually applied at a rate of about 150 l/m^2 of exchanger. For sea water, about 2.8 to 4.0 l/m^2 of exchanger is necessary.

The total rinse water requirement is 3 to 10 m^3/m^3 of material and applied at a rate of 5 to 18 $m^3/h/m^2$ in the slow and 30 $m^3/h/m^2$ in the fast types. The rinse water is introduced through the brine distribution network or by simply flooding the unit through a hose.

the following information is available to the public: (1) the name of the organization, (2) the date of the meeting, (3) the location of the meeting, and (4) the subject of the meeting.

16. *Right of Public Access*

The purpose of this section is to ensure that the public has access to the records of the meetings of the governing body of the local government. The governing body of the local government shall make available to the public the records of the meetings of the governing body of the local government, including the minutes of the meetings, the agenda of the meetings, and the records of the meetings of the governing body of the local government.

17. *Right of Public Access to the Records of the Governing Body*

The purpose of this section is to ensure that the public has access to the records of the meetings of the governing body of the local government. The governing body of the local government shall make available to the public the records of the meetings of the governing body of the local government, including the minutes of the meetings, the agenda of the meetings, and the records of the meetings of the governing body of the local government.

- (a) The governing body of the local government shall make available to the public the records of the meetings of the governing body of the local government, including the minutes of the meetings, the agenda of the meetings, and the records of the meetings of the governing body of the local government.
- (b) The governing body of the local government shall make available to the public the records of the meetings of the governing body of the local government, including the minutes of the meetings, the agenda of the meetings, and the records of the meetings of the governing body of the local government.
- (c) The governing body of the local government shall make available to the public the records of the meetings of the governing body of the local government, including the minutes of the meetings, the agenda of the meetings, and the records of the meetings of the governing body of the local government.
- (d) The governing body of the local government shall make available to the public the records of the meetings of the governing body of the local government, including the minutes of the meetings, the agenda of the meetings, and the records of the meetings of the governing body of the local government.

The purpose of this section is to ensure that the public has access to the records of the meetings of the governing body of the local government. The governing body of the local government shall make available to the public the records of the meetings of the governing body of the local government, including the minutes of the meetings, the agenda of the meetings, and the records of the meetings of the governing body of the local government.

18. *REMOVAL OF RECORDS AND ARCHIVAL OF RECORDS*

The purpose of this section is to ensure that the public has access to the records of the meetings of the governing body of the local government. The governing body of the local government shall make available to the public the records of the meetings of the governing body of the local government, including the minutes of the meetings, the agenda of the meetings, and the records of the meetings of the governing body of the local government.

9.6.1 SOURCES AND NATURE

Iron and manganese occur in soluble and insoluble water-soluble forms, often in association with organic matter, with being generally predominant, when they are soluble. They could also be found in surface waters, especially in iron-rich straggers, in form of a soluble in water dissolved form, because of the presence of iron, manganese, calcium, fluorine, these are usually common. The presence of iron can also be observed in the form of iron and organic material waste in rock coatings.

Iron and manganese in groundwater are associated with soluble forms of iron and manganese, such as siderite, sulphate, carbonate and silicate, of course, under the influence of the presence of a low degree of iron in groundwater.

Iron occurs in water in the form of soluble iron (II) as ferrous iron, which is soluble in water, but is not stable in the presence of oxygen, which is oxidized to ferric iron, which is insoluble in water. The iron in clear ground waters, the iron is present as dissolved iron (II) in groundwater, which is water normally in the form of soluble iron, which is insoluble in water, which is soluble in water.

The forms of iron in the form of iron (II) and iron (III) are soluble in water, but are not soluble in water, and are not soluble in water, and are not soluble in water. The iron in clear ground waters, the iron is present as dissolved iron (II) in groundwater, which is water normally in the form of soluble iron, which is insoluble in water, which is soluble in water.

The iron in groundwater is not soluble in water, but is soluble in water, and is not soluble in water. There are no analytical methods for the determination of iron in groundwater.


Water with high alkalinity has low iron and manganese concentrations, and is not soluble in water, and is not soluble in water, and is not soluble in water. The iron in clear ground waters, the iron is present as dissolved iron (II) in groundwater, which is water normally in the form of soluble iron, which is insoluble in water, which is soluble in water.

9.6.2 REMOVAL METHODS

The removal of iron and manganese from water is a common problem in the water supply industry. There are several methods available for the removal of iron and manganese from water, and the most common are: precipitation, adsorption, ion exchange, and membrane filtration. The most common method is precipitation, which involves the addition of a precipitant to the water, which causes the iron and manganese to precipitate out of the water. The most common precipitant is lime, which is added to the water in the form of a slurry. The iron and manganese are then removed from the water by filtration.

9.6.2.1 Precipitation

In iron precipitation, the water is reduced to iron (II) by the addition of a reducing agent, which is then oxidized to iron (III) by the addition of an oxidizing agent, which is then precipitated as iron (III) hydroxide. The reaction period is about 5 minutes, and is a pH of 7.0 to 8.0. The amount of oxygen is needed to convert 1 mg/l of iron (II) to iron (III) hydroxide is 0.14 mg/l, as follows:



$$1 \times 56 \text{ mg/l Fe}^{2+} = 2 \times 16 \text{ mg/l O}_2$$

$$1 \text{ mg Fe}^{2+} \approx 0.14 \text{ mg O}_2$$

The rate of oxidation of ferrous iron by aeration is slow under conditions of low pH, increasing 100% for every unit rise of pH. Increased aeration time would be necessary for stripping the carbon dioxide, hydrogen sulphide etc. Addition of lime can also remove the carbon dioxide or in case where there is residual acidity it can accomplish the raising of pH. Rates of precipitation and flocculation are increased in practice by contact and coagulation. Water is allowed to settle over tanks or similar structures. The deposition of hydrated oxides of iron and manganese and bacteria on the contact media is believed to act as catalysts which accelerate the oxidation of iron.


The contact beds for determination are normally 2 to 3 m deep, operating at a surface loading of 4 to 20 m³/d/m² with the contact medium of sieps 30 to 150 mm. Accumulation of iron and manganese are flushed out by rapid drainage after filling the bed to near overflow level. Sedimentation before filtration will be necessary when the iron content exceeds 10 mg/l. A settling period of 15 to 20 minutes is adequate. The water has to pass through filter (gravity or pressure type) with 15 cm depth of sand or sand and anthracite. Filter rates are usually of 6 to 9 m³/hr.



Oxidation of iron can be inhibited possibly due to the binding of iron ions by organic substances and ammonia which behave in a manner similar to a trace of alkali or acetic acids. All the organic material has to be oxidized before any perceptible oxidation of iron can be effected. Chlorination of raw water being various can bring about the oxidation of the organic matter and other reducing agents facilitating the oxidation of ferrous iron. Deep filter beds of 7 to 2.5 m with sand size of 15 mm have also been used with good results. In some waters, especially containing organic matter, precipitation, flocculation, sedimentation and filtration at pH values between 7.5 and 8.0 usually will ensure removal to acceptable limits.

By addition of lime to raw or pre-treated waters, carbon dioxide content can be brought down to zero and the resulting high pH value will promote the flocculation of iron and manganese. The plants will require washing of filter medium. Necessity of washing is established when there is overflow through the overflow pipe provided in the filter compartment of the units. The interval between successive washing varies and depends on the initial turbidity and iron content. Experience indicates a close interval of one week for turbidity around 40 mg/l and 1-2 months for waters with low turbidities (less than 10 mg/l). Washing of filter medium involves removal of ca. 5 to 10% of filter medium and washing it manually with water to free it from sediments and replace the same in position. The whole medium needs washing/replacement once in 6 to 24 months depending on the iron content in raw water.

Iron removal is also concomitant at the high pH value reached in municipal softening plants using lime.

Manganese removal requires a pH adjustment upto 9.6 to 9.6. 0.29 mg of oxygen is needed to remove 1 mg manganese.





$$1 \text{ mg Fe}^{2+} = 0.29 \text{ mg O}_2$$

The chlorination to free residual chlorine up to 1.0 mg/l will effect the oxidation and precipitation of manganese.

9.6.2.2 Contact Beds

The purpose of contact beds is to facilitate oxidation of iron & manganese through the entire section of previously prepared masses of these materials on the gravel or coarse sand. Results are claimed for the manganese ore process, which is an oxide of manganese. Usually upward flow at rates up to 5.0 m/h is preferred, but a lower rate may be used. Bed depth should be 1.5 m or a greater depth found necessary by pilot plant studies. Provision must be made for the equalizing of the beds, so as to wash excess oxides from one part or more, and for the use of a back-scan in the periodic cleaning of the particles on. The beds are regenerated by backwashing with potassium permanganate solution when permanganate is not applied as a raw water treatment.

Contact beds of pyrolite ore, for removal of iron without loss of potassium permanganate treatment, may be included sandstones to prevent the entrance of an upward flow, at interest, which by pilot plant tests would be provided. A trial rate of 4.8 m/h with a bed depth of 1.5 m is suggested giving a contact period of 9 minutes, with a usual load volume of 40%. The effluent from such beds would be treated in a downward flow to meet lead return concentration to facilitate passage. Fine filter filtration is needed as discussed earlier.

Manganese zeolite, formed by treating sodium zeolite with a solution of potassium permanganate is an effective contact material that will remove by oxidation about 1.65 mg manganese per cubic meter of zeolite per cubic ft. oxidation or regeneration of all material in each cycle is achieved by backwashing with a solution of potassium permanganate containing about 0.20 kg of the chemical per cubic meter of zeolite. Incomplete re-oxidation will result in the passage of manganese through the contact bed. The need to regenerate may be estimated by computing the volume of the raw water which contains 1.65 kg manganese per cubic meter of zeolite. For example, a water which contains 1 mg/l manganese will contain 1 kg/m³. Then a contact bed with a volume of say, 4 m³ would treat 4 x 1.65 x 10³ = 6.62 m³ of the water before regeneration is necessary. A solution of

to form a permanent deposit. It is not to be used to remove the iron when the solution is hard water, or to precipitate iron from the solution.

The iron should be removed from the water by the use of a pump and a filter. The pump should be of the type which is used for the removal of iron from the water.

2.2.2.2.2.2.2.

The iron should be removed from the water by the use of a pump and a filter. The pump should be of the type which is used for the removal of iron from the water.

The iron should be removed from the water by the use of a pump and a filter. The pump should be of the type which is used for the removal of iron from the water.

2.2.2.2.2.2.2.

The iron should be removed from the water by the use of a pump and a filter. The pump should be of the type which is used for the removal of iron from the water.

9.6.3 SIMPLE TENSILE TENSION TESTS FOR ADHESIVE BONDING OF STEEL COMPONENTS

The results obtained from tensile tests on a variety of materials of various profiles distributed as given in table 2, provide a means for the comparison and determination of ultimate strength and maximum strain and energy to failure at various temperatures under the difficulties of operation and manufacture. In general, the results show that the adhesive bond is not the critical link in the joint. In some cases, however, the failure of the adhesive bond is observed, especially in the case of the steel-to-steel joints.

When the joints are subjected to cyclic loading, the results show that the adhesive bond is not the critical link in the joint. In some cases, however, the failure of the adhesive bond is observed, especially in the case of the steel-to-steel joints. The results show that the adhesive bond is not the critical link in the joint. In some cases, however, the failure of the adhesive bond is observed, especially in the case of the steel-to-steel joints. The results show that the adhesive bond is not the critical link in the joint. In some cases, however, the failure of the adhesive bond is observed, especially in the case of the steel-to-steel joints.

9.6.3.1 Package from Removal Flaws for Steel Joints

Since the design of the adhesive resin and the nature of the adhesive is primarily determined by the type of metal to be joined, the design of the adhesive is primarily determined by the type of metal to be joined. The results show that the adhesive bond is not the critical link in the joint. In some cases, however, the failure of the adhesive bond is observed, especially in the case of the steel-to-steel joints. The results show that the adhesive bond is not the critical link in the joint. In some cases, however, the failure of the adhesive bond is observed, especially in the case of the steel-to-steel joints.

9.6.4 FROX REMOVAL PLAN FOR STEEL JOINTS

When the adhesive resin and the nature of the adhesive is primarily determined by the type of metal to be joined, the design of the adhesive is primarily determined by the type of metal to be joined. The results show that the adhesive bond is not the critical link in the joint. In some cases, however, the failure of the adhesive bond is observed, especially in the case of the steel-to-steel joints. The results show that the adhesive bond is not the critical link in the joint. In some cases, however, the failure of the adhesive bond is observed, especially in the case of the steel-to-steel joints.




FIG. 9.1 IRON REMOVAL PLANT FOR 1 MGD

Tray aerators are commonly used for aerating water. The trays are designed for an aeration rate of $1.26 \text{ m}^3/\text{m}^2/\text{hr}$ and spaced at intervals of 3 m. Then the water is settled in a sedimentation basin having a detention period of 2.5 hours. The clarified water is filtered through a rapid sand filter having sand of effective size 0.6-0.8 mm and uniformity coefficient 1.3 with an effective depth of 1.2 m. The head of water above sand is 1.35 m and the rate of filtration $5 \text{ m}^3/\text{m}^2/\text{h}$. The minimum backwash rate is $35 \text{ m}^3/\text{m}^2/\text{h}$ and the total head required for filter wash is 12 m.

Type designs for iron removal plants for 5, 10 and $15 \text{ m}^3/\text{hr}$ of flow are given in Appendix 9.3 along with drawings.

The sand is supported over a gravel layer of depth 0.39 - 0.62 m, and it is arranged as follows

size	depth
65 - 38 mm	13 - 20 cm
38 - 20 mm	8 - 13 cm
20 - 12 mm	8 - 13 cm
12 - 5 mm	5 - 8 cm
5 - 2 mm	5 - 8 cm

Power shut-downs are frequent and rarely more than two hours supply is available in the morning and evening in rural areas. Hence raw water pumping hours can be assumed to be 2 hours in the morning and 2 hours in the evening. During these 4 hours of pumping the total daily requirements of water are to be pumped to the raw water elevated storage tank. The treatment plant has therefore to be designed to operate under gravity from the raw water storage tank taking these facts into account. To avoid extra cost for additional overhead tank for filtered water, the filtered water from the pump-well could be directly pumped for the distribution. The distribution of treated water would follow the same time schedule as for pumping raw water. Backwashing of the sand filter would be carried out by using raw water from the overhead tank.

9.7 DEFLUORIDATION OF WATER

Excessive fluorides in drinking water may cause mottling of teeth or dental fluorosis, a condition resulting in the discoloration of the enamel, with chipping of the teeth in severe cases, particularly in children. In Indian conditions where the temperatures are high, the occurrence and severity of mottling increases when the fluoride levels exceed 1.0 mg/l . With higher levels, skeletal or bone fluorosis with its crippling effects are observed. The chief sources of fluorides in nature are (i) fluorapatite (phosphate rock), (ii) fluor spar, (iii) cryolite and (iv) igneous rocks containing fluorosilicates. Fluorides are present mostly in ground waters and high concentrations have been found in parts of Andhra Pradesh, Bihar, Gujarat, Haryana, Karnataka, Kerala, Madhya Pradesh, Maharashtra, Punjab, Rajasthan and Tamil Nadu in the country. While majority of values range from 1.5 to 6 mg/l some cases as high as 16 to 18 mg/l and in one solitary instance, even 36 mg/l have been reported.

9.7.1. REMOVAL METHODS

The removal of excessive fluoride from public water supplies or individual water supplies is possible solely on public health grounds. This is a problem particularly in rural areas and hence the attention has to be on simplicity of operation, cheapness and applicability to small water supplies. The methods use fluoride exchangers like tricalcium phosphate or bone meal, anion exchangers, active iron carbon, magneite, zeolite or aluminium salts.

9.7.1.1 Fluoride Exchangers

Degreased and alkali treated bone possess the ability to remove fluorides but have not been used on a plant scale. Bone charcoal prepared by controlled combustion of bones under limited supply of air in the presence of catalysts when treated with alkali or phosphate has been found to be useful. One cubic meter of bone charcoal is capable of removing 1.1 g/l of fluoride from a water with fluoride content upto 6.0 mg/l. The spent material can be regenerated with mono or trisodium phosphate. Tricalcium phosphate in powdered form can also be used but it has a lesser capacity of 0.7 kg of fluoride/m³. The spent material is regenerated by treatment with 1% alkali solution and rinsed with dilute hydrochloric acid.

9.7.1.2 Anion Exchangers

Fluorides can also be removed by anion exchange resins strongly basic formaldehyde resin quaternary ammonium type in hydroxide or chloride form. But their efficiency is lowered in the presence of other anions like bicarbonates, hydroxides and sulphates in the water.

9.7.1.3 Activated Carbon

Activated carbons have also been known to have the capacity for removal of fluorides. An activated carbon for fluoride removal has been developed in India by carbonising poultry husk or saw dust, digesting under pressure with alkali and quenching it in a 2% alum solution. This could remove 520 mg of fluoride per kilogram of the dry material. The spent material could be regenerated by soaking it in a 2% alum solution for 14 hours. The adsorption and hydraulic properties of the carbon are however poor.

A granular ion-exchange material Defluoror 2, which is a sulphated coal operating on the aluminium cycle has been developed in the country. The capacity of the material is estimated to be 500 gm of fluorides/m³ with raw water containing 5 mg/l and 150 mg/l alkalinity. The regeneration is carried out by means of a 2.5% alum solution, with replacement of two bed volumes. A flow rate of 4.0 m³/hr for a bed area is adopted. The raw water requirements after regeneration are 9.13 m³/m³ of water for a continuous duration of 16 minutes. The medium has a life of three years.

High alkalinity of the water considerably lowers the capacity as well as the efficiency of the bed. Hydroxyl alkalinity beyond 5 meq/l has a deleterious effect on the removal efficiency of the medium. The efficiency of the medium falls down by 30% when hydroxyl alkalinity becomes 25 mg/l.

Treatment cost using Defluoror 2 varies from Rs. 1.0 to Rs. 5.0 per 1000 litres of water treated, depending upon the initial fluoride concentration and the alkalinity of water.

9.7.1.4 Magnesium Salts

Excess lime treatment for softening effects increases fluoride due to its adsorption by the magnesium hydroxide floc. The fluoride reduction is given by the following expression:

$$\text{Fluoride reduction} = 75\% \text{ initial fluoride concentration} - \text{fluoride removed} \quad (9.17)$$

Sizeable fluoride removals are possible only when magnesium is present in large quantities which may not always be the case and it requires a higher dose of precipitant in the form of salts. The process is suitable only when the water is very soft.

Magnesia and hydrated magnesia have also been used for removal of fluoride from water. The study established the following empirical relationships for amounts of MgO which are required to obtain 1 or 2 mg/l fluoride in treated water:

$$(a) \quad MgO \text{ required to obtain } 1 \text{ mg/l fluoride in water } (F_2 = 3 \text{ mg/l})$$

$$1.75(1.33) \left[1 - \frac{1}{F_2} \right] = 16.5 \text{ quantity of raw water (mg/l)} \quad (9.18)$$

$$(b) \quad MgO \text{ required to obtain } 2 \text{ mg/l fluoride in water } (F_2 = 3 \text{ mg/l})$$

$$1.75(1.33) \left[1 - \frac{1}{F_2} \right] = 26.5 \text{ quantity of raw water (mg/l)} \quad (9.19)$$

F_2 represents the fluoride concentration in the raw water. The pH of the treated water was always beyond 10 and its correction by recarbonation was essential, adding to the complexity of operations and control.

9.7.1.5 Aluminium Salts

Aluminium salts like filter alum and activated aluminium and alum treated cation exchangers have shown beneficial effects. Filter alum during coagulation brings about some removal of fluorides from water. The removal efficiency is improved when used along with coagulant aid-like activated silica and clay. 300 to 500 mg/l of alum is required to bring down fluoride from 4.0 mg/l to 1.0 mg/l while with coagulant aid, the fluorides were reported to be reduced from 6.0 mg/l to 1.0 mg/l with alum dose of only 100 mg/l.

Alum treated polystyrene cation exchangers and sulphinated coals have also been used successfully. A cation exchanger prepared from extract of Avaram bark and formaldehyde when soaked in alum solution has been found to have good fluoride removal capacity (800 mg/kg).

Calcinated or activated alumina in granular form can be used for fluoride removal and the spent material regenerated with strong acid or by both alternately (removal efficiently 1.2 kg of fluoride/m³). A dilute solution of aluminium sulphate used as the regenerate for the spent material makes the alumina four times more efficient.




FIGURE 9.2: DEFLUORIDATION AT DOMESTIC LEVEL

9.7.2 SIMPLE METHOD OF DEFLUORIDATION

Defluoridation is achieved either by fixed bed media which could be regenerated or by the process of precipitation and formation of complexes. A simple method of defluoridation is employed in the Nalgonda Technique. It involves the use of aluminium salts for the removal of fluoride. The Nalgonda Technique employs either the sequence of precipitation, settling and filtration or precipitation, flocculation and filtration and can be used for domestic as well as community water supply schemes.

(i) Domestic Treatment: Precipitation, Settling and Filtration

Treatment can be carried out in a container (bucket) of 40 l capacity with a tap 3-5 cm above the bottom of the container for the withdrawal of treated water after precipitation and settling (Fig. 9.2). The raw water taken in the container, is mixed with adequate amount of lime or sodium carbonate, bleaching powder and aluminium sulphate solution, depending upon its alkalinity and fluoride content. Lime or sodium carbonate solution is added first and mixed well with water.

Alum solution is then added and the water stirred slowly for 10 minutes and allowed to settle for about one hour. The supernatant which contains permissible amount of fluoride is withdrawn through the tap for consumption. The settled sludge is discarded. The amount of alum to be added in 40 litres of water at various alkalinity and fluoride levels is given in Table 9.3.

TABLE 9.5

ALUM DOSE FOR DIFFERENT FLUORIDES AND ALKALINITY LEVELS

Test water Fluoride mg F/l	Test water Alkalinity, mg CaCO ₃ /l							
	125	200	300	400	500	600	800	1000
2	60	90	110	120	140	160	190	210
3	90	120	140	160	205	210	235	310
4		160	165	190	225	240	275	375
5			205	240	275	300	355	405
6			245	285	315	375	325	485
8					395	460	520	570
10							605	675

(ii) Fill and Draw Type for small community

This is also a batch method for communities upto 200 population. The plant comprises a hopper bottom cylindrical tank with a depth of 2 m equipped with a hand operated or power driven stirring mechanism (Fig. 9.3). Raw water is pumped or poured into the tank and the required amounts of bleaching powder, lime or sodium carbonate and alum added with stirring. The contents are stirred slowly for ten minute and allow to settle for two hours. The defluoridated supernatant water is withdrawn to be supplied through standposts and the settled sludge is discarded.

The notable features are:

- (a) With a pump of adequate capacity the entire operation is completed in 2-3 hours and a number of batches of defluoridated water can be obtained in a day.
- (b) The accessories needed are few and these are easily available (these include 16 l buckets for dissolving alum, preparation of lime slurry or sodium carbonate solution, bleaching powder and a weighing balance).
- (c) The plant can be located in the open with precautions to cover the motor.
- (d) Semi skilled labour can perform the function independently.

(iii) Fill and draw type (electrically operated)

The Fill and Draw type vertical unit comprises cylindrical tank of 10 m³ capacity with dished bottom, inlet, outlet and sludge drain. The cylindrical tank will have sturdy bulging, etc. Each tank is fitted with an agitator assembly consisting of (i) 3 HP dog gear of electric motor, 3 phase 50 Hz, 1440 RPM with 415 V $\pm 5\%$ voltage fluctuation, and (ii) gear box for 1440 RPM input speed with reduction ratio 1:24 to attain an output speed of 24 RPM,

complete with downward shaft to hold the agitator paddles. The agitator is fixed to the bottom of the vessel by sturdy, suitable stainless steel supporting basings.

The system comprises two of 10 m³ capacity each, a sump well and an overhead reservoir. The plant layout consists with two units in parallel for heating water for 1500 population at 40°C as shown in Fig. 9.4. Raw water is pumped into the units and treated by Nalgonda technique. The treated water collected in a sump is pumped to an overhead tank, from where the water is supplied through a tap post.

Approximate alum doses (mg/l) are given in column permissible limit (1 mg/l) of fluoride in water at various alkalinity and hardness levels are given in Table 9.6.

TABLE 9.6

ALUM DOSE FOR DIFFERENT FLUORIDE LEVELS AND ALKALINITY LEVELS

Test water Fluoride mg F ⁻ /l	Test water Alkalinity, mg CaCO ₃ /l							
	125	200	300	400	500	600	800	1000
1	113	227	279	312	351	409	468	520
3	221	229	351	403	507	520	585	767
4		403	436	468	559	758	789	936
5			507	598	669	715	884	1011
6			611	715	780	936	1066	1239
8					988	1118	1300	1430
10							1508	1690

Note: (i) Alum dose increased after increasing the alkalinity with lime or sodium carbonate.

(iv) *Precipitation, Flotation and Filtration*

Domestic treatment is achieved using a 100 l capacity batch type dissolved air flotation cell with hand operated pressure pump. The pump and cell form a compact dissolved air flotation defluoridation system.

Raw water in the cell is mixed with alkali and aluminium salts. A small quantity of air-water mix from the pressure pump is allowed into the cell. The precipitate with fluoride lifts to the top and floats. The treated water is collected in a bucket filtered through a sand filter. Using this cell, 100 l water is available for use in 20 minutes (Fig. 9.5).

The same principle of flotation is extended to a 500 l capacity dissolved air flotation cell to obtain nearly 1 m³ treated water per hour for small communities.




FIGURE 9.3: FILL AND DRAW TYPE DEFLUORIDATION PLANT FOR POPULATION UPTO 200 @ 40 lpcd




FIG. 9.4 FILL AND DRAW TYPE DEFLUORIDATION SYSTEM FOR RURAL WATER SUPPLY

9.7.2.1 Mechanism Of Defluoridation by Nalgonda Technique

The chemical reactions involving fluorides and aluminium species are complex. It is a combination of polyhydroxy aluminium species complexation with fluoride and their adsorption on polymeric aluminic hydroxides flocs. Besides fluorides, turbidity, colour, odour, pesticides and organics are also removed. The bacterial load is also reduced significantly. All these occur by adsorption on the floc surface. Lime or sodium carbonate insures adequate alkalinity for effective hydrolysis of aluminium salts so that residual aluminium does not remain in the treated water. Simultaneously disinfection is achieved with bleaching powder and this keeps the systems free from undesirable biological growth.

9.7.2.2 Rural Water Supply Using Precipitation, Settling, Filtration Scheme Of Nalgonda Technique-Continuous Operation

This scheme intends to treat the raw water for villages and includes channel mixer, pebble bed flocculation, sedimentation tank and constant rate sand filters. The designs of entire water facilities are available for 500, 1000, 2000 and 5000 populations. The scheme is gravity operated except the filling of the overhead tank and delivery from treated water sump. Channel mixer is provided for mixing lime slurry or sodium carbonate solution and aluminium salts with the raw water. Pebble bed flocculation is used in place of conventional flocculation in order to avoid the dependence on electric power supply. The scheme envisages power supply for 2 hours each during morning and evening for filling the over head tank and for supply of treated water. The basis of design of various units are given below:

(i)	Water consumption	70 l/c/d
(ii)	Flash mixing detention period, velocity to be maintained	30 secs
(iii)	Pebble bed flocculator	
	detention period (considering 50% voids)	30 minutes
	size of media	20-40mm
	depth of media	1.2m
	rate of backwash	0.5m ³ /min
(iv)	Sedimentation	
	liquid depth	3m
	weir loading rate	< 300 m ³ /m ² /d
	surface overloading rate	< 20 m ³ /m ² /d
(v)	Sand gravity filter	
	depth of water over sand	2m
	rate of filtration	5 m ³ /m ² /h
	head required for backwashing filter	1.2m
	minimum backwash rate	36m ³ /h
	gravel depth	0.45m
	effective size of sand	0.6mm to 0.8mm




FIGURE 9.5: MUSCLE-POWER DISSOLVED AIR FLOATATION SYSTEM FOR WATER TREATMENT

The size of all units, viz., overhead tank, channel mixer, pebble bed flocculator, sedimentation tank, sand filter and underground treated water storage tank are based on these design considerations for populations 500, 5000, 20000 and 50000. Layout plan and sectional elevation for treatment plant of Nalgonda Technique are given in Fig. 9.6

Nalgonda Technique has several advantages over the fixed bed ion-exchange processes. It does not involve regeneration of media and employs chemicals which are readily available and easy to operate and maintain using local skills. Colour, odour, turbidity, bacteria and organic contaminants also get removed simultaneously. The sludge generated is convertible to alum for use in removal of excess turbidity of surface waters.

9.8 DEMINERALISATION OF WATER

Conventional methods of water treatment do not materially change the mineral content of water. Base exchange softening merely converts the calcium and magnesium salts to the corresponding sodium salts. Lime softening causes a slight decrease in the contents of total solids but does not bring about any decrease in the content of sodium chloride or sulphate. Hence these methods are not effective in converting brackish water into a potable one. For providing a potable supply in brackish water area, the least mineralized water source could be

prospected. When potable water is unavailable some method of treatment has to be adopted. Thus ships on the high seas as well as lifeboats are provided with stills for manufacturing distilled water. Distillation of seawater has also been adopted during the war in isolated gullies which had to be occupied.

9.8.1 DISTILLATION

Of the processes of removing water from saline solutions, distillation is the oldest and in many of established plants, the most productive. It differs from the other processes in its passage of water through the vapour phase. The plant design is directed to tapping the most economic source of heat energy and exploiting the most efficient processes of heat transfer.


While relatively small quantities of water are to be distilled, straight or single effect distillation is preferred because of the simplicity of operation and the lower capital cost of the installation. With larger outputs improvement in efficiency acquires much greater importance because of the much higher rates of evaporation involved and the need for the highly efficient heat transfer systems. Problems of scale formation also play a significant role.

Performance of an evaporator plant is measured by the specific heat consumption, i.e. the number of kilocalories required to produce one kilogram of distillate. Distillation plants are generally better for lower values of specific heat consumption. The introduction of the flash evaporator has helped in better economies of heat recovery and more efficient plants can be built more cheaply. It is only in such situations where natural gas or fuel is available cheaply that low thermal performance evaporators can be used with the resultant saving in capital cost.


9.8.1.1 Solar Stills

Solar energy can be harnessed by the use of a system of mirrors following the path of the sun to focus the sunlight on sheets of water. In one of the popular methods, the salt water trickles down to trays mounted on an inclined compartment provided with glass sides and a heat insulated back which screens the condensing chamber from the sun. Since the focussing mirrors form an important element in the cost of the stills, the development of cheaper non-focussing types of mirrors and use of inexpensive materials of construction have been resorted to. In basin solar stills, a commonly used design, salt water tanks, filled either by gravity or by stainless steel impeller pumps, feed the solar still whose cover is at a shallow angle of 10° to 18° with the glass panes tightly sealed to the holding frame and the joints between the still cover and the vertical walls perfectly tight. The rate of feed to still should be such that for each 7.6 litres of salt water, 3.7 litres of fresh water is obtained and 3.7 litres of brine is discarded. The collecting troughs at the foot of the still cover must be constructed so that water will drain freely to the pipe which carries the distillate to the fresh water tank but preventing the entry of any contaminated water either from the roof or the ground in which it is constructed. In addition to the fresh water tank, it is good practice to construct additional distilled water storage so as to balance out the fluctuations between production and demand.

By their very nature, still covers are ideal for collection of run off of rain water and every advantage should be taken of the available rainfall by diverting in to the fresh water tank after disinfection. Such an addition can be substantial in areas, as for example, where annual rainfall is of the order of 30 cm and a still is so arranged as to recover 70% of it. The increase



SECTIONAL ELEVATION



LAYOUT PLAN

FIG. 9.6 DEFLUORIDATION PLANT USING NALGONDA TECHNIQUE

per square metre of still area is about 230 liters per year. The efficiency of a solar distiller is the condensed water actually produced divided by the water which could theoretically be evaporated by all the solar energy reaching the outer cover.

In general, wherever skies are generally clear, solar distillation is feasible upto 40° latitude, where 1000 kW/m² of energy from the sun in each year can be available, the solar radiation being more important than the mean ambient temperatures and the wind factors being negligible except as they relate to stresses upon solar distillation structures. The production of water by still varies from month to month and even day to day depending upon the solar radiation available. The size of still is often to be designed on the basis of the least productive month. Yields of about 1 m³/m²/year have been adopted for some of the bigger stills constructed and used successfully. The still area needed is given by the expression:

$$Q = 6.008 \times 10^3 \times S \quad (9.4)$$

Where

- Q = Output per square metre of still area in lpd and
- S = Insolation or solar radiation in calories/cm²/day

Values typical for India for various latitudes are given in Appendix 9.4

The best situations for the use of solar distillation are the isolated areas and certain regions where fresh water is unobtainable, solar intensities are high, fuel resources are meager and industrial development is poor.

9.8.1.2 Single-Effect Distillation

The sea water is boiled in a vessel, using steam as the heating medium. The vapour is condensed by heat extraction to a cooling supply of sea water, part of which forms the feed to the plant.

It is not useful to install liquid/liquid heat exchangers to recover heat from the exit brine and exit distillate. The vapor produced has to be condensed. Any recovery of heat could only be used to heat the feed water, and if this were done, the circulating water supply to the condenser would need to be increased.

9.8.1.3 Multiple-Effect Evaporation

Each component unit of a multiple-effect evaporator is maintained in series at slightly lower pressure and temperature in order to permit the steam produced in one effect to serve as the source of heat in the next. Weight for weight, the amount of product water then approximates the number of effects. It has been computed that the quantity of water that can be evaporated by one kg of steam in single double and triple effect evaporations are in the ratio of 0.9, 1.7 and 2.5 respectively.

(a) Multi-Stage Flash Evaporation

This is also accomplished at successively lower pressure and temperatures. The multistage flash systems is logically related to the multiple effect system by extending the preheaters to full condensation duties and omitting all evaporation heating surface entirely, so that all

vapour is obtained by flashing. The incoming water is warmed by the heat of condensation and only a small amount of heat energy is required to flash the preheated water in the reduced pressure stage into steam. Specific heat consumption values as high as 110 are possible.

(b) Low Temperature Flash Evaporation

This method has for its object, the exploration of the possibility of utilizing the energy in streams of warm water from power plant, oil refineries and industrial plants as well as from naturally occurring sources. The studies show that this method for warm saline waters is theoretically sound and technically feasible.

(c) Vapour Compression Process

This process relies on mechanical compression of the vapour to boost its temperature high enough to supply through its own condensation the heat necessary to evaporate the feed water. Once started, this process does not draw upon further heat energy but only upon mechanical energy.

Steam at 100° C is compressed so that its temperature is raised to about 105° C and this compressed steam is used to raise the temperature of the feed water to the boiling point. Vapour compression distillation improves the efficiency of the reuse of the latent heat of steam. Heat is required only for the initial production of vapour. Thereafter the heat derived from the mechanical energy developed by the motor that drives the compressor may supply all the needs of energy. The method has been found to be remarkably efficient. Heat transfer coefficients can further be improved 4 to 6 times by making a thin film of the water flow rapidly over a rotating surface. The rotating surface showed no scale or corrosion. This mechanism appears to be self-cleaning.

Because of high cost of the compressor, the expected overall efficiency of vapour compression as far as cost is concerned is not good. However, there are many special applications, particularly in small capacity plants, where considerations other than cost determine that the vapour compression process is most suitable and economical.

(d) Critical Pressure Distillation

The principle of this method is that by operating at pressures in excess of 250 kg/cm² and temperatures greater than 370° C, the density difference between the liquid and vapour phases is made relatively small so that the size of the vapour handling equipment can be greatly reduced. The main difficulties in this process are the rigid bonding up of scale and the need for developing materials of construction which can withstand these elevated temperatures and pressures.

(e) Vapour Reheat Distillation

This process is similar, in several respects, to multiple flash evaporation. In this system deaerated sea water enters the system and passes through a heat exchanger counter current to hot flash water. The temperature is then raised with heat from an external source (the prime energy supply). The hot sea water then cascades through a series of flash chambers counter current to a stream of fresh water flowing in open channels. In each stage, some sea water flashes to form steam, which condenses on the stream of fresh water. As a result, sea

water is cooled and fresh water is heated. Hot fresh water leaving the highest pressure stage is used to heat incoming sea water. Part of the cooled fresh water is recycled to the lowest pressure stage; the rest is product.

In most processes involving sea water distillation, scaling limits the maximum temperature in the systems. In the vapour reheat system, the absence of heat transfer surfaces and reduction of fouling problems removes this limitation.

9.8.2 FREEZING

Water can be transposed from saline water to the solid phase as ice. The fact that the latent heat of fusion, viz., 80 Kcal/kg is small compared to the latent heat of vaporization is taken advantage of in this process. However, even though the ice crystals formed constitute essentially pure water, the yield of product water is decreased because some of it is used to wash salt from the ice surfaces and because it is required to melt the ice crystals. As in distillation, countercurrent operation conserves heat energy in this system also. By cooling the feed water to the freezing point before a refrigerant is evaporated in direct contact with the feed and by countercurrent washing and melting of the ice crystals, maximum economy is effected.

(a) Contact Freezing

This makes use of two heat transfer circuits of recovering hydrocarbons. The first circuit absorbs heat from the incoming salt water, transfers it in part to the fresh water and loses it in part to the waste brine. The second circuit vaporizes the liquid hydrocarbon in contact with the salt water to freeze off the vapour is then compressed and the heat energy released is used to melt the ice. The vapour separating from the fresh water is repumped through the freeze chamber.

(b) Eutectic Freezing

This operates at the eutectic temperature of the incoming water. Down to the eutectic point only ice is formed. At the eutectic point, ice crystals nucleate and grow independently of salt crystals and other substances in the water, thus permitting separation. Further removal of heat does not continue to lower the temperature.

9.8.3 SOLVENT EXTRACTION

Organic solvents partially miscible with water can be used to extract the fresh water leaving behind a more concentrated salt solution. The solvent fresh water phase can be separated out from the concentrated salt solution and distilled to yield fresh water.

9.8.4 OSMOSIS

Certain natural and synthetic membranes have the property of permitting the solvent (water) to get through them but not the solute. Such semipermeable membranes permit the separation of solute from solvent. This phenomenon is known as Osmosis.

(a) Reverse Osmosis (RO)

Reverse Osmosis is a membrane potential process for separating relatively pure water (or other solvent) from a less pure solution. The solution is passed over the surface of an appropriate semi permeable membrane at a pressure in excess of the effective osmotic pressure of the feed solution. The permeating liquid is collected as the product and the

concentrated feed solution is generally discarded. The membrane must be highly permeable to water, highly impermeable to solutes, and capable of withstanding the applied pressure without failure. Because of its simplicity in concept and execution, reverse osmosis appears to have considerable potential for wide application in water and waste water treatment.

(b) Electrodialysis (ED)

Unaided osmosis is a relatively slow process and hence attempts have been made to combine this with electrolysis. Application of an external electromotive force can draw the ions away from the salt solution towards the electrodes so that the solution is impoverished of its salt content. The reunion of the ions by diffusion can be prevented by using suitable membranes to separate the cathode and anode chambers and also by continuously removing the relatively concentrated solution of the electrolytes from the electrode chambers. To obtain purification of sufficient magnitude a number of electrolytic cells have to be used in series. In essence the apparatus would consist of a number of electrolytic cells each of which is composed of 3 compartments separated from each other by suitable membranes. The saline water circulates in series through the middle compartments of the cells and undergoes progressive purification. The number of cells and the rate of flow may be adjusted to give the degree of purification required. A direct current of 110 to 220 volts is employed. The electrodes are continuously washed with the treated water. One of the main disadvantages of the electrodialysis process is that the membranes get badly damaged as a result of corrosion and scale formation. Another disadvantage is that the cost goes up steeply as total solids content of the finished water decreases. Power loss is minimized if the water is demineralised only partially to final concentrations of less than 500 mg/l in a multi compartment cell. Average power requirements are 1 kWh/ m³ of water/1000 mg/l of TDS removed for waters with initial TDS values of 10,000 and less. Since power requirements rise sharply with higher initial values in this method compared to distillation and freezing, this process is adapted only for waters containing less than 10,000 mg/l of dissolved solids.

(c) Osmotic Process

This process is based on the principle of osmosis through ion selective membranes which pass only anions or cations preventing the passage of the other ions. The concentration gradient between the solutions supplies the potential required to drive the ions through the ion selective membranes unlike in the case of reverse osmosis where pressure is applied to force the water but not the salts through the membranes.

9.8.5 ION-EXCHANGE PROCESS


When a salt solution is percolated through a cation exchange resin treated with acids the effluent contains equivalent amounts of the corresponding acids as shown below.



Where M⁺⁺ is Ca⁺⁺ or Mg⁺⁺. The same equation can also be written for monovalent ions like Na⁺ or K⁺.

When this acidic effluent is passed through an anion exchange resin which has been treated with alkali so that it contains replaceable hydroxyl ions, the anions are exchanged for

the hydroxyl ion with the result that the effluent is rendered free from salts as illustrated as follows:



Thus it is possible to remove salts from brackish water by a process requiring no more technical skill than that involved in the use of percolation columns. The beds could be regenerated and used repeatedly without appreciable loss in capacity.

High capacity cation exchange materials have been discussed in 9.5.2.2 (b). The anion exchange materials have been prepared by condensing substituted aromatic amines with formaldehyde. Large ion exchange resins have been used in the field of treatment of water for industries and especially in the production of make up water for Liquefied Petroleum Gas. They have also a place in the treatment of brackish water for the production of potable water.

9.8.6 PERFORMANCE OF RO AND ED PLANTS

Based on evaluation studies conducted by NIEERI in the working of desalination plants employing Reverse Osmosis and Electrodialysis principles, following information emerged:

- Returning cost of desalination by Reverse Osmosis (RO) and Electrodialysis (ED) ranges from Rs. 2 to Rs. 33 and Rs. 8 to Rs. 27 respectively per m³ (1987) including depreciation and interest on capital, the cost works out as Rs. 40 to Rs. 131 for RO and Rs. 28 to Rs. 85 in case of ED (1987).
- Quality of product water in RO is consistent while it is generally not so in ED.
- In spite of elaborate pre-treatment, operation and maintenance, the plants could not yield consistent quality of product water within permissible limits. Whenever such consistency in quality was attempted, the product water quantity decreased considerably, thereby raising the cost of treatment of desalinated water. The output water quantity correspondingly increased.
- In the RO plants evaluated, rated capacity of product water was rarely achieved. In the plants studied by NIEERI, only one produced at 100% capacity, while others functioned at 50,50 to 77% of the rated capacity, associated with problems during operation.
- Membrane life indicated by various firms for RO plants varied from 1 to 3 years. A membrane life of upto 7 years is claimed for ED. These claims, however, need validation as all plants evaluated operated on an average for 5.8 hours, but make and the frequency of membrane changes was higher.
- Pressure pumps and tanks pose several problems during operation, non-availability of spare parts at site can seriously affect their maintenance.
- Due to frequent deposition of salts on membrane, that needed acid wash more frequently, the maintenance of ED plants becomes more difficult.
- Scaling is a potential problem and large quantities of acid are used to prevent its formation. General practice has been to use the Langlier saturation index of 0.

concentration to calculate acid requirements. Stiff and Davis Stability Index is recommended which results in a significant reduction in acid use.

- (j) Energy costs are typically 40-60% of the total operating costs of Reverse Osmosis. The production of 1 m³ of water requires 4-6 kWh of energy, compared with 12-18 kWh for distillation process. However, the requirement can be reduced if energy recovery machines are used, wherever feasible.
- (k) Membrane replacements, during the life of an RO plant, are typically estimated to account for 25-35% of the operating costs. There is plenty of scope for reducing the frequency of membrane replacement.

There is no one 'best' method of desalination. Generally, Distillation and Reverse Osmosis are recommended for seawater desalination, while Reverse Osmosis and Electrodialysis are used for brackish water desalination. However, the selection and use of these processes should be very site specific; they must be selected very carefully, especially in rural areas.

One of the major considerations in the selection of a desalination process should be its cost and maintenance. However, despite the substantial costs involved, the availability of desalinated water in arid zones can be a boon to that area. Where the water is saline, alternative water for consumption is often transported over long distances by truck or animal. When the water is sold, its unit price often exceeds that of desalinated water. Therefore, the economic conditions to support desalination already exist in many water-short areas.

9.9 CORROSION

Corrosion is the phenomenon of the interaction of a material with the environment (water, soil, air, etc.) resulting in its deterioration. In water supply, corrosion causes significant loss in the hydraulic carrying capacity of pipes and fittings, poor quality of water transported and possible structural failures. Corrosion of metal due to soil electrolyte and stray currents are termed as 'underground' corrosion' while that due to water flowing or contained in the pipes or containers is denoted as 'internal corrosion' or 'underwater corrosion'.

9.9.1 MECHANISM OF CORROSION

When a metal is in contact with an electrolyte, it has a tendency to ionize and go into solution. The driving force for this process is called the solution potential.



The hydrogen ion required for this reaction comes from the ionization of water



The hydrogen ion liberated on the metal surface has to be taken away for the ionization to continue according to equation (1). Otherwise, it will cover the metal surface preventing further reaction. The hydrogen atom can be removed according to the following reactions:



Reaction (3) is quite significant in water supplies since dissolved oxygen is always present. Reaction (4) requires low pH or a second metal which can serve as an outlet for the hydrogen (depolarizes). In water supplies such low pH conditions are not possible. When contact with another metal is available galvanic reaction occurs.

9.9.2 TYPES OF CORROSION


The major types of corrosion are galvanic, concentration cell, stress, stray current, electrolysis and bacteria (biochemical).

9.9.2.1 Galvanic Corrosion

When a metal is kept in an electrolyte, it forms a half cell or electrode and the potential associated with it is called half cell potential or electrode potential. In a galvanic cell anodic metal goes into solution while metal is deposited on the cathode. The metal that is placed higher in the galvanic series (electrode potential) will form anode and will be corroded. The Galvanic Series of metals and alloys given is under.

GALVANIC SERIES

Least noble Most Corroded	<i>Corroded End</i>
⋮	Magnesium
⋮	Magnesium alloys
⋮	Zinc
⋮	Aluminum 2S
⋮	Cast iron
⋮	Aluminum 17S1
⋮	Steel or iron
⋮	Cast iron
⋮	Chromium iron (active)
⋮	Stainless type 410
⋮	Nickel-Resist cast iron
⋮	18-8 Chromium nickel iron (active) Stainless type 304
⋮	18-8 Chromium nickel molybdenum iron (active) Stainless type 316
⋮	Lead tin solders
⋮	Lead
⋮	Tin
⋮	Nickel (active)
⋮	High nickel chromium alloys



Galvanized iron (zinc coated) is more serviceable than steel alone, because the iron exposed at joints is protected at the expense of the zinc.

9.9.2.2 Concentration Cell Corrosion

This type of corrosion is most prevalent and occurs when there are differences in the metal ion concentration, anion concentration, hydrogen ion concentration, temperature, or dissolved oxygen level which cause a difference in the solution potential of the same metal thereby promoting corrosion.

In water containing dissolved oxygen, the oxidation of iron from ferrous to ferric state with subsequent hydrolysis results in the increase of hydrogen ion concentration. The increase in the hydrogen ion concentration in contact with hydrogen results in a hydrogen ion concentration cell at this point thus accelerating the rate of corrosion. Similarly an oxygen concentration cell is established due to the difference in the dissolved oxygen content near the anode and cathode areas. This also increases the rate of corrosion at the anode where there is little or no oxygen. In the case of buried pipes, the nature of the soil plays an important role in the availability of oxygen. For example, lime and sandy soils have different

permeability for air penetration to the surface of the buried pipelines and local cells form between various parts of the pipeline.

The porous ferrous hydroxide deposit acts as a protective coating and retards the corrosion. The accumulation of hydroxide ions near the cathode which reduces the free movement of electrons also retards the corrosion reaction.

9.9.2.3 Stray Current Corrosion

Stray current corrosion is a complex process of metal disintegration under the combined action of soil and stray currents whose usual source is electrified railway track and earthing of electrical fittings. The flow of stray current depends on the distribution of potentials in the track circuit. All metals have greater conductivity than the surrounding environment and hence the current will stay with the metal until there is discontinuity of the metal conductor. Excess of electrons will leave the metal at the points where the environment is highly conductive receptor for the current. Corrosion takes place at the anode, the points where the current leaves the metal and returns to the power source.

Of paramount importance is the simple, reliable and efficient method of measuring the densities of leakage current flowing off the metal in underground pipelines which lie in the field of action of stray currents. This stray current corrosion can be alleviated by making the interfacial resistance of the pipe significantly higher than the surrounding soil, e.g. coating of the pipe. In addition, cathodic protection can be given.

9.9.2.4 Stress Corrosion

Potential difference between different parts of the same metal is due to various factors such as non-homogeneity of surface and non-uniformity of pressure. A smooth surface is less susceptible to corrosion than a rough surface. In fact, the grain size of a metal is important since the solubility of very small grains is greater and hence it is likely to be corroded easily. Metal under stress is easily corroded because the stressed areas become anodic. Therefore, metals exposed to different stresses and strain like points of bolts and nuts in pipe supports are more corroded compared to plain pipes. When a freshly forged metal is used in machinery along with parts made of the same metal but which has been in service for sometime and in which the strain has been relaxed, more rapid corrosion of the new piece of metal is noticed. Residual stress may be relieved by annealing the metal at suitable temperature. Cycles of alternate stresses and strains which induce fatigue also tend to increase the rate of corrosion.

9.9.2.5 Bacterial (Biochemical) Corrosion

Several bacteria like the sulphate reducing bacteria, iron fixing bacteria and other micro-organisms that enter into electrolytic or ionic reactions are responsible for bacterial corrosion. Stagnation of water as in the dead ends gives scope for the development of anaerobic conditions with the production of sulphide from sulphate present in the water. The sulphide thus formed will attack the pipe metal forming black deposits of the metal sulphides which are noticed when the dead ends are flushed. Iron bacteria like *Glenothrix* and *Leptothrix* grow utilizing the energy available in the oxidation of metallic iron to the

oxide films corroding the metal. The characteristic string masses that come out of high pump tubewells are the result of such growths.

9.9.3 PHYSICAL AND CHEMICAL FACTORS OF WATER AFFECTING CORROSION

Velocity and temperature of water in pipes affect the rate of corrosion. In aggressive waters, high velocities more than 1 mps are conducive for rapid corrosion. With adequate inhibitor concentration referred to in 9.2.5.3.1, high velocities normally prevent metal corrosion. At low velocities the protective properties of water retarding inhibitors are not utilized to their best advantage, since the slow movement does not aid the efficient diffusion of the protective ingredients to the metal surface. For example, at velocities below 0.5 mps corrosion is significant even in the presence of inhibitors.

In general, corrosion increases with temperature. The rate due to the increase of polarization and diffusion as temperature increases. Local pitting and general corrosion are also increased at elevated temperature. If the heating products have alkaline nature, at operation, it may form HCl and consequently produce more corrosion. The alkaline nature of alkali and alkali earth metals enhance the corrosion of many metals since the alkaline ion destroys the protective film on the metals. Some anions like silicate form insoluble products that get deposited on the metal's surface forming a protective layer, thus acting as inhibitor of corrosion. The nature of cations present will also influence the corrosion rate. Traces of copper and other noble metals will accelerate the rate of corrosion of iron pipes. Iron and several other metals corrode more readily in ammonium salt solutions than in sodium salt solutions of the same concentration. Some inhibitors which protect iron increase the corrosion rate of copper and brass because of the formation of complex anions with the metals.

Concrete constructions will be attacked by salts present in the ground water. Formation of calcium sulphate from sulphate and calcium ions in concrete is responsible for the later's corrosion. Water with 200 to 600 mg/l of sulphate and 200 to 400 mg/l of magnesium are considered to be slightly aggressive and water with 600 to 1200 mg/l of sulphate and 500 to 1500 mg/l of magnesium are aggressive to concrete.

9.9.4 SOIL NATURE AND CORROSION

The corrosion current will depend on the conductance of the medium which is an important factor in the corrosion of buried pipelines and structures. Dry sandy soil has low conductance but in moist clay and mineral areas it is too high. This difference in the conductivity of the soil permits its classification into cathodic and anodic sections. Stray currents from power leaks will be more dangerous to buried structures in low conductivity soils of high conductance which is a significant factor in its corrosive nature. Therefore, investigations for conductivity should form an essential part of the soil analysis, particularly for long and lengthy buried pipelines apart from the routine tests of pH, redox potential, chemical analysis for calcium carbonate, sulphate, sulphide, protein, free carbon, moisture content, organic content and grain size analysis.

9.9.5 CORROSION TESTING

Corrosion rates are often expressed as loss in weight from clean metal per unit surface area (g/cm^2) during a specified period of time (hour, day, month or year). If pitting is caused by the corrosion, then the intensity of corrosion is expressed as the depth of the pit during a specified period (mm/year).




FIGURE 9.7: CATHODIC PROTECTION ASSEMBLY

Corrosion testing can be carried out either in the field or in the laboratory under controlled environment simulating field conditions. Corrosion testing is done using coupons or resistance probes. Coupons are made up of the same material as the structure and normally insulated from the main structure. The coupons are cleaned before and after insertion and the weight loss is expressed as $g/cm^2/year$ which is the measure of corrosion rate. Resistance probes are metallic rods or plates inserted at elbows using a tee in the mainstream of water or in a bypass. They operate on the principle that when a thin wire or foil corrodes its electrical resistance increases due to the decrease of its cross sectional area. The resistance measurements are converted to corrosion rate. Other field tests use thickness detectors for measuring the metal remaining in the corroded pipes or visual examination as a grade method. All these tests are not completely conclusive by themselves.

Investigation of groundwater level and characteristics of water along with the results of laboratory or field test can be used to predict the possible corrosivity of the soil in which pipes are laid. Correlation between the soil resistivity or conductivity and corrosion is given in Table 9.7.

TABLE 9.7

CORRELATION BETWEEN THE RESISTIVITY AND CORROSION

Resistivity (ohms/cm)	Corrosion
Upto 500	Very strong
500-1500	Strong
1500-2500	Moderate
above 3000	Feeble or none

Mud, muck, clay, tidal marsh and organic soils in high water tables fall under the category of strong to very strongly corrosive. Silts, sandy loam, porous and clay loam or low water

tables are moderately corrosive. Even soils with good or fair corrosion may contain pockets of low resistivity. It is at the junction of such soils that corrosion is most maximum. A pipeline passing from a high resistance soil to a low resistance soil will corrode in the latter because of difference in pipe to soil potentials of the two area. The current flows from the pipe through the bad soil to the good soil and then back to the pipe.

9.9.6 CORROSION CONTROL

9.9.6.1 Cathodic Protection

Cathodic protection is the application of electricity from an external power supply or the use of galvanic methods for controlling electrochemical corrosion. Cathodic protection should be used as a supplementary and not as an alternative technique to other methods of protection. It may be a more suitable and expeditious method for control of external corrosion of pipelines.

(a) Basic Principle

The basic principle is to make the entire surface of the equipment cathodic thus affording protection since corrosion takes place only at the anodic surface. This can be achieved by connecting it to a D.C. source. In this case, the anode consists of specially earthed electrodes. The general arrangement in a cathodic protection assembly is shown in the fig. 9.7.

The current from the positive pole of the D.C. source flows through the conductor 2 into the earthed anode 3 and then into the soil. From the soil the current flows to the surface of the pipe 4 to its protected end and flows along the pipe to the drainage junction point 5, the conductor 6 and back to the negative terminal of the current source. Thus the entire surface of the underground pipe or equipment becomes cathodic and is protected from corrosion while the earthed anode gets corroded. The anode is usually a series metal e.g. old tubes, rails etc. Other metals which are resistant to attack by surrounding soil like special alloys or graphite are also used. The conductivity of the protective coating has a direct influence on the length of the protected section of the pipe. The required power increased with increasing conductivity of the coating.

(b) Preliminary Investigations

The existing pipeline has to be inspected to ascertain the sections which require protection. Other basic information required are:

- (1) Plan and details of the pipelines (showing branch connections, diameter, length and wall thickness) and
- (2) Location plan of the section to be protected along with:
 - (i) Data on soil resistance along the section to be protected at the intervals of at least 100 m as well as the earthing points.
 - (ii) Information on the availability of sources of electricity, ampereage, voltage, AC/DC (phase) in the vicinity and spaces for locating current supply and controls.

- (iv) Data on the conductivity, resistivity of the existing protective insulation; and
- (v) Condition of the pipeline, if it is already in use.

(c) Power Requirements

With the above data, minimum current density and maximum protection potential can be worked out. The capacity of the current source for a cathodic protection system depends on (1) length of the section to be protected (2) type and state of the coating of the pipeline (3) diameter of the pipe (4) wall thickness of the pipe (5) conductivity of the soil and (6) design of anode earthing. The power requirements vary from 0.4 to 10 kilowatts in most cases. The possible current sources are DC generator, converter-rectifier, storage batteries of dry or acid type. The pipeline should be at least 0.5 V negative to the soil.

(d) Anodes

The main power loss occurs in the anode earthing. The earthing can be carried out by any metal (pure or scrap) of any shape and also carbon forms like coke or graphite. When tubes are used the earthing can be either horizontal or vertical. Near the earthing zone, soil treatment can be done to reduce soil resistance by adding salts like sodium chloride, calcium chloride or moistening the soil, the former being better and long lasting. Carbon or graphite electrodes have longer durability than metal electrodes.

(e) Other Facilities

A cathodic protection station should provide space for housing the equipment, installation of current sources, supply and distribution zones, equipment for check measurements, construction of earthing structures and facilities for carrying out operational tests.

9.6.6.2 Protection by Sacrificial Anode

Sacrificial anodes serve the same purpose as the cathodic protection system but does not require electric power supply. The required current is supplied by an artificial galvanic couple in which the parts to be protected, usually iron or steel, is made as the cathode by choosing the other metal, having the higher galvanic potential, as the anode. Zinc, aluminium and magnesium (with sufficient purity) or their alloys which are higher up in the galvanic series must be used for this purpose. Sheets of zinc suspended in a coagulation basin is an example. A single protector anode will not be sufficient and it will be necessary to install a number of such anodes generally spaced at 4 to 6 m in the pipeline or the structure to be protected.

The performance and service life of anodes depend mostly on the nature of soil or water surrounding them. Use of SF materials in the soil such as clay and gypsum powder results in low resistance of anode earthing and yields a high current. The costs of protection by galvanic anode would be proportionally higher on the case of pipeline networks in big towns since it would be necessary to suppress accidental contacts. For the application of galvanic protection the resistance of the soil should be less than 12 ohm-m. A higher resistance of the

current can neither achieve the required current density nor reduction of the pipe to soil potential. In such cases, cathodic protection by means of external power supply offers better protection.

9.9.6.3 Control Of Internal Corrosion

(a) Associated Factors

Corrosion of the internal surfaces of waterpipes results in reduced carrying capacity, red water and taste and odour problems. Experience in the country has shown that the 'C' value of cast iron pipes have gone down to as low as 45 in 5 years of service due to corrosion.

The mineral content, dissolved oxygen and pH of water influence the corrosion rate of mild steel. The effect of dissolved oxygen is decreased by increase in pH. With no minerals the pH of water in mild steel containers adjusts itself to about 8.4 and corrosion becomes negligible. Pitting can occur at pH 8 and welds (stressed areas) if pH is around 8.4 but not above that required for complete protection.

In the absence of carbonate minerals, increasing concentration of other minerals such as chloride and sulphate salts increases the corrosion rate at all pH values below the pitting range of pH. Increasing temperature accelerates both general corrosion and pitting.

Bicarbonates inhibit corrosion. In the absence of calcium, the inhibitory effect of bicarbonate is maximum at pH 6.5 to 7 when its concentrations are 5 to 10 times above the chlorides and sulphates. It is maximum at pH 8 to 9.

When dissolved oxygen is absent, the role of minerals present have insignificant effect on mild steel.

The method of controlling corrosion by deposition of calcium carbonate was first suggested by Langlier. According to him the tendency of deposition of calcium carbonate depends upon carbon dioxide and calcium carbonate balance in water.

Langlier index, $I = (d/c) - (p/c_s)$, where d/c is associated with calcium carbonate equilibrium (determined by simple test or by calculation from dissolved solids) and p/c_s is the actual pH of the water in the pipeline. When $I = 0$ neither deposition nor dissolution of calcium carbonate takes place. A positive value indicates that the water is oversaturated with calcium carbonate (or lacking in free carbon dioxide) and will tend to deposit calcium carbonate. A negative value indicates that the water is undersaturated (or has an excess of free carbon dioxide) and will tend to dissolve existing deposits of calcium carbonate.

The Langlier's saturation index is not quantitative but shows only the directional tendency. Hence other indices of evaluating the scale forming or dissolving properties of water have been developed.

An index was proposed by Ryznar, using the empirical expression $2 \text{ pH} - \text{pH}$, which is known as Ryznar Stability Index (a difference) from the saturation index. Values of the stability index greater than about 7.0 indicate a corrosive water, while values less than 7.0 indicate a scale-forming water. This index is of particular interest in evaluating waters of widely different composition.

A major drawback of the use of inhibitors is the O₂ and H₂ consumption of about 0.001 mol electrons/g of O₂ ions to prevent a normal temperature of 100°C for every 1000 mg degree of protection. The protective action is destroyed by traces of Cu²⁺, Fe²⁺, Fe³⁺, Zn²⁺, Mg²⁺, chlorides and sulphates. The best inhibitor is sulphite ions in the absence of dissolved oxygen.

Excessive residual chlorine may increase the rate of corrosion in water. High sulphur content will tend to increase the rate of corrosion while chlorides will remain constant. Sea waters are generally more corrosive than fresh waters.

Carbon dioxide, acidity or mineral acidity will increase corrosion. A major difficulty are protective coatings. High pH will increase corrosion, but very high pH levels may be destructive to polymers, or other protective coatings thereby actually increasing the corrosion.

(d) Inhibitors

An inhibitor is a chemical which when added to the system under examination will effectively decrease the corrosion rate. It can be made up of the opposite of a catalyst or catalyst or stops the corrosion reaction. Inhibitors can be inorganic or organic in nature. Most of the organic inhibitors are inorganic in nature, but some are organic. Inorganic inhibitors control corrosion by forming a film on the metal. The rate of corrosion is not reversed. Under all conditions, for example, by improper use, it is possible to increase the rate of corrosion rather than inhibiting. If hydrogen peroxide is present, the addition of any amount of any other oxidizing agent will cause discolouration and thus increase the flow of corrosion current. Again if insufficient metal inhibitor is used to provide a complete film over the metal, the small area left exposed will corrode with increased frequency, thus causing pitting. Sodium chromate is a very good inhibitor, a mixture of chromate and borate is a good inhibitor with other inorganic inhibitors such as phosphate is a good inhibitor. Sodium borate with sodium nitrate is a good inhibitor for iron.

Organic inhibitors may act in a variety of ways. Organic solids form protective layers by adsorption. Organic bases form protective coatings in highly soluble forms. These positive cations attach themselves through nitrogen to the cathodic surface. Their effectiveness as inhibitors depend on the size of the hydrocarbon. A few parts per million of tertiary amine gives almost complete protection. High molecular weight amines, derived from trimethylamine are good inhibitors. The protective action of the inhibitors increases with temperature.

Vapour phase inhibitors (VPI) vaporize readily and form an inhibiting (or) protective layer. These inhibitors are used to protect steel in use in presence of humidity and SO₂. Internal parts may be wrapped in papers impregnated with VPI instead of oily layers of grease or oil as most protective substances. Diethyl-dimethylamine carbonate and ethyl-diethylamine carbonate are used as good VPI.

Some of these inhibitors may not be suitable for community water supply unless they are proved to be harmless for consumption. But they are suitable for industrial water systems.

(c) Methods

(i) Deposition of Protective Coatings

A thin film of calcium carbonate can be deposited by the water on the inner surface of pipes by adjusting pH and alkalinity of the water to keep the Langelier Saturation Index 'I' to a slightly positive value. Lime or soda ash or both can be used to raise pH and alkalinity.

Small amount of sodium silicate can deposit dense, adherent but slightly permeable film. A dose of 12 to 16 mg/l is maintained in the beginning and gradually reduced to 3 to 4 mg/l. Organic coatings such as enamels, tar or bituminous coating are effective only to the extent of their coverage and durability. Epoxy coatings hold promise but their toxic effects due to leaching are not fully established. For cast iron and steel pipes, cement lining of the interior surface is satisfactory. Insertion of plastic pipe into an existing partly corroded pipe is also useful. For controlling corrosion of reinforcing steel and preventing disintegration of concrete in RC dome covers of overhead tanks, the concrete cover of such domes may be adequately protected (IS No. 456 - 1978). Protective coating to reinforcement is also suggested.

Some polyphosphates are reported to inhibit corrosion by forming protective films on the cathodic area. They also function as inhibitors for precipitation of calcium, magnesium and iron. Red water problem has been minimized in certain cases because oxidation and precipitation of iron is prevented. Sodium hexametaphosphate (Calgon) is the most widely used polyphosphate. The effectiveness of polyphosphates is progressively greater at increasing turbulent velocities and at increasing concentrations. The initial dose may be as high as 6 to 12 mg/l and then reduced to 1 to 2 mg/l. This can prevent the formation of tough deposits and remove sharp projections from the existing rough films.

(ii) Treatment of Water

Treatment of water such as adjustment of pH, removal of carbon dioxide, increase in calcium or carbonate ion concentration or addition of inhibitors can overcome to a large extent the corrosive nature of water. Chemical treatment can be effective as only a supplement to other methods like protective coatings and is limited by the cost.

Iron bacteria problems in pipelines can be overcome by treating the well with concentrated bleaching powder solution dose of 50 mg/l (as chlorine) and a contact period of 6 hours. It is necessary to periodically flush out the dead ends so that stagnation for more than a month does not take place. After flushing, these dead ends have to be disinfected by chlorine. De-oxygenation & re-aeration of water is the essence of reducing corrosive nature of water and is accomplished by passing over heated scraps of iron or by deoxygenation under vacuum. These methods, however, are not practised in community water supply systems because of cost considerations but are eminently suitable for industrial water systems.

CHAPTER 10

DISTRIBUTION SYSTEM

10.1 GENERAL

The purpose of the distribution system is to convey wholesome water to the consumer at adequate residual pressure in sufficient quantity at convenient points. Water distribution usually accounts for 40 to 70% of the capital cost of the water supply project. As such, proper design and layout of the system is of great importance. Metering is recommended for all cities as indicated in section 17.4.2.

10.2 BASIC REQUIREMENTS

The requirements for the distribution system may be classified as functional and hydraulic. The geometrical configuration of pipes, reservoirs and boosters, selection and proper location of valves, specials, etc., for efficient operation and maintenance and overall economy in cost constitute some of the functional aspects. Adequate residual pressure at the maximum demand depends upon the hydraulic characteristics of the system.

10.2.1 CONTINUOUS VERSUS INTERMITTENT SYSTEM OF SUPPLY

In the continuous system of supply, water is made available to consumer all the twenty-four hours a day, whereas in the intermittent system, the consumer gets supply only for certain fixed hours (a few hours in the morning and a few hours in the evening).

The intermittent system suffers from several disadvantages. The distribution system is usually designed as a continuous system but often operated as an intermittent one. There is always a constant doubt about the supply in the minds of the consumers. This leads to limited use of water supplied, which does not promote personal hygiene. The water is stored during non-supply hours in all sorts of vessels which might contaminate it and once the supply is resumed, this water is wasted and fresh supply stored. During non supply hours, polluted water might reach the water mains through leaky joints and thus could pollute the protected water. There will be difficulty in finding sufficient water for fire fighting purposes also during these hours. The taps are always kept open in such system leading to wastage when supply is resumed. This system does not promote hygiene and hence, wherever possible, intermittent supply should be discouraged.

10.2.2 SYSTEM PATTERN

For efficient and equitable distribution of water, a grid pattern, where the different mains are interconnected keeping dead ends to a minimum, is recommended. The system facilitates

any one point being fed in least from two different directions. In a small water supplies, the tree or branch system with smaller mains branching off from a single trunk main may be adequate.

10.2.3 ZONING

Zoning in the distribution system entails the separation of supply of water throughout the area. The zoning depends upon (a) density of population (b) type of locality (c) topography and (d) facility for isolating for assessment of waste and leak detection. If there is an average elevation difference of 15 to 25m between zones, then each zone should be served by a separate system. The neighboring zones may be interconnected to provide emergency supplies. The valves between the zones, however, should normally be kept closed and not partially opened. The main should be such that the difference in pressure between different areas of the same zone or same system does not exceed 3 to 5 bar.

10.2.4 SYSTEM OF SUPPLY

In selecting a source of water supply for a town, the mode of conveyance of water from the source to the town is a factor for consideration. Water could be conveyed by gravity alone, or by pumping, or by gravity combined with pumping. Any of these three modes could be selected based mainly on the elevation of the source of supply with respect to the town. Effort should be made to minimize the cost of transmission by considering the various alternatives and their suitability for the given situation.

10.2.5 LOCATION OF SERVICE RESERVOIRS

The location of service reservoirs is of importance for regulation of pressures in the distribution system as well as for coping up with fluctuating demands. In a distribution system fed by a single reservoir, the ideal location is a central place in the distribution system, which affects minimum average run or pipe sizes. Where the system is fed by direct pumping as well as through reservoirs, the location of the reservoirs may be at the tail end of the system. If topography permits, ground level reservoir may be located, taking full advantage of difference in elevation. Even when the system is fed by a central reservoir, it may be desirable to have tail end reservoir for the distant districts. These tail end reservoirs may be fed by direct supply through continuous booster facilities may be provided.

10.3 GENERAL DESIGN GUIDELINES

10.3.1 PEAK FACTOR

The peak quantity of water supply is often only the average consumption of water per day per person over a period of time. In a well designed water supply distribution system, it is to be recognized that consumption varies with the seasons, month, day and hour. As far as the design of distribution system is concerned, it is the hourly variation in consumption that matters. The fluctuation in consumption is accounted for by considering the peak rate of consumption which is equal to average rate multiplied by a peak factor or rate of flow in the design of distribution system.

The variation in the demand will be more pronounced in the case of smaller population and will gradually even out with the increase in population. This is so because in a large population different habits and customs of several groups tend to minimize the variation in the demand pattern.

The following peak factors are recommended for various population figures:

For population less than 50,000	3.0
For a population range of 50,000 to 2,00,000	2.7
For population above 2,00,000	2.0
For Small Water Supply Schemes (Where supply is effected through standposts for only 6 hours)	5.0

10.3.2 FIRE DEMAND

Fire demand can be assessed as per the norms given in section 2.2.8.3. Reference can also be made to IS 5668:1987.

10.3.3 RESIDUAL PRESSURE

Distribution system should be designed for the following minimum residual pressures at service points:

Single storey building	⇒ 7 m
Two storey building	⇒ 12 m
Three storey building	⇒ 17 m

Distribution system should not ordinarily be designed for residual pressures exceeding 22 metres. Multistoreyed buildings needing higher pressure should be provided with boosters.

10.3.4 MINIMUM PIPE SIZES

Minimum Pipe sizes of 100 mm for towns having population upto 50,000 and 150 mm for those above 50,000 are recommended. For dead ends, less than 100 mm can be considered. If it is a goal, less than 100 mm can be used in situations where no further expansion is contemplated.

10.3.5 LAYOUT

The distribution layout should be such as to facilitate hydraulic isolation of sections, metering for assessment and control of leakage and wastage.

10.3.6 ELEVATION OF RESERVOIR

The elevation of the service reservoir should be such as to maintain the minimum residual pressure in the distribution system consistent with its cost effectiveness. The hydraulic gradient in the pipe should normally be between 1 and 1.5 m thousand at peak flow.

A suitable combination of pipe sizes and staging height has to be determined for optimization of the system. The staging height of service reservoirs is normally kept as 15-20m.

10.3.7 BOOSTING

For distant localities, boosters may be provided instead of increasing the size of mains or height of the reservoir unduly for maintaining the required pressure.

10.3.8 LOCATION OF MAINS

For roads wider than 25 meters, the distribution pipes should be provided on both sides of the road, by running side mains parallel & linked with trunk mains.

10.3.9 VALVES

(a) Sluice Valves

Sluice valves shall be located on at least three sides of every cross-junction and at every kilometre on long mains. The size of the sluice valve shall be the same as the size of the main up to 300 mm diameter and at least two thirds the size of main for larger diameters.

(b) Air Valves

These have been discussed in 6.16.3.

(c) Scour or Blow Off Valves

The scour or blow off valves have been discussed in 6.16.2.

(d) Flow Dividing Valves

These specially devised and constructed valves are used in distribution and other mains at the branch point to ensure that the supply flow in a distribution main is always maintained. These are based on the principle that the diaphragm or the other arrangement in valves opens proportionally depending upon the upstream pressure allowing the regulation of flow, irrespective of the pressure conditions obtained in the distribution main.

(e) Maximum Demand Controllers

The maximum demand controller permits all flows upto a preset value and automatically assumes control when the flow just exceeds this predetermined rate, thus preventing excess withdrawals. This form of controller finds considerable use both in municipal and industrial installations, where two or more users taking water from a common source, are to be prevented from consuming more than a set quantity.

10.4 SERVICE RESERVOIRS

10.4.1 FUNCTION

The service reservoirs provide a suitable reserve of treated water with minimum interruptions of supply due to failure of mains, pumps etc. They also enable meeting the widely fluctuating demands when the supply is by intermittent pumping. They are also helpful in reducing the size of the mains which would otherwise be necessary to meet the

peak rates of demand. They can serve as an alternative to partial duplication of an existing feeder main as the load on the main increases.

10.4.2 CAPACITY

The capacity of the service reservoir to be provided depends upon the better economic alternatives amongst various options. A system supplied by pumps with 100% standby will require less storage capacity than that with less standby provision. Similarly a system divided into interconnected zones will require less storage capacity for all the zones except for the zones at higher elevations.

However, the minimum storage or balancing capacity depends on the hours and rate of pumping in a day, the probable variation of demand or consumption over a day, the hours of supply can be calculated from a mass diagram or by a demand and pumping budget. The variation of demand in a day for a town which depends on the supply hours may have to be assumed or known from similar towns or determined based on household survey.

Typical example of estimation of storage capacity is given in Appendix D.1.

10.4.3 STRUCTURE

The ground level reservoir is generally preferred as storage reservoir which is circular or square or rectangular in shape. If it is circular, it is usually constructed of RCC and in the case of other shapes it is constructed either of RCC or masonry. The elevated reservoirs are used principally as distributing reservoirs and can have shapes like circular, square, rectangular and conical or may be of lattice type. They are generally made of RCC or prestressed concrete. Small capacity tanks can be fabricated with steel or PVC or HDPE. Circular shapes are generally preferable as the length of the wall for a given capacity is a minimum and further the wall itself is self supporting and does not require counterfort. Reservoirs of one compartment are generally square and the section of three compartments may be rectangular with length equal to two times half of the breadth. The economical water depth for reservoirs with flat bottom up to 100 m³ capacity is between 3 and 5 dm. The service reservoirs should be covered or avoid contamination and prevent algal growth. Suitable provision should be made for manholes, mosquito proof ventilator, access ladders, scour and overflow arrangements, water level indicator, and if found necessary, lightning arresters.

10.4.4 INLETS AND OUTLETS

The draw pipe should be placed 15 centimeters above the floor and is usually provided with a strainer of perforated cast iron. The reservoirs filled by gravity are provided with ball valves or the equilibrium or other type which close when water reaches full tank level. The overflow and scour main should be of sufficient size to take away by gravity the maximum flow that can be delivered through the reservoir. The outlet of the scour and overflow mains should be protected against the entry of vermin and other sources of contamination. The inlet or outlet of reservoir should be such that no water stagnates. When there are two or more compartments, each compartment should have separate inlet and outlet arrangements, while the scour and overflow from each compartment may be connected to a

and used to avoid the use of multiple students in the same formation experiment. In contrast to the traditional formation experiment, the procedure advanced by proceeding in different formations during the course of the experiment allows the full use of the different stages of action and product of the reaction.

105 BALANCING RESOURCES

The main objective of this activity is the use of balancing resources in a laboratory to the search for the identification of the chemical reaction of copper sulfate and sodium hydroxide. In order to identify the reaction, a series of experiments will be carried out through the use of qualitative methods. The series of experiments will supply the information and help to identify the chemical reaction that is being investigated as well as the reaction equation.

When the solution of each substance is prepared by the milligram scale, it is used to carry out the search for the identification of the chemical reaction. The reaction is carried out by the use of the reaction mixture in the laboratory. When the reaction is carried out, the desired chemical reaction is carried out. The reaction is carried out by the use of the reaction mixture. The reaction is carried out by the use of the reaction mixture. The reaction is carried out by the use of the reaction mixture. The reaction is carried out by the use of the reaction mixture.

106 HYDRATION OF METALS AND METAL OXIDES

106.1 PRINCIPLES

Hydration of metals and metal oxides is the process of the addition of water molecules to the metal or metal oxide. The process of hydration of metals and metal oxides is carried out by the use of the reaction mixture. The reaction is carried out by the use of the reaction mixture. The reaction is carried out by the use of the reaction mixture.

The reaction of hydration of metals and metal oxides is carried out by the use of the reaction mixture. The reaction is carried out by the use of the reaction mixture. The reaction is carried out by the use of the reaction mixture. The reaction is carried out by the use of the reaction mixture. The reaction is carried out by the use of the reaction mixture.

The reaction of hydration of metals and metal oxides is carried out by the use of the reaction mixture. The reaction is carried out by the use of the reaction mixture. The reaction is carried out by the use of the reaction mixture. The reaction is carried out by the use of the reaction mixture. The reaction is carried out by the use of the reaction mixture. The reaction is carried out by the use of the reaction mixture. The reaction is carried out by the use of the reaction mixture. The reaction is carried out by the use of the reaction mixture. The reaction is carried out by the use of the reaction mixture. The reaction is carried out by the use of the reaction mixture.

(1) The reaction of hydration of metals and metal oxides is carried out by the use of the reaction mixture.

(2) The reaction of hydration of metals and metal oxides is carried out by the use of the reaction mixture.

The reaction of hydration of metals and metal oxides is carried out by the use of the reaction mixture. The reaction is carried out by the use of the reaction mixture. The reaction is carried out by the use of the reaction mixture. The reaction is carried out by the use of the reaction mixture. The reaction is carried out by the use of the reaction mixture. The reaction is carried out by the use of the reaction mixture. The reaction is carried out by the use of the reaction mixture. The reaction is carried out by the use of the reaction mixture. The reaction is carried out by the use of the reaction mixture. The reaction is carried out by the use of the reaction mixture.

to digital category. These methods have virtually replaced other earlier ones largely on account of their accuracy and efficiency. The Hardy Cross method is a relaxation technique, which, through successive iterations, applies a series of linearly approximated correction to either assumed flows or head losses of all the pipes of the network.

10.6.2 METHODS OF BALANCING

(a) Hardy Cross Method

(i) Balancing Heads

In this method, from the knowledge of system inflows and outflows, the flows in all the pipes of the network are distributed so as to meet continuity constraints at all the nodes. When inflows and outflows are explicitly known, this will involve assigning as many flows as there are primary loops in the system. The requirement that the sum of head losses around all primary loops should equal zero gives rise to a system of as many equations. Solution of the exactly determined system of non-linear equations is effected by a systematic relaxation in the Hardy-Cross method. In the Hardy Cross method of balancing heads, which is a trial and error process, the correction factor for assumed flows (necessary formulae are made algebraically consistent by arbitrarily assigning positive signs to clockwise flows and associated head losses and negative signs to anti-clockwise flows and associated head losses) ΔQ in a circuit is calculated by the formula:

$$\Delta Q = \frac{\sum H}{n \cdot \sum H/Q}$$

Where Q = Quantity of flow

H = Head loss

n = Constant, 1.85 for Hazen William's formula

The assumed flows are corrected accordingly and the procedure repeated until the required degree of precision is reached. This is essentially a repetitive procedure. The sequential steps are presented below:

- (i) Assume suitable values of flow Q in each pipeline such that the flows coming into each junction of the loop are equal to flows leaving the junction,
- (ii) Assign positive sign to all clockwise flows and negative sign to all anti-clockwise flow,
- (iii) Compute the head loss H in each pipe by use of the friction formula with the help of chart or monogram giving the same sign as for the flows,
- (iv) Compute $\sum H$ (i.e. algebraic sum of the head losses) around each loop and if this is nearly equal to zero in all loops (within allowable limits of ± 0.15 m), the assumed flows are correct,
- (v) Otherwise, if $\sum H$ is not equal to 0 for any loop, compute the error in flow

$$\Delta Q = -0.54 \frac{\sum H}{\sum \frac{H}{Q}}$$

and the correction factor is of the opposite sign. Add the correction factor to the assumed flows with due regard to the sign of flows.

- (vi) Pipes operating in more than one circuit draw corrections from each circuit. However, the second correction is of the opposite sign as applied to the first circuit,
- (vii) Repeat the cycle, till $\sum H$ (around each loop) is nearly equal to zero within the allowable limits. Then the final values of flows are the actual values in the pipelines,
- (viii) If during the correction process, the head difference in an element becomes zero, the pipe should be omitted from the particular balancing operation in which this occurs.

A computer program for solution of the head balance problem could be written.

In setting up the program, the following guidelines will be helpful.

- (i) Each primary loop is first numbered, (i) serially starting from 1 ($i = 1, 2, \dots, N$),
- (ii) The pipes in each loop are then numbered, (i,j) with the loop number first and pipe number second, serially starting from (i, 1) ($j = 1, 2, \dots, N_p$),
- (iii) Flows in the clockwise direction in the pipe of any loop is considered positive, anti-clockwise negative. This applies to correction ΔQ_i also. The sign of head loss $H_{i,j}$ is the same as that of $Q_{i,j}$. The ratio H/Q or Q/H is thus always positive,
- (iv) Successive corrections to flows (ΔQ_i) are calculated from Equation

$$\Delta Q_i = - \frac{\sum_{j=1}^n H_{i,j}}{n \sum_{j=1}^n \frac{H_{i,j}}{Q_{i,j}}} \quad (10.1)$$

Here n is the exponent of Q in the simplified pipe flow formula $H_{i,j} = K_{i,j} Q_{i,j}^n$. These corrections are applied to $Q_{i,j}$ by the computer and the balancing operation repeated until a desired tolerance for either ΔQ_i or $|\sum H_i|$ is obtained, at which the program terminates. Specification on this criterion is a nontrivial problem reflecting the desired accuracy.

- (v) Pipes common to two loops i and k receive flow corrections from both with due regard to signs. When the pipe is being considered in loop i , corrected $Q_{i,j} = (Q_{i,j} + \Delta Q_i - \Delta Q_k)$ whereas when being considered under loop k as pipe (k,j), corrected $Q_{k,j} = (Q_{k,j} + \Delta Q_k - \Delta Q_i)$.

In case of smaller networks, the calculations could be made manually as well.

A typical problem of balancing head loss by correcting assumed flows by hand computation is presented in Appendix 10.3.

(ii) Balancing Flows

When using the method of balancing flows at junctions or nodes of the system, pressures at nodes are assumed on the basis of given pressure surface elevations at some nodes (e.g. fixed elevation reservoirs) and the flows in the pipes are estimated.

In the 'method of balancing flows' (modification of original Hardy Cross Method), which is applicable to junctions and nodes, the flows at each junction are made to balance for the assumed heads at the junctions and the corresponding head losses in the pipes. The correction factor for assumed head losses in the pipes (H) is calculated using the formula :

$$\Delta H = +1.85 \frac{\sum Q}{\sum \left(\frac{Q}{H} \right)}$$

The steps in the computation are as under :

- (i) Assume heads at all the free junctions such that the sum of the head losses in clockwise direction equals the sum of the head losses in the anti-clockwise direction in all the loops,
- (ii) Assign positive sign to head losses for flows towards the junction and negative sign to those away from the junction,
- (iii) Compute the flows in each pipe by use of the friction formula with the help of chart or monogram giving same signs as for the head losses,
- (iv) Compute ΔQ (i.e. algebraic sum of the flows) at each free junction and if this is nearly equal to zero at all junctions (within allowable limits of $\pm 2\%$), the assumed head losses are correct,
- (v) Otherwise, if $\sum Q$ is not equal to zero at any junction, compute the error in head loss

$$\Delta H = -1.85 \frac{\sum Q}{\sum \frac{Q}{H}}$$

The correction factor is of the opposite sign. Add the correction factor to the assumed head losses with due regard to the sign of head losses,

- (vi) Pipes common to more than one loop receive corrections from each loop. However, corrections to the companion circuit is of the opposite sign to that of the first circuit,
- (vii) Repeat the cycle till $\sum Q \approx 0$ at each node or junction when the final corrected values of H are obtained.

Although the Hardy Cross Method is rational and mathematically correct, drastic skeletonising of the network because of the complexity, the time consuming nature and the tedium of calculations, particularly for the large size networks and the uncertainty of convergence of values impose serious limitations on this method.

In setting up a computer program, the following guidelines will be helpful:

- (i) Each junction of the system is numbered serially, starting from 1, except those with an unknown inflow or take off, where usually a fixed water elevation is specified ($i = 1, 2, \dots, N$)
- (ii) All pipes joining node i are numbered (i, j) , denoting the pipe number at junction i ($j = 1, 2, \dots, N_{pi}$)
- (iii) Heads and flows towards the node are considered positive; away from it, negative. The same applies to correction ΔH_i also. H/Q and Q/H are always positive
- (iv) At each node, i , a test of $\sum Q_i$ is then made to see whether it is zero. If not, the head correction ΔH_i to be applied to all the head losses $H_{i,j}$ in pipes (i, j) meeting at junction i is calculated from equation

$$\Delta H_{i,j} = \frac{\sum_{j=1}^n Q_{ij}}{\sum_{j=1}^n \frac{Q_{ij}}{H_{ij}}} \quad (10.2)$$

and applied. The process is repeated until either

$$\text{Max}_i |\Delta H_i| \text{ or } \text{Max}_i \left| \sum_j Q_{i,j} \right|$$

is less than the prescribed limit.

- (v) Pipes common to more than one junction receive ΔH correction from both with due regard to signs, as stated before.

It is pointed out here that any network balancing problem can be solved by either of the two methods-head or flow balance. Where there are two or more reservoirs with fixed water elevations in the system, synthetic or artificial loops can be introduced between them to introduce exactly as many additional equations as necessary to make the system exactly determined. Although, the Hardy-Cross method can be used to solve network problems to any desired degree of accuracy, it is highly time-consuming for large and complicated networks. More powerful rapidly converging methods are now available.

(b) Newton-Raphson Method : Balancing Heads

Network balancing using Newton-Raphson method is again an iterative process but the method seems to be faster and convergence much more rapid from a reasonably good start. The principle of this method is explained most simply by reference to solution of a single equation $f(p) = 0$. According to Newton's rule, if p is an approximation to a root of $f(p)$, then $(p + \Delta p)$ is a better approximation where,

$$\Delta p = -\frac{f(p)}{f'(p)} \quad (10.3)$$

The nature of this result can be recognized from the Taylor series expansion of $f(p + \Delta p)$, viz.

$$f(p + \Delta p) = f(p) + (\Delta p) \cdot f'(p) + \frac{(\Delta p)^2}{2!} f''(p) + \dots + \quad (10.4)$$

terms involving higher powers of (Δp) .

$f(p + \Delta p)$ is equal to zero if $(p + \Delta p)$ is in reality a solution to $f(p) = 0$. If, in the above equation, the terms involving powers of Δp higher than the first are neglected, one obtains Newton's rule. The method can be extended to the solution of n simultaneous equations with n variables.

In setting up a water distribution network for balancing heads by Newton-Raphson method on the computer, it is useful to note the following steps and observations; Flows in the pipes are assumed so as to meet all the continuity constraints. The flows in all pipes of loop i are assumed to be in error by ΔQ_i , correction from both loops, the one coming from the loop under consideration being algebraically added, the other being algebraically deducted.

Equations to balance head losses around loops are then framed in terms of corrected flows.

In general, the arranged loop head loss equations take the following form:

$$\left(\sum_j \frac{H}{Q} \right)_i \Delta Q_i + \sum \left[-\left(\frac{H}{Q} \right)_{i,j} Q_k \right] = -\frac{(\sum H)_i}{n} \quad (10.5)$$

Where the second summation on the L.H.S extends only for the common pipes of loop i . The number of equations in the system is the same as the number of primary loops in the system. For the i^{th} loop on the L.H.S $\left(\sum_j \frac{H}{Q} \right)_i$ for all pipes of the loop forms the coefficient of ΔQ_i , the correction for all pipes of the loop. The other non-zero terms are of the form $\left[-\left(\frac{H}{Q} \right)_{i,j} \Delta Q_k \right]$, where ΔQ_k is the correction for loop k which has a pipe in common with loop i . The common pipe is called (i,j) in loop i , and by some other name like (k,l) in loop k . If loop t has no pipe in common with loop i , the coefficient of ΔQ_t in the equation for loop i , will be zero. On the R.H.S of the equation, we have the unbalanced head in loop i with a negative sign, multiplied by the inverse of exponent n in the pipe flow formula chosen.

A general Fortran Program for network head balance according to Newton-Raphson Method could be written to compute H_{ij} from input Q_{ij} values and set up the coefficient matrix A for solution for ' ΔQ 's. The set of linear simultaneous equations could be solved by calling appropriate library subroutines. The computed ΔQ are applied to all pipes of the network as explained under Hardy Cross method giving due consideration to common pipes between loops and the iteration proceeds. The program terminates at the allowable head tolerance or when iterations exceed a certain prescribed limit.

The success of the Newton-Raphson technique lies in the selection of a good starting approximation. If the approximation is poor, it can result in the divergence of the solution. Computer programmes are readily available for the Newton-Raphson technique.

(c) Linear Graph Theory

The analysis of water distribution network requires that the node and loop continuity equations be satisfied. Linear graph theoretic approach differs from other methods in a fundamental way. While in other methods, it is customary to change the value of either the assumed flow or head loss using one set of continuity equations and satisfying the other set as constraints, this method depends on the simultaneous utilisation of both sets of equations (node equations and loop equations).

In the graph theory approach, the water supply distribution pipe network is treated as a linear graph (consisting of points or vertices and lines or edges). By the properties of graph theory and matrices, the system equations involving the three physical laws of fluid flow, i.e., Kirchoff node law, Kirchoff loop law and pipe flow formula are combined to form a single set of non-linear equations involving one set of variables i.e., either head loss variables or flow variables. These non-linear equations are then solved by iterative methods. After one set of variables are obtained, the other set of variables are calculated from the pipe flow formula.

In this approach, by dividing the variables as primary and secondary variables according to 'tree' and 'co-tree' pipes, the decision variables are confined to only the primary variables. The application of the Graph theory helps considerably in formulating the hydraulic equation and also in deriving a good starting approximation to ensure fast convergence.

(d) Linear Theory Method

This method, proposed by Wood and Charles is useful for network balancing through "balancing heads by correcting assumed flows". This is also an iterative method, said to converge faster than the Hardy Cross method.

In the methods of balancing described earlier, it is necessary to assume certain values for the variables to start the iterative procedure. Naturally, therefore, the number of iterations depend upon the initial guess. No such initialization is needed in the linear theory method.

The linear theory transforms the loop head loss non-linear relationships into linear relationships by approximating the head loss in each pipe by

$$h_p = (rQ^n)_p = (rQ^{n-1})_p Q_p = (r'Q)_p \quad (10.6)$$

in which Q_p is the assumed flow in pipe p . Thus the pipe resistance constant r_p is replaced by $(r')_p$ so that, $(r')_p = (rQ_p^{n-1})_p$

All the nonlinear loop head loss relationships become linear. These linear equations and the node flow continuity linear equations are solved simultaneously to obtain all Q_p values. The solution, however, will not be correct as the obtained Q_p values will not be the same as assumed Q_p values. However, it is claimed that by repeating the process several times, the obtained and the assumed values will be found to be identical, thus giving the correct solution.

In the linear theory, for the first iteration, all the Q_p values are taken as i giving $(r')_p = r_p$. (This amounts to assuming the flow to be laminar for the first iteration). It will be observed that this method, if used just as suggested earlier, yields pipe flows which tend to oscillate about the final solution. To obviate this, Wood and Charles have suggested that after two iterative solutions, for all the iterations thereafter, the initial flow rates to be used in the computations should be the average of the flow rates obtained from the past two iterations. Thus, for the i^{th} iteration,

$$Q_p = \frac{(i-1)Q_p + (i-2)Q_p}{2} \quad (10.7)$$

in which the subscript $i, i-1$ and $i-2$ denote the $i^{\text{th}}, (i-1)^{\text{th}}$, and $(i-2)^{\text{th}}$ iterations respectively.

(e) Use Of Models For Analysis

A model must truly represent the system under consideration so that the pressure drops and discharges can be measured directly without trial and error procedures. The variables like head loss, flow and head loss coefficients in a pipe, as also circuits, junctions, and friction laws that govern the system should be properly represented in the analogous model devices. Two kinds of models, namely hydraulic models and electric analogue models have been used. The hydraulic models however have not proved very popular.

(f) Electric Analogue Model

In the direct electrical analogue mode which is used for pipe network analysis, the analogies existing between hydraulic and electric systems are considered. The use of non-linear resistors in electrical systems has made possible the representative simulation of the hydraulic system.

The source of supply in the hydraulic system is represented in the electrical analogue by a constant voltage generator or battery, take-offs by load resistors or electronically controlled devices and pipes by non-linear resistors. Camp and Hazen built the first electric analyzer designed specifically for the hydraulic analysis of water distribution systems. McIlroy continued this approach to network analysis and developed an analyzer that is manufactured commercially. For each branch of the system, the pipe equation, $H = KQ^n$ is thus replaced by an electrical equation, $V = K_e I^n$, where V is the voltage drop in the branch, I is the current and K_e is the non-linear resistor coefficient whose value is suited to the pipe coefficient 'K' for the selected voltage-head loss and the amperage-water flow scale ratios. If

the current inputs and take-offs are made proportional to the water flowing into and out of the system, the head loss will be proportional to the measured voltage drops.

The most important advantage of the direct electric pipeline network analyser is the physical feel of the network system experienced by the designer or operator. Once the pipe network is simulated in the electric network analyser, results can be obtained in a few minutes for alternative sizes of pipes or alternative flow conditions.

The analyzers give the pressure losses and flows in pipelines at an instant in time and the accuracy of the results depends only on the precision of physical elements and measuring instruments involved and the accuracy of the data introduced.

10.7 DESIGN OF PIPE NETWORKS

The problem of design of pipe networks essentially involves determination of pipe sizes which will meet the physical and operational requirements imposed on the network at minimum cost.

The constraints include the hydraulic laws and operational ones such as the minimum permissible sizes, restriction to commercially available sizes, and mainly, minimum residual pressure requirements at critical nodes. The total cost of the network is generally assumed to include the cost of the pipes, pumps and other components and the present value of the maintenance and operating costs. Several approaches have been suggested for handling this economic design problem over the years. Some significant attempts are summarized in the following sections.

10.7.1 APPROXIMATE METHODS

These methods are simple, approximate and are used as a quick check for an existing system or for obtaining preliminary pipe sizes for a new network before subjecting it to detailed analysis. Such methods include method of sections in which the network is cut by imaginary section lines (chosen with regard to the critical points in the distribution system), for an assumed hydraulic gradient (usually 1 to 3 per 1000) and velocity (0.6 to 1.2 mps). The capacity of the pipeline cut by the lines are matched with the actual demand in the areas to be supplied. Any deficiency in the pipe sizes is rectified by the addition of an extra pipe or replacing by a larger size pipe and rechecking in a similar way.

10.7.2 EQUIVALENT PIPE METHOD

A network can be simplified considerably to obtain useful preliminary information on the flows and head losses at important junctions by this method, where a complex system of pipes is replaced by a single line of hydraulically equivalent capacity. The pipes of the sizes smaller than 150mm in the more elaborate systems as well as the connecting pipes with no appreciable pressure differential may be omitted to skeletonise the system to a workable one. The various combinations of pipes between selected junctions could be replaced by hydraulically equivalent pipes reducing the number of units to be analyzed.

In 1969, Teng, O'Connor, Steams and Lynch published an 'equivalent length method' of balancing hydraulic networks and indicated that an approximate solution to the problem of

economic pipe sizing can be simultaneously obtained therefrom. Using Hazen-William's formula for pipe flow, a new term L_e was introduced which was

$$L_e = l(100/c)^{1.85} (0.667/D)^{4.86} \quad (10.8)$$

Where L_e is the length of a pipe of standard diameter (8-in) and standard Hazen Williams C-Value of 100. This pipe is hydraulically equivalent to a pipe whose actual length l , diameter D and Hazen Williams coefficient is C . Instead of applying the Kirchoff's loop law to the sum of the head-losses $\sum H$ in the loops, the equivalent length method distributes the available head loss to the several pipes directly meeting the requirements $\Delta H = 0$, and attempts to balance the relative pipe resistances in the form of equivalent lengths, L_e in all the loops of the network i.e.

$$\sum L_e = 0 \text{ for all loops} \quad (10.9)$$

An iterative procedure similar to the Hardy Cross method has been used for balancing L_e in this study. Assumed flows in all the pipes of the network are successively adjusted to balance the relative pipe resistances. It is claimed that such a balance leads to a minimum possible total of all the equivalent lengths and thus to least amount of pipe in a network of equal-sized pipes. Also, the imposition of the above condition $\sum L_e = 0$, is reported to establish a general 'evenness' of flow throughout the system, and 'optimum' design for any set of fixed conditions of topography, pressure requirements, source of supply, draft and geometric pattern of distribution network. The elimination of the trial and error feature of the Hardy-Cross method was cited as an advantage of this algorithm.

In the search for better methods of water distribution system design, the balancing of equivalent lengths' technique would appear to have merit particularly in initial studies preliminary to a comprehensive systems analysis. However, in networks with multiple sources and pump-type boundary conditions, the flow pattern may not be so obvious and problems of convergence could arise.

10.7.3 PIPE NETWORK COST MINIMIZATION PROBLEMS

It can be shown that the problem of minimum-cost design of a distribution pipe network subject to

- (i) the provision of required domestic and fire flows at specified draw off junctions, and
- (ii) the maintenance of minimum residual pressure at critical junctions

can be cast as one of non-linear, integer programming. Such a model and an engineering approach to its solution are briefly discussed. More detailed exposition and reference to earlier works in the topic can also be found in literature.

10.7.3.1 Formulation Of The Objective Function

The principal part of the total cost function of a distribution pipe network is the cost of pipes. The installed first costs of pipes can be related to their diameter by an empirical, exponential function of the form:

$$C' = \alpha l D^\eta \quad (10.10)$$

Where C' is the cost, l is the length of pipe and D is the diameter, α and η are parameters to be determined locally. Then the total installed cost of all the pipes in the networks is

$$C = \sum_{\text{all } i,j} \alpha l_{i,j} D_{i,j}^\eta \quad (10.11)$$

Where the paired subscript (i,j) denotes the j^{th} pipes in loop i .

In addition to pipe cost, the cost of friction losses in the pipe network constitutes another important component of the total cost. In pumped systems, it represents the cost of energy required to overcome pipe friction. In gravity systems, the same is an indirect 'cost' on the system if we consider that higher pressures are desirable at the draw-off points. As such, the energy cost of pipe friction losses can be incorporated in the objective function for all supplies. Relating this cost to motive power prices (here assumed as electricity), the present value of costs associated with pipe friction losses in the system can be computed and incorporated in the objective function to be minimized. Such a total cost function is

$$C_T = \alpha \sum_{i,j} l_{i,j} D_{i,j}^\eta + P_v \frac{(P_w b E)}{\theta} \times \sum_{(i,j)} Q_{i,j} H_{i,j} \quad (10.12)$$

Where $Q_{i,j}$ and $H_{i,j}$ stand for the flow and head loss in pipe (i,j) P_v is the present value of an annuity of 1 Rupee discounted at rate r over the economic time horizon T ; w is the unit weight of water; b is a load building factor; E is the unit cost of electricity and θ is the wire-to-water efficiency of pumping.

10.7.3.2 Formulation Of The Constraints

The diameters, flows and head losses in the pipe network must meet certain constraints in the form of hydraulic flow formulae, Kirchoff laws for nodes and loops and certain operational constraints regarding minimum pipe sizes, commercially available pipe sizes and minimum permissible residual pressures. Such constraints can be represented by the following set;

$$(a) \quad H_{i,j} - \left[84.1 \frac{1}{1.85} l_{i,j} D_{i,j}^{-1.37} |Q_{i,j}|^{0.36} \right] \times Q_{i,j} = 0 \text{ for all pipes} \quad (10.13)$$

$$(b) \quad \sum_{i,j} Q_{i,j} + q_m = 0 \quad \text{for all nodes} \quad (10.14)$$

$$(c) \left[\sum_j H_{i,j} \right] + S_i = 0 \quad \text{for all loops} \quad (10.15)$$

$$(d) D_{ij} > D_{min} \quad \text{for all pipes}$$

$$(e) D_{ij} \sum (DA) = (D_1, \dots, D_n) \quad \text{for all pipes}$$

$$(f) [\sum H_{i,j}]_k < h_k \quad \text{over all specified paths (some } i, j)$$

$$(g) g(\text{relevant } q_m, S_i) = 0 \quad \text{for all pumps, if any.} \quad (10.16)$$

In the constraints set, (a) is a version of Hazen Williams formula for flow in pipes, (b) and (c) are Kirchoff's node and loop laws respectively, (d) assures that all pipes are not smaller than the prescribed minimum size D_{min} , (e) specifies that the sizes shall correspond to commercially available ones ($D_1, D_2, D_3, \dots, D_n$), (f) is the equivalent of maintaining minimum permissible residual pressures at draw off nodes, by requiring that along specified pathways in the network the sum of head losses shall not exceed preset magnitudes, and (g) guarantees that the inflow and pressure at pump nodes shall correspond to the specified characteristic curves of pumps. The quantities q_m , S_i , and h_k stand for inflow (or outflow) at node m , unbalanced head at loop i , and maximum pressure difference permissible over path k , respectively.

10.7.3.3 Analysis

This mathematical model for cost minimization of pipe networks assumes that the layout and lengths of pipes are known and, for the moment, that only one demand pattern is considered. The problem can now be recognized as one of non-linear, constrained minimization in numerous variables. The constraint set (e) restricts the domain of feasible diameters to a few specific values, thereby discretizing the objective function and the set of feasible diameters. In this analysis, it is assumed that P_v , b , E , e and C are known, non-negative parameters and l_{ij} , q_m , S_i , D_{min} , D and h_k are given input vectors. The three sets of variables D_{ij} , Q_{ij} and H_{ij} are treated as decision variables, i.e., the solution seeks that set of feasible D_{ij} , Q_{ij} and H_{ij} which minimizes the total cost of the pipe network. For this non-linear, integer programming problem, an iterative, sequential search procedure has been developed and the same is briefly outlined in the following subsections.

10.7.3.4 Constructing A Starting Solution

The most direct way of meeting constraint sets (d) and (e) is to choose diameters as the variables to be set for a trial, and derive other decision variables (Q and H) therefrom. Then, while selecting the diameters, only those feasible with respect to (d) and (e) may be chosen. Such diameter selection is a significant initial step which eliminates the round-off procedures

that would be otherwise required. The setting of such a diameter vector (D_{ij}) leaves the flows and head losses to be determined. Solving for Q_{ij} , and H_{ij} , with given D_{ij} from constraint sets (a), (b) and (c) is the familiar problem of hydraulic network balancing.

10.7.3.5 Constructing A Penalty Function

If the constraints system is now examined, the method of starting with a feasible diameter vector and balancing the network to obtain feasible flows and head losses has given rise to a solution feasible with respect to all constraints except set (f). The resulting head losses may either satisfy or fail to satisfy set (f), i.e. head losses summed over all specified paths may or may not be less than the permissible limits set. A rational approach to the treatment of these constraints is to weigh them and blend them into the objective function in such a form that the violation of these constraints will penalize the causative design while ranking alternative designs. Such is the penalty function approach. This penalty function can be related to the extent of violation of the (f) type constraints.

10.7.3.6 Sequential Random Search Procedure

Having established the model and formulated a function to rank alternative designs, a sequential random search should be conducted starting with a trial design (set of diameters) and improving it in successive iterations until a terminal design with very low probability of improvement results. The rationale of this method differs from that of classical optimization in that it does not attempt to identify the global optimum with complete certainty; rather, it provides a statistical estimator of the best design.

The technique can be summarized as follows:

- (i) Select a starting design from a specified population of starting designs
- (ii) Proceed sequentially from the starting design to an improved terminal design (T.D) according to a set of rules involving random sampling (sweetening)
- (iii) Repeat the above steps until several T.D's are obtained. This provides a sample of, say, n Terminal Designs
- (iv) Identify the least costly of the n Terminal Designs as the current estimator of the global optimum (we will call it the 'Optimal Design' hereafter). Such steps (i) to (iv) constitute a search.

The algorithm described is a practical, heuristic tool for a mathematically complex and computationally laborious problem.

A schematic flow chart for the sequential random search procedure is presented in Fig. 10. 1.

10.8 RURAL WATER SUPPLY DISTRIBUTION SYSTEM

The water supply in rural areas is effected by one of the following two methods.

- (i) Shallow well or deep bore well fitted with hand pump
- (ii) Piped water supply with or without house connection through overhead tank and standpipes located at strategic points within the community.




FIGURE 10.1 : SCHEMATIC CHART FOR STOCHASTIC SEARCH TECHNIQUE

The distribution system suitable for the situation is the dead end system of branched system. The system is economic, easy to design and operate. The elevation of the overhead tank is fixed by taking into consideration the residual pressure to be maintained at the farthest end of the distribution system and the length of the connecting pipe. When water is supplied only through stand posts, the tank is generally constructed with a staging height of 6 m for communities with population upto 1500 and with a staging height of 7.5 m for communities with population greater than 1500.

When house connections are also provided, the height of staging may be suitably increased to ensure minimum prescribed terminal pressure.

The distribution system for rural water supply scheme is designed for the peak demand, which is assumed to be four times the average demand (duration of supply is 6 hrs). Techniques are available for the optimization of rural water supply distribution system.

An optimization method is available for single branch dead end system using Lagrangian multiplier technique with an equality constraint on the pressure head in the system. The solution is obtained in the closed form.

A compound water main system consisting of pipes connected in series and with intermediate draw off at the end of each pipe has been subject to cost minimization, using the Lagrangian technique. The input data include water pressure at the inlet, the desired residual head at the extreme end of the pipe, the length of pipes, draw-offs at the end of each pipe and cost function parameters. The closed form analytical solution has been derived for the size of pipe in each leg of compound pipe.

10.9 HOUSE SERVICE CONNECTIONS

10.9.1 GENERAL

The supply from the street main to the individual buildings is made through a house service connection. This consists of two parts viz., the communication pipe which runs from the street main to the boundary of the premises and the service pipe which runs inside the premises. The communication pipe is usually laid and maintained by the local authority at the cost of the owner of the premises while the service pipe is usually laid by the consumer at his cost.

The service connection including the details of the internal plumbing system should conform generally to the National Building Code and particularly to the bye-laws of the concerned local authority. Extreme care should be bestowed for the design and construction of plumbing system. The rational design criteria evolved by CBRI for plumbing should be followed.

10.9.2 SYSTEM OF SUPPLY

The water supply in a building may be through one of the following or combinations of both depending upon the intensity of pressure obtained in the street main and the hours of supply.

- (a) Direct supply system, and

(b) Down-take supply system with or without sump and pump.

If the pressures near the premises are adequate to supply water for sufficient number of hours to the water fittings at the highest part of the building, then suitable connections may be allowed to deliver water directly. In cases, where the pressures in the street mains are not sufficient to deliver water supply directly, the down-take supply system with ground level storage and boosting is adopted. Direct supply system is recommended under one condition only when the number of floors in a building is not more than two.

In any case, only one connection is to be granted for the whole building to deliver the total domestic requirement of the day. If there is, however, a non-domestic requirement in the building, then a separate connection shall be given.

The supply in any case is controlled usually by a ferrule on the main, which is throttled sufficiently to deliver the required supply at the pressure contemplated. The supply is also controlled by a stop cock at the beginning of the service pipe. A meter is to be installed beyond the stop cock for measuring the flow. Any temporary disconnection of the supply is made by the stop cock and any permanent disconnection is made at the ferrule. The size of the ferrule should not exceed a quarter of the nominal diameter of the main and also be less than the size of the communication pipe. If a larger size of connection is required, branch with the required number of common service pipe can be used. Where the pipe has to cross a drain, a suitable sleeve pipe may be provided for prevention of cross connection.

10.9.3 DOWNTAKE SUPPLY SYSTEM

(a) General Criteria

In this system, the supply may be delivered directly to the overhead storage tank or to the ground level storage tank. Separate overhead tanks should be provided for flushing and other domestic purposes. The capacity of the overhead and ground level storage tanks are decided by the local bye-laws. Generally a capacity of 50% of the daily requirement is provided in the ground level storage tank. For overhead tanks directly receiving water from public mains, the capacity should take care of the total daily requirement, which could be reduced to 75% if the supply is pumped from the ground level tank.

The pumps shall be designed for peak rate at 3 times the average over 24 hours; or average rate of the 50% of the daily requirement over the actual hours of supply, whichever is greater. A standby pump set of equal capacity shall be provided.

(b) High Rise Buildings

(1) **Systems:** The down-take system of water supply in high rise buildings may be one or a combination of the following systems viz., overhead storage system, break pressure tank system and hydro-pneumatic system.

(i) Overhead Storage System

In this system, the tanks are provided on the terrace. A manifold down-take may be taken out from the storage tank which should be laid out horizontally in a loop on the terrace to carry a designed peak load demand. The pressure in the loop at peak demand shall not

become negative. Vertical down-takes, as many as necessary, may be taken out from the loop and should be linked to one down-take for a zone of 4 storeys at a time and designed for the peak demand it has to serve. A pressure-reducing valve shall be provided in the down-takes to limit the head to a maximum of 25m in easily accessible places like ducts, cat walks, etc.

(ii) Break Pressure Tank System

In this system, the entire building is to be conveniently divided into suitable zones of 5 to 8 storeys each. For each such zone, there shall be a break pressure tank, the capacity of which should be such that it holds 10 to 15 minutes supply of the floors it feeds below and shall be not less than 2KL each for flushing and other domestic purposes separately. The down-take from the master overhead tank feeds into the break pressure tank.

(iii) Hydropneumatic System

In this system, the supply is through a hydropneumatic pressure vessel fitted with accessories like non-return valves and pressure relief valves. Each zone of supply should be restricted to about 7 storeys or 20m, whichever is less. The capacity of the pump should be such as to cope up with the peak demand. Normally three pumps called the lead pump, the supplementary pump and the standby pump respectively, are provided. The last pump is preferably diesel driven to serve when there is a power failure. The hydropneumatic pressure vessel should be an air tight vessel, cylindrical in shape and fabricated from mild steel plates according to pressure tank fabrication code. The capacity should be equivalent to three minutes requirements. The air compressor is also necessary to feed air into vessel so as to maintain the required air-water ratio in the vessel. As soon as the demand exceeds the capacity of the lead pump, the supplementary pump must start automatically.

(c) Fire Storage

Multi-storeyed buildings above 25m height have to be provided fire storages in addition to domestic needs, adequate to fight a fire at the rate of 2250 lpm, as a normal fire fighting tanker cannot cope up with fires beyond an elevation of 25m. This limit, however, varies from place to place depending upon the normal height of ladder available with the local fire brigade service for extinguishing of fire.

The tank capacity for fire storage may be of 100 KL, where the supply is intermittent so that it is adequate to fight a fire in the premises at the rate of 2250 lpm for about 45 minutes by which time the replenishment from municipal mains would have commenced. The overflow from the fire fighting tank should flow into the suction tank to maintain a continuous circulation in the static fire tank and also maintain a reserve storage for fire fighting purposes.

The fire fighting pumps may be located in the basement to have a positive suction head and designed to deliver 2250 lpm with a terminal pressure of 3Kg/cm² at the topmost floor so as to obtain from the hydrant 900 lpm discharge with a jet of about 6 m.

On the fire fighting rising main, hydrant tees of 60mm may be provided at every landing of each stair case. A small 20mm tapping may be provided at each landing with a wheel valve and adequate length of hose pipe for fighting small fires due to electrical short circuiting etc.

The pump set is to be provided with a pressure vessel and automatic pressure switches which start operating when there is a pressure fall on the rising main due to the commissioning of any of the hydrant tees for fighting a fire.

To deal with cases when there is a power failure the high rise buildings should be provided with independent electrical circuits, one connected to the normal external power and the other to the diesel-run generating set in the buildings. This generating set should automatically come into operation in the event of external power failure or fire in the building. The independent electric circuit from the generating set should be for all pumps including fire pumps, emergency lights, lifts, and lights in stair cases and yards.

10.9.4 MATERIALS FOR HOUSE SERVICE CONNECTIONS

The various pipes used for service connections should conform to the relevant Indian Standards.

- (a) Normally G.I. pipes are used for service connections. They have the advantage of low cost and high strength. They suffer from the disadvantage of short life in corrosive soils especially at the screwed joints. Bituminous covering for the pipe increases its longevity. The carrying capacity of the pipe may also be reduced due to incrustation. Rigid PVC pipes as well as high density polyethylene pipes are also coming into use. These pipes are flexible and light and the carrying capacity is not reduced with age due to incrustation. They, however, are liable to be damaged easily. They also soften at temperatures above 65°C and as such cannot be used for hot water systems.
- (b) The communication pipe is attached to ferrules or saddles depending on the material of the distribution main in the street. Gun Metal or bronze ferrules are screwed into C.I. mains while special screwed saddles are fixed on cement asbestos and PVC pipes.
- (c) Since the minimum residual pressures in an area are to be maintained as indicated in 1.2.8.3, ferrules of suitable sizes are to be provided for adjacent buildings of different heights to get equitable supply.
- (d) Usually 12.5 or 18.75 mm rotary water meters are fixed on the service pipe immediately after the stop cock in the consumers premises and located in a masonry pit.

10.10 PREVENTIVE MAINTENANCE

10.10.1 GENERAL

Preventive maintenance of water distribution system pipelines assures the twin objectives of preserving the hygienic quality of water in the distribution mains and providing conditions for adequate flow through the pipelines. Some of the main functions in the management of preventive aspects in the maintenance of mains are assessment, detection and prevention of wastage of water from pipelines, maintaining the capacity of pipeline and cleaning of pipelines.

10.10.2 WASTE ASSESSMENT AND DETECTION

Wastage is due to leakage in water mains due to corrosion, fracture, faulty joints, ferrule connection, service pipes and fittings inside the consumer's premises due to joints, corrosion, faulty washers on glands in valves and taps; abandoned service pipes and ferrule connections in mains; and failure to turn off taps in premises willfully or inadvertently. Another important source of waste noticed in intermittent systems, particularly where metering is not enforced, is the tendency of the householder to keep the taps open throughout and also emptying stored water to replace by a batch of fresh water. Wastage is due to leakage from reservoirs and treatment plant which cannot be accounted for by the normal metering and can be as high as 40%. Pilot studies in a few cities in the country reveal that wastage in the mains alone can be 15 to 25%.

A systematic waste and leakage survey and detection, followed by prompt corrective action is of importance in bringing about a reduction in the wastage. The frequency and extent of the survey depends on the cost and the net benefits accruing therefrom.

(a) Assessment Of Waste

In residential areas where 24-hour supply is effected, it is possible to assess the total wastage occurring both in the water mains and the consumer's premises when the consumption is at a minimum which is likely to occur at midnight. The difference between the minimum night flow in the system and the accountable flow at midnight divided by the average daily flow at mid-night can provide the percentage of waste in an area. Levels of wastage upto 10% may be considered as low, 10 to 20% as average, 20 to 50% as excessive and over 50% as alarming. Remedial measures are called for, for levels above 10%.

In intermittent supplies, only leakages related to water mains are assessed. Waste in mains in such cases is assessed in a zone by closing all the taps or stop cocks in the house service connections. The percentage of wastage in intermittent supplies is the ratio of the flow in the mains (with stop cocks or tap closed) to the average daily domestic consumption.

Losses at about 5 to 7% may be considered as satisfactory while 10 and 20% as unsatisfactory and action is advisable, and beyond 20% level, remedial measures are positively indicated.

For any component of a water supply, the information on population, average daily flow, consumption by industry or trade, minimum night flow (in case of continuous supply) or flow in mains with all stop cocks or taps closed in intermittent supply, and transfer of flow from one zone to the other is required for estimation of the waste.

(b) Waste Survey Procedure

The approach of the problem requires careful planning and preparatory work and a large amount of routine field survey and investigations. Waste survey consists of the following steps:

1. Preparatory Work

It consists of:

- (i) Delineation of zones and sub-zones of distribution network from field inspection and plans
- (ii) Collection of statistics of population, houses, connections (metered and non-metered) of the selected zones
- (iii) Location inspection, testing and repairing of valves, fittings, taps and meters
- (iv) Correct alignment of pipelines by electronic pipeline locator and by inference
- (v) Checking and updating of the distribution networks of zones and sub zones; and
- (vi) Testing for isolation of zones and sub-zones from others by feeding water through a single feeder pipe with closure of all boundary valves of zones except the feed valve.

2. Waste Assessment

The steps involved are:

- (i) Estimation of total daily consumption of the sub-zone by computation or by flow gauging and studying the water consumption pattern of sub-zone for the day;
- (ii) 'Flow Test' for measurement of waste through the leaks by isolation of sub-zones and by means of an integrating type water meter or mobile waste water meter; and
- (iii) 'Step Test' to assesses and localize the leakage in various parts of the sub-zone by internal valves.

The daily consumption pattern taken over a period of days can provide data for arriving at the actual average daily consumption of water in the area surveyed. These figures can be obtained through house meter readings, or by actual spot measurements by an integrating meter installed in the pipe feeding a group of houses in metered or unmetered areas. Otherwise, average daily consumption may have to be suitably assumed for the area.

A section or zone of water distribution system is isolated by allowing water to be fed into the zone through a single feeder pipe controlled by a valve. The zone is usually divided into workable sub-zones with a viable number of connections of about 150 to 300 in each sub-zone. Each sub-zone could also be isolated from the rest and be fed through a single entry pipe controlled by a valve. The boundary valves (i.e. the valves connecting the common pipes of two zones or sub-zones) are located in such a way that the water does not enter or flow out of the sub-zone from or to the adjacent ones.

The rate of flow in the zone or subzone is measured by a pitometer inserted in the pipe, if the feeder pipe and the flows are large. Otherwise, the flows are gauged by a mobile waste water meter, or integrating meter temporarily installed or by Deacon's water meter permanently installed in the system.

After gauging of the flows, the next step is to narrow down the area under test to localize the leakage in various parts. This is carried out by the 'step test' by noting the flow into the

pipe system of sub-zone after every stepwise reduction in the size of the zone by closing the internal valves in each step.

The internal valves of a sub-zone are checked for water tightness by sounding over the spindle using the sounding rod under unbalanced pressure conditions created by supplying water through a single feed to the system with the direction of flow of water towards one face of the valve only. All the stop cocks or taps in the house service pipes are checked and if necessary rectified to ensure water tightness and complete cut off of the supply to consumers when stop cocks are closed.

The whole system must, as far as practicable, be brought to a 'tree' system by closing such valves in the mains in a loop during the test to prevent circulation. Then step wise isolation of mains in a zone or subzone is feasible and the possible sources and extent of wastage through leaks could be found within a short reach of the main.

(b) Leakage Detection

Leakage detection survey is confined only to the areas with heavy leakages as arrived at by the waste assessment survey. The survey consists of:

- (i) Finding leaks in the pipes by visual determination of surfaces and
- (ii) Traversing the sub-zone in the night by sounding rod or electronic leak locator for pinpointing of leaks in pipes.

Use of 'electronic pipe locator' can expedite the location and alignment of buried pipes particularly when the records for pipes in distribution maps are not adequate or complete. Some times, by physical inspection of valves or by occasional opening of trenches and through information obtained from valve operator or fitters, the alignment of buried pipes along streets could be made. Sounding rods alone or along with the electronic leak detector are traversed over the surface above the centre line of the alignment pipe for detecting noise generated by possible leaks in the mains. These are carried out usually at midnight when extraneous noise is minimum and the distribution system of the zone is also at a higher pressure.

Methods employing radioactive isotopes, nitrous oxide gas and halogens can easily and exactly pinpoint leaks but are not usually practiced in water works system as a routine measure since they require specialized equipment involving high costs.

Visual indications of leakage in pipes like dampness and stagnant water are noticeable in cases of large leaks, or even small leaks of pipelines located just below the surface depending upon the soil conditions.

The usual way to detect leaks in buried pipes without opening the road surface for visual inspection is by acoustic methods. The sound generated by the leaks through the overburden is picked up by the ear through the conventional sounding rod, stethoscope or the sophisticated electronic leak detector.

(1) Instrument 122

The instrument is a simple instrument for measuring the flow rate of water in a pipe. It consists of a flowmeter, a pressure gauge, and a flowmeter. The flowmeter is a device that measures the flow rate of water in a pipe. The pressure gauge is a device that measures the pressure of water in a pipe. The flowmeter is connected to the pipe and the pressure gauge is connected to the pipe.

(2) Flowmeter (Variable)

The flowmeter is a device that measures the flow rate of water in a pipe. It consists of a flowmeter, a pressure gauge, and a flowmeter. The flowmeter is a device that measures the flow rate of water in a pipe. The pressure gauge is a device that measures the pressure of water in a pipe. The flowmeter is connected to the pipe and the pressure gauge is connected to the pipe.

(3) Pressure Gauge (With 45000)

The pressure gauge is a device that measures the pressure of water in a pipe. It consists of a pressure gauge, a flowmeter, and a flowmeter. The pressure gauge is a device that measures the pressure of water in a pipe. The flowmeter is a device that measures the flow rate of water in a pipe. The pressure gauge is connected to the pipe and the flowmeter is connected to the pipe.

(4) Integrating-type Water Meter

The integrating-type water meter is a device that measures the flow rate of water in a pipe. It consists of a water meter, a pressure gauge, and a flowmeter. The water meter is a device that measures the flow rate of water in a pipe. The pressure gauge is a device that measures the pressure of water in a pipe. The flowmeter is a device that measures the flow rate of water in a pipe. The water meter is connected to the pipe and the pressure gauge is connected to the pipe.

(5) Multi-Water Flow Meter

The multi-water flow meter is a device that measures the flow rate of water in a pipe. It consists of a multi-water flow meter, a pressure gauge, and a flowmeter. The multi-water flow meter is a device that measures the flow rate of water in a pipe. The pressure gauge is a device that measures the pressure of water in a pipe. The flowmeter is a device that measures the flow rate of water in a pipe. The multi-water flow meter is connected to the pipe and the pressure gauge is connected to the pipe.

(6) Hydrants and Fire Pipes

The hydrants and fire pipes are devices that are used to measure the flow rate of water in a pipe. They consist of a hydrant, a fire pipe, and a flowmeter. The hydrant is a device that measures the flow rate of water in a pipe. The fire pipe is a device that measures the flow rate of water in a pipe. The flowmeter is a device that measures the flow rate of water in a pipe. The hydrant is connected to the pipe and the fire pipe is connected to the pipe.

(7) Electronic Water Meter

The electronic water meter is a device that measures the flow rate of water in a pipe. It consists of an electronic water meter, a pressure gauge, and a flowmeter. The electronic water meter is a device that measures the flow rate of water in a pipe. The pressure gauge is a device that measures the pressure of water in a pipe. The flowmeter is a device that measures the flow rate of water in a pipe. The electronic water meter is connected to the pipe and the pressure gauge is connected to the pipe.

(8) Electronic-type Line Locator

The electronic-type line locator is a device that is used to locate the location of a pipe. It consists of an electronic-type line locator, a pressure gauge, and a flowmeter. The electronic-type line locator is a device that is used to locate the location of a pipe. The pressure gauge is a device that measures the pressure of water in a pipe. The flowmeter is a device that measures the flow rate of water in a pipe. The electronic-type line locator is connected to the pipe and the pressure gauge is connected to the pipe.

(9) Sounding Bell

The sounding bell is a device that is used to measure the flow rate of water in a pipe. It consists of a sounding bell, a pressure gauge, and a flowmeter. The sounding bell is a device that is used to measure the flow rate of water in a pipe. The pressure gauge is a device that measures the pressure of water in a pipe. The flowmeter is a device that measures the flow rate of water in a pipe. The sounding bell is connected to the pipe and the pressure gauge is connected to the pipe.

(9) Electronic Leak Detector

The sensors of a pipe cap, an inlet and backflow. The sound vibrations created by water escaping through leaks in pipes are sensed and magnified by a magnetic pickup and converted to electrical impulses. These impulses are amplified and can pinpoint the position of the leak.

(10) Road Measurer

This is a single wheel driven integrating type roller facilitating the measurement of the length travelled as it moves along the road.

(ii) Corrective Action

After location of the leaks in the pipe, prompt repairs to pipes and valves are to be undertaken. The flow loss in the wet zone can be determined the cost and efficacy of the corrective measures. If re-testing proves that there are further leakages, they have to be attended to until the losses in the zone are reduced to the minimum. The experience of water works in different surveys indicates that a few major leaks in a zone or subzone contribute to about 50% of the total loss. A sizable reduction in wastage can be brought about by locating and repairing promptly all such leaks. In fact, sometimes, it is prudent in a zone to go in for the eradication of probable leaks in pipes which will be preceded by waste assessment.

The leaks are usually noticed at or near family connections and so corrected. C.I. house service pipes or in the runs of main and house service pipes. The savings in water resulting from the programme are more than offset the investments. In addition to the favourable direct economic effects due to saving of water, the secondary benefits accruing out of such savings are: improvement of distribution system, draughts, maintaining valves, hydrants and street works, the improved quality of water in the system due to prevention of back flow of pollution into the main in non supply areas and above all, the public goodwill earned due to the improved supply. Some of these cannot be exactly quantified.

10.10.3 CLEANING OF PIPES

The necessity for systematic and periodic cleaning of pipelines is borne out by the fact that the carrying capacity of the pipes gets reduced due to growth of slimes, incrustations or deposits. Flushing and swabbing of pipes, which are simple and inexpensive can go a long way in maintaining the capacity.

The old cast iron and steel pipes which are cleaned can be protected from further incrustations or corrosion by cement lining. Insertion of a plastic pipe has also been done successfully.

Disinfection of the mains has been discussed in Appendix 5.8. This can be done at site specially for large diameter pipelines.

(i) Flushing

Water of high velocity is allowed to flow in the pipe and finally escape through a scour valve or hydrant. The minimum velocity to be achieved varies from 90 to 120 cm/s and it is to be ensured that the flows are in one direction and the dirty water does not enter the

cleaned sections. Flushing can only remove loose deposits of small size and not the slurry layers, large sized deposits and hard encrustations. Flushing also disintegrates microscopic biological growths which, if left unattended, are likely to grow further and create problems. The period of flushing is determined by the quality of moving water in hydrant or valves. Ideally, this amounts to the flushing out of a volume of water equal to twice the capacity of the pipe length under consideration. About 10⁶ to 10⁷ m length of pipe can be flushed in one operation.

(b) *Swabbing*

The swab used is made of polyethylene fibres of 10 mm depth and 30 to 60 cm long with varying diameters. It is soft and flexible, highly compressible and can retain the original shape when released from compression. Two varieties are available – one soft and the other relatively hard.

This swab is pushed into the pipe by the momentum of the flowing water. As the swab moves, it sweeps out the loose and slurry layers adhering to the inside of the pipeline and the deposits are carried away by the flowing water. Swabbing is not successful for dealing with hard deposits.

Swabs are slightly larger in diameter than the pipe to be cleaned. In certain cases with heavily encrusted pipes, swabs of the same diameter as the pipe are used usually. For pipe diameters of 75 to 100 mm the swab diameter is usually 75 mm larger in size while for larger diameter pipe it is 50 to 75 mm larger.

For clearing pipe below 100 mm diameter or less, the following procedure is adopted. In distribution systems, where hydrants are connected vertically above a main without a duck-foot bend, the insertion of swab and its expansion from the pipe are carried out at the hydrant. In situations where the hydrants are laterally connected to the main, insertion of the swab has to be either through an existing tap in the line or by pumping water under pressure through the hydrant. The exit can be through another hydrant or a tee connected to the other end of the pipe and kept open.

The length of the main to be cleaned is isolated by valves. The swab is dipped in bleaching powder solution of strength 50 mg/l of chlorine per cc insertion. After insertion, the hydrant valve is closed or the valve body is packed. Water is allowed into the pipe by opening the valve near the hydrant and keeping the near hydrant valve open, while the valve on the other side of pipe is kept closed. This ensures water flows in one reach only between the point of insertion and point of exit of the swab.

The movement of swab depends on the rate or flow or velocity of flush in the pipe which usually should not be less than 30 cm/s. If swab gets stuck or blocked in the pipe, water can be passed from the opposite direction in the pipe to release it.

As a precautionary measure, tee branches can be provided near the junction points of the pipe network provided by the valves (Fig. 10.2). These tee connections are covered by blank flanges. The tee can be vertical or horizontal and the outlet end with blank flanges can be enclosed in a chamber. Whenever swabbing or flushing is desired, the blank flange can be opened after closing the downstream valve and allowing the water and swab to escape through the tee.

and low density solids, and that the water main should be installed at least 10 feet below the frost line. The water main should be installed in a trench that is deep enough to prevent the water main from being exposed to the frost line. The water main should be installed in a trench that is deep enough to prevent the water main from being exposed to the frost line.

DEFLECTION FROM AGENSIVE OF FIBER NEAR SLIVERS AND DEATHS

RECOMMENDATION FOR AGENSIVE

The water main should be installed in a trench that is deep enough to prevent the water main from being exposed to the frost line. The water main should be installed in a trench that is deep enough to prevent the water main from being exposed to the frost line. The water main should be installed in a trench that is deep enough to prevent the water main from being exposed to the frost line.

RECOMMENDATION FOR AGENSIVE

The water main should be installed in a trench that is deep enough to prevent the water main from being exposed to the frost line. The water main should be installed in a trench that is deep enough to prevent the water main from being exposed to the frost line. The water main should be installed in a trench that is deep enough to prevent the water main from being exposed to the frost line.

RECOMMENDATION FOR AGENSIVE

The water main should be installed in a trench that is deep enough to prevent the water main from being exposed to the frost line. The water main should be installed in a trench that is deep enough to prevent the water main from being exposed to the frost line. The water main should be installed in a trench that is deep enough to prevent the water main from being exposed to the frost line. The water main should be installed in a trench that is deep enough to prevent the water main from being exposed to the frost line.

The water main should be installed in a trench that is deep enough to prevent the water main from being exposed to the frost line. The water main should be installed in a trench that is deep enough to prevent the water main from being exposed to the frost line. The water main should be installed in a trench that is deep enough to prevent the water main from being exposed to the frost line.

DEFLECTION FROM AGAINST FREEZING

The water main should be installed in a trench that is deep enough to prevent the water main from being exposed to the frost line. The water main should be installed in a trench that is deep enough to prevent the water main from being exposed to the frost line. The water main should be installed in a trench that is deep enough to prevent the water main from being exposed to the frost line. The water main should be installed in a trench that is deep enough to prevent the water main from being exposed to the frost line.




FIGURE 10.2 : THE BRANCHES TO ENABLE SWABING

even as an unprotected welded steel pipe at 0°C. With lower outside temperatures water is likely to freeze irrespective of the velocity in long main, unless they are laid below the frost line. In Indian conditions, frost does not penetrate more than 2 m even in extreme cold areas. The cover of 4 to 5 m needed from the structural and traffic considerations should be adequate to take care of freezing also. When cast iron pipes are exposed to air temperatures below 0°C, they are laid at a minimum size of 50 mm diameter and totally isolated, the common specification being three layers of glass wool matting (total nominal thickness 75 mm), protected by means of weather proof wrapping. Joints are being socket lapped and sealed at all points. This specification is suitable when water circulation is maintained continuously or when circulation is interrupted for only brief intervals.

CHAPTER II PUMPING STATIONS AND MACHINERY

PLF REQUIREMENTS

Planning and operation of a pumping station involves considerations of the following points

- (i) Selection of the pumps
- (ii) Intake design
- (iii) Pump layout
- (iv) Providing space, equipment and facilities for
 - (a) Substation, if needed, for receiving and distributing the power supply
 - (b) Auxiliary power or, generally, diesel
 - (c) Control panel
 - (d) Keys for loading and unloading
 - (e) Overhauling, repairs and maintenance of pumps and all other equipments
 - (f) Tool room and material handling table
 - (g) Ventilation
 - (h) Lighting
 - (i) Safety from fire
 - (j) Railings, ladders and passages for safe, easy and efficient movement of people
 - (k) Office and administrative area, including room for lockers, dress change and toilets for sanitary and hygienic needs of the working staff
- (v) Installation of pumps
- (vi) Operation of pumps
- (vii) Maintenance of pumps
- (viii) Breakdown of pumps
- (ix) Selection of motors
- (x) Selection of starters
- (xi) Discussion on control panel

11.1.2.3 Pump Types Based On The Method Of Coupling The Motor

Pumps are classified into three types based on the method of coupling the motor to the pump shaft. They are direct drive pumps, belt drive pumps and gear drive pumps.

11.1.2.3.1 Pump Types Based On The Method Of Coupling The Motor

The pump is directly coupled to the motor shaft in direct drive pumps. In belt drive pumps, the motor shaft is coupled to the pump shaft through a belt and pulley system. In gear drive pumps, the motor shaft is coupled to the pump shaft through a gear system.

11.1.2.3.2 Types of pumps based on the method of coupling the motor

The pumps are classified into three types based on the method of coupling the motor to the pump shaft. They are direct drive pumps, belt drive pumps and gear drive pumps. Direct drive pumps are the most common type of pump. In direct drive pumps, the motor shaft is directly coupled to the pump shaft. Belt drive pumps are used when the motor and pump are located at different locations. In belt drive pumps, the motor shaft is coupled to the pump shaft through a belt and pulley system. Gear drive pumps are used when the motor and pump are located at different locations and the pump requires a high speed. In gear drive pumps, the motor shaft is coupled to the pump shaft through a gear system.

The pump is directly coupled to the motor shaft in direct drive pumps. In belt drive pumps, the motor shaft is coupled to the pump shaft through a belt and pulley system. In gear drive pumps, the motor shaft is coupled to the pump shaft through a gear system.

11.1.3 CRITERIA FOR PUMP SELECTION

The following criteria are used for pump selection. They are: 1. Capacity, 2. Head, 3. Efficiency, 4. NPSH, 5. Material, 6. Cost, 7. Maintenance, 8. Reliability, 9. Safety, 10. Environmental impact.

1. Capacity: The capacity of the pump is the volume of liquid that it can pump per unit time.

2. Head: The head of the pump is the height to which it can lift the liquid.
3. Efficiency: The efficiency of the pump is the ratio of the power output to the power input.
4. NPSH: The NPSH of the pump is the minimum head required for the pump to operate without cavitation.
5. Material: The material of the pump should be compatible with the liquid being pumped.
6. Cost: The cost of the pump should be within the budget.
7. Maintenance: The pump should be easy to maintain.
8. Reliability: The pump should be reliable and have a long life.
9. Safety: The pump should be safe to operate.
10. Environmental impact: The pump should have a low environmental impact.

11.1.4 CONSIDERATIONS OF THE PARAMETERS OF HEAD, DISCHARGE AND SPEED IN THE SELECTION OF A PUMP

These parameters are combined together in the term Specific Speed of a pump, which is calculated by the following formula:

$$n_s = \frac{3.65 N Q^{1/3}}{H^{3/4}} \quad (11)$$

Where,

- n_s = Specific speed
- N = The operating speed of the pump in rpm
- Q = The rate of flow in cubic meters per second
- H = The total head per stage of the pump in meters

Most aspects of the performance characteristics of the different types of pumps can be compared, based on their specific speed. Some useful observations are summarized below:

- (i) Positive displacement pumps are predominantly used when high pressures/high heads are to be developed or for low discharge/slow flows at zero loading/sludge.
- (ii) Centrifugal pumps are made with specific speeds above 30. Fig. 11.1 illustrates the relationships amongst the pump capacity, the size of the impeller and the nature of the curves of Head (H), discharge (Q), power (input) (P) and Efficiency, versus Q as influenced by the specific speed of the pump. The figure also helps in obtaining estimates of pump efficiency, which is useful in planning a pump system.
- (iii) For high discharges, by which specific speed becomes high, the corresponding Net Positive Suction Head required (NPSH, see 11.1.4) also becomes high; it can be arranged that the discharge is shared by two impellers or by two sides of an impeller as in a double suction pump. While estimating the available efficiency for such ranges, any loss of the total Q should be considered.
- (iv) Similarly, for high heads, by which low specific speed becomes low, and hence the available efficiency becomes low, it can be arranged that the head be introduced amongst a number of stages as in a multi-stage pump, thus improving the specific speed of each component, consequently, the overall efficiency.

11.1.5 CONSIDERATION OF THE SUCTION LIFE CAPACITY IN PUMP SELECTION

11.1.5.1 The Meaning Of NPSHr

The suction life capacity of a pump depends upon its NPSHr characteristics. The meaning of NPSHr can be explained by considering the formation of a pump cavitation and suction lift as illustrated in Fig. 11.7.

When a pump is installed as shown in Fig. 11.7, it is clear that the water in the pump is not under any vacuum developed at its suction. The atmospheric pressure acting on the water in the suction sump then pushes the water through the head valve into the suction pipe, raising




FIG. 11. SPEED AND EFFICIENCY CURVES AT 100% WET SPINNING



FIG. 12. SCHEMATIC OF SPINNING SYSTEM AT 100% WET SPINNING

it upto the suction of the pump. While reaching upto the suction of the pump, the energy content of the water, which was one atmosphere when it was pushed through the foot valve would have reduced, partly in overcoming the friction through the foot valve and the piping and the pipe fittings, partly in achieving the kinetic energy appropriate to the velocity in the suction pipe and partly in rising up the static suction lift. The energy content left over in the water at the suction face of the pump is thus less than one atmosphere until here the flow is a fairly streamlined flow. But with the impeller rotating at the pump suction, the flow suffers turbulences and shocks and will have to lose more energy in the process. This tax on the energy of the water demanded by the pump, before the pump would impart its energy, is called the NPSHr of the pump.

The NPSHr characteristics of a pump is parabolic, increasing with flow rate.

Pumps of high specific speed have high NPSHr.

11.1.5.2 Vapour Pressure And Cavitation

The energy of the water at the pump suction, even after deducting the NPSHr should be more than the vapour pressure V_p , corresponding to the pumping temperature. The vapour pressures in meters of water column (mWC), for water at different temperatures in degrees Celsius are given in Table II.1.

TABLE II.1
VAPOUR PRESSURE OF WATER

$^{\circ}\text{C}$	(mWC)
0	0.054
5	0.092
10	0.125
15	0.177
20	0.238
25	0.329
30	0.427
35	0.579
40	0.762
45	1.006
50	1.281

If the energy of the water at the pump suction would be less than the vapour pressure, the water would tend to evaporate. Vapour bubbles so formed will travel entrained in the flow until they collapse. This phenomenon is known as cavitation. In badly devised pumping systems, cavitation can cause extensive damage due to cavitation erosion or due to the vibration and noise associated with the collapsing of the vapour bubbles.

11.1.5.3 Calculating NPSHa

To insure against cavitation, the pumping system has to be so devised that the water at the pump suction will have adequate energy. Providing for this is called as providing adequate Net Positive Suction Head available (NPSHa). The formula for NPSHa hence becomes as follows.

NPSHa = Pressure on the water in the suction sump.

$$= P_s - Hf_s - \frac{V_s^2}{2g} - Z_s + V_p$$

P_s = suction pressure

Hf_s = friction losses across the foot valve, piping and pipe fittings

V_s = velocity-head at the suction face

Z_s = the potential energy corresponding to the difference between the levels of the pump-centre line and of the water in the suction-pump

V_p = the vapour pressure

While calculating NPSHa, the atmospheric pressure at the site should be considered, as the atmospheric pressure is influenced by the altitude of the place from the mean sea level (MSL). Data on the atmospheric pressure in mWC for different altitudes from MSL is given in Table 11.2.

TABLE 11.2

ATMOSPHERIC PRESSURE IN mWC AT DIFFERENT ALTITUDES ABOVE MSL

altitude above MSL in m	mWC
upto 500	10.3
1000	9.8
1500	9.3
2000	8.8
2500	8.3
3000	7.8
3500	7.3
4000	6.8

11.1.5.4 Guidelines On NPSHr

The NPSHa has to be so provided in the systems that it would be higher than the NPSHr of the pump. The characteristics of the pump's NPSHr are to be obtained from the pump-manufacturers. However some general guidelines for max. suction lift or min. NPSHa based on the type of a pump and based on the range of head and the specific speed are compiled in Figs. 11.3, 11.4 and 11.5.

11.1.5.5 General Observations

- Horizontal centrifugal pumps are installed with suction lift.




FIG. 1.3. NEEDS FOR SINGLE SUCTION PUMPS WITH OVERLAPPING IMPELLERS.




FIG. 1.4. NEEDS FOR SINGLE SUCTION PUMPS WITH SHAFT THROUGH EYE OF IMPELLER.




FIG. 11.5. STATIC PRESSURE DISTRIBUTION IN A DUCT WITH A 90° BEND AND A 180° TURN.

Figure 11.5 shows the static pressure distribution in a duct with a 90° bend and a 180° turn. The pressure is higher in the center of the duct and lower near the walls. The pressure is also higher at the inlet and lower at the outlet. The pressure distribution is shown in Figure 11.5. The pressure is higher in the center of the duct and lower near the walls. The pressure is also higher at the inlet and lower at the outlet.

The pressure distribution is shown in Figure 11.5. The pressure is higher in the center of the duct and lower near the walls. The pressure is also higher at the inlet and lower at the outlet.

The pressure distribution is shown in Figure 11.5. The pressure is higher in the center of the duct and lower near the walls. The pressure is also higher at the inlet and lower at the outlet.

11.3.6 CONSIDERATIONS ON THE BOUNDARIES OF A FLOW FIELD IN PRACTICE

In a typical case, the boundaries of a flow field are defined by the physical boundaries of the duct. To evaluate the need needed to be developed, the flow field is divided into a grid. A part of these errors is called the boundary layer. The boundary layer is the region near the wall where the velocity is zero. The boundary layer is the region near the wall where the velocity is zero.




FIG. 11.6 SYSTEM HEAD CURVE

(a) Static Head

This is the difference between the level of the liquid in the suction-sump and the level of the highest point of the delivery piping, obviously the static head is more at the low water level (LWL) and less at the high-water level (HWL).

(b) Friction Head

This is sum of the head-losses in the entire length of the piping, from the foot valve to the final point of delivery piping, also the losses in all the valves i.e. the foot valve, the non-return (reflux) valve and the isolating (generally, sluice or butterfly) valves, and the losses in all pipe fittings such as the bends, tees, elbows, reducers, etc. The friction head varies particularly with the rate of flow. Details for calculating the friction heads are given in Chapter 6.

(c) Velocity Head

At the final point of delivery, the kinetic energy is lost to the atmosphere. To recover part of this loss, a bell-mouth is often provided at the final point of delivery. The kinetic energy at the final point of delivery has also to be a part of the velocity head. Figs. 11.6 (a, b & c) show typical System Head Curves. As shown in Fig. 11.6(b) the System Head Curves for HWL and LWL are parallel to each other.

The system head curve will change by any changes made in the system, such as change in the length or size of the pipings, change in size and/or number of pipe fittings, changes in the size, number and type of valves by operating the valves semi open or fully open. These changes can cause the System Head Curve to be steep or flat as shown in Fig. 11.6 (c).

11.1.7 SUMMARY VIEW OF APPLICATION PARAMETERS AND SUITABILITY OF PUMP

Based on the considerations in 11.1.4 and 11.1.5, a summary view is compiled of the application parameters and suitability of pumps of various types and presented in Table 11.3. However, these are general guidelines. Specific designs may either not satisfy the limits or certain designs may exceed the limits.

TABLE 11.3
APPLICATION OF PUMPS

Pump type	Suction-capacity to lift			Head range			Discharge range		
	Low 3.5m	Medium 6m	High 8.5m	Low Upto 10m	Medium 10- 40m	High Above 40m	Low Upto 30L/s	Medium Upto 500L/s	High Above 500L/s
Centrifugal, horizontal end-suction	Ok	Ok	Ok	Ok	Ok	No	Ok	Ok	No
Centrifugal horizontal axial split casing	Ok	No	No	Ok	Ok	No	No	Ok	Ok
Centrifugal, horizontal multistage	Ok	Ok	No	No	Ok	Ok	Ok	Ok	No
Jet- centrifugal, combinations	When limitations of suction lift are to be overcome			Ok	Ok	No	Ok	No	No
Centrifugal, vertical turbine	when suction lift is to be avoided			Ok	Ok	Ok	Ok	Ok	Ok
Centrifugal, vertical submersible	when suction lift is to be avoided			Ok	Ok	Ok	Ok	Ok	Ok
Positive displacement pumps	Normally self priming			Limited only by the pressure which casing can withstand			Ok	Ok	No Basic adaptation for dosing or metering




Fig. 1. OPERATING POINT

1.1.3.1.1. OPERATING RANGE OF THE PUMP

1.1.3.1.1.1. DETERMINING THE OPERATING POINT AND THE OPERATING RANGE OF A PUMP

The operating range of a pump is the range of flow rates and heads over which the pump can operate. The operating range of a pump is determined by the characteristics of the pump and the system. The operating range of a pump is the range of flow rates and heads over which the pump can operate.

The operating range of a pump is determined by the characteristics of the pump and the system. The operating range of a pump is the range of flow rates and heads over which the pump can operate.

The operating range of a pump is determined by the characteristics of the pump and the system. The operating range of a pump is the range of flow rates and heads over which the pump can operate.

The operating range of a pump is determined by the characteristics of the pump and the system. The operating range of a pump is the range of flow rates and heads over which the pump can operate.

The operating range of a pump is determined by the characteristics of the pump and the system. The operating range of a pump is the range of flow rates and heads over which the pump can operate.




FIG. 11.7(B) CHANGE IN OPERATING POINT OF PUMP WITH CHANGE IN WATER LEVEL IN SUCTION SUMP




FIGURE 11.7(C): CHANGE IN OPERATING POINT OF PUMP BY OPERATION OF DELIVERY VALVE

- (c) When specifying the operating point of the pump, margins and safety factors, especially in specifying head should be avoided. On providing margins and safety factors, the rated head for the pump would work out high. In actual running the pump would work at a head less than the rated head and yield high discharge. From Fig. 11.1, it would be noted that the Power versus Q characteristics of pumps of specific speeds upto 300 is with positive gradient, hence demanding more power at higher discharge. By such higher power demand, the drive may get over loaded.

By working at high discharge, the NPSHr demanded by the pump would be higher. If NPSHa is not adequate for this higher NPSHr, the pump may cavitate.

Due to the high discharge included, the pump may vibrate. Sometimes this may result in serious damage to the shaft and bearings.

11.1.9 DRIVE RATING

After the operating point of a pump is decided as discussed in 11.1.7, the efficiency of the pump can be estimated from Fig. 11.1. The rating of the drive should be such that it would not get overloaded when the pump would be delivering the high discharge, as with HWL in the suction-sump. Also, the drive rating should be adequate to provide for the negative tolerance on efficiency and the positive tolerance on discharge, applicable for variations in actual Pump-performance from the rated performance.

The power needed to be input to the pump is the power to be output by the drive, i.e. at the pump shaft. Since, most drives are coupled direct to the pump, the power at the pump shaft denotes the brake power of the drive. All drives are rated only as per their brake power capacity, often quoted in Brake Kilowatt (BKW).

To provide margins over the BKW required at the operating point, so that the overloading would not happen at HWL, the following margins are recommended.

TABLE 11.4
MARGINS TO DECIDE DRIVE RATING

BKW required at the operating point	Multiplying factor to decide drive rating
upto 1.5	1.5
1.5 to 3.7	1.4
3.7 to 7.5	1.3
7.5 to 15	1.2
15 to 75	1.15
above 75	1.1

11.1.10 STABILITY OF PUMP CHARACTERISTICS

In the $H-Q$ characteristic of the centrifugal pump, the flow reduces as the head increases. If the head increases continuously until zero flow or until full close i.e., shut-off of the delivery valve, as shown in Fig. 11.8 (a) the $H-Q$ characteristic is said to be stable. However, it is also probable that the shut off head of a pump may be less than the maximum head, as

shown in Fig. 11.8 (b) which may be realized at some positive flow. Such a characteristic of a pump is called as unstable characteristic. When operating such a pump at any head between the shut-off head and the maximum head, the flow will keep hunting between two values. Because of this, the performance of the pump becomes erratic and unstable.




FIG. 11.8 STABLE AND UNSTABLE CHARACTERISTICS OF PUMPS

While selecting a pump, it ought to be checked that the highest head by the intersection of the system head curve would be less than the shut off head, in the case of pumps with unstable characteristics.

11.1.11 CONSIDERATIONS WHILE SELECTING PUMPS FOR SERIES OR PARALLEL OPERATION

- (a) When pumps are to run in parallel, to obtain the combined H-Q characteristics, for different values of head, the values of the flow of individual pumps are to be found and to be added. See Fig. 11.9 (a). The system head curve then intersects the combined H-Q characteristics at higher head and discharge. Each individual pump ought to be capable of developing such high head, that too within its zone of stability. Rather, it is always desirable to put into parallel operation only pumps having stable H-Q characteristics.
- (b) A pumping system is often sought to be modified to meet increasing demand by commissioning additional pumps in parallel. It must be noted however that because the system head curve intersects the combined H-Q curve at a point having the head also higher, an additional pump would not increase the discharge proportionately, i.e. by making two identical pumps to work in parallel, when one is previously operative, the discharge would not double.
- (c) Conversely, if a system is to run with a number of pumps in parallel, but is modified to run with only a few of the pumps as in summer, for example, then the duty flow of each pump becomes more than when all the pumps be running. The individual pump would demand higher NPSH_r at the higher duty flow. If the




FIG. 11.9 (A) COMBINED CHARACTERISTICS OF TWO PUMPS IN PARALLEL




FIGURE 11.9(B) : ONE OR MORE PUMPS IN PARALLEL




FIGURE 11.10 : SERIES OPERATION OF PUMPS

NPSHa would not be adequate, the pump/s would cavitate. To prevent such possibility, individual pumps, which are to be put into parallel operation, would be so selected that the duty flow of combined parallel operation would be to the left of the BEP of the individual pump. By this, when only a few pumps are to run, the duty flow of the individual pump would shift to the higher flow nearer to its BEP Fig. 11.9 (b).

- (d) Pumps in series are similar to multi stage pumps. Rather, multi stage pumps are only a compact construction, where series operation is inbuilt. To obtain the combined H-Q characteristics of pumps in series, for various values of discharge, the values of head from the H-Q characteristics of individual pumps are to be noted and added. The system-head curve would intersect the combined H-Q curve at a point of higher head and discharge. See Fig. 11.10. The individual pump in this case ought to be capable of giving the higher discharge.

If the system head curve comprises high static head and a flat curve, the intersection at higher discharge on the combined H-Q characteristics may be at such discharge where the NPSHr of the individual pump would be high and the pump/s may cavitate.

Series operation is most appropriate, where the system-head curve is steep.

For the pumps to be put in series operation, each pump should be capable of withstanding the highest pressure that is likely to be developed in the system.

The head towards the potential difference between the centre-line of one pump and the suction of the next pump, plus the friction losses in the pipeline between the delivery of one pump upto the suction of the next pump has to be considered as a part of the total head of the pump giving the delivery. In a series system, the total head of each pump may have to be individually calculated, especially when the features contributing to head calculations are significantly different, as in the case of booster stations along a long conveyance pipeline.

11.1.12 CONSIDERATIONS OF THE SIZE OF THE SYSTEM AND THE NUMBER OF PUMPS TO BE PROVIDED

- (a) For small pumping systems, generally of capacity less than 15 mld, two pumps (One duty and one standby) should be provided. Alternatively, two duty and one standby, each of 50% capacity may be provided. Although this alternative would need larger space, it facilitates flexibility in regulating the water supply. Also, in an emergency of two pumps going out of order simultaneously, the third helps to maintain at least partial supply.
- (b) In the case of medium and large pumping stations, at least two standby should be provided.

11.1.13 CONSIDERATIONS REGARDING PROBABLE VARIATIONS OF ACTUAL DUTIES FROM THE RATED DUTIES

11.1.13.1 Affinity Laws

The running speed of the electric induction motors is at a slip from its synchronous speed. The running speed of the motor is also influenced by variations in the supply frequency. Since the pump characteristics furnished by the pump manufacturers is at certain nominal speed, depending upon the actual speed while running, the actual pump performance would be different from the declared characteristics. Estimates of the pump performance in actual running can be worked out from the declared characteristics, by using the following affinity laws.

$$\text{if } \frac{n''}{n'} = k, \text{ then } \frac{Q''}{Q'} = k;$$

$$\frac{H''}{H'} = k^2; \text{ then } \frac{P''}{P'} = k^3;$$

In the above formulae, n denotes the speed of the pump, p denotes the power input to the pump, the superscript " denotes the values at the actual speed and the superscript ' denotes the values at the nominal speed.

Recalculating the pump-performance at the actual speed would reveal the following.

- (a) If the actual speed is less than the nominal speed, then the values of the discharge, head and power required to be input to pump would all be less than the values from the declared characteristics.
- (b) Similarly, if the actual speed is more than the nominal, it should be checked that the higher power input required would not overload the motor.
- (c) When the actual speed is more, because the discharge is also correspondingly more, the NPSHr would also be more, varying as per the following formula.

$$\frac{NPSHr''}{NPSHr'} = k^2$$

11.1.13.2 Scope For Adjusting The Actual Characteristics

To avoid overloading or cavitation, marginal adjustment to the pump performance may be done at site, either by employing speed-change arrangements or by trimming down the impeller. The modifications in the performance on trimming the impeller can be estimated using the following relations:

$$\text{if } \frac{D''}{D'} = k, \text{ then } \frac{Q''}{Q'} = k;$$

$$\frac{H''}{H'} = k^2; \quad \text{then } \frac{P''}{P'} = k^3;$$

Such modifications are recommended to be done within 10 to 15 percent of the largest diameter of the impeller. The percentage depends upon the design, size and shape of the impeller. The pump manufacturer should be consulted on this.

11.1.14 PUMP TESTING

The objective of pump testing is to verify that the performance characteristics of the pump are appropriate for the service desired.

The testing is done both at the manufacturers' works and only for preventive maintenance and in the field, with the following limitations:

- (1) The testing at the manufacturers' work is done with water under ambient conditions. It is not practical for the manufacturer to provide the service fluid to be the test fluid. It is also not practical to exactly duplicate the site conditions viz. suction sump, piping layout, atmospheric pressure, fluid temperature and pressures etc.
- (2) For the testing at the site, it is often impractical to provide adequate instrumentations of appropriate class of accuracy. Setting up the instrumentation

may disrupt the on-line operation of the pump. Field test of the pump has to be scheduled considering when the disruption of the on-line operation can be tolerated. Apart from the disruption, certain temporary modifications will be needed to introduce flow-measuring devices like orifice plates, etc. in the line. In situations where service-fluid is likely to entrain solids, this is likely to cause the measuring instruments either to give erratic reading or even suffer damage. Then the field test may not be feasible at all. The field test even where feasible, is often done to keep a track of deterioration in efficiency due to increase in running clearances, particularly at the wearing rings. The objective of the field test is one of preventive guidelines and not one of obtaining very elaborate details of the pump characteristics.

- (3) Since the testing at the manufacturers' works is done with water under ambient conditions, the duties desired with service-fluid have to be translated to equivalent duties with water under ambient conditions. In the Standards on testing, viz. IS: 9137-1978 or IS:10981-1983 permissible tolerances for the variation of test results from guaranteed duties are also given. Out of these two standards, IS: 9137-1978 details class C code of testing and IS:10981-1983 details Class B code of testing. The Class B code of testing specifies narrower band for tolerance. The implicit stringency affects both the cost and the period of delivery. The class C code of testing is the most widely followed and adequate in most of the cases.

The scheme of testing includes taking readings, doing calculations and plotting of

- (i) the H-Q characteristics
- (ii) the P-Q characteristics and
- (iii) the efficiency versus Q characteristics.

The actual speed of the shaft at the time of each reading would be different from the nominal speed. The value of the total head, flow-rate and power-input are to be converted to the nominal speed, using the affinity laws.

The readings of power-input, noted during testing are often the values of power input to the motor. Values of power-input to the pump have to be derived by multiplying the values of power input to the motor with the appropriate values of motor-efficiency.

For the values of motor-efficiency, reference has to be made to the motor-characteristics. Often these are available as motor output to motor-efficiency relationship. Since the readings during the test are for the motor input, the motor-characteristics need to be converted into the appropriate motor-input to motor-efficiency relationship.

After the performance-characteristics are plotted, an assessment has to be made to check whether the plottings reveal variations from the guaranteed duties. The pump can be approved if the variations are within the permissible tolerances.

It may be noted that the tolerances specified in IS: 9137-1978 and IS:10981-1983 give limits also for positive variances. However, in most water-supply situations, positive variances on discharge and efficiency would not be critical, if the motor would not get overloaded. This aspect, is so provided in IS:11346-1985, which deals with testing of pumps

for agricultural purposes. The technical provisions therein can be extended to pumps for water supply.

Only occasionally the testing is extended to cover testing the NPSHr characteristics of the pump. Basically care is always to be taken to provide NPSHa such that it has adequate margin over NPSHr at all flow rates in the operating range. Hence the data of NPSHr provided by the manufacturer need not be verified by an actual test. This is so advocated considering that

- (i) conducting test for NPSHr requires elaborate and often special arrangement on the test bed and becomes costly and time consuming,
- (ii) even on readily available test rigs, the actual conducting of the test itself becomes time consuming and exerting and a cost-element,
- (iii) the variations from the declared data are mostly on the safer side.

However, if the site-plan is laden with such constraints that NPSHa cannot have adequate margins over NPSHr, then testing for NPSHr may be stipulated very clearly in the purchase specifications. Unless stipulated, routine testing of a pump does not comprise in its scope the test for NPSHr.

11.1.14.1 Testing At Site

At site the testing is done soon after installation to assess whether any adjustments are required to the pump characteristics as detailed in 11.1.13.2. Further testing is done at site, mostly once in a year to assess whether there is any deterioration in the performance of the pump due to wear and tear.

The objective of the field test is to serve as a timely caution for preventive maintenance and not one of obtaining very elaborate details of the pump-characteristics.

During the testing at site, it is often impractical to provide adequate instrumentation of appropriate class of accuracy. Setting up the instrumentation may disrupt on-line operation of the pump. Apart from the disruption, certain temporary modifications may be needed to introduce flow-measuring devices like the orifice plates, etc. in the line. Field test has to be scheduled considering when the disruption of the on-line operation can be tolerated.

11.2 INTAKE DESIGN

11.2.1 THE OBJECTIVES OF INTAKE DESIGN

Detailed consideration needs to be devoted to the intake design to serve various objectives, as follows:

- (a) to prevent vortex formation,
- (b) to obtain uniform distribution of the inflow to all the operating pumps and to prevent starvation of any pump,
- (c) to maintain sufficient depth of water to avoid air entry during draw down.

11.2.2 GUIDELINES FOR INTAKE DESIGN

Figs. 11.11 (a, b, c, d and e) illustrate the recommended and the not-recommended practices for pump or intake design. Following points are to be noted in this respect. Note, D is the diameter of the suction bell mouth.

- (a) Avoid mutual interference between two adjoining pumps by maintaining sufficiency clearance, the dimension 'S' in Figs. 11.11 (a) and (b) equal to $2D$ to $2.5D$. It is also advisable to provide dividing walls between the pumps, as shown in Fig. 11.11 (b). The walls should have rounded or ogive ends.
- (b) As shown in Fig. 11.11 (b), avoid dead spots by keeping rear clearance, the dimension 'B' to about $5D/6$ from the centre line of the pump. A dummy wall may be provided, if necessary.
- (c) As shown in Fig. 11.11 (c), provide tapered walls between the approach channel and the sump. By this the velocity should reduce gradually to about 0.3 m/s near the pump. This also helps to avoid sudden change in the direction of the flow.
- (d) Avoid dead spots at the suction bell mouth by maintaining the bottom clearance, dimension C in Fig. 11.12, between $D/4$ to $D/2$, preferably $D/3$. The suction flow becomes guided by providing vertical splitters under the centre line of the pump. See Fig. 11.13 (a). A cone may be added to reduce the possibility of submerged vortex formation. See Fig. 11.13 (b).
- (e) Avoid sudden drop between the approach channel and the sump. A slope of maximum 15° is recommended as shown in Fig. 11.12. The floor underneath the pump suction should be flat upto $3D$.
- (f) Keep adequate submergence of the pump under the LWL, dimension H in Fig. 11.12, so as to prevent entry of air during draw-down and to satisfy NPSHr.

For the typical proportions illustrated in Fig. 11.12, recommendations for the values of the dimensions A and H , based on the recommended main-stream velocity of 0.6 m/s are given in Table 11.5.

The Dimension D is generally the diameter of the suction bell measured at the inlet. This dimension may vary depending upon pump design. Refer to the pump manufacturer for specific dimensions.

TABLE 11.5
RECOMMENDATIONS REGARDING INTAKE-DESIGN

Flow-rate in m^3/hr	Minimum submergence Dimension 'H', m	position of trash-rack dimension 'A', m
1000	1.23	3.28
1600	1.50	5.20
2500	1.80	8.07
4000	2.17	12.83
6400	2.63	20.37
10000	3.15	31.61
16000	3.80	50.20
25000	4.56	77.91
40000	5.52	123.74





FIG. 11-11(a)





FIG. 11-11(b)







FIG. 11-11(c)



NOT RECOMMENDED UNLESS $W \geq 5D$ OR MORE OR $V_c = 0.061 \text{ m/s}$ OR LESS
 $Y = \text{SAME AS CHART TO LEFT}$
 $S = \text{IS GREATER THAN } 4D$

W/Y	1.0	1.5	2.5	4.0	10.0
Y_{min}	3D	6D	7D	10D	15D
V_{Dmax}	0.3	0.6	1.2	1.8	2.5

FIG. 11-11(d)





FIG. 11-11(e)

FIGURE 11.11 : MULTIPLE PUMP PITS




FIG. 11.12 SUMP DIMENSIONS ELEVATION VIEW




FIG. 11.13 VERTICAL SPLITTERS IN THE SUMP

11.3 PIPING LAYOUT

11.3.1 SUCTION PIPING

- (a) The suction piping should be as short and straight as possible,
- (b) Any bends or elbows should be of long radius,
- (c) As a general rule the size of the suction pipe should be one or two sizes larger than the nominal suction size of the pump. Alternatively the suction pipe should be of such size that the velocity shall be about 2 m/s. Where bell-mouth is used, the inlet of the bell-mouth should be of such size that the velocity at the bell-mouth shall be about 1.5 m/s,
- (d) Where suction-lift is encountered, no point on the suction pipe should be higher than the highest point on the suction part of the pump,
- (e) When a reducer is used, it should be of the eccentric type. When on suction-lift, the taper side of the reducer should be below the centre line of the pump,
- (f) The suction strainer should have net open area, minimum equal to three times the area of the suction pipe.

11.3.2 DISCHARGE PIPING

- (a) The size of the discharge piping may be selected one size higher than the nominal delivery size of the pump. Alternatively, the delivery pipe should be of such size that the velocity shall be about 2.5 m/s,
- (b) Discharge piping connection to a common manifold or header should be connected by a radial tee or by 30° or 45° bend,
- (c) A dismantling joint must be provided between the pump and the valves. The design of the dismantling joint should be such that no pull or moment is transmitted to the pump.

11.3.3 VALVES

11.3.3.1 Suction Valves

- (a) When suction lift is encountered, a foot valve is provided to facilitate priming. The pump can be primed also by a vacuum pump, if the pump is of large size, usually with suction-pipe larger than NS 300 mm.

The foot valves are normally available with strainers. The strainer of the foot valve should provide net area of its openings, to be minimum equal to three times the area of the suction pipe.

- (b) When there is positive suction head, a sluice or a butterfly valve is provided on the pump suction, for isolation. The sluice valves should be installed with their axis horizontal to avoid formation of air-packets in the dome of the sluice valve.

11.3.3.2 Delivery Valves

Near to the pump, a non-return (reflux) valve and a delivery valve (sluice or butterfly valve) should be provided. The non-return valve should be between the pump and the delivery valve. The size of the valve should match the size of the piping.

11.3.3.3 Air Valves

Whenever there are distinct high points in the gradient of the pipeline, an air valve should be installed to permit expulsion of air from the pipeline. If the air is not expelled, it is likely to be compressed by the moving column of water. The compressed air develops high pressures, which can even cause the bursting of the pipeline.

Air valves also permit air to enter into the pipeline, when the pipeline is being emptied during shut down. If air would not enter during emptying, the pipeline will have vacuum inside and the atmospheric pressure externally. The pipeline would hence get subjected to undue stresses.

Details on provision and sizing of valves are given in 6.16.3.

11.3.4 SUPPORTS

All valves (including the foot valve, where necessary) and piping should be supported independent of each other and independent of the pump foundation.

11.3.5 SURGE PROTECTION DEVICES

When starting or stopping a pump (or by operating the regulating valves rapidly) certain pressure fluctuations are caused, which travel up and down in the pipeline during the transient conditions. This can cause low pressure zones, particularly at apex points on the pumping main and subsequently cause very high pressures causing hammering noise. If such pressure surges exceed the pressure permissible in the pipeline, the pipeline may even burst. To prevent against such occurrences, the recommended practices are detailed in 6.17.

11.4 SPACE REQUIREMENT AND LAYOUT PLANNING OF PUMPING SYSTEM

- (a) Sufficient space should be available in the pump house to locate the pump, motor, valves, pipings, control panels and cable trays in a rational manner with easy access and with sufficient space around each equipment for the maintenance and repairs.
The minimum space between two adjoining pumps or motors should be 0.6 m for small and medium units and 1 m for large units.
- (b) Space for the control panels should be planned as per the Indian Electricity (I.E.) Rules. As per these:
 - (i) a clear space of not less than 915 mm in width shall be provided in front of the switch board,

In case of large panels, a draw out space for the circuit breakers may exceed 915 mm. In such cases the recommendations of the manufacturers should be followed,

- (ii) If there are any attachments or bare connections at the back of the switch board, the space, if any behind the switch-board shall be either less than 230 mm or more than 750 mm in width measured from the farthest part of any attachment or conductor,
 - (iii) If the switch board exceeds 760 mm in width, there shall be a passage-way from either end of the switch-board clear to a height of 1830 mm,
- (c) A service bay should be provided in the station with such space that the largest equipment can be accommodated there for overhauling and repairs.
- (d) A ramp or a loading and unloading bay should be provided. In large installations the floors should be so planned that all pipings and valves can be laid on the lower floor and the upper floor should permit free movement.
- (e) Head room and material handling tackle.
- (i) In the case of vertical pumps with hollow shaft motors, the clearance should be adequate to lift the motor clear off the face of the coupling and also carry the motor to the service bay without interference with any other apparatus. The clearance should also be adequate to dismantle and lift the largest column assembly.
 - (ii) In the case of horizontal pumps (or vertical pumps with solid shaft motors) the head room should permit transport of the motor above the other apparatus with adequate clearance.
 - (iii) The mounting level of the lifting tackle should be decided considering the above needs and the need of the head room for the maintenance and repair of the lifting tackle itself.
 - (iv) The traverse of the lifting tackle should cover all bays and all apparatus.
 - (v) The rated capacity of the lifting tackle should be adequate for the maximum weight to be handled at any time.

11.5 INSTALLATION OF PUMPS

The procedure of installation depends upon whether the pump is to be mounted horizontal or vertical. Most pumps to be mounted horizontal are supplied by the manufacturers as a wholesome, fully assembled unit. However, pumps to be mounted vertically are supplied as sub assemblies. For the installation of these pumps the proper sequence of assembly has to be clearly understood from the manufacturer's drawings.

The installation of a pump should proceed through, five stages in the following order:

- (i) Preparing the foundation and locating the foundation bolts,
- (ii) Locating the pump on the foundation bolts, however resting on leveling wedges, which permit not only easy leveling but also space for filling in the grout later on,
- (iii) Leveling,
- (iv) Grouting,
- (v) Alignment






FIGURE 11.14 : TYPICAL FOUNDATION DESIGN

- (a) The foundation should be sufficiently substantial to absorb vibrations and to form a permanent, rigid support for the base-plate. A typical foundation is illustrated in Fig. 11.14.
- (b) The capacity of the soil or of the supporting structure should be adequate to withstand the entire load of the foundation and the dynamic load of the machinery. As mentioned in clauses 6.2.2 and 6.2.3 of IS: 2974 (Part iv) - 1979 the total load of the pump and the foundation should include the following:
 - (i) constructional loads
 - (ii) three times the weight of the pump
 - (iii) two times the total weight of the motor
 - (iv) weight of water in the column pipe
 - (v) half of the weight of the unsupported pipe connected to the pump flanges.
- (c) If the pumps are mounted on steel structures, the location of the pump should be nearest as possible to the main members (i.e. beams or walls). The sections of structurals should have allowance for corrosion also.
- (d) A curb ring or sole plate with machined top should be used as a bearing surface for the support flange of a vertical wet pit pump. The mounting face should be machined because the curb ring or sole plate is used to align the pump. Fig 11.15 shows typical arrangement with curb ring and with sole plate,
- (e) Pumps kept in storage for a long time should be thoroughly cleaned before installation,



(a) ROUND TYPE CURBING FOR ABOVE GROUND DISCHARGE VERTICAL PUMP



(b) GROUTING FORM FOR VERTICAL PUMP SOLEPLATE

FIG. 11.15 FOUNDATION FOR VERTICAL PUMPS

- (f) Submersible pumps with wet type motors should be fitted with water and the opening should be properly plugged after filling the water.
- (g) Alignment of the pump sets should be checked even if they are received aligned by the manufacturers. The alignment should be proper both for parallelism (by filler gauge) and for coaxiality (by-straight edge or by dial gauge).

During all alignment-checks both the shafts should be pressed hard, over to one side while taking the readings.

Alignment should also be checked after fastening the piping and thereafter, periodically during operation.

11.6 COMMISSIONING

It should be ensured that the direction of the motor agrees with the arrow on the pump.

A specimen test should be conducted to derive the system-head curve and to understand the actual operating point/range of the pump and the variation, if any, from the original estimated duties. In the case of variations some analysis may be done to explore any feasible modifications of the system to bring it nearer to the original estimates or to generally improve the system so that it can work better and work trouble free for long.

11.7 OPERATION OF THE PUMPS

Summarized below are a few points to be observed while operating the pumps.

- (a) Dry running of the pumps should be avoided. Centrifugal pumps have to be primed before starting. Helical rotor pumps, although they are self priming, being of the positive displacement type, need the rubber stator to be wetted before starting.
- (b) Pumps should be operated only within the recommended range on the H-Q characteristics of the pump.
Operation near to the shut off should be avoided, as in the operation near the shut off, there happens substantial recirculation within the pump, which causes over heating.
- (c) Whether the delivery valve should be open or closed at the time of starting is to be decided by studying the power characteristics of the pump.

As seen in Fig. 11.1 pumps of low and medium specific speeds draw more power as the flow increases. So to minimise the load on the motor while starting, such pumps are started with the delivery valve closed. Conversely pumps of high specific speed draw more power at shut off. Such pumps should hence be started with the delivery valve open. While stopping, the position of the delivery valve should be as at the time of starting.

- (d) The delivery valve should be operated gradually to avoid surges,
- (e) When pumps are to operate in parallel, the pumps should be started and stopped with a time lag between two pumps. The time lag should be adequate to let the pressure gauge stabilize,

- (f) When the pumps are to operate in series, they should be started and stopped sequentially, but with the minimum time lag as possible. Any pump, next in sequence should be started immediately after the delivery valve of the previous pump is even partly opened.

Due care should be taken to keep the air vent of the pump next in sequence, open before starting that pump.

- (g) The stuffing box should let a drip of leakage to ensure that no air is passing into the pump and that the packing is getting adequate water for cooling and lubrication. When the stuffing box is grease sealed, adequate refill of the grease should be maintained,

- (h) The running of the duty pumps and of the standbys should be so scheduled that all pumps are in ready-to-run condition.

11.8 MAINTENANCE OF PUMPS

11.8.1 PERIODIC INSPECTION AND TEST

The maintenance schedule should enlist items to be attended to at different periods, such as daily, semi- annually, annually, etc.

11.8.2 DAILY OBSERVATIONS

A log-book should be maintained to record the observations, which should cover the following items.

- (i) timings when the pump was run during the previous 24 hours,
- (ii) at the time of observation, whether the leakage through the stuffing box is alright,
- (iii) bearing temperature/s,
- (iv) whether any undue noise or vibration,
- (v) readings of pressure, voltage and current.

11.8.3 SEMI ANNUAL INSPECTION

- (i) free movement of the gland of the stuffing box,
- (ii) cleaning and oiling of the gland bolts,
- (iii) inspection of the packing and repacking, if necessary,
- (iv) alignment of the pump and the drive,
- (v) cleaning of oil lubricated bearings and replenishing fresh oil. If bearings are grease lubricated, the condition of the grease should be checked and replaced/replenished to correct quantity. An antifriction bearing should have its housing so packed with grease that the void spaces in the bearings and the housing be 1/3 to 1/2 filled with greases. A fully packed housing will cause the bearing to overheat and will result in reduced life of the bearing.

11.8.4 ANNUAL INSPECTION

- (i) cleaning and examination of all bearings for flaws developed, if any.
- (ii) examination of shaft sleeves for wear or scour.
- (iii) checking clearances.

Clearances at the wearing rings should be within the limits recommended by the manufacturer. Excessive clearances cause a drop in the efficiency of the pump. If the wear is only on one side, it is indicative of misalignment. Not only that the misalignment should be set right, but also the causes for the disturbance of the alignment should be investigated. When the clearances have to be redeemed to the values recommended by the manufacturers, some general guidelines detailed in Table 11.6 would come handy.

If the clearance on wear is seen to be 0.2 or 0.25 mm more than the original clearance, the wearing ring should be renewed or replaced to get the original clearance.

In using the tolerance given in Table 11.6, they are to be used unilaterally. For example, while machining the i.d. of the wearing ring of basic size, say 175 mm the limits for machining would be 175.00 minimum and 175.04 maximum. For the corresponding O.D. at the hub of the impeller, the basic size will be with a clearance of 0.35, hence 174.65 mm and the machining limits will be 174.65 maximum and 174.61 minimum.

TABLE 11.6
WEARING RING I.D. DIAMETER CLEARANCE
AND MACHINING TOLERANCE

Inside dia. of wearing ring mm	Diametral clearance mm	Machining Tolerance mm
upto100	0.3	0.04
100-150	0.35	0.04
150-200	0.4	0.06
200-300	0.45	0.06
300-500	0.55	0.06
500-750	0.58	0.06
750-1200	0.69	0.08
1200-2000	0.79	0.1

- (iv) Impeller hubs and vane tips should be checked for any pitting or erosion.
- (v) End play of the bearings should be checked.
- (vi) All instruments and flow meters should be recalibrated.
- (vii) Pump should be tested to determine whether proper performance is being obtained. In the case of vertical turbine pumps, the inspection can be bi-annual. Annual inspection is not advisable, because it involves disturbing the alignment and clearances.

11.8.5 FACILITIES FOR MAINTENANCE AND REPAIRS

11.8.5.1 Consumables And Lubricants

Adequate stock of such items as gland packings, belts, lubricating oils, greases should be maintained.

11.8.5.2 Replacement Spares

To avoid downtime, a stock of fast moving spares should be maintained. A set of recommended spares for two years of trouble free operation should be ordered alongwith the pump.

11.8.5.3 Repair Work-Shop

The repair workshop should be equipped with:

- ◆ tools such as bearing, pullers, clamps, pipe wrenches, etc.
- ◆ general-purpose machinery such as welding set, grinder, blower, drilling machine, etc.

11.9 TROUBLE SHOOTING

The check charts detailed in Tables 11.7, 11.8 and 11.9 provide guidelines for diagnosing the causes of troubles likely to arise during the operation of centrifugal, rotary and reciprocating pumps, respectively. As remedial measures, the cause/s of the trouble will have to be corrected.

TABLE 11.7
CHECK CHART FOR CENTRIFUGAL PUMP TROUBLES

Symptoms	Possible cause of trouble (Each number is defined in the list below)
Pump does not deliver water:	1, 2, 3, 4, 6, 11, 14, 16, 17, 22, 23
Insufficient capacity delivered:	2, 3, 4, 5, 6, 7, 8, 9, 10, 11, 14, 17, 20, 22, 23, 29, 30, 31.
Insufficient pressure developed.	5, 14, 16, 17, 20, 22, 29, 30, 31.
Pump loses prime after starting.	2, 3, 5, 6, 7, 8, 11, 12, 13
Pump requires excessive power	15, 16, 17, 18, 19, 20, 23, 24, 26, 27, 29, 33, 34, 37.
Stuffing box leaks excessively:	13, 24, 26, 32, 33, 34, 35, 36, 38, 39, 40.
Packing has short life.	12, 13, 24, 26, 28, 32, 33, 34, 35, 36, 37, 38, 39, 40.

Symptoms	Possible cause of trouble (Each number is defined in the list below)
Pump vibrates or is noisy:	2, 3, 4, 9, 10, 11, 21, 23, 24, 25, 26, 27, 28, 30, 35, 36, 41, 42, 43, 44, 45, 46, 47.
Bearings have short life:	24, 26, 27, 28, 35, 36, 41, 42, 43, 44, 45, 46, 47
Pump overheats and seizes.	1, 4, 21, 22, 24, 27, 28, 35, 36, 41

SUCTION TROUBLES

1. Pump not primed.
2. Pump or suction pipe not completely filled with liquid.
3. Suction lift too high.
4. Insufficient margin between suction pressure and vapour pressure.
5. Excessive amount of air or gas in liquid.
6. Air pocket in suction line.
7. Air leaks into suction line.
8. Air leaks into pump through stuffing boxes
9. Foot valve too small
10. Foot valve partially clogged.
11. Inlet of suction pipe insufficiently submerged.
12. Water-seal pipe plugged.
13. Seal cage improperly located in stuffing box, preventing sealing fluid from entering space to form the seal.

SYSTEM TROUBLES

14. Speed too low.
15. Speed too high.
16. Wrong direction of rotation.
17. Total head of system higher than design head of pump.
18. Total head of system lower than pump design head.
19. Specific gravity of liquid different from design.
20. Viscosity of liquid different from that for which designed.
21. Operation at very low capacity.
22. Parallel operation of pumps unsuitable for such operation.

MECHANICAL TROUBLES

23. Foreign matter in impeller.

24. Misalignment.
25. Foundations not rigid.
26. Shaft bent.
27. Rotating part rubbing on stationary part.
28. Bearings worn.
29. Wearing rings worn.
30. Impeller damaged.
31. Casing gasket defective, permitting internal leakage.
32. Shaft or shaft sleeves worn or scored at the packing.
33. Packing improperly installed.
34. Incorrect type of packing for operating conditions.
35. Shaft running off center because worn bearings or misalignment.
36. Rotor out of balance, causing vibration.
37. Gland too tight, resulting in no flow of liquid to lubricate packing.
38. Failure to provide cooling liquid to water cooled stuffing boxes.
39. Excessive clearance at bottom of stuffing box between shaft and casing, causing packing to be forced into pump interior.
40. Dirt or grit in sealing liquid leading to scoring of shaft or shaft sleeve.
41. Excessive thrust caused by a mechanical failure inside the pump or by the failure of the hydraulic balancing device, if any.
42. Excessive grease or oil in anti-friction bearing housing or lack of cooling, causing excessive bearing temperature.
43. Lack of lubrication.
44. Improper installation of anti-friction bearings (damage during assembly, incorrect assembly of stacked bearings, use of unmatched bearings as a pair, etc.)
45. Dirt in bearings.
46. Rusting of bearings from water in housing.
47. Excessive cooling of water-cooled bearing, resulting in condensation of moisture from the atmosphere in the bearing housing.

TABLE 11.8
CHECK CHART FOR ROTARY PUMP TROUBLES

Symptoms	Possible cause of trouble (Each number is defined in the list below)
Pump fails to discharge	1, 2, 3, 4, 5, 6, 8, 9, 16
Pump is noisy	6, 10, 11, 17, 18, 19
Pump wears rapidly	11, 13, 13, 23, 24
Pump not up to capacity.	5, 5, 6, 7, 9, 16, 21, 22
Pump starts, then loses suction.	1, 2, 6, 7, 10
Pump takes excessive Power	14, 15, 17, 20, 23

SUCTION TROUBLES

1. Not properly primed
2. Suction pipe not submerged
3. Strainer clogged
4. Leaking foot valve
5. Suction lift too high
6. Air leaks in suction.
7. Suction pipe too small

SYSTEM PROBLEMS

8. Wrong direction of rotation.
9. Low speed
10. Insufficient liquid supply.
11. Excessive pressure.
12. Grit or dirt in liquid.
13. Pump runs dry
14. Viscosity higher than specified.
15. Obstruction in discharge line.

MECHANICAL TROUBLES

16. Pump worn.

17. Bent drive shaft
18. Coupling out of balance or alignment.
19. Relief valve chattered.
20. Pipe strain on pump casing
21. Air leak at packing.
22. Relief valve improperly seated
23. Packing too tight.
24. Corrosion.

TABLE 11.9
CHECK CHART FOR RECIPROCATING PUMP TROUBLES

Symptoms	Possible cause of trouble (Each number is defined in the list below)
Liquid end noise.	1, 2, 7, 8, 9, 10, 14, 15, 16
Power end noise.	17, 18, 19, 20
Overheated power end:	10, 19, 21, 22, 23, 24.
Water in crankcase	25
Oil leak from crankcase	26, 27
Rapid packing or plunger wear.	11, 12, 28, 29.
Pitted valves or seats	3, 11, 31.
Valves hanging up	31, 32
Leak at cylinder valve hole plugs	10, 13, 33, 34
Loss of prime.	1, 4, 5, 6

SUCTION TROUBLES

1. Insufficient suction pressure
2. Partial loss of prime.
3. Cavitation.
4. Lift too high
5. Leaking suction at foot valve
6. Acceleration head requirement too high.

11.10 SELECTION OF ELECTRIC MOTORS

11.10.1 GENERAL

In water supply systems, mainly three types of motors are used:

- ◆ Induction (A.C.) motors
- ◆ Synchronous (A.C.) motors.
- ◆ D.C. motors

Amongst these, induction motors are the most common.

Synchronous motors merit consideration when large HP, low speed motors are required. D.C. motors are used occasionally for pumps where only direct current is available as in ships, railways, etc.

11.10.2 SELECTION CRITERIA

Type of motor has to be selected considering various criteria such as the constructional features desired, environmental conditions, type of drive, etc.

11.10.2.1 Constructional Features Of Induction Motors

Squirrel cage motors are most commonly used. Normally the starting torque requirement of centrifugal pumps is quite low and squirrel cage motors are therefore suitable.

Slip ring or wound rotor motors are to be used where required starting torque is high as in positive displacement pumps or for centrifugal pumps handling sludge.

The slip ring motors are also used when the starting current has to be very low, such as 1/3 of the full load current, such regulatory limits being specified by the Power Supply Authorities.

11.10.2.2 Method Of Starting

Squirrel cage motors when started direct on line (with DOL starter) draw starting current about 6 times the full load (FL) current. If the starting current has to be within the regulatory limits specified by the Power Supply Authorities, the squirrel cage motors should be provided with the star delta starter or auto transformer starter.

11.10.2.3 Voltage Ratings

Table 11.10 would give general guidance on the standard voltages and corresponding range of motor ratings.

For motors of rating 330 kW and above, where high tension (HT) voltages of 3.3 KV, 6.6 KV and 11 KV can be chosen, the choice should be made by working out relative economics of investment and running costs, taking into consideration costs of transformer, motor, switchgear, cables etc.

TABLE 11 (Contd.)

STATISTICAL COMPUTATIONS BASED ON MULTIVARIATE DATA

Type	Sample size	Range of Error	
		1000000	10000000
Exact method	10000	0.0	2.1
Exact method	100000	0.0	2.1
	1000000	0.0	7.0
	10000000	0.0	0.0
	100000000	0.0	0.0
Exact method	100000000	0.0	0.0

Note: The error is the number of incorrect results received. The error is zero means correct results were received in all cases.

TABLE 12 (Contd.)

STATISTICAL COMPUTATIONS

Type	Statistical code	Observed
Exact method	1000000	10000000
	10000000	10000000
Exact method	100000000	10000000000
	1000000000	10000000000
	10000000000	1000000000000

Exact method is given in item

1. The error is zero. The number of incorrect results is given in the observed column.

1) - independent environmental indicators - level of compliance with environmental legislation

2) - measures to deal with the negative effects of any activity

13.2.4 - Evaluation

Choi (1994) has proposed the following measures to evaluate the performance of:

1) - a company's environmental performance - the environmental performance of a company is considered

2) - the environmental management system - the environmental management system is evaluated

13.2.5 - Scientific & Sectoral Rating

More recently, a paper by the Institute for Environmental Studies (IES), University of Toronto, has introduced a performance rating system for the environmental performance of companies.

THE SCORING

QUALITY FACTORS

The measures of environmental performance (EPI) are based on the following factors: 1) - the environmental performance of a company is evaluated 2) - the environmental performance of a company is evaluated 3) - the environmental performance of a company is evaluated

THE SCORING SYSTEM FOR THE ENVIRONMENTAL PERFORMANCE

Several environmental indicators, which are measured as a percentage of the total score (EPI) of the company. The environmental performance of a company is measured as a percentage of the total score (EPI) of the company.

Table 13.1

THE SCORING SYSTEM FOR THE ENVIRONMENTAL PERFORMANCE OF A COMPANY

Type of Factor	Percentage of total score	Structure of the factor	Relative importance of the factor
Quality	50%	Environmental	10%
Quantity	50%	Environmental	10%
Quantity	50%	Environmental	10%
Quantity	50%	Environmental	10%
Quantity	50%	Environmental	10%
Quantity	50%	Environmental	10%

Note : As per the torque speed characteristics of the motor, the torque of the motor at the chosen percentage of reduced voltage should be adequate to accelerate the pump to the full speed.

11.11.2.1 Selection Of The Tapping Of Auto Transformer Type Starter

The torque available from the motor is generally much higher than the starting torque required by the pump, as the starting torque required by the pump is also regulated by starting the pump with the delivery valve closed or open, depending upon the nature of the power versus Q characteristics of the pump.

The torque available from the motor being more than the starting torque required by the pump draws an unnecessary excessive current. This can be controlled as the torque available from the motor varies as the square of the applied voltage. For reducing the excessive torque available from the motor, the voltage to be applied to the motor can be reduced by selecting the appropriate percentage tapping on the auto transformer starter. The value of the percentage for the tapping position can be decided by the following formula

$$\text{Tapping\%} = 100 \times \sqrt{\frac{\text{Torque for pump}}{\text{Torque for motor}}}$$

where,

Torque for pump is the torque required by the pump at its rated speed and at its maximum power demand, and

Torque from motor is the torque available from the motor at its full load capacity at its rated speed at rated voltage.

Based on the above calculation, the nearest higher available position of tapping should be selected.

11.12 PANELS

11.12.1 REGULATIONS

The regulations, as per I.E. Rules, in respect of space to be provided around the panel are detailed under 11.4.

11.12.2 VARIOUS FUNCTIONS

The various functions, which the panel has to receive and the corresponding provisions to be made in the panel are detailed below:

1. For receiving the supply – Circuit breaker or switch and fuse units.
2. For distribution – Bus bar, Switch fuse unit, circuit breaker.
3. For controls – Starters, level controllers, electrical flow - devices.
4. As protections – Under voltage relay, Over current relay, D.O. (Auto reset), Single Phasing Protection.

1. The program will be a success if the following conditions are met:
a. The program is properly implemented.
b. The program is properly monitored.
c. The program is properly evaluated.

2. The program will be a success if the following conditions are met:
a. The program is properly implemented.

3. The program will be a success if the following conditions are met:

a. The program is properly implemented.
b. The program is properly monitored.

4. The program will be a success if the following conditions are met:
a. The program is properly implemented.

5. The program will be a success if the following conditions are met:

a. The program is properly implemented.
b. The program is properly monitored.
c. The program is properly evaluated.
d. The program is properly implemented.
e. The program is properly monitored.
f. The program is properly evaluated.
g. The program is properly implemented.
h. The program is properly monitored.
i. The program is properly evaluated.

6. The program will be a success if the following conditions are met:
a. The program is properly implemented.
b. The program is properly monitored.
c. The program is properly evaluated.
d. The program is properly implemented.
e. The program is properly monitored.
f. The program is properly evaluated.

7. The program will be a success if the following conditions are met:

a. The program is properly implemented.

b. The program is properly monitored.

c. The program is properly evaluated.

d. The program is properly implemented.
e. The program is properly monitored.
f. The program is properly evaluated.

g. The program is properly implemented.
h. The program is properly monitored.

i. The program is properly implemented.
j. The program is properly monitored.

k. The program is properly implemented.
l. The program is properly monitored.
m. The program is properly evaluated.
n. The program is properly implemented.
o. The program is properly monitored.
p. The program is properly evaluated.

TABLE 11.13

RECOMMENDED CAPACITOR RATING FOR DIRECT CONNECTION TO INDUCTION MOTORS
 (◊ improve power factor to 0.95 or better)

Motor H.P.	Capacitor rating in KVAR when motor speed is						Capacitor rating in KVAR when motor speed is					
	1500 r.p.m.	1000 r.p.m.	750 r.p.m.	600 r.p.m.	500 r.p.m.	Motor H.P.	3000 r.p.m.	1500 r.p.m.	1000 r.p.m.	750 r.p.m.	600 r.p.m.	500 r.p.m.
2.5	1	1.5	2	2.5	2.5	1.5	22	24	27	29	36	41
5	2	2.5	3.5	4	4	110	23	25	28	30	38	43
7.5	3	3.5	4.5	5	5.5	115	24	26	29	31	39	44
10	4	4.5	5.5	6	6.5	120	25	27	30	32	40	46
12.5	4.5	5	6.5	7.5	8	125	26	28	31	33	41	47
15	5	6	7.5	8.5	9	130	27	29	32	34	43	49
17.5	5.5	6.5	8	9	10.5	135	28	30	33	35	44	50
20	6	7	9	11	12	140	29	31	34	36	46	52
22.5	6.5	8	10	12	13	145	30	32	35	37	47	54
25	7	9	10.5	13	14.5	50	31	33	36	38	48	55
27.5	7.5	9.5	11.5	14	16	55	32	34	37	39	49	56
30	8	10	12	15	17	60	33	35	38	41	50	57
32.5	8.5	11	13	16	18	65	34	36	39	42	51	59

Capacitor rating in KVA when motor speed is

Motor	3000	3600	4200	4800	5400	6000	6600	7200	7800	8400	9000	9600	10200	10800	11400	12000
HP	3	5	7.5	10	15	20	25	30	35	40	45	50	55	60	65	70
cos φ	0.85	0.85	0.85	0.85	0.85	0.85	0.85	0.85	0.85	0.85	0.85	0.85	0.85	0.85	0.85	0.85
Motor	3000	3600	4200	4800	5400	6000	6600	7200	7800	8400	9000	9600	10200	10800	11400	12000
HP	3	5	7.5	10	15	20	25	30	35	40	45	50	55	60	65	70
cos φ	0.85	0.85	0.85	0.85	0.85	0.85	0.85	0.85	0.85	0.85	0.85	0.85	0.85	0.85	0.85	0.85

Capacitor rating in KVA when motor speed

Capacitor rating in KVA when motor speed

Motor	100	150	200	250	300	350	400	450	500	550	600	650	700	750	800	850	900	950	1000
Cap	1.0	1.5	2.0	2.5	3.0	3.5	4.0	4.5	5.0	5.5	6.0	6.5	7.0	7.5	8.0	8.5	9.0	9.5	10.0

Note: The motor speed is given in rpm. The capacitor rating is given in KVA. The capacitor rating is given in KVA. The capacitor rating is given in KVA.

- (d) While making a test, the high voltage circuit and interlocks should never be removed or disconnected. The voltage must be gradually increased or reduced through 100% of the test voltage before the test voltage is applied or removed. This may otherwise result in an electrical fire or personal injury.
- (e) Remove the variables, fuses and circuitry of the capacitor bank.

11.12.3.3 Operation And Maintenance Of Capacitor.

- (a) The supply voltage of the capacitor bank should always be not more than the voltage of the capacitor winding insulation. It is desirable to use a shock free circuit breaker for starting and stopping the capacitor.
- (b) The parameters of the capacitor should be checked at a regular interval. The maximum allowed 60 percent increase in the following operations.
 - (i) The discharge resistance allowed an upper limit should be checked. If a warning showing is observed, it indicates the capacitor is not working properly. It should be off. If the discharge resistance falls below the lower limit, the capacitor should be replaced or made to be repaired.
 - (ii) Leakage or leakage from the capacitor should be checked. It should be checked at a regular interval. If a large amount of leakage is observed, it should be replaced.
 - (iii) Before physically handling the capacitor, the capacitor must be discharged. It is advised that a discharge resistor should be connected in parallel with the capacitor.

11.13 CABLES

Table 11.13 gives guidance of the types of cable used in the distribution system.

TABLE 11.13

TYPES OF CABLES FOR DIFFERENT VOLTAGES

Sl. No.	Voltage (kV) range	Types of cable system	IS No.
1	0.250-1.1 kV 0.415 kV	PVC insulated and cross-linked	IS 4724
2	1.1-10 kV	PVC insulated, PVC sheathed	IS 1554
		Thermosetting resin sheathed	IS 692
		Non-metallic sheathed, fibre braided insulated PVC sheathed	IS 7098
3	11 kV	Paper insulated and sheathed	IS 632

we have the cube root of a is $a^{1/3}$ and the cube root of a^2 is $a^{2/3}$. When we cube $a^{1/3}$, we get a and when we cube $a^{2/3}$, we get a^2 . The cube root of a^2 is $a^{2/3}$ because $(a^{2/3})^3 = a^2$.

Therefore, the cube root of a^2 is $a^{2/3}$ and the cube root of a^3 is a .

- The cube root of a^2 is $a^{2/3}$ and the cube root of a^3 is a .
- The cube root of a^4 is $a^{4/3}$ and the cube root of a^5 is $a^{5/3}$.
- The cube root of a^6 is a^2 and the cube root of a^7 is $a^{7/3}$.
- The cube root of a^8 is $a^{8/3}$ and the cube root of a^9 is a^3 .
- The cube root of a^{10} is $a^{10/3}$ and the cube root of a^{11} is $a^{11/3}$.
- The cube root of a^{12} is a^4 and the cube root of a^{13} is $a^{13/3}$.
- The cube root of a^{14} is $a^{14/3}$ and the cube root of a^{15} is a^5 .
- The cube root of a^{16} is $a^{16/3}$ and the cube root of a^{17} is $a^{17/3}$.
- The cube root of a^{18} is a^6 and the cube root of a^{19} is $a^{19/3}$.
- The cube root of a^{20} is $a^{20/3}$ and the cube root of a^{21} is a^7 .

4.1.7. THE CUBE ROOT OF A NUMBER

4.1.7.1. THE CUBE ROOT OF A NUMBER

The cube root of a number a is the number b such that $b^3 = a$. The cube root of a is denoted by $\sqrt[3]{a}$.

- The cube root of a is $a^{1/3}$.
- The cube root of a^2 is $a^{2/3}$ and the cube root of a^3 is a .
- The cube root of a^4 is $a^{4/3}$ and the cube root of a^5 is $a^{5/3}$.
- The cube root of a^6 is a^2 and the cube root of a^7 is $a^{7/3}$.
- The cube root of a^8 is $a^{8/3}$ and the cube root of a^9 is a^3 .
- The cube root of a^{10} is $a^{10/3}$ and the cube root of a^{11} is $a^{11/3}$.
- The cube root of a^{12} is a^4 and the cube root of a^{13} is $a^{13/3}$.
- The cube root of a^{14} is $a^{14/3}$ and the cube root of a^{15} is a^5 .
- The cube root of a^{16} is $a^{16/3}$ and the cube root of a^{17} is $a^{17/3}$.
- The cube root of a^{18} is a^6 and the cube root of a^{19} is $a^{19/3}$.
- The cube root of a^{20} is $a^{20/3}$ and the cube root of a^{21} is a^7 .

Example: Find the cube root of 8 . Solution: The cube root of 8 is 2 because $2^3 = 8$.

11.14.2 DUPLICATION TRANSFORMS RENTY OF OTHERS. EQUIPMENT INSTALLATION STANDARDS

11.15 MAINTENANCE AND REPAIRS OF THE EQUIPMENT ACQUISITION

11.15.1 CONSUMPTION

Appropriate stock of consumables and spare parts should be maintained.

11.15.2 REPLACEMENT PARTS

The part of the equipment which is damaged or worn out should be replaced by most efficient and economical. A stock of spare parts should be maintained for a period of six to twelve months of the equipment.

11.15.3 TOOLS AND TEST EQUIPMENT

Tools and test equipment which are damaged and worn out should be replaced by the best.

11.15.4 PREVENTIVE MAINTENANCE

Preventive maintenance schedule should be established and a number of the equipment should be available for inspection. The schedule and maintenance should be checked and revised regularly. The schedule should be checked and revised regularly. The schedule should be checked and revised regularly.

11.15.11 Daily

(a) Pre-Start

- (i) Check the engine oil level.
- (ii) Check the water level in the radiator.

(b) Pre-park, pre-travel, or return

- (i) Check the parking brake.
- (ii) No to be any oil or fuel leaks.
- (iii) No to be any air leaks.

(c) Pre-transformation and start

- (i) No to be any oil or fuel leaks.

11.15.12 Weekly

(a) Pre-park, pre-travel, or return

(b) Pre-park, pre-travel, or return

- (i) Check the engine oil level.
- (ii) Check the water level in the radiator.
- (iii) Check the parking brake.
- (iv) Check the engine oil level.
- (v) Check the engine oil level.

(vi) For 110 kV or above substations

- (a) Check the level of the transformer oil
- (b) Check that the operation of the O.C.D. is okay
- (c) Check status of the O.C.D. and/or auto-recloser (A.R.) relay
- (d) Check temperatures of the oil, hot air and arcing
- (e) Check meters to be free of dust and scales
- (f) Check the status of the air and the bush

11.13.4.3 Quarterly

(a) For 110 kV

- (i) Blow away dust and dirt away especially at oil or grease
- (ii) Check level of shunting and bushing insulating components or replace, if necessary. Check spring tension. Check bush setting for proper contact on the top ring.
- (iii) Check status connections and terminals. Insulation of the cable near the tags, check all cables, if insulation is damaged, by so doing, investigate and rectify. All connections should be done tight.

(b) For 220 kV or above substations

- (i) Check shunt and shunting contacts at the circuit breakers, switches. Check and clean other contacts with fine glass paper or silk.
- (ii) Check status and quantity of shunt gaps in circuit breaker, auto-transformer status and busbar controller.

(c) For transformer substations

- (i) Check condition of the O.C.D. winding

Check the condition of the condenser of bushing and replace for silicified charge, if necessary. Reactivate old charge for reuse.

11.13.4.4 Semi-Annual

(a) For 110 kV

- (i) Check condition of oil or grease and replace, if necessary. With greasing, avoid excessive greasing.
- (ii) Insulation by the pipe

(b) For 220 kV, etc

Check for corrosion and take corrective measures. Check by megger the insulation resistance of switches, bushing, arcing terminals, auto-reclosers, etc. for phase-to-earth and phase-to-phase resistance.

(c) For transformer substations

- (d) Check for any cracks in the wrap.
- (e) Check that there is no leakage (dry or single phase).
- (f) Check also that any Foreign matter has entered the air-gap, causing obstructions to the smooth operation of the motor.

11.16.3 SCALING/DESKALER FRIS

- (a) Check whether the motor is properly grounded, the settings if necessary.
- (b) Check that the motor is running at speed & drawing more than the rated current, for which it is rated, at normal voltage.
- (c) Check if the motor may be either underloaded or of low efficiency.
- (d) Check that there are no loose connections.
- (e) Check whether the correct setting of a motor or auto transformer circuit is proper.

11.16.4 VIBRATIONS IN MOTOR

- (a) Check for structural rigidity in supporting frame and foundation.
- (b) Check for quality of pump motor.
- (c) Check for the correct condition of the supply.
- (d) Check if there is any unbalance.
- (e) Check if the machine runs smoothly up to various at handovers or from critical speed of the motor (resonance vibration) of the pump equipment.

11.16.5 CABLES GET OVERHEATED

- (a) Check whether the cable is overloaded & change the cable if possible another cable is possible.
- (b) Check for the insulation of the motor, the transformer & the cable properly and
- (c) Check & add only a few strands of the cable are inserted in the bag, insert all strands only a few if necessary.

CHAPTER 12

INSTRUMENTATION AND CONTROLS IN WATER TREATMENT PLANT

12.1 INTRODUCTION

Instrumentation and control plays an important role in efficient and effective operation of any water treatment plant. In order to maintain the quality and quantity of water produced and to have trouble free operation of water treatment plant, it is desirable to provide proper instrumentation and control system in the plant. The impact of sudden changes in raw water quality, peak demands and seasonal variations require quick responses and proper action. This is possible only if the plant is provided proper instrumentation and control systems.

This chapter covers the general applications of instrumentation and control system in water treatment plant. Water treatment plant equipments are generally of a rugged nature and not prone to such mechanical defects. However, therefore, can be desirable to zoom in for complex automatic control systems.

12.2 PURPOSE AND OBJECTIVE

The purpose and objectives of instrumentation & Control system in a water treatment plant are:

- (a) To produce water at a low cost in the long run.
- (b) To control certain key functions in order to maintain balance in plant processes.
- (c) To obtain plant operating data such as (i) characteristics of raw & treated water, in flow and quantity measurements including the record of consumables.
- (d) To guide the operator by providing all related data for efficient functioning of various units of water treatment plant.

12.2.1 INSTRUMENTS & CONTROL SYSTEMS

The instruments and control systems when properly applied and used will provide:

- (i) Precision of operation and instantaneous response to changes in important process variable.
- (ii) Indication and recording of key processes (e.g.)
- (iii) Means of better utilization of manpower and treatment chemicals and reduction in down time due to disruptions in normal operating procedure.

The integration of a computer system into a process is usually a two-stage process. First, what are the essential system functions considered as a part from the point of view of safety of the process (e.g., control and operation) and what constitute the essential systems. The essential systems are developed by the engineer and the operators. Once all the systems are considered what does the computer do in the system function. The data and information generated would be related to the process variables.

12.2 SYSTEMS ANALYSIS

The main purpose of any computerized control system is to control plants and

- a) to control,
- b) to measure,
- c) to record,
- d) to perform mathematical
- e) to display control.

12.3.1 MEASUREMENT

The measurement system is the hardware and software for the measurement of parameters. The specific parts of the measurement system are as follows: a) measurement principle, b) sensors, plants, cables and parts, c) data module, d) transmitters, gauges, flow indicators and flow measuring devices.

12.3.2 INSTRUMENTS

The instrument operated, transmitted, and received by the system uses about 10% and altered are 1% and transmission and power is the 10% of the total. The control of the system is the 10% of the total. The system is operated by the system.

12.3.3 CONTROL

The control system is the system which is used to control the system. The control system is the system which is used to control the system. The control system is the system which is used to control the system.

12.3.4 TRANSMISSIONS

The transmission system is the system which is used to transmit the data. The transmission system is the system which is used to transmit the data. The transmission system is the system which is used to transmit the data.

12.3.5 DISPLAY DEVICES

The display device is the system which is used to display the data. The display device is the system which is used to display the data. The display device is the system which is used to display the data.

12.3.6.5 MANUAL CONTROL

The operator, with direct control of water treatment plant can be manual, starting, stopping, or adjusting.

The system to be adopted will depend upon location, capacity, skilled man power available, spare parts availability etc. The adoption of any particular system also depends upon the development of the extent of information required by the operating personnel for proper operation of the plant.

12.3.6.6 Manual

This class of models do use of instruments to read plant variables manually. Adjustment of the processes take a required are made manually by turning of a dial, pushing a button or such simple operation.

12.3.6.7 Semi-Automatic

This class of models for use of instruments to automatically control a function or series of functions, with set points set manually or by room to push of a button an automatic sequence operation program.

12.3.6.8 Automatic

The control models use instruments to automatically control and maintain in balance the process of flow rate. A close loop system is used with feed back of signal or when there is change in any process variable, the change is sensed and transmitted to a control instrument that adjust the flow to restore the system to balance.

12.4 DESIGN PRINCIPLES AND PRACTICES

The general "Standard" design for instrumentation or control system applied to a water treatment plant. However, there are a number basic considerations that govern the application of instrumentation, and general to water treatment plant design concepts regardless of plant capacity, water quality or main process factors. Examples of these considerations include flow measurements, rate controllers, loss of head control, and level indication, etc.

The various measurements of control system, trends, etc. are grouped so that requirements can be checked based on the principle:

12.5 LEVEL MEASUREMENT

Level measuring instruments are commonly available in containers of all types. They are inherently simple in construction. They are not reserved or used available, due to wide range of processes surface the demand. Inertness, detection, easy setup methods have been developed. With the exception of venturi measurement, all measuring method determine the volume of liquid in the container by measuring the level within the container. The possible methods are:

- (b) Mechanical measuring methods. Here mechanical devices are employed such as floats, mechanisms, float operated systems, use of strain gauges etc.
- (c) Physical measuring methods. Here certain physical characteristics are utilised such as electrical conductivity (for acid), use of optical orasonic beams etc.

12.5.1 ESSENTIAL INSTRUMENTS

The following level measuring instruments are considered essential:

(a) Chemical Tanks

Each chemical tank in the plant should be provided with float operated type local level indicator except in cases where the line tanks have MS cup type agitators rotating in the horizontal plane which lead to fluctuating solution levels. Float and wire rope should be of corrosion resistant material. The indicator should be either vertical arrow scale type or horizontal arrow scale type but the graduations should be of such a size that reading can be varied clearly from a distance not less than 2.5 to 3.0 m.

(b) Overhead Tank

Generally all water treatment plants have an overhead tank which caters to the water requirements for chemical solution preparation and filter backwashing. The overhead tank is usually at a higher elevation. It is necessary to have a remote indication of the water level in overhead tank in the filter house or chemical house or near overhead tank filling pumps in case the overhead tank is filled by pumps in the treatment plant area. In case of a float operated level indicator, the float should be 2 to 316 or equivalent and coupled to a wire transmitter for signal for remote indication.

(c) Tanks/Sumps

In a battery of the pumps agitated or running, each tank/sump where draw-off is by sumping, should be provided with magnetic type or electronic level switch which will be actuated by low level in the tank. It is advisable to instal dipper type tank top mounted magnetic or electronic remote switches. It should also be possible to adjust the actuation level of these switches in field. The auto stopping of respective pumps should be controlled

through these level switches. Level switch dispenser and wire rope should be of SS 316 while switch assembly may be housed in Al-alloy enclosure, which should be weatherproof.

(d) Loss Of Head For Filters

For loss of head across filter, a float operated direct reading meter is used. The pressure of water beyond the filter outlet valve and the pressure of water above the sand filter are directly transmitted to float chambers where two different floats correspond to the two different levels. Separate chain, sprocket and counter weight arrangements are used that raise the indicator pointer over the engraved dial to show in one case and the dirt itself in case of the second level. The dial and the indicator pointer move in the same direction and the difference between two levels in two different tanks is obtained directly from the gauge calibrated accordingly. A more simple system is obtained when differential is available in a graduated glass tube manometer.

The floats used for the flow of head meters generally of 100, but in cases where the water pressure is very low a R.F. or any other corrosion resistant material can be used for longer trouble free life.

12.6 FLOW MEASUREMENT

In treatment of water, distribution is made on a wide scale and many of the measurement of water quantities.

- (a) Open system where flow rate is a function of water level.
- (b) Closed system where flow rate is a function of liquid level.

Open system has its specific applications. This method is used where water supply is transmitted by gravity, whereas the second method is normally used where the flow is under pressure.

The flow measurement in open channel requires the flow section to be well defined on both side. The water flowing through the channel has a free surface and cross section of channel is restricted in order to increase the velocity of the liquid. The acceleration results from the

measurement of potential energy. The resulting head difference is related to the measurement of flow rate.

Various systems have been developed using this basic principle to measure the flow for many types of water treatment plant. The instruments for this purpose can be of either type:

- (i) Flow rate measurement with flow pipe.
- (ii) Flow rate measurement with level in a pipe.
- (iii) Flow rate measurement with constant velocity pipe section.
- (iv) Flow rate measurement with velocity head at orifice.

Each system has its own advantages and disadvantages. The orifice flow relation may be used on a case to case basis. Generally the application of orifice flow measurement is not suitable for water treatment plants because in a typical orifice flow measurement, the flow rate is dependent on the head of water in the pipe. Parallel flow relation may be used for constant flow devices. Flow pipe flow rate measurement should be used for pipe material of solid but porous or thin wall sections. Velocity head measurement is also incorporated in the orifice measurement. However, the orifice device should be equipped with flanking material such as brick, or concrete or high density atmosphere up to 0.5% RH.

The methods employing tank operation and drainage flow rate system have inherent disadvantages and hence they are seldom used.

The system which is becoming very popular for water application is the ultrasonic device. Due to the freedom of movement, lack of contact, smaller size and ease of transmission of ultrasonic devices, its accuracy and reliability is better than other flow devices. The channel transmits a beam of ultrasonic signal which is reflected from the surface of the water and returns an echo. In travelling time of signal is a proportion of the water level. The measuring principle gives rise to linear current which is proportional to the level and presents it to a linearizer which gives the direct linear output proportional to flow rate.

More accurate, analog/digital converter is used in the case of the output of linear. Since the number of codes is finite, various pair of the instrument and the number of flow measuring, such system with a pair of instruments.

2.5.1 FLOW MEASUREMENT BY ORIFICE METHOD

These flow measurement is based on mass balance principle. Because the density change of the gases cannot be neglected, the flow rate is determined from the equation. Size of measuring device is not determined.

1. Orifice nozzle or nozzle
2. Venturi tube
3. Flow tube
4. Variable area meter
5. Rotameter or variable area tube
6. Laser doppler flow meter
7. Ultrasonic flow meter

(A) *Orifices/Nozzle Meter*

This is based on the principle that fluid is projected by the pressure in tube and create jet of speed proportional to the square root of the pressure drop. Since the kinetic energy of the flow is converted into heat energy, the remaining is mainly static pressure. The nozzle should not be too small, because strong solid is required.

(B) *Venturi Tube*

This operates on a principle that a fluid in a pipe that constricts, but contains a convergent and a section of known shape and area will cause a pressure drop at the restriction site. The difference in pressure between sites and the flow is directly proportional to the square of the flow. In a venturi, generally, $Q = 0.75 \sqrt{\Delta P}$ of accuracy. The venturi tube must run full all times.

(c) Pitot Tubes

Pitot tubes operate on the principle where velocity head is converted to static through a meter section that contains a convergent and a section of known shape and area will cause a pressure drop at its restriction area. The difference between inlet and throat pressure is proportional to the square of the flow. Each tube must be calibrated individually. The accuracy of pitot tubes is around $\pm 1\%$ of actual flow rate. Pipe rough piping configurations substantially affect the accuracy of measurements.

(d) Variable Area Meter

This meter or float meter operates on the principle with float position a function of viscous drag that is differential head or pressure. In the variable area meter, the constriction area varies while maintaining an essentially constant pressure drop.

The meter consists of a plenum on top and an upright tapered tube. This plenum is filled with a gas of equal density to the liquid being measured upward and downward. The sensing area attached to the tube is essentially meter. Because of constant differential pressure, the accuracy is usually $\pm 2\%$ of actual flow rate.

(e) Venturi or Parabolic Nozzle

This operates on the principle that as a flow through a partly filled and properly graded pipe when passed through a nozzle or orifice will produce a hydraulic head at a specific area of constriction. This may be essentially directly proportional to flow provided nozzle has fine discharge. The accuracy is a function of $(h \pm 0.01)$.

(f) Electro Magnetic Flow Meter

This meter has an insulating ceramic and operates on the principle that any conductor such as a bar of steel or column of conductive liquid passing through the lines of force of a axial magnetic field which generates an electromotive force (e.m.f. voltage) directly proportional to rate at which the conductor is moving through the field. Each meter requires calibration and must run full at all times. The system accuracy is $\pm 1\%$ of meter scale for volume range of 100 to 500 m³/h. Below this capacity, the system accuracy is ± 1.0 to $\pm 1.5\%$.

(g) *Ultrasonic Flow Meter*

This is an obstructionless flow measuring system that can be installed in pipes carrying liquids. The two principal components comprise the ultrasonic flow metering system and the sensor containing transducer, receiver and transmitter package. The transducer receiver and emit pulses. The pulses are transmitted against & along the direction of flow alternately. The pulse rate so time is expressed in terms of frequency. The average fluid velocity is proportional to the difference between these two frequencies.

12.7 FILTER FLOW CONTROL

During operation of rapid gravity filter, materials brought up are deposited in the pores of filter bed. Increasing the sediment against downward water movement. With the other factors unchanged, a drop in filtration rate is observed. A similar drop in flow rate may result take place when raw water head above filter bed goes down or the filtered water level downstream of filter bed goes up while the water movement would result an increase of the rate of filtration. It is required to either manually however, the filtration rate should be kept as constant as possible. Some particular sudden fluctuations should be avoided. An abrupt increase in filtration rate might cause hydraulic jump the raw water to break through the filter bed, increasing effluent quantity. Also with respect to beds a sudden reduction in the rate of filtration might release gas bubbles, can be accumulated in the filter bed. When these gas bubbles reach upward, holes might be produced in the filter bed, through which raw water can pass without proper treatment. A manual control of the rate of filtration is desirable and safe.

Flow control is observed by observing a main differential head or filter head upstream or across the filter bed. Downstream control can achieve this loss of head in such a way as to keep the sample of raw water or the characteristics of filtered water constant or the desired value since the rapid gravity operating conditions is on constant supply system and having automatic control by mechanical, hydraulic, pneumatic or electrical means becomes essential.





FIGURE 12.1



FIGURE 12.2: PLAN OF DOUBLE OVERHUNG CRANK MECH.
 (NOTE FOR REDUCED DIMEN. FIG. 12.2B)



LEGEND

- CV. CONTROL VALVE
- CF. CONTROLLER FLOAT
- OG. ORIFICE GEAR
- FF. FILTER FLOAT
- FRG. FLOAT RAISING GEAR
- RS. RATE SETTER
- BPV. BY PASS VALVE
- W. WEIR
- L. LEVER
- SV. SOURCE VALVE
- OR. VALVE OPERATING ROD
- HS. HEAD STOCK
- PWC. PURE WATER CHANNEL

SECTION B-B

FIGURE 12.2 : DETAIL OF FILTER CONTROLLER CHAMBER

The filter control valve is of GI construction with flange of GI, FRP, copper or any other corrosion resistant material.

The other type of controllers such as venturi one, work on pressure differential system which sends a signal to the controller. These differential pressures are reflected directly on the piston moving at a certain distance depending upon the difference between the pressures being exerted. The pressure is balanced by counter weights thus regulating the valve opening and closing. The controllers compare the actual flow with the set flow control points. According to the difference, the controller closes or opens the component, giving the discharge (butterfly valve, diaphragm, siphon).

The declining rate filter, however, does not require such control arrangement. However, to control the excess flow beyond the design capacity of any filter, a restriction valve is introduced at the outlet so that filter is not allowed to operate at a filtration rate higher than assumed design values.

12.8 RATE OF FLOW OF CHEMICALS

For regulating alum dose or polyelectrolyte flow where used, the chemical solution is fed by gravity from solution tanks to a constant head box generally located near the dosing point. The constant head box (illustrated in Fig. 12.3) is fitted with a PVC float operated stainless steel valve to keep constant level in dosing box. The rate of chemical flow is regulated by a stainless steel tapered needle valve over a stainless steel orifice in the constant head box. A scale gives directly the rate of flow of chemical corresponding to opening of tapered needle valve.

For regulating lime solution being dosed, generally a V-notch assembly with adjustable MS shutter and a graduated scale is used. Regulated flow of lime solution is observed as head over V-notch indicated by graduated scale is allowed to flow by adjusting opening of MS shutter while the excess lime solution over flows back to the chemical tanks. (Fig. 12.4)





FIGURE 12.6 : 644 RUBBER LINED CONSTANT HEAD BOX FOR ARM DUSTING




FIGURE 12-4. WIRE DOSING TANK

12.9 PRESSURE MEASUREMENT

Pressure is a parameter that is used extensively in testing and monitoring the performance of various types of pumping equipment, the measurement of pressure gradients or pressure control and the regulation of pressure within industrial plants.

The most common types of pressure gauges are:

- (1) Liquid or air or liquid-filled diaphragm
- (2) Bourdon tube
- (3) Strain gauge
- (4) Bellows.

The liquid-air diaphragm is a sensor and works on the principle of balancing pressure across a diaphragm with a liquid on one side and is regulated by a nozzle-baffle system on the other side. Due to change in liquid pressure, the movement of diaphragm is balanced by build up of air pressure. Liquid system adopts a liquid-filled system.

The gauges should have minimum 1.5 bar rated dial and should have range 1.5 to 2 times the normal operating pressure. The gauges are generally suitable for pressures up to 200 meters of water with accuracy of $\pm 1\%$ of maximum scale.

In the case of strain gauge, the sensor is used to measure dimensional change either on the surface of a specimen when subjected to mechanical, thermal or combination of both inputs. The electrical type strain gauge is most frequently used and is based on measurement of capacitance, inductance or resistance change that is proportional to strain.

The Bellows element is a most convenient method of sensing pressure. It consists of a multi-convoluted bellows and its displacement by pressure change gives a mechanical linkage connected to a needle.

The Bourdon tube works on a principle that a curved tube with a cross-sectional area that is not a circle will tend to uncoil or flatten out when it becomes circular if not subjected to pressure changes. The uncoiling movement is calibrated to provide an indication of pressure. The pressure range in this type are from 1 bar to 100 bar to 500 kg/cm² with an accuracy of $\pm 1\%$ of full scale. This type is available when the liquid handled is non-corrosive type while for corrosive application, diaphragm type is preferable.

However, in pressure gauges not used in this manner, where reciprocating pumps or pulsating discharge should be anticipated in the pressure gauge, AS pressure gauges should have overpressure safety mechanism and safety device mechanism. Pressure gauges installed on any pipeline or on other part for installation, control and safety purpose, however should follow the manufacturer's safety critical requirements.

12.10 WATER QUALITY

Water quality monitoring is essential for proper functioning of plant and to ensure correct public supply of water. The water quality monitoring can be achieved at the plant or at the distribution network or at the distribution network of discrete interval using laboratory or on-line equipment. Various cases for installation of on-line details regarding the installation, operation, maintenance and equipment.

12.11 OPTIONAL INSTRUMENTATION AND CONTROLS

12.11.1 LEVEE

(a) *Flow Water Flow Control by level in partially filled water tank*

When the flow rate is controlled by the level in a partially filled water storage tank, a float-operated electrically-actuated valve or float-operated flow control valve may be used. The flow control of the valve may be done by the controller using remote manual operation. In automatic control, level in the tank is measured and transmits the level in the tank gate an input signal to a pressure sensor which is used to control the float valve. The float valve output signal is used to flow control valve. The controller is based on a discrete control system with remote manual operation. The controller is used to plan and level of water in elevated filter water tank is observed and the control starts into the opening of the float control valve, which is a float-operated induct, located in the control room. The push button is used to reset the signal when control is the control room. The float valve control valve system is installed in the flow control room.

(b) *Level Automation and Auto Control Of Pumps*

The purpose of level automation is to provide high and low level maintenance for all the tanks in the control room. The level automation is done by control panel or by used. The above can be done by using level switches similar to the one described in 12.5.1.

However, if the level automation is done, the level automation serves its purpose in times when the level of the filling water pumps level switches can be used for automatic supply of the pumps at high and low levels. Care should, however, be taken to have correct installation for maintenance and control of pumps.

(c) *Remote Indications and Accumulation of Loss of Head Across Filter*

Where a considerable head loss is to be expected, it is sometimes preferable to have a remote indication for loss of head across filter or unfiltered filter head loss and alarm can be set up in the loss of head loss, for the backwash, for the filter or some control and alarm. Location of differential pressure gauges, electronic components located at

field test filters may be used for this purpose, with pressure tapping downstream of the control valves and over sand media respectively.

Flowmeter transmitters should be suitable for high humidity atmosphere upto 95% RH and should have 4-20 ma. signal. A remote indicator can be analog or digital type with facility for zero and span adjustment.

12.11.2 FLOW

(a) Remote Indication of Raw Water Flow

Raw water flow indication at a remote location may also be provided. This will facilitate operation of inlet valve as also in data logging. The remote flow indicator may be of analog or digital type. It is also preferable to have an integrator to know the cumulative flow to the plant. This integrator should be hard reset type only and the reset facility should be provided in such a way that accidental resetting or re-entry is avoided.

(b) Remote Indication of Rate of Flow through Filters

Remote indication of rate of flow of individual filters may also be provided. For this purpose, flow operated electronic type flow rate transmitter with 4-20 ma. output may serve the purpose using the filter outlet valve as the basic flow element. A differential pressure transmitter with an orifice in the filter outlet pipeline acting as the basic flow element may also be used. The remote indicator can be analog or digital type. Integrator similar to one described in Clause (a) above may also be used to know cumulative flow through the filter.

(c) Wash Water Flow Indicator

Wash water flow to filters may be measured locally by installing a rotameter in the main wash water header line to filter. This rotameter is usually a metal cased bypass rotameter with stainless steel float, stainless steel orifice and carrier ring assembly. In cases where remote indication of wash water flow to filter is desired, a differential pressure transmitter using a stainless steel orifice in the wash water header as basic flow element, may be used with a signal or analog output transmitter located at convenient location for the operator.

Repeat indicators of wash water flow may also be installed in individual filter consoles where such a system is adopted. However, the same need not be kept 'ON' at all times. The indication is to facilitate tank washing and it may be switched 'ON' for that period only.

(d) Chemical Flow

For regulating flow of chemicals solution, positive displacement metering pumps with 0.1 to 1 capacity mechanical stroke adjustment by means of a screw driven dial screw on the pump may be used.

The stroke adjustment may be manually done by means of an external stroke positioner on the control panel.

12.11.3 PRESSURE SWITCH APPLICATIONS

In applications, where a minimum fluid pressure is required in a particular pipeline, a pressure switch may be incorporated for automation as well as a warning of the operator.

equipment. For example, certain pumps requiring external water supply for cooling of the bearing should have a pressure switch on cooling water line to pumps.

12.11.4 FILTER CONSOLE

Filter consoles for each individual filter can be provided when such an operational system is called for. The filter console table can be of FRP/MS sheet epoxy painted framed structure. All filter controls can be attended to by the operator from the individual filter console.

Open/close push buttons for filter inlet, outlet, wash water inlet, drain and air inlet valves are provided on the filter console along with their open/close indication. In such an operational arrangement all filter valves are to be pneumatically or electrically actuated. Control of air blowers for air scouring of filters are also incorporated in the filter console. If desired, wash water flow indicator, filter loss of head indicator and filter rate of flow indicator can also be incorporated in the filter console table.

It is also possible to have programmable logic based filter washing arrangement for the filters. The programmable controller should have required number of outputs each to be programmed independently and for pre-determined decisions to be decided at the time of commissioning.

12.11.5 CLARIFIER DESLUDGING

A programmable logic based clarifier desludging arrangement may be provided to open the clarifier desludging valves at adjustable predetermined time intervals for an adjustable predetermined duration. In such a system of operation the desludging valve will have to be electrically or pneumatically actuated. In case of pneumatic mode of operation, the solenoid valve used for the purpose should be of SS-316 or equivalent construction while the solenoid coil should be epoxy coated, suitable for outdoor installation. The programmable controller may be located at a remote location preferably in the central control panel of the plant. Positive indication of valve operation by way of limit switches may also be provided to the programmable controller.

12.11.6 WATER QUALITY

Online instruments with automation facilities may be provided for online monitoring of the water treatment plant for the following parameters:

(a) Turbidity

Online turbidity meters working on the surface scatter principles may be provided for indication of raw water, clarifier water and filtered water turbidity. Alarm annunciator can also be provided to alert the turbidity of clarified water or filtered water is outside their respective acceptable values.

(b) pH

Online pH sensor with pre-amplifier and two wire pH transmitters, if necessary, can be used for remote continuous pH indication. The pH transmitter should be housed in a

where $\text{cos}(\theta)$ is the cosine of the angle of rotation and θ is provided in case of a 3rd order failure for a given α and β as in Table 10.7.

12.10.3.2.3.2 *Keyhole Effect*

Although significant stresses are induced in the composite material, a significant portion of the stresses are due to the presence of the interface between the two materials. The stresses in the matrix are much higher than in the composite material.

The residual stresses are due to the anisotropic nature of the composite, relative to the analysis. In each case, the stresses are distributed in a particular way, depending on the appropriate failure mechanism, as in Table 10.8.

In both cases, the manufacturing process provided a residual stress distribution which is quite acceptable and useful.

12.10 INSTRUMENTATION OF THE CAPAX 21 VANE

The baseline performance of the vanes is established on a set of standard torsion measurements, using a standard torque wrench, as described in the previous section. The torque history is recorded on a torque wrench which is capable of recording a complete torque history, with a resolution of 0.01% of the maximum torque. The torque wrench is used to apply the torque to the vanes, and the torque wrench is used to record the torque.

It is also advised that the vanes be tested at a temperature of 20°C, as the torque wrench is calibrated at 20°C. The vanes are tested at a torque of 1000 Nm, which is a torque of 94.2 Nm. The vanes are tested at a torque of 1000 Nm, which is a torque of 94.2 Nm. The vanes are tested at a torque of 1000 Nm, which is a torque of 94.2 Nm. The vanes are tested at a torque of 1000 Nm, which is a torque of 94.2 Nm.

Two reasons of importance are given as to why the vanes are tested at a torque of 1000 Nm, single phase. *M*

The torque wrench is used to apply the torque to the vanes, and the torque wrench is used to record the torque. The torque wrench is used to apply the torque to the vanes, and the torque wrench is used to record the torque. The torque wrench is used to apply the torque to the vanes, and the torque wrench is used to record the torque.

12.10 CONCLUSION

The vanes are tested at a torque of 1000 Nm, which is a torque of 94.2 Nm. The vanes are tested at a torque of 1000 Nm, which is a torque of 94.2 Nm. The vanes are tested at a torque of 1000 Nm, which is a torque of 94.2 Nm. The vanes are tested at a torque of 1000 Nm, which is a torque of 94.2 Nm. The vanes are tested at a torque of 1000 Nm, which is a torque of 94.2 Nm. The vanes are tested at a torque of 1000 Nm, which is a torque of 94.2 Nm.

The vanes are tested at a torque of 1000 Nm, which is a torque of 94.2 Nm. The vanes are tested at a torque of 1000 Nm, which is a torque of 94.2 Nm. The vanes are tested at a torque of 1000 Nm, which is a torque of 94.2 Nm. The vanes are tested at a torque of 1000 Nm, which is a torque of 94.2 Nm. The vanes are tested at a torque of 1000 Nm, which is a torque of 94.2 Nm. The vanes are tested at a torque of 1000 Nm, which is a torque of 94.2 Nm.

CHAPTER 13

OPERATION AND MAINTENANCE OF SEWERWORKS

13.1 INTRODUCTION

Various types of sewers are employed in a sewerage system. Each of these is designed to carry a certain type of effluent. It is, therefore, essential that the sewerage system should be properly designed, constructed, installed, operated and maintained. It is, therefore, necessary to study the operation and maintenance of sewerworks. The sewerage system is a complex system and its operation and maintenance is a continuous process. It is, therefore, necessary to study the operation and maintenance of sewerworks. The sewerage system is a complex system and its operation and maintenance is a continuous process. It is, therefore, necessary to study the operation and maintenance of sewerworks.

The operation and maintenance of sewerworks is a continuous process. It is, therefore, necessary to study the operation and maintenance of sewerworks. The sewerage system is a complex system and its operation and maintenance is a continuous process. It is, therefore, necessary to study the operation and maintenance of sewerworks.

13.2 OPERATION AND MAINTENANCE

The operation and maintenance of sewerworks is a continuous process. It is, therefore, necessary to study the operation and maintenance of sewerworks. The sewerage system is a complex system and its operation and maintenance is a continuous process. It is, therefore, necessary to study the operation and maintenance of sewerworks.

The operation and maintenance of sewerworks is a continuous process. It is, therefore, necessary to study the operation and maintenance of sewerworks. The sewerage system is a complex system and its operation and maintenance is a continuous process. It is, therefore, necessary to study the operation and maintenance of sewerworks.

The operation and maintenance of sewerworks is a continuous process. It is, therefore, necessary to study the operation and maintenance of sewerworks. The sewerage system is a complex system and its operation and maintenance is a continuous process. It is, therefore, necessary to study the operation and maintenance of sewerworks.

13.3 COMMON FEATURES OF OPERATION AND MAINTENANCE

The operation and maintenance of sewerworks is a continuous process. It is, therefore, necessary to study the operation and maintenance of sewerworks. The sewerage system is a complex system and its operation and maintenance is a continuous process. It is, therefore, necessary to study the operation and maintenance of sewerworks.

13.3.1 AVAILABILITY OF DETAILED PLANS, DRAWINGS AND OPERATION AND MAINTENANCE MANUALS

When a water works is taken over for operation and maintenance, it must be ensured that at least five to six sets of the detailed drawings, maps of each of the components of the water works along with all relevant O & M Manual are available with the operating authority. One of the sets may be preserved as a master set in apex office for reference. The other sets may be distributed to sub-offices in charge of relevant operations activity. All these sets must be corrected and updated whenever any additions, alterations/ deletions are done to any of the set-figures and equipment.

13.3.2 SCHEDULE OF DAILY OPERATIONS

For each of the activity where operators are employed, a detailed sub-rotal schedule of unit operations should be worked out and a copy of the same should be available with each operator. This schedule of unit operations may have to be altered to suit changes in raw water quality, hours of availability of power, break-downs and operational conditions etc.

13.3.3 SCHEDULE OF INSPECTION OF MACHINERY

A regular schedule of inspection of machinery, equipment their lubrication and servicing programme must be prepared and controlled. Appropriate supervisory control should be exercised to see that these inspections, lubrications and servicing are being regularly carried out.

13.3.4 RECORDS

For each piece of equipment and machinery a record register should be maintained in which all records of the equipment such as servicing, lubricating, replacement of parts, operating hours, including cumulative, are other important data is entered.

13.3.5 RECORDS OF QUALITY OF WATER

Complete records of bacteriological and chemical analysis of water from source to the consumers tap should be maintained and analyzed. Charts could also be prepared for the incoming characteristics of the water and any changes in these characteristics as compared to the standards must be taken note of.

13.3.6 RECORDS OF KEY ACTIVITIES OF O & M

For planning future suggestions and improvements of a water works an operator should be available to enter in certain key records such as daily and cumulative supply over the years, number of connections of various sizes, cost of J-volumetric, number of connections each month, water treated and the supply bill.

13.3.7 STAFF POSITION

Appropriate charts indicating the staff position for each of the unit of operations and maintenance and the staff status (in particular, vacancies if possible) shall be maintained in each office for review.

13.3.8 INVENTORY OF STORES

A reasonable assessment of the stores and spare parts of machinery required over a period of time say, one year or half a year can be made and an inventory of the same prepared. Issues and replacement of store articles could be watched and procurement procedures laid down and supervised. The firm should be free any material required for replacement is available at all times for the maintenance.

13.4 FEATURES OF OPERATION AND MAINTENANCE OF INDIVIDUAL COMPONENTS OF WATER WORKS

13.4.1 SOURCE AND INTAKE WORKS

(a) Sanitary Survey

Sanitary Surveys at regular intervals at both management levels and inspections at supervisory management level should be conducted. The catchment area of the source should be located on the maps. Potential sources of pollution observed in the catchment should be marked. The type of pollution e.g. industrial, domestic waste discharges, wastes of animal origin and agricultural run offs should be discerned.

The quality of such discharges has to be ascertained and its likely effect on water being drawn at source should be mentioned. Reports of such surveys should be promptly sent to the Pollution Control Authorities as well as water works authorities to promote corrective action. Procedure for monitoring or preventive action taken should be laid down and observed. An instant action plan for providing substitution of raw water should be available and brought into effect under such circumstances.

(b) Measurement of Flow

In cases of sources such as springs, rivers, canals, etc., there should be a permanent arrangement for recording daily flows near the intake works. Appropriate records in the form of graphs showing variation of flows in the source for each month in a year and for each year shall be maintained. New gauge stations should be established to record daily rainfall in the reservoir catchment and appropriate rainfall records should be built up and compared with discharges/storages available. In cases of reservoirs, the timing tables for filling and emptying of storages should be maintained for each year.

13.4.2 MAINTENANCE OF DAMS

- Pre, during and post monsoon inspection of dams should be undertaken to check settlements, longitudinal/transverse cracks in the embankment/masonry structures.
- Behaviour of spillways should be observed during floods. Procedures for safe and proper operation of spillway gates should be prescribed and observed.
- In case of earth dam, special attention should be paid to slipping of slopes, damages and water seepage. The functioning of sand galleries, drains, relief wells should be watched carefully. In case of masonry dams, sweating, leakages, seeping

of rest or of appreciable magnitude. Items removed should be repaired or returned to Porting of damaged hardware as early as possible after receipt of repair parts.

13.4.3 MAINTENANCE OF INSULATION

- It should be ensured that sufficient attention is given to the inspection and maintenance of insulation to ensure removal of any oil present in room. Insulation should be replaced as required.
- Oil leaks should be checked regularly to ensure that the presence of oil is detected as early as possible and removed immediately.
- Oil damages to structural components of machinery and other equipment should be prevented, repaired and replaced as required.
- Sufficient stocks of oil/insulation should be maintained in the machinery room and a regular inventory exercise should be performed to ensure sufficient stocks are available.
- A schedule of periodic oil testing should be adopted as part of the normal work schedule to prevent oil from becoming contaminated with water.
- When water leakage occurs, water should be removed immediately and the cause of the leakage identified and repaired as soon as possible.

13.4.4 MAINTENANCE OF TRANSFORMER & DIELECTRIC FLUIDS

(to be reviewed regularly)

13.4.5 MAINTENANCE OF TRANSMISSION SYSTEMS

The transmission system is one of the most important parts of the machinery room equipment and its correct operation is essential for the normal functioning of the vessel. Problems of 400V transmission should be solved as early as possible. The conditions of the transmission system should be checked regularly and any problems identified by the vessel's crew should be immediately reported to the relevant shore-based authority.

a) MS Pipes and other fittings

- Pipes should be maintained in good condition and repaired as required.
- Any leakage of steam, hot water, oil, diesel, engine oil, hydraulic oil, etc. should be detected, repaired and removed as soon as possible and where necessary, cleaned. The cleaning and removal of any spillage should be carried out as soon as possible to prevent any contamination.
- Expansion joints should be replaced as required.
- The condition of pipes should be checked regularly and any repairs to be carried out as soon as possible. The condition of all pipes should be checked regularly and any repairs to be carried out as soon as possible.

(b) *Staff types*

- (i) Laboratory staff: Employees who are primarily skilled in the maintenance and operation of laboratory tests.
- (ii) *Skilled* types: Employees who have a vocational training or a college degree of some kind in their field.
- (iii) *Unskilled* types: Employees who do not have a college degree or a vocational training in their field, but who are able to perform a job that may require some degree of technical or clerical training.
- (iv) *Unskilled* and *semi-skilled* types: Employees who have an education level that is below that of a high school graduate, but who are able to perform a job that may require some degree of technical or clerical training.

13.5.10 QUALITY CONTROL AND WATER TREATMENT PLANTS

13.5.10.1 PURPOSE

The purpose of this study is to determine the appropriate classification of employees working in a water supply plant, and to determine the appropriate classification for the plant's maintenance staff. The study will also determine the appropriate classification for the plant's administrative staff and the plant's maintenance staff.

The study will also determine the appropriate classification for the plant's maintenance staff, and will determine the appropriate classification for the plant's administrative staff. The study will also determine the appropriate classification for the plant's maintenance staff, and will determine the appropriate classification for the plant's administrative staff.

- (i) *Skilled* types: Employees who have a vocational training or a college degree of some kind in their field.
- (ii) *Unskilled* types: Employees who do not have a college degree or a vocational training in their field, but who are able to perform a job that may require some degree of technical or clerical training.
- (iii) *Unskilled* and *semi-skilled* types: Employees who have an education level that is below that of a high school graduate, but who are able to perform a job that may require some degree of technical or clerical training.
- (iv) *Unskilled* types: Employees who do not have a college degree or a vocational training in their field, but who are able to perform a job that may require some degree of technical or clerical training.

13.5.12 SKILL MATRIX

The purpose of this study is to determine the appropriate classification of employees working in a water supply plant, and to determine the appropriate classification for the plant's maintenance staff. The study will also determine the appropriate classification for the plant's administrative staff and the plant's maintenance staff.

- (i) *Skilled* types: Employees who have a vocational training or a college degree of some kind in their field.
- (ii) *Unskilled* types: Employees who do not have a college degree or a vocational training in their field, but who are able to perform a job that may require some degree of technical or clerical training.
- (iii) *Unskilled* and *semi-skilled* types: Employees who have an education level that is below that of a high school graduate, but who are able to perform a job that may require some degree of technical or clerical training.

- ii) Establish a regular schedule for maintenance of valves, and lubrication and maintain records thereof. In structure for lubrication, the type of lubricant applied and the frequency of application should be drawn out.
- iii) Make a record of the record of maintenance giving details of cleaning and replacement of components. Signs of wear of importance such as unusual incidence on filter, increasing condensation, etc. for any special equipment, should be changed from the maintenance.
- iv) Keep a record of water used in various points from the source to the distribution system to check on the effect of such wastes on the water units of operation; and
- v) Test unit safety, wear and tear, etc. as per the page.

13.5.3 RAW WATER

The problem will reside relative to the quality of the raw water due to natural causes and by man created pollution of the water.

In the case of a river, control of the day to day quality of the water may be undertaken at regular intervals and the results of the analysis of points where pollution is likely to take place. The analysis of the samples will reveal the degree and nature of pollution and thus help in taking the necessary measures to check or control the pollution. If the fluctuation is rapid and irregular, then action should be undertaken more intensively. You may need a special procedure to deal with the change of the quantity of pollution received. On the other hand, steady flow of pollutants coming will require pollution most probable due to sewage treatment or other pollution source should be undertaken such as for nitrogen in its various forms, dissolved oxygen, oxygen absorbed and ultimate demand to help the operators to deal with the pollution source, along place and to fix the dose of pollution source.

In the case of a lake, even a small pollution is a biological and the main explanation of the samples will indicate if there is any kind of the growth of algae which may lead to taste and odour problems or clogging of filters. Samples taken at different depths in the lake will indicate the level of the water and the pollution may be best quality of the water.

13.5.4 FLOW MEASUREMENT DEVICES

Flow measurement devices should be periodically inspected and if it does not work properly which may affect the proper functioning of the plant, repair and performance must be worked adequately. Annual calibration requires calibration of these devices by comparison. Annual servicing and checking of the instrument is a must.

13.5.5 CHEMICAL FEEDING UNIT

As the preparation tank is to be run or usually for an emergency or safety, rough wear and tears and floating arrangements should be checked daily. An open space for the rising device or the manual preparation should be stocked. Setting of the V-notch should be checked periodically.

Whenever it is found necessary to repair equipment which is used by a plant, the repair should be completed in the fewest hours possible. The repair process should not be delayed as it will result in waste of time and excessive damage of plant assets. It should be done in a systematic and disciplined way. The following equipment is included in the systematic timing of repair and completion should be in written groups. The demand for a repair may vary from day to day. The electrical feeding rate should be controlled by changing speed for repair time to take.

13.5.6 RAPID MIXER

Adequate spares should be kept in the inventory. Ready replacement spares necessary life of the equipment could be prolonged by periodic cleaning with an automatic pump.

13.5.7 SLOW MIXER

Slow mixer should be operated in a closed and revolving shape build up. All parts used should be painted with oil emulsion paint every year. Mechanical devices should be properly lubricated and worn out parts should be replaced. The final type of discharge valve should be changed and flow control valve should be replaced in the field maintenance.

13.5.8 CLEARER OR SEDIMENTATION TANK

Annual overhauling and repair of the tank should be done at least once a year as per the manner.

Single lines should be kept free of all damage. The tank should be fitted with high pressure water jet. Checkups are made of the tank after storage discharge devices which provided should be checked for free circulation of water and it should be maintained.

The reaction between the chemicals in the operation should be checked when replaced. It required.

The tank should be checked for water level and for the condition of parts. If any of them is damaged, and if any other part is damaged, the tank should be repaired. If any part should be kept checked for normal condition of the tank, provide it as per the following. It should provide the water.

The important features to be checked are as follows:

- (a) The functioning of water into the tank and the manner of discharge,
- (b) The process and status of complete work of operation and
- (c) The removal of the effluent with a minimum of disturbance to avoid solid material being stirred up in the tank.

Whenever a basin with a new line or line provided can be repaired by making changeable inlets and outlet devices by installing it. This kind of repair provides a repair of the equipment. The main reasons mentioned above. It should provide the water and the result of it.

13.5.9 RAPID GRAVITY FILTERS

The common problems during operation

6.1.1. *Effect of flow rate*

The effect of flow rate on the efficiency of the roughing tank is shown in Figure 10. The results are similar to those obtained in the roughing tank. The maximum efficiency is obtained at a flow rate of 1.5 m³/hr.

The efficiency of the roughing tank is also affected by the nature of the water. The efficiency is higher for the water from the roughing tank than for the water from the filter tank. This is due to the fact that the water from the roughing tank is more turbid than the water from the filter tank.

It is seen from Figure 10 that the efficiency of the roughing tank is higher for the water from the roughing tank than for the water from the filter tank. This is due to the fact that the water from the roughing tank is more turbid than the water from the filter tank. The efficiency of the roughing tank is also affected by the nature of the water. The efficiency is higher for the water from the roughing tank than for the water from the filter tank. This is due to the fact that the water from the roughing tank is more turbid than the water from the filter tank.

6.1.2. *Effect of quite Media on efficiency*

The efficiency of the roughing tank is also affected by the nature of the water. The efficiency is higher for the water from the roughing tank than for the water from the filter tank. This is due to the fact that the water from the roughing tank is more turbid than the water from the filter tank. The efficiency of the roughing tank is also affected by the nature of the water. The efficiency is higher for the water from the roughing tank than for the water from the filter tank. This is due to the fact that the water from the roughing tank is more turbid than the water from the filter tank.

6.1.3. *Effect of loading*

The efficiency of the roughing tank is also affected by the nature of the water. The efficiency is higher for the water from the roughing tank than for the water from the filter tank. This is due to the fact that the water from the roughing tank is more turbid than the water from the filter tank. The efficiency of the roughing tank is also affected by the nature of the water. The efficiency is higher for the water from the roughing tank than for the water from the filter tank. This is due to the fact that the water from the roughing tank is more turbid than the water from the filter tank.

The efficiency of the roughing tank is also affected by the nature of the water. The efficiency is higher for the water from the roughing tank than for the water from the filter tank. This is due to the fact that the water from the roughing tank is more turbid than the water from the filter tank. The efficiency of the roughing tank is also affected by the nature of the water. The efficiency is higher for the water from the roughing tank than for the water from the filter tank. This is due to the fact that the water from the roughing tank is more turbid than the water from the filter tank.

6.1.4. *Effect of duration of flow*

The efficiency of the roughing tank is also affected by the nature of the water. The efficiency is higher for the water from the roughing tank than for the water from the filter tank. This is due to the fact that the water from the roughing tank is more turbid than the water from the filter tank. The efficiency of the roughing tank is also affected by the nature of the water. The efficiency is higher for the water from the roughing tank than for the water from the filter tank. This is due to the fact that the water from the roughing tank is more turbid than the water from the filter tank.

6.1.5. *Effect of quantity of sand used*

The efficiency of the roughing tank is also affected by the nature of the water. The efficiency is higher for the water from the roughing tank than for the water from the filter tank. This is due to the fact that the water from the roughing tank is more turbid than the water from the filter tank. The efficiency of the roughing tank is also affected by the nature of the water. The efficiency is higher for the water from the roughing tank than for the water from the filter tank. This is due to the fact that the water from the roughing tank is more turbid than the water from the filter tank.

the specific details of the business plan. The business plan is a blueprint for the business, and it is essential for the entrepreneur to have a clear understanding of the business and its goals. The business plan should be a living document, and it should be updated as the business evolves.

the nature of letter head

The letter head is the first page of the business plan, and it is the most important part of the plan. It should be clear, concise, and easy to read. The letter head should include the name of the business, the address, the phone number, and the email address. It should also include a brief description of the business and its goals.

of Market

The market is the target market for the business, and it is essential to understand the market and its needs. The market should be defined in terms of geography, demographics, and psychographics. The market should also be analyzed in terms of its size, growth, and competition.

The market analysis should include a description of the market and its needs, a description of the competition, and a description of the business's competitive advantage. The market analysis should also include a description of the market's growth and a description of the business's growth strategy.

of products

The products are the goods and services that the business will sell, and it is essential to understand the products and their value. The products should be described in terms of their features, benefits, and price. The products should also be described in terms of their quality and their reliability.

the nature of the plan

The nature of the plan is the overall structure and content of the business plan. The plan should be clear, concise, and easy to read. It should include a description of the business, a description of the market, a description of the products, and a description of the business's financial plan. The plan should also include a description of the business's growth strategy and a description of the business's risk management strategy.

of Market and its requirements

The market and its requirements are the factors that influence the business's success, and it is essential to understand the market and its requirements. The market and its requirements should be described in terms of the market's size, growth, and competition. The market and its requirements should also be described in terms of the market's needs and the business's competitive advantage.

The requirements of the market are the factors that the business must meet in order to succeed in the market. The requirements of the market should be described in terms of the market's needs and the business's competitive advantage. The requirements of the market should also be described in terms of the market's growth and the business's growth strategy.

Backwashing of filters should not be based on arbitrary fixed time schedule; but the frequency should be in accordance with the filter quality and head loss measurement. Duration should be dependent upon the turbidity of the wastewater.

13.5.10. **SCUM SAND FILTERS**

The total float valve should be periodically checked with a view to maintain the desired level in the bed.

The water level arrangement should be checked periodically with a view to ensure the design rate of filtration. Where there is self-cleaning arrangement, it should be functioning smoothly and without drawing in water through the sides. Where manual adjustment is to be done with a raking float, it should be done at specified intervals.

The filter head indicator should always be kept in working condition. When a filter is stopped, most of the head loss is reported to the top layer of sand and if the filter head exceeds 100, pressures below, should once in a while be sand/gravel and in the under drains, leading to air bowing or dissolved air causing gas in solution. One source of negative head can be avoided by placing the rise of the water level in level with the top of the sand bed.

It is most important to avoid rapid backwashing at alternate rates. Cleaned or washed filter should be put into operation gradually with a view to filtering good and minimum loss as far as possible at a moderate rate until the bed is fully settled. The amount of flow in the bed should be taken up for cleaning.

On no account the filter rate by itself, should be reduced by disturbing the top of the sand with a float in the bed and all necessary to filter.

13.5.11. **CHLORINATION**

The chlorine demand of the effluent should be studied and a dose criterion reached which may or may not completely kill all the organisms which are harmful in not finishing chlorinated for secondary.

Backwashing of filter is good thing, but the water should be the water reserved by dipping in clean water, not treated water, as treated water may be harmful. Chlorine application should be done through a chlorinator pump. The chlorinator should be maintained properly. If the pump is not at hand, the tank should be equipped properly and to be maintained.

It is in the backwashing of the pump, a very large quantity of chlorine gas, filters and chlorine gas, as for preventing, but low amount of chlorine gas, concrete water require frequent cleaning of the treatment and the water usage capacity. All factors must have safe backwashing equipment and be completely dissolved in every unit or two years, which is a maintenance program.

13.5.12. **CUMULATIVE WATER SUPPLY & DISCHARGE**

As filter should be periodically checked to ensure that no obstructions there so that sufficient water is provided. The filter should be regularly checked and cleaned to

guard against mosquito breeding and bird nesting. The storage of the sewage and effluent should be done regularly and reservoirs should be free from any breeding of fish or birds.

The total capacity of clear water reservoirs should be maintained for storage of treated water, especially during low supply periods of year when water availability in all instances are reported, where water treatment facilities have limited capacity to meet daily pollution, thus reducing the rate of effluent. It is strongly recommended that any additional water reservoirs be planned or constructed for the five years to be immediately provided in the following reservoirs in the town.

13.5.13 TREATED WATER

The quality of the water before distribution should be controlled by adjusting the chlorine-carbonate balance to the water or sulphuric acid or another suitable material should be added to the pipes. The periodical analysis of the water can also indicate a time as any biological growth in the main and of any other natural water in the area to check on. The samples of water collected from several points should be examined for residual chlorine, pH, other chemical and bacteriological parameters.

13.5.14 PROBLEMS RELATED TO THE QUALITY & FLOW PATTERN

When flow problems exist it may not be desirable to cut out entire main but it is preferable to locate all the points with respect to the main lines in an area, then the flow through each flow in the several cuts should be carefully studied using appropriate meters. This will help to locate if there is any flow restriction or that some type of restriction can be adopted.

The flow in the main or pipe channel should be examined periodically to avoid obstructions and heading up which will affect the flow in any especially in the lower end of the distribution main.

13.6 AERATORS

Aerators are required to be installed in a certain condition of that mechanical water supply and agitation are provided.

Slime and algae growth on the surface water treatment devices and in the treatment with copper sulphate with a solution may be laid out with the primary plates or other acid with diffusion aeration can be removed. The clogged filter or diffuser should be compressed from time to time. The collection of sediment in the tanks and lines with the aerators are sludge, algae, etc. cleaning with detergent or a strong brush should be completed. Clogging of diffuser plates can be prevented by 90 minutes to 24 hours in effective maintenance, oil, and oil-lubricating air conditioning and blowing and maintaining air pressure in diffusers, when compressors are not used.

13.7 MASTER BALANCING RESERVOIRS AND DEVAILED RESERVOIRS

Important aspects to be considered during the construction.

- (c) A maximum of 10 minutes of programme time should be provided for this. The content of an entire week of material catch-up should be seen to some extent in advance by each individual employee under
- (iii) Some guidelines for the content of programmes should be set out in appendix 1.
- (d) Programmes should take account of individual organisational characteristics and objectives. These should be discussed and put in writing with management in order to make a plan.
- (e) A central evaluation system for all the programmes should be introduced, i.e. a set of standard criteria for each programme should be provided.
- (f) A programme for a radical change of the organisation structure or system should be undertaken during the normal time of a structural change to have the best impact on the organisation.
- (g) A programme which consists of several components should be viewed as a whole. The objectives should be combined in a single set of objectives.

THE ORGANISATIONAL DESIGN SYSTEM

Organisations are made up of many interrelated parts. Each part is a sub-system of the organisation as a whole. It is the interaction of these parts, however, that makes the organisation a whole. The system of parts that makes up an organisation is its design. Design is the process of creating a set of interrelated parts that will work together to achieve the organisation's objectives. Design is a process that involves the design of the organisation's structure, processes, and systems. Design is a process that involves the design of the organisation's structure, processes, and systems.

The design process is a series of steps that lead to the creation of a set of interrelated parts that will work together to achieve the organisation's objectives. The design process is a series of steps that lead to the creation of a set of interrelated parts that will work together to achieve the organisation's objectives. The design process is a series of steps that lead to the creation of a set of interrelated parts that will work together to achieve the organisation's objectives. The design process is a series of steps that lead to the creation of a set of interrelated parts that will work together to achieve the organisation's objectives.

- (i) A design team should be appointed to develop the design.
- (ii) The design team should be given a clear mandate to develop the design.
- (iii) The design team should be given the necessary resources to develop the design.
- (iv) The design team should be given the necessary support to develop the design.

The design process is a series of steps that lead to the creation of a set of interrelated parts that will work together to achieve the organisation's objectives. The design process is a series of steps that lead to the creation of a set of interrelated parts that will work together to achieve the organisation's objectives.

distribution system should have powers to inspect any household for water supply to know as from where that household is taking water.

The entire distribution system could be divided into sub-zones served preferably from one elevated service reservoir. The maintenance and operation of each zone of distribution system should be entrusted to atleast a junior engineer who should be made the authorised official of the controlling authority to receive and deal with the complaints. Appropriate registers should be maintained by him to refer to the complaints and to note in it the follow up action till the complaint is redressed. If the complaint is such that it cannot be dealt with at his level, he should at once refer the matter to higher authorities under intimation to the complainant. Frequent vigilance checks in the areas having maximum complaints should be made a part of the duty of the supervisory staff.

It is preferable to have meters provided by the water works controlling agency after charging appropriate monthly rentals to the consumer. This enables effective control over defective meters. Meter repair workshops should be established to attend to repairs of meters promptly. Surface boxes and chamber covers of valves should be frequently inspected and kept in proper condition. Billing for an out of order meter for more than three times consecutively should be avoided. All attempts should be made to repair/replace out of order meters once these are detected.

Sufficient stock of meters and spares should be available at hand to keep almost every meter in the field in working order.

Comprehensive water rules should be framed to make the maintenance operation most effective.

The consumers should be made aware of difficulties and shortcomings in the maintenance and operation of water supply system. Adequate publicity and public relations are required to be developed for this purpose.

13.9 CONTROL OF QUALITY OF WATER

For a waterworks industry, ensuring an appropriate quality of water to the consumer is its primary responsibility. Quality control is, therefore, required at every step in the water supply process. The physical, chemical and bacteriological tests of water samples need to be carried out at as frequent intervals as required. Reference may be made to Chapter 15 for more details. The results of these tests should be sorted and remedial measures taken promptly as and when required.

These tests are usually needed at:

- (i) Sources-to determine the raw water quality,
- (ii) Treatment Plants to determine whether the treatment is in conformity with raw water quality; and
- (iii) Distribution system-to determine whether adequate residual chlorine is present in the water supply to consumers.

13.10 TANKS & CHECK CONTROL

- (a) Maximum pressure is applied to tanks with flow control;
- (b) Design combination of surge, inflow, control and forced water and on less than standard is common to tanks & dams;
- (c) Pressure treatment with copper sulphate and its solution;
- (d) Routine maintenance of drainage distribution system, especially at hydroelectric served by creek and river, and;
- (e) Maintenance of records of electrical equipment and concrete retention tank to avoid structural gate failure.

13.11 STAFF PATTERNS

Recommended staff pattern for Operation & Maintenance of Waterworks for different projects given in Appendix 13.1 to 13.4.

CHAPTER 14

WATER WORKS MANAGEMENT

14.1 LEVELS OF MANAGEMENT

In India, Community Water Supply Systems are normally managed by local bodies. In a few specific cases these are managed by State Government Departments, when the system is supplying water to more than two local body areas, the bulk supply component of the system is some times managed by statutory Water Supply Boards set up by State Governments. This service facility falls under the water supply and sanitation sector. The development of this sector is assisted at three levels.

14.1.1 GOVERNMENT OF INDIA (G.O.I.) LEVEL

Broad policies for sector development of water supply systems in urban and rural areas are formulated and circulated to State Governments and Union Territories as guide lines. Technical manuals are drafted and published for use by the Water Works Industry. General progress in providing these services in the urban and rural areas is monitored. External or G.O.I. assistance as required to needy areas is offered for capital investment and implementation of water supply schemes. Similar in service training programmes for the employees of the Water Works Industry in the states are sponsored. Financial assistance for specific assistance training programmes of the states is offered.

14.1.2 STATE GOVERNMENT LEVEL

The State Governments offer to assist the local bodies in planning and implementation of water supply schemes of individual or a group of local bodies. Financial assistance is also given for these local body schemes in the form of Grant in Aid (GIA) and loan etc. for capital investment. In certain special circumstances, the State Governments assist the local bodies in operating and maintaining their water supply schemes wholly or upto bulk supply level through its own departments or through the statutory boards of the state governments. Trained engineers and skilled workmen are sometimes deputed to local bodies on request to plan, implement and operate the water supply systems. The state governments monitor general progress of water supply schemes of local bodies in respect of planning, implementation, operation and maintenance.

It is the voluntary responsibility of consumers (households, shopping centres) or private water supply companies to be met under their respective responsibilities. Depending upon financial means of each water body, the State/Government may or may not in the help of these water bodies to meet a part/bulk of their current or future cost in water supply system (such as pressure schemes in the form of O&M, and/or loan). The expenditure on stand operations and maintenance of these schemes has, however, to be met by the local body concerned. In case, revenue to be generated from water charges and water supply and the respective loss of total works, there has to be compensated to the local receiver state charges. It is to be in the interest of them water facility to provide a service of best.

18.2 COMMON ASPECTS OF WATER WORKS MANAGEMENT

The aspects considered in this chapter for the management of operation and maintenance of water supply systems. It includes the important aspects of management that could be considered namely, (i) Control Administration, (ii) Personnel Administration, (iii) Finance and Control, (iv) Investment Decision making, (v) the Rehabilitation programme, (vi) water audit & management system and (vii) the water conservation. The management of general should be as per following objectives:

- (a) The quality of water supplied should be safe.
- (b) Service to consumers should be satisfactory.
- (c) Personnel should be safe and well supported.
- (d) Financial management should be sound.

An efficient and effective management of water supply systems is most essential for their proper functioning.

18.3 GENERAL ADMINISTRATION

This could be further subdivided into two categories, viz. (a) Supervisory and (b) Executive. The operational level is to be subordinate to supervisory level.

The supervisory administration is expected to control all the functions of management. Water works is an engineering service. Hence, it is a general practice to set up an Engineering Supervisory Department on the consideration of present work load expenditure to be handled by the organisation. This may consist an engineering Division and the Regional Engineering and Division from the R.E. division including their staffs and the staffing pattern may be considered separately as per Appendix 18.1. Annual work load per unit could be observed or reduced depending upon local conditions such as high cost of power and increase in water area to be covered (e.g. for regional schemes etc). The work distribution considered in the present chapter of all aspects covered during annual O & M, is to be made. It is suggested that the following aspects of assistance to water connections and service customers, the maintenance of water and effluent treatment plants should be strictly controlled. These engineering functions to be management and control. In the usual work

head of water works to a group of water works controlled by one local body (agencies higher than that provided for one Division), financial and physical together with special technical costs such as a super-levy on the Government's share, can be established. These Engineering Unit would be set up mainly to control the head of engineering department under the control and advice of the State Council and local committees.

14.3.1 DUTY AND RESPONSIBILITIES

The duties and responsibilities of the division are mentioned below in brief:

- (a) To operate and manage the water works
- (b) To develop annual operation and maintenance planning programme and the strategy.
- (c) To implement O&M budget and to study up-to-date existing and relevant techniques.
- (d) To keep accounts, records and to monitor and to evaluate performance and to make operational work establishment.
- (e) To monitor and maintain equipment and to monitor the condition of O&M equipment and to do it.
- (f) To prepare and to submit a report to the division and to the State Council on a regular basis.
- (g) To be assigned to work to which the division is concerned to do operation.
- (h) To be assigned to work to which the division is concerned to do planning.
- (i) To be assigned to training.

In addition to the above, it should also be considered in following aspects:

- (a) That the division should have a staff of
- (i) Civil operations engineers.
- (ii) Civil engineering assistants.
- (iii) Civil administration assistants and a person whose program is to be managed.
- (b) That the equipment and supplies are not in full supply.
- (c) That the staff of the division is well trained.
- (d) That appropriate plan for the division is made.

Some of the additional duties for these agencies can be explained in parallel with the briefly stated as under:

- (a) The entire work of O&M could be provided in a general table of functions. This function may be assigned to a group of persons.

- (b) Whenever found necessary and in the interest of work powers could be delegated to subordinates.
- (c) The organisation could be flexible in order to enable it to respond to changing work load and work conditions.
- (d) Organisation manual and charts could be developed containing (i) Role of Organisation, (ii) job descriptions, (iii) Statements, etc.
- (e) O&M schedules could be prepared assigning works to individuals.
- (f) Works could be checked to see that these are being done as required/expected.
- (g) O & M manual could be developed to include (i) Description of systems, (ii) System operation, (iii) Spare list items to be considered, (iv) Lubrication and maintenance, and (v) Report etc.
- (h) Office operations include answering telephone calls, handling correspondence, records, typing letters/minutes etc. standardising work forms for transmission of information etc.
- (i) Computation of statistical information. The task could include (i) Quantity of water pumped/purified into system, (ii) Quantity of water billed/sold to consumers, (iii) Consumer patterns, (iv) Rate of increase in the number of consumers, (v) Service levels, (vi) Waste maps including location of encroachments, (vii) Delivery patterns of the system at different stages, (viii) Relation of supply to demand by a suitable regulated form.
- (j) Number and nature of complaints received.

14.3.2 GENERAL ADMINISTRATION AT OPERATING LEVEL

The administration required at the operating level of a water works is determined on the basis of physical work output to be expected from each individual. A general guide line for the number in some of the categories of staff at operating level is indicated in Appendix 14.2. The requirements are expected to vary according to individual circumstances, like topography and geographical location etc.

In order to ensure that each of the operating staff certain modern business principles could be inculcated such as

- (a) Unity of Command - Each worker should report to only one person in charge. One worker in charge may not have more than 8 to 10 person for direct control.
- (b) Each worker must have a clear understanding as to the expectations of the job handed by the supervisory units.
- (c) The worker should be given the index or extract of the operating manual.
- (d) Regular work reports should be maintained by each worker and submitted to controlling person in charge.

- (c) Time records of each worker should be kept up-to-date by supervisory section and all dues paid to him on time.
- (d) All possible service facilities should be provided to the operating staff so that he can devote his full attention to work entrusted to him.
- (e) Personal grievances of workers should be attended as promptly.

14.3.3 PERSONNEL ADMINISTRATION

The personnel administration can be classified into a few categories, namely:

- (a) Presenting and classifying the work for developing job descriptions, specifying qualifications and goals for each position and developing wage and salary structure.
- (b) Recruiting and selecting employees for a position.
- (c) Evaluating the work of the employees as a criteria of evaluation, some of them confidential reports are. The work should be compared and achievements measured against each rate. General assessment can be done by a panel and report prepared. The evaluation may refer to (i) knowledge, (ii) punctuality, (iii) quality of work, (iv) dependability, (v) initiative, and (vi) the nature of criticism.
- (d) In-service training of employees (i) on-the-job training, (ii) off-the-job.

14.4 INVENTORY CONTROL

Inventory control is the management of supplies received and used in the O&M of water works. It involves (i) determine what supplies to be stocked, (ii) keeping a record of supplies and inventories, and (iii) determining the critical values of supplies.

Many of the water works failures to pump systems, etc., supplies could be readily supplied by a system based on working inventory. There should be enough stock to be able to deal with the failure repairs and repairs to be carried out. Materials of stock should have a control which have by purchase and a record of usage and returns.

Inventory control can be used for the purpose of accountability and stock demand by collecting usage pattern, doing a physical stock count and record purchasing requirements.

Inventory control would include tools required for O&M of the system. Although new purchases for these may not be as frequent as for stock materials for repairs and replacement. Requirements have to be checked at intervals.

14.5 ACCOUNTING & BUDGETING

Accounting is the process of recording and summarizing (based on transactions) that affect the financial status of the O & M organization of the water works. It is an important tool for monitoring revenue and expenditure activities and for interpreting the financial results of the organization.

Budgeting is the art of interpreting the goal of O & M organization in meaningful monetary terms. It should be used to control the financial activities of the organization.

Accounting system would involve the following functions.

- (a) A basic chart of accounts for the organisation.
- (b) Accounting reports such as income and expenditure statements, balance sheets, cash flow statements and debt servicing, etc.
- (c) Annual O & M budget.
- (d) A frequent review (say quarterly) of income analysis from customer class as desirable.

This would enable the regulatory unit and the authorities of the water works to decide at each level, a review of water tax structure is called for. It would also review ways and means of effecting recovery of outstanding dues from consumers. Legal powers of the authorities to effect full arrears recovery from consumers may have also to be examined periodically and enhanced if required by legislation. A review of expenditure pattern on the basis of revenue raised could also be simultaneously done.

It would be desirable to keep financial aspects of the system to include

- (a) Depreciation of the system.
- (b) Depreciation.
- (c) Operating expenses.
- (d) Investments in new capital equipments.
- (e) Long term debts, interest services.
- (f) Appropriate schedules of water rates.

Development and implementation of appropriate water rates would go a long way in helping to generate adequate annual revenues of the water works.

11.6 INSERVICE TRAINING

The object of well founded short term in service training for the employees of water works undertaking is

- (a) To improve group level of operational efficiency.
- (b) To acquaint the group with the new developments.
- (c) To develop amongst the members of the group a better understanding of human relations and concept of their individual responsibility to the community.
- (d) To bring about and increase the community awareness of water works operation.

The training could include

- (a) Orientation courses to describe duties and responsibilities of individuals in the organisation.
- (b) Knowledge in employee with a handbook.
- (c) On the job training to work with specific need employee for some time.

(j) Work shops, short courses and seminars on concerned subjects

The subjects to be included in the training could be:

- (a) Use of personnel on other projects/water works.
- (b) Features on practical aspects of subjects covered under O&M of water works.
- (c) Laboratory work of tests.
- (d) Physical, chemical and bacteriological examination of water and interpretation of results.
- (e) Disinfection.
- (f) Design of treatment works of various.
- (g) Supervisory control.
- (h) Systems management and Administration.
- (i) Accounting, budgeting and financial management.

Each one of the supervisory and operating staff on the water works should be subjected to appropriate training course depending upon work to be handled by him at least once in three or five years of his service period.

14.7 LONGTERM PLANNING

One of the important functions of a water works management is to develop technical and financial plans for future expansion of the water works. For this purpose, the management should review periodically present expansion and future requirements. Some of the reasons to be reviewed could be:

- (a) Analyse the ability of the system to deliver water of acceptable quality, at proper quantity and make sufficient provision at times of emergency.
- (b) Forecast future requirements, determine the areas and population to be served and the future likely consumption.
- (c) On evaluating construction and financing.

It is much better to keep up and improve the system through small construction programmes and plan to reach them to allow deficiencies to accumulate. The major improvement should be planned to fit in with the prospective objectives and requirements.

- (d) The planning for future expansions require knowledge of project designs and basis for present water system.

There is no harm for the local bodies in following assistance from external agencies such as Governments and consultants for development of future plans and implementation programmes as required.

14.8 PUBLIC RELATION

The object of public relations is to develop:

- (a) Consumer satisfaction
- (b) Opportunities for the community to know how works are managed.
- (c) Frequent dialogue between the community, owner and management.
- (d) Act of keeping owners informed about day to day working of the system, shortfalls, if any, and assistance required.
- (e) Interpretation of articles in the news papers about O&M situation, deficiencies, deviations, etc., based on facts and figures.

Sufficient publicity needs to be given to O&M work being done by the management, difficulties experienced and operational aspects known public to make good the decision making. Information could be given in newspapers. Appropriate ads could be given on TV, P.R. etc. All criticism in the press about O&M of the system could be promptly attended to and appropriate replies published, particularly in the same news papers in which criticism appeared.

In addition to the above activities, publicity of O&M works is automatically enhanced if:

- (a) Every employee of the management who makes public contacts adopts a kind and courteous attitude towards customers and public.
- (b) Personal interest is shown in customers' complaints and problems and these are dealt with promptly with courtesy and competence.
- (c) Customers are encouraged to give water works which should be kept clean, tidy and in good repair.
- (d) Good relations are established with local press by providing timely, possible information on the O&M of water works.
- (e) Contacts are established with bodies about, street, health and environmental issues.
- (f) Small pamphlets on water works are periodically published and distributed.

CHAPTER 15

LABORATORY TESTS AND PROCEDURES

15.1 GENERAL

Laboratories with diagnostic facilities and staff of qualified personnel are essential for inspection and verification of the quality of water supplies for public use as well as for controlling the water treatment processes. The general aim of laboratory examination of water is to ensure that potable water conforming to the drinking water standards is supplied to the consumers.

Tests carried out in the laboratory are intended to assess the quality and classify the raw water to be treated to determine the need and nature of treatment, to check that water has been properly prepared for each phase of treatment process; to ensure that each phase of treatment proceeds according to plan and to ascertain the finished water to ascertain that it conforms to the standard. Other objectives that could be served by a regular testing programme include (i) determination of trends in drinking water quality over time, (ii) provision of information to public health authorities for general public health protection purposes and (iii) identification of sources of contamination.

Laboratory facilities are thus indispensable for controlling plant operation and for assessing and improving plant performance which helps to cost and time savings.

15.2 TYPES OF EXAMINATIONS

The laboratory examination comprises of physical, chemical, bacteriological and biological analysis.

Physical analysis determines the aesthetic quality and assess the performance of various treatment units.

Chemical analysis determines concentrations of chemical substances which may affect the quality of water and be indicative of pollution and which reflect variations due to treatment – a requirement for control of water treatment processes.

Bacteriological examination indicates the presence of bacteria characteristic of pollution and hence the safety of water for consumption.

Biological examinations will find application in providing information on causes of objectionable tastes and odours in water or clogging of filters and dictating remedial measures.

15.5 SAMPLING

The value of any laboratory analysis will be dependent upon the method of sampling. Figure 15.1 shows the proper procedure in securing a representative sample of water in the analysis which is to be made. The source of any community water supply should be known. Frequently the only source of hot water is a steam-heated physical chemical and biological analysis and processing, the analysis is best, while possible analysis may be adequate for industrial water use, piping, fixtures, or heating systems. Biological analysis will be required for limnological work or water taste and odour problems are encountered.

All samples of water should be properly labelled and should be accompanied by complete and accurate identifying and descriptive data. Data should include date and time of collection, type of source of the sample and temperature of water at the time of collection. When samples are being collected from the same sampling point at different intervals, it is essential that the sample for bacteriological examination be collected first. The sample should be supplied with the sample collection form (see Appendixes 15.3, 15.4, 15.5, 15.6 and 15.7).

The transport bottles may be packed in a wooden, metal, plastic or heavy fibreboard cases, with a separate compartment for each bottle. These may be lined with corrugated fibre paper, felt or other suitable material or may be covered with ground cotton wool. They should be packed in a rigid polythene bag to prevent breakage and should be stored in a cool, dark place.

15.5.1 SAMPLING FOR PHYSICAL AND CHEMICAL ANALYSIS

Samples should be collected in containers of high quality or inert material, such as polythene.

Samples for the most accurate determination of dissolved oxygen should be collected with care and increasing rapidly by filling a 250 ml glass bottle with a stopper and stop with water 5 to 35 ml saturated mercury solution of known volume and allowing peroxide to form on the water surface. The bottle should be inverted three times to mix the water thoroughly with the mercury and then inverted once of water.

At least 2.5 litres of the sample should be available for analysis. If only 1.0 litre is to be used, it should be mixed with twice the amount of water to be analysed. This should be done to obtain a sample that is not representative of the original sample and to introduce no such way that it does not deteriorate in bottles recommended before it reaches the laboratory.

The sample should reach the place of analysis as quickly as possible within 72 hours of collection. The time elapsed between collection and analysis should be recorded in the laboratory report.

Some determinations are likely to be affected by storage of samples. Wells of glass or silver are likely to absorb traces of silver, selenium, cadmium, chromium, copper, iron, lead, manganese, silver or zinc which are best collected in a separate bottle and acidified by concentrated hydrochloric or nitric acid to a pH approximately 3.5 to minimise precipitation and adsorption on the walls of the container.

Certain parameters like temperature, pH dissolved gases like carbon dioxide, hydrogen sulphide, chlorine and oxygen need special apparatus during transport. For this reason, determinations of pH, carbon dioxide, ferric iron, dissolved oxygen and chlorine should be carried out on the spot. Hydrogen sulphide can be measured by using it with zinc acetate and the complex is used for analysis.

The samples collected under pressure should be sealed while under pressure. Samples normally drawn by wells, should only after the well has been purged for a sufficient time to ensure the flow sample will be representative of the ground water.

15.3.2 SAMPLING FOR BACTERIOLOGICAL ANALYSIS

15.3.2.1 Sampling bottles

Sterilized glass bottles provided with ground glass stopper having an overlapping rim should be used. The stopper and the neck of the bottle should be protected by brown paper. The sterilization is carried out in autoclave at 121°C pressure for 15 minutes or by autoclaving at 167°C for 1 hr.

15.3.2.2 Dechlorination

Dechlorination is necessary for chlorinated water samples. For this, sodium thiosulphate should be added to the clean, the sampling bottles before sterilization in an amount to provide an approximate concentration of 1 mg/l in the sample. This can be done by adding 0.2 ml of 10% thiosulphate solution to a 200 ml bottle and the bottles should be sealed.

15.3.2.3 Sample Collection

The sample should be representative of the water to be tested and they should be collected with utmost care to ensure that no contamination occurs at the time of collection or prior to examination. The sample bottle should not be opened till the time of filling. The stopper with the cap should be removed with care to avert any seepage. During sampling, the stopper and the neck of the bottle should not be touched by hand and they should be protected from contamination. The bottle should be held over the nose, filled with care, and the stopper replaced immediately. The bottle should not be filled completely, but sufficient space left for shaking before analysis. Then the brown paper wrapping should be used to protect the sample from contamination.

(a) Sampling from Taps

The tap should be opened fully and the water allowed to run to waste for two or three minutes so that sufficient time to permit clearing of the service line. The flow from the tap should then be restricted to permit filling the bottle without splashing. Backing taps, which allow water to flow over the outer surface of the bottle, must be avoided as sampling points. If it becomes necessary to collect from this point, the leak should be attended to before sampling. When a tap is not in satisfactory service, it is advisable to wipe the tap free of any grease or preferably flame before collection of the sample. It should be ascertained whether

the tap from which the sample is collected is supplying water from a service pipe directly connected with the main or with a line or a storage tank. This information should be sent along with sample.

(b) Sampling Direct from a Source

When the sample is to be collected directly from a stream, river, lake, reservoir, spring or a shallow well, it should be representative of the water that will be taken for treatment. Hence, a sample should not be taken from a point which is too near the bank or too far from the point of draw-off or at a depth above or below the point of draw-off. Areas of relative stagnation in a stream should be avoided.

Sample from a river, stream, lake, or a reservoir can often be taken by holding the bottle in the hand near its base and plunging its neck downward, below the surface. The bottle should then be tilted until the neck points slightly upward, the mouth being directed against the current. If no current exists, as in a reservoir, a current should be artificially created by pushing the bottle horizontally forward in a direction away from the hand. If it is not possible to collect samples from this situation, in this way, a weight may be attached to the base of the bottle which can then be lowered into the water. In any case, damage to the neck must be guarded against as otherwise foaming of the water can occur. Special apparatus which permits mechanical removal of the stopper of the bottle below the surface is required to collect samples from the depths of a lake or a reservoir. If the sample is to be taken from a well fitted with a hand-pump, water should be pumped to waste for four to five minutes before the sample is collected. If the well is fitted with a mechanical pump, the sample should be collected from a tap on the discharge end. If there is no pumping mechanism, the sample can be collected directly from the well by means of a sterilized bottle attached with a weight at the base. In this case, care should be taken to avoid contamination of the sample by any surface scum. Where it is not possible to collect the sample directly into the bottles as for example where there is a high bank, the sample may be obtained by means of a double metal jug. The jug is sterilized by pouring into a 3 to 5 gal. of fluctuating water and tilting the jug in such a way that the spout comes in contact with the entire inner surface of the jug and agitating. The jug should be lowered to the required depth and then drawn up and down two or three times before it is brought to the surface. It should be rinsed out about twice before the sample is taken. Should the jug come in contact with the bottom or soil along the surface so that it may have collected the surface film, the sample should be discarded, the jug re-sterilized and another sample drawn. The water from the jug should be poured into the bottle and the glass stopper of the bottle be replaced, care being taken to avoid the water being caught between the stopper and the neck of the bottle.

15.3.2.4 Size Of The Sample

The volume of the sample should be sufficient for carrying out all the tests required and in no case, it should be less than 250 ml.

15.3.2.5 Preservation And Storage

Water samples should be examined immediately after collection. However, this is seldom practical and hence it is recommended that the samples should be preferably analysed within one hour after collection and in no case this time should exceed 24 hours. During transit, the character of the sample should be maintained or close as possible to that of the source of the sample, at the time of sampling. The time and temperature of storage of all samples should be recorded since they will be considered in the interpretation of the laboratory results. If they can not be analysed within 24 hours, the samples must be preserved in ice until analysis. The sample is fit for bacteriological analysis after 72 hours.

15.3.3 SAMPLING FOR BIOLOGICAL ANALYSIS

For this purpose, two samples should be collected in clean two litre wide mouthed bottles with a glass stopper or a bakelite screw cap.

In making this collection, the bottle, after the stopper is removed, is thrust as far as possible mouth downward into the water. It is then inverted and allowed to fill.

One bottle is to be stoppered as such. The another bottle, add 5 ml. of commercial formalin for every 100 ml. of water sample immediately after collection. Both the bottles should be despatched with the label on the sample containing the one with formalin.

If two litres of samples could not be collected, then 200 ml. of the sample can be collected as above and formalin added to one sample (10 ml. of formalin added to 200 ml. of water).

15.3.4 FREQUENCY OF SAMPLING

The frequency of collection of samples for chemical analysis depends on the variability of the quality of water, the types of treatment processes used and other local factors.

Samples for general systematic chemical examination, should be collected atleast once every three months in supplies serving more than 50,000 inhabitants and atleast twice a year in supplies upto 50,000 inhabitants. More frequent sampling for chemical examination may be required for the control of water treatment processes.

It is necessary to collect samples of both raw and treated water for examination of toxic substances atleast every three months and more frequently when substantial levels of toxic substances are known to be generally present in the source of supply or where such potential pollution exists.

For bacteriological sampling, which controls the safety of supply to the consumer, the frequency of sampling and the location of sampling points at pumping stations, treatment plants, reservoirs and booster pumping stations, as well as the distribution system, should be such as to enable a proper evaluation of the bacteriological quality of the entire water supply.

The minimum number of samples to be collected from a distribution system should be as prescribed in Table 15.1.

The samples should be taken from the different points on each session to enable overall assessment.

In the event of an epidemic or immediate danger of pollution, it should be borne in mind that much more frequent bacteriological examination will be required than the recommended minimum frequencies for routine bacteriological examination.

For biological examinations, where seasonal growth of plankton are known to be a regular occurrence, samples may need to be taken at weekly or even shorter intervals, in order to determine the type of treatment. During treatment operations, samples for examination would need to be taken at short intervals, probably daily. When growth of plankton is not anticipated, samples should be drawn on a monthly or less frequent basis. Greater frequencies, determined by experience may be needed to trace any possible entrance of pollution into water sources or trace particularly into distribution systems.

TABLE 15.1
MINIMUM SAMPLING FREQUENCY AND NUMBERS FROM
DISTRIBUTION SYSTEM

Population Served	Maximum intervals between successive sampling	Minimum No. of samples to be taken from entire distribution system
Up to 25,000	One month	
20,000-50,000	Two weeks	One sample per 5,000 of population per month
50,000-100,000	Two days	
More than 100,000	One day	One sample per 10,000 of population per month

15.4 STANDARD TESTS

The standard tests that are employed in the analysis of water are as follows:

15.4.1 PHYSICAL EXAMINATION

The parameters tested are temperature, turbidity, colour, taste and odour.

15.4.2 CHEMICAL EXAMINATION

- This includes tests for consistency and characteristics of water that affect the health of the consumers and the potability of water, viz. pH, acidity, alkalinity, hardness, calcium, magnesium, iron, manganese, copper, zinc, aluminium, sulphates, fluorides, chlorides, nitrate, total dissolved, and suspended solids.

- (5) Tests for efficacy of treatment, viz., chlorination, ozonation, activated residual chlorine, coagulant dosage
- (6) Tests for chemical parameters which are indicators of pollution, viz., iron, lead, manganese and nitrogen in various forms like ammonia, nitrite, nitrate, nitrite, nitrate, dissolved oxygen, etc. (6.1)
- (7) Tests for toxic chemical substances, lead, arsenic, iron, nickel, cyanide, chromium, cobalt, plastic, pesticides and herbicides, etc.
- (8) Test for rad. source.

15.4.3 BACTERIOLOGICAL EXAMINATION

Microscopic tests for identification and characterisation of microorganisms, viz., bacteria are included in this category.

15.4.4 SCHEDULE OF TESTS

The schedule of laboratory tests followed by a minimum recommended volume of water, the size of the plant and character of water used (rough for sanitary plant), the minimum schedule should include turbidity, colour, alkalinity, pH, hardness, total dissolved solids, bacterial count at 37°C and coliform bacterial number (total, faecal coliform and fermenting).

Occasionally special tests may be necessary such as residual chlorine and manganese, taste and colour and other conceivable examinations if wished under. Where possible, chlorine is preferred, residual chlorine should be tested at each major stage of treatment. Chlorine demand tests should be carried out in the order.

15.5 METHODS OF EXAMINATION

The physical, chemical, bacteriological and biological procedures for the various laboratory examinations given in the Manual of methods for the Examination of Water, Sewage and Industrial Wastes published by the International Council of Medical Research, are to be followed. For procedures regarding trace and ultra elements see, except by the I.C.M.R., the procedures recommended in Standard Methods for the Examination of Water and Wastewater prepared and published by American Public Health Association, American Water Works Association and Water Pollution Control Federation as given in the following.

Conformance to standard analytical methods to compare and contrast results of tests carried out by different laboratories are to be meaningful.

15.5.1 REPORTING OF RESULTS

Specimen forms for reporting results of analysis of chemical examination, complete chemical examination and bacteriological examination are given in Appendices 15.1 and 15.6. For purposes of uniformity, standard specimen forms should be used and this should be clearly stated in the report.

number of laboratory equipment and other apparatus that will be required should be expressed in terms of M or the "millionth" of the year. The laboratory should be able to conduct about 100000 analyses per year. It is suggested that the laboratory should be able to handle a maximum period of 24 hours. It is expected in some instances, as a sample management system, that with the help of an experienced staff, that the results in terms of analytical results should be available soon.

Key words, methods, results of a project, laboratory should include the project name of the laboratory and the respective area of the laboratory, wherever appropriate.

15.6.2 RESEARCH

The laboratory should be able to handle the following types of work: (a) research and development work, (b) research and development work, (c) research and development work, (d) research and development work, (e) research and development work, (f) research and development work, (g) research and development work, (h) research and development work, (i) research and development work, (j) research and development work, (k) research and development work, (l) research and development work, (m) research and development work, (n) research and development work, (o) research and development work, (p) research and development work, (q) research and development work, (r) research and development work, (s) research and development work, (t) research and development work, (u) research and development work, (v) research and development work, (w) research and development work, (x) research and development work, (y) research and development work, (z) research and development work.

15.6.3 QUALITY CONTROL

The laboratory should be able to handle the following types of work: (a) quality control, (b) quality control, (c) quality control, (d) quality control, (e) quality control, (f) quality control, (g) quality control, (h) quality control, (i) quality control, (j) quality control, (k) quality control, (l) quality control, (m) quality control, (n) quality control, (o) quality control, (p) quality control, (q) quality control, (r) quality control, (s) quality control, (t) quality control, (u) quality control, (v) quality control, (w) quality control, (x) quality control, (y) quality control, (z) quality control.

15.7 RECORDS

The laboratory should be able to handle the following types of work: (a) records, (b) records, (c) records, (d) records, (e) records, (f) records, (g) records, (h) records, (i) records, (j) records, (k) records, (l) records, (m) records, (n) records, (o) records, (p) records, (q) records, (r) records, (s) records, (t) records, (u) records, (v) records, (w) records, (x) records, (y) records, (z) records.

All details of work should be recorded in a clear, legible and readable manner. The laboratory should be able to handle the following types of work: (a) records, (b) records, (c) records, (d) records, (e) records, (f) records, (g) records, (h) records, (i) records, (j) records, (k) records, (l) records, (m) records, (n) records, (o) records, (p) records, (q) records, (r) records, (s) records, (t) records, (u) records, (v) records, (w) records, (x) records, (y) records, (z) records.

The laboratory should be able to handle the following types of work: (a) records, (b) records, (c) records, (d) records, (e) records, (f) records, (g) records, (h) records, (i) records, (j) records, (k) records, (l) records, (m) records, (n) records, (o) records, (p) records, (q) records, (r) records, (s) records, (t) records, (u) records, (v) records, (w) records, (x) records, (y) records, (z) records.

Reports must be filed on the following schedule: if new or revised results and papers are filed, the original and updated must be submitted annually.

5.6 LABORATORY OFFICESTAFF

Laboratory reports must be signed by a qualified individual from the Environmental Education Council. When under the control of a person who is not a staff member, reports may be kept in charge of the laboratory.

The environmental education officer must ensure that all reports are filed as per appendix B. The environmental education officer must also ensure that the results for general environmental education are filed in the appropriate folders.




FIGURE 16.1. CONVENTIONAL WATER TREATMENT SYSTEM SCHEMATIC.




FIGURE 16.2. FUNCTIONAL PHASES OF DYNAMIC PROGRAMMING

When eq. (16.41) is used, suspended solids concentration, pH and alkalinity of raw water are selected as design parameters for coagulation and that of $M(10)$ is pre-specified as 100 mg/l . The final balance then yields:

$$M(10) = X + Y + 100 \quad (16.42)$$

Where X = suspended solids concentration in the addition of 5 mg/l of coagulant,

Y = 100 mg/l of $M(10)$ to 100 mg/l of suspended solids.

X is the residual solids concentration in 5 mg/l in the effluent from rapid mix unit.

It is generally accepted that the primary design parameters of rapid mix are velocity gradient (G) and detention time (t). A long list of length-related factors such as pH and alkalinity is often mentioned, also influence the process of coagulation flocculation. The analysis of eq. (16.42) expressed in terms of velocity gradient and velocity gradient. The value of 100 mg/l has been removed as 100 mg/l .

16.4.2 SLOW MIX (FLOCCULATION UNIT)

The flocculation should be designed to generate particle aggregates such that the coagulating and flocculating of the suspended matter is improved. The important attributes in the design are the particle size, particle surface area of water. The effluent from the rapid mix unit will influence the flocculation unit. Assuming that no settlement of floc particles occurs in the flocculation basin, then the lower limit of suspended solids in the effluent would remain unchanged.

Thus:

$$M(10) = X + 100 \quad (16.43)$$

Where X = suspended solids concentration in the effluent from the flocculation unit

$M(10) = 100 \text{ mg/l}$ will remain constant in the effluent from the flocculation unit

Although the mass of suspended solids remains unchanged in the process of flocculation, the size of the particles increases from micro-particle to macro-flocculation size by the applied velocity gradient. The size of the aggregates thus formed is related to the velocity gradient as follows:

$$d = 1.75 G^{-0.4} t^{0.75} \quad (16.44)$$

Where d = particle diameter in micrometers (μm)

G = applied velocity gradient s^{-1}

t = flocculation time (s) - no experimental values are always available, determined experimentally.

For this recommended type of water treatment, the following relationship has been developed for eq. (16.44)

$$G = 17.6 \times 10^{-4} d^{-2.5} \quad (16.45)$$




FIGURE 16.3: INFORMATION FLOW DIAGRAM FOR WATER TREATMENT PROCESS

the rate of reaction of the dissolved species is determined by the rate of diffusion of the reactants into the reaction zone.

The rate of reaction of the reactants for a given flow rate can be increased by increasing the pressure, increasing the surface area of the particles, which are often done in industrial processes, and providing sufficient mixing. The rate of reaction is dependent on the rate of diffusion of the reactants into the reaction zone.

15.1.3 SURFACE REACTION RATE

The rate of surface reaction is given by the rate of change of the number of molecules per unit area of the surface of the reactants. The rate of surface reaction is given by the rate of change of the number of molecules per unit area of the surface of the reactants. The rate of surface reaction is given by the rate of change of the number of molecules per unit area of the surface of the reactants.

$$r_s = \frac{dN}{dt} \quad (16.1)$$

- (a) rate of surface reaction
- (b) concentration of reactants
- (c) surface area of the reactants
- (d) rate of change of the number of molecules
- (e) kinetic energy of the reactants

The rate of surface reaction is given by the rate of change of the number of molecules per unit area of the surface of the reactants. The rate of surface reaction is given by the rate of change of the number of molecules per unit area of the surface of the reactants.

$$r_s = \frac{dN}{dt} \quad (16.2)$$

The rate of surface reaction is given by the rate of change of the number of molecules per unit area of the surface of the reactants. The rate of surface reaction is given by the rate of change of the number of molecules per unit area of the surface of the reactants.

$$\frac{dN}{dt} = \frac{dN}{dt} \quad (16.3)$$

where,

$$\frac{\sum_{i=1}^n SS_i}{SS_2} = \text{observed solids rate ratio, } f_{\text{obs}},$$

$n =$ coefficient that identifies basis for variance

$SS_2 =$ surface overflow rate for ideal basin

$Q/A =$ required surface overflow rate to achieve the required efficiency

The value of n is assumed to be best (good) performance, 3-4 for average performance, 4-5 for poor performance, 5-6 for good performance and 7 for very poor performance.

A well designed sedimentation basin, regardless of the influent suspension concentration, should produce clarified water of turbidity less than 27 NTU or suspended solids less than 50 mg/L.

16.4.4 RAPID SAND FILTRATION

Filtration is an important step in the pollution control chain. Mathematical models are presented by most of the researchers for predicting filter performance. In the development of models, some idealized assumptions are made with regard to the nature of suspension in which filter beds are significantly. In a real life situations, also these models do not eliminate the need for some empirical constants. A method has been proposed for prediction of filter performance and demonstrated its effectiveness. In a variety of suspensions using different chemical coagulants and filter media, it was observed that the removal of particles per unit depth through a filter bed is quite similar to the Chi-square probability distribution. The variance (V) of this distribution is considered a measure of the clogging process and is related to the filtration rate as follows:

The ratio of concentration at any time (t) and any depth (L) to the influent concentration is equated to the cumulative probability (P) in the Chi-square distribution, i.e.

$$\frac{\sum_{i=1}^n SS_i}{SS_2} = P \quad (16.8)$$

The filtration rate (F) in hours is equated to the degrees of freedom (ν), i.e. $F = \nu$ (degrees of freedom)

The variables such as filtration rate, diameter of sand grain and the filter porosity are grouped into a single term (V) as under:

$$V = 0.25 F_1^{0.5} d^{0.5} \mu \quad (16.9)$$

Where,

- L = filter media depth, m/ft
 d = grain diameter, (1 - X_1)/ ρ_s , mm
 t = filter run time, hr

Similarly, the variables found to be statistically significant in the determination of suspended concentration have been grouped into a single term U as:

$$R = \frac{4.55d^{2.3}H}{L^{1.12}SS_1} \quad (15.12)$$

- Where,
 H = increase in head loss at the end of t , m
 SS_1 = influent suspension concentration, mg/l

Using the above two group terms, the performance prediction models developed are:

$$\log \left(\frac{t}{(1.5 \times 10^4)} \right) = -0.203 + 1.950 \log \left(\frac{Q}{(1.13 \times 10^6)} \right) + 0.64 \left[\log \left(\frac{U}{(1.33)} \right) \right] \quad (15.13)$$

$$\log \left(\frac{R}{(0.15 \times 10^3)} \right) = 3.250 + 1.612 \log \left(\frac{Q}{(1.13 \times 10^6)} \right) + 0.03 \left[\log \left(\frac{U}{(1.33)} \right) \right] \quad (15.14)$$

From the value of variable U obtained from above relationships, the probability $P(U)$ which can be expressed as normal deviate, $\left(\frac{SS_1 - SS_0}{SS_1} \right) Z_p$ could be read from the correlation table of Chi square distribution if compared mathematically using the expression:

$$R = \sum_{i=1}^{n-1} \frac{(f_i - E_i)^2}{E_i} \quad (15.15)$$

Using the above functional relationships, the filter performance can be predicted for various combinations of influent suspended solids concentration (SS_1), size of filter sand (d), flow rate (Q), depth of filter bed (L), length of filter run (t), and quartz (SS_0) and basins (H). A properly designed rapid sand filter should be capable of producing a filtered water of turbidity of less than 1 NTU, at SS_1 concentrations less than 2 mg/l.

16.4.5 DRINKING WATER

Treatment processes such as coagulation, flocculation, sedimentation and rapid sand filtration reduce turbidity, whereas chlorination degrades the bacteria content of water. However, they do not necessarily always produce a water safe from bacteriological point of view. Technical objections, especially, are raised, to assure the microbiological safety of the treated water. Chlorine and chlorine compounds are commonly used for disinfection in India. The dose of chlorine depends on the quality of the filtered water. If the filtered turbidity is consistently less than 1 NTU, the chlorine dose required may remain more or less uniform.

16.5 COST MODELS

The cost of the water treatment system includes costs of rapid mix unit, slow sand unit, sedimentation tank and well-type filter. These costs (civil, mechanical and electrical) depend on the capacity of the biological treatment unit required. While civil costs mainly include excavation and construction, the mechanical and electrical costs relate to the requirements of accessories necessary for efficient operation of the treatment units. These costs include the costs of motor assembly, including pump, motor and gear assembly etc. for rapid sand mixer (including shaft, gears, bearings, pulleys, etc.), motor drive, reaction drive unit for clarifier, motor and drive costs of open penstock, such as motor setting, rate of flow controller, flow indicator, flow flow indicator, air blower, submersible pump, etc. For rapid gravity filter, the costs can be divided separately for individual treatment unit and expressed in the following form as unit:

$$C_{11} = 1.15 \times 10^{-4} Q^{0.75} \text{ (where } Q \text{ is in } m^3/\text{min)}$$

The station design law, developed for the design of water works such as raw water pumps, raw water intakes, clarifiers, filter, distribution, clear water pumps, etc., is also the same with a few minor variations in the same irrespective of variation in the size of the treatment unit and flow capacity considered in the economic analysis.

16.6 PROBLEM FORMULATION

How could we find a number of designs which would satisfy the product quality standards prescribed in the Model. The objective function, should be to minimize the system cost satisfying all the constraints. A rational comparison of various feasible designs should be based on the capitalized cost or annualized cost of the system. Hence, the objective function will be

$$\text{Minimize } Z = \sum_{i=1}^n C_i \quad (16.11)$$

Where,

C_1 = annual cost of M_1 of primary treatment unit

C_2 = annual cost of M_2 of secondary treatment unit

Where,

C_0 = annualized capital cost

C_M = annual maintenance cost of civil works

C_{MM} = annual maintenance cost of mechanical equipments/machinery

C_E = annual energy cost

$$TCR = C_0 \frac{(1+i)^n}{(1+i)^n - 1}$$

Where,

C_0 = Capital cost, i.e. cost that civil and mechanical) of the treatment unit

i = rate of interest

n = number of years over which the capital cost is to be repaid.

CONSTRAINTS

- ◆ Suspended solids concentration in the effluent from clarifier 2, 50 mg/l
- ◆ Suspended solids concentration in the filtered water = 2 mg/l
- ◆ Diameter of clarifier 2 = 30 m
- ◆ Retention time, T_R in clarifier 2 = $1.5 \leq T_R \leq 4 \text{ hrs}$
- ◆ Flow loading rate = $1.5 \text{ m}^3/\text{m}^2/\text{d}$
- ◆ Length of filter run = 2 Mm
- ◆ Maximum headloss in the filter bed $\leq 3 \text{ m}$

SOLUTION

The flow chart for computer aided factorial and minimum cost design of water treatment system is presented as Fig. 16.1. The major inputs required are

- (i) Design data on input, decision or a state variables and size/length
- (ii) Data for formulating the cost models for treatment units.





FIGURE 16.4: ALGORITHM FOR COMPLETE FUNCTIONAL AND MENTAL COST DESIGN OF CONVENTIONAL WATER TREATMENT SYSTEM



CHAPTER 17

FINANCING AND MANAGEMENT OF WATER SUPPLY PROJECTS

17.1 WATER SUPPLY FINANCING

The aim of any water supply engineering project is to provide safe and adequate supplies of potable water to the beneficiary population. The main activities involved in the design of water works (planning, design, construction and installation) as well as the understanding of the elements of financial policy, etc.,

- (i) The equitable spreading of the cost of water supply by means of appropriate scales of charge and a potable water tariff.
- (ii) The economic aspects of the operation and maintenance of the works, the methods of providing the capital needed, the nature of the charges and the means of providing for the repayment of such capital.

Apart from the above, however, in the water supply sector features considerations of expanding requirements of the community, the need to increase the quality of services, the living habits and also increasing requirements for technological developments in agriculture, industry, etc.

17.1.1 SCOPE

The salient features of water supply financing are:

- ◆ Methods of raising capital for the construction of the water supply project and the repayment of loans when needed.
- ◆ Methods of raising revenues to cover the annual expenses of water supply including the determination of tariffs and the usual economic return on charges.
- ◆ The application of economic devices in water charges.
- ◆ The formation and use of reserves and contingencies funds.
- ◆ Accounting, in connection with the related expenditure.
- ◆ Wages, store and other services charges.
- ◆ Financial organization and the various sources of income including the various payments, internal and external, including the interest.

Notes

1. The β coefficient in the regression model is the slope of the regression line for the dependent variable on the independent variable. It is the change in the dependent variable for a one-unit change in the independent variable.
2. The β coefficient is also known as the slope of the regression line. It is the change in the dependent variable for a one-unit change in the independent variable. The β coefficient is also known as the slope of the regression line. It is the change in the dependent variable for a one-unit change in the independent variable.

17.3. APPLICATIONS: S&P 500 INDEX

Suppose that the return on the S&P 500 index is given by the following equation:

Concepts

The return on the S&P 500 index is given by the following equation: $R_{S\&P} = \alpha + \beta R_M + \epsilon$, where R_M is the return on the market portfolio, α is the intercept, β is the slope, and ϵ is the error term.

- (a) The return on the S&P 500 index is given by the following equation: $R_{S\&P} = \alpha + \beta R_M + \epsilon$.
- (b) The return on the S&P 500 index is given by the following equation: $R_{S\&P} = \alpha + \beta R_M + \epsilon$.

(c) Results

The return on the S&P 500 index is given by the following equation: $R_{S\&P} = \alpha + \beta R_M + \epsilon$. The return on the S&P 500 index is given by the following equation: $R_{S\&P} = \alpha + \beta R_M + \epsilon$. The return on the S&P 500 index is given by the following equation: $R_{S\&P} = \alpha + \beta R_M + \epsilon$.

17.4. SOURCES OF FIRM FINANCING: PAPER

The sources of firm financing are given by the following equation:

- (a) The sources of firm financing are given by the following equation: $F = \alpha + \beta R_M + \epsilon$.
- (b) The sources of firm financing are given by the following equation: $F = \alpha + \beta R_M + \epsilon$.
- (c) The sources of firm financing are given by the following equation: $F = \alpha + \beta R_M + \epsilon$.
- (d) The sources of firm financing are given by the following equation: $F = \alpha + \beta R_M + \epsilon$.
- (e) The sources of firm financing are given by the following equation: $F = \alpha + \beta R_M + \epsilon$.
- (f) The sources of firm financing are given by the following equation: $F = \alpha + \beta R_M + \epsilon$.
- (g) The sources of firm financing are given by the following equation: $F = \alpha + \beta R_M + \epsilon$.
- (h) The sources of firm financing are given by the following equation: $F = \alpha + \beta R_M + \epsilon$.
- (i) The sources of firm financing are given by the following equation: $F = \alpha + \beta R_M + \epsilon$.
- (j) The sources of firm financing are given by the following equation: $F = \alpha + \beta R_M + \epsilon$.
- (k) The sources of firm financing are given by the following equation: $F = \alpha + \beta R_M + \epsilon$.
- (l) The sources of firm financing are given by the following equation: $F = \alpha + \beta R_M + \epsilon$.
- (m) The sources of firm financing are given by the following equation: $F = \alpha + \beta R_M + \epsilon$.
- (n) The sources of firm financing are given by the following equation: $F = \alpha + \beta R_M + \epsilon$.
- (o) The sources of firm financing are given by the following equation: $F = \alpha + \beta R_M + \epsilon$.
- (p) The sources of firm financing are given by the following equation: $F = \alpha + \beta R_M + \epsilon$.
- (q) The sources of firm financing are given by the following equation: $F = \alpha + \beta R_M + \epsilon$.
- (r) The sources of firm financing are given by the following equation: $F = \alpha + \beta R_M + \epsilon$.
- (s) The sources of firm financing are given by the following equation: $F = \alpha + \beta R_M + \epsilon$.
- (t) The sources of firm financing are given by the following equation: $F = \alpha + \beta R_M + \epsilon$.
- (u) The sources of firm financing are given by the following equation: $F = \alpha + \beta R_M + \epsilon$.
- (v) The sources of firm financing are given by the following equation: $F = \alpha + \beta R_M + \epsilon$.
- (w) The sources of firm financing are given by the following equation: $F = \alpha + \beta R_M + \epsilon$.
- (x) The sources of firm financing are given by the following equation: $F = \alpha + \beta R_M + \epsilon$.
- (y) The sources of firm financing are given by the following equation: $F = \alpha + \beta R_M + \epsilon$.
- (z) The sources of firm financing are given by the following equation: $F = \alpha + \beta R_M + \epsilon$.

- International agencies such as the World Bank, Asian Bank, International Development Association, etc.

17.3.1 AUTHORITY RESPONSIBILITY

It is the responsibility of the local body to carry out being responsible for water supply to provide to its rural adequate water supply. It may be responsible starts its in the rural water supply through the various stages (i.e. Planning, and detailed investigations, design, identification, financial and technical arrangements, construction, operation and maintenance, and upto the termination of the loan) from start to the project. The role of other agencies such as the State Government in the rural programme is only to help the local body to achieve its objective by furnishing the technical and administrative services necessary for the purpose to regard to the financial arrangements. The local body is responsible for and to be exempt in the services where the State Government agrees to meet a part of its total capital budget according to its accepted policy.

The problems facing the local body is how to finance it. The total capital to meet the heavy investment of the schemes under this scheme may also include the repairing the line over a period of years. The local body has to bridge the repairing expense of the beneficiaries against the capital loan secured for the purpose. The success of the project is guaranteed by the assurance of a safe and sufficient water supply to every community. The financial of the local body is to sponsor the project on behalf of the community. The State and Central Governments generally provide the necessary technical and administrative services to implement the project and money for the capital funds necessary there for. When loans are to be raised by the local body, the State Government acts as a security for the local body to underwrite its financial capacity. It is in recognition of these basic principles of financing and management of water supply facilities for communities that the World Bank and especially the I.D.A. have come out with its assistance for a community water supply to the different countries as part of a rural programme.

Financial autonomy can be built into the operation of water supply systems through revolving funds, welfare loan funds and distribution sales in the open market and to public investment institutions as well as assistance from international, bilateral financing agencies. The use of each method or some combination of them, has proven effective elsewhere in financing water systems on the way to self support, relieving the State and Central Government of some part of their burden of support. The local bodies/water supply undertakings should realise that the objectives have to be self supporting.

No proposal for supplying water to a community should be considered complete until adequate arrangements for the disposal of the community waste water are included. A proper strategy as a sum of the direct and indirect effects of water supply and sewage facilities for water supply should also be made to present the financial implications in proper perspective. It will be seen that the consequences of postponing these facilities will be greater than the cost of providing them.

17.3.3 THE REVENUÉ METHODS OF THE VARIOUS METHODS

The sharing of a load from the Government is best with the difficulty that the Government will not be able to change. If local bodies interested in the provision of water supply really do not like to share and want to, the local body will have to share priority for its scheme, advantage, etc. with a number of other, the State Government may go in for a water supply "fund" of the Government as a borrowing agency to meet, and other agencies should consider the value of its funds for the purpose of the fund, and the value of the water supply which class of investment and a part of the Government's budget.

Direct or indirect on the project would include the estimate of the annual price of the fund investment to be adjusted for against the local body's own expenditure for and water charges. The potential revenue of the fund not been proposed for should be taken full advantage of.

Indirectly, the local body may be able to get a part of the water supply in reasonable rates of interest and be able to use it to explain this to the public.

The Government's Agreement, based on certain conditions relating to the provision of the project, its construction, operation and maintenance, and the local body's contribution.

17.4 METHOD OF RAISING REVENUE

The source of revenue for the fund is the Government's tax, such as water tax, or a part of the general property tax which is raised by assessment on all taxable property and water rates paid by those who use the water, more or less in proportion to the amount consumed.

17.4.1 WATER TAX

Since the provision of a water supply increases the value of the property, a water tax is justifiable on the actual rental value of the property. This may be a separate tax or included in the general property tax. It is desirable that the revenue under this head is earmarked for water supply purposes.

The supply of water for general purposes such as the supply through public fountains, parks, or public restrooms, for fire protection, etc., which no charge is levied on the public individuals or collectively, the local body has to support a part of its income from general taxes for meeting this obligation. This will help the water supply of the local body to average no affairs on a sound business footing. This revenue is awarded for the local body as it is independent of the actual quantity consumed and the party concerned. This revenue is preferably utilized to pay annuity charges on the loan obtained for the installation of the water supply system and can be adjusted to meet this commitment fully.

17.4.2 WATER RATES

The revenue from the sale of water or water rates recoverable from parties actually consuming the water such as for domestic purposes or for commercial and industrial purposes is utilised to meet the annual recurring cost of operation and maintenance and to provide for a reserve for meeting the capital expenses for future improvement to the system.

At the same time, it is important to remember that the model is not a substitute for which the specific details of a particular case are required.

The purpose of this report is to provide a general overview of the current state of research on the effects of the environment on the development of the child. It is not intended to be a comprehensive review of the literature on this subject, but rather a summary of the major findings and their implications for practice. The report is organized into three main sections: (1) a review of the current state of research on the effects of the environment on the development of the child; (2) a discussion of the implications of this research for practice; and (3) a conclusion.

The first section of the report reviews the current state of research on the effects of the environment on the development of the child. This section is organized into three main areas: (1) a review of the current state of research on the effects of the environment on the development of the child; (2) a discussion of the implications of this research for practice; and (3) a conclusion.

Second, it should be noted that the model is not a substitute for which the specific details of a particular case are required. The model is a generalization of the findings of research on the effects of the environment on the development of the child. It is not intended to be a comprehensive review of the literature on this subject, but rather a summary of the major findings and their implications for practice. The model is organized into three main sections: (1) a review of the current state of research on the effects of the environment on the development of the child; (2) a discussion of the implications of this research for practice; and (3) a conclusion.

- (1) The model is a generalization of the findings of research on the effects of the environment on the development of the child. It is not intended to be a comprehensive review of the literature on this subject, but rather a summary of the major findings and their implications for practice.
- (2) The model is organized into three main sections: (1) a review of the current state of research on the effects of the environment on the development of the child; (2) a discussion of the implications of this research for practice; and (3) a conclusion.
- (3) The model is a generalization of the findings of research on the effects of the environment on the development of the child. It is not intended to be a comprehensive review of the literature on this subject, but rather a summary of the major findings and their implications for practice.

It is important to remember that the model is not a substitute for which the specific details of a particular case are required.

17.5 WATER SUPPLY MANAGEMENT

Efficient and effective management of water supply services is most essential for the people and the nation. The water supply organization should be treated as a business enterprise. An effective management skills and engineering knowledge is vital to successful management of a water supply organization. The following concepts applied should be the prime considerations for any water supply organization in the safety and health of the people depend upon it.

The successful management of public resources in the running of a water supply organization will be a successful stakeholder's response to the need of the management.

17.5.1 SCOPE

The good management of a water supply system includes a number of functions such as:

- (i) Policy development and management of adequate facilities,
- (ii) Local and network operation,
- (iii) Billing and revenue generation management,
- (iv) Finance administration,
- (v) Total demand of service requirements,
- (vi) Development of suitable water control and water rates,
- (vii) Diffusion of water supply projects and services,
- (viii) Long-term planning and investment strategy,
- (ix) Good public relations and customer services to consumers and
- (x) Development of technical and managerial plans for future expansion.

17.5.2 TASKS

A successful management involves:

- (i) Acquired knowledge of the components of the system, the basis of their design and the assumptions made.
- (ii) Objective plans which takes account of the work, past, present and future and become a model.
- (iii) Promptness to carry out plans to meet any contingencies and unforeseen conditions.
- (iv) Detailed job specifications.
- (v) Prescription of the roles, powers and responsibilities of each employee of the organization to be managed, and their location, managers and to prepare a list of "do's and don'ts" for employees and staff.

- (vi) The manual should be drafted in a form which can be easily understood by the operators, particularly in the language they are accustomed to.
- (vii) A quantity of spare parts and accessories of various sizes, drawings, lubrication charts for machines and tools should be available even after a decade or two, because it is very likelihood that they cannot be obtained from manufacturers etc. due to possible change of design or other reasons.
- (viii) There should be an allocation of responsibilities and efficiencies in the working of the system.
- (ix) A continuous and intensive training of the personnel is essential and mandatory.
- (x) Recognition of team and individual working efficient men is mainly one part of higher responsibility. The one is selected at the construction stage should be preferred as key person in the future and the appointment of another stage now the system had been put together and is in the mode of its working.
- (xi) A thorough knowledge of the machine methods including financing, budgeting, billing and a complete collection of work and maintenance of the system.
- (xii) Training can be in the form of programmes to provide for the operation of the machine, not only providing the maintenance of the entire system but also making that equipment at some of projected system with a view to prevent wastage.

7.6 FINANCIAL APPRAISAL OF WATER SUPPLY PROJECTS

7.6.1 INTRODUCTION

Financial appraisal is the analysis of the economic benefits of a proposed project with a view of choosing a rational alternative of social selection among alternative investments opportunities in view of achieving a more specified goals for the National Development Programme. In the appraisal of projects, to carry the identified needs exceed the resources available project appraisal becomes necessary to choose between alternative one or more package of projects. Moreover, financial project analysis with a more realistic and sustainable assumptions are indicated a project can be considered to be a project is readily presentable in any form of project can be analyzed and assessed on the basis of the analysis has a much in project appraisal as a fundamental tool for cost-benefit analysis and results arrived.

In project analysis, there are a number of variables identification to be kept in mind together to be complementary points of view are:

- (a) Economic analysis and
- (b) Financial analysis.

Necessary analysis is concerned with the cost-benefit or the advantage or profitability to be gained by means of all the resources committed to the project, regardless of where the source of funds are derived or whether the activities involves the benefits.

the social cost transfer or economic analysis aims at evaluating the gas market reforming on the impact on the society as a whole, while the financial cost benefit analysis is set to assess the profitability to the operators only.

Accounting principle is used in social cost benefit analysis to establish the uncorrelated basic relationship between goods, prices and discounts. It is often an easy way of doing this. The first method known as tariff and World received government's ruling. It regards and services in terms of world prices without taking of exchange rate. The second method known as CMBCE method envisages that world prices and services in terms of their manifestation in manufacturing, domestic goods, exports and imports prices, and the method of conversion to domestic price follows by the use of Shadow Exchange Rate (SE) process of the cost relating to allow an anti-export distortions between domestic and world prices.

On the other hand, the new analysis is concerned with the individual financial entities which participate in a project, as entrepreneur, business, industry, public agencies, etc. each is characterised in the nature of the nature of the contribution. Project appraisal is very important for the employing organisations and also for the interests of achieving a project work at a budget. Financial cost-benefit analysis help to understand the needs and welfare of the people.

The appraisal is carried out by using the following formula. Financial supply (cost) requires deriving value of the cost minus value (BFA) at any rate of return (RR) and its benefit (cost) is $(1 - RR) \times \text{cost}$. The main details are as follows:

Net present worth for Net present value (NPW) (NPV)

This is defined as the present value of the net benefits, i.e. present discounted of the opportunity cost of cost.

$\text{NPW} = \text{cost} - \text{cost} \times (\text{Present value}) \times \text{cost} = \text{Net benefits} - \text{cost}$

Internal rate of return (IRR)

This is defined as any discount rate which makes the present worth of benefits equal to the present worth of cost. The relevant parameters for a project over the life of the project are the revenues and cost of the project.

The discount rate (RR) and PV of the cost and income of different discounting rates (0% to 7% being the higher and lower discounting rate).

$$IRR = \frac{\text{cost} - \text{cost} \times PV}{\text{cost} - \text{cost}}$$

Benefit Cost Ratio (B/C Ratio)

This is defined as the ratio of the total benefits to the present worth of costs.

17.6.2 Project CCEB

Any project has a number of financial and non-financial costs.

Objectives

By the end of this course, you should be able to apply your knowledge of probability distributions to solve problems involving continuous random variables.

Introduction

Probability is a branch of mathematics that deals with the study of random events. It is a measure of the likelihood of an event occurring. Probability is used in many areas of science, engineering, and business.

Probability distributions are a collection of probability values that describe the likelihood of an event occurring. There are many types of probability distributions, including the normal distribution, the binomial distribution, and the Poisson distribution. Each distribution has its own unique properties and is used to model different types of random events.

Introduction

Probability distributions are a collection of probability values that describe the likelihood of an event occurring. There are many types of probability distributions, including the normal distribution, the binomial distribution, and the Poisson distribution. Each distribution has its own unique properties and is used to model different types of random events.

Probability Distributions

- Normal
- Binomial
- Poisson
- Exponential

Probability distributions are a collection of probability values that describe the likelihood of an event occurring. There are many types of probability distributions, including the normal distribution, the binomial distribution, and the Poisson distribution. Each distribution has its own unique properties and is used to model different types of random events.

Probability distributions are a collection of probability values that describe the likelihood of an event occurring. There are many types of probability distributions, including the normal distribution, the binomial distribution, and the Poisson distribution. Each distribution has its own unique properties and is used to model different types of random events.

Probability distributions are a collection of probability values that describe the likelihood of an event occurring. There are many types of probability distributions, including the normal distribution, the binomial distribution, and the Poisson distribution. Each distribution has its own unique properties and is used to model different types of random events.

Probability distributions are a collection of probability values that describe the likelihood of an event occurring. There are many types of probability distributions, including the normal distribution, the binomial distribution, and the Poisson distribution. Each distribution has its own unique properties and is used to model different types of random events.

Some central equipment – by the time the work has nearly finished, it will be almost ready to go. It is a good idea to think about this.

The development of a design and construction programme is a long one and it will probably not be possible to carry out a design to a standard to which the full range of these conditions has to be met. It is possible to make a design to a lower standard than the conditions to be met, and to provide a programme of work to meet the conditions of the design.

(iv) Negotiations with the Financing Institution

The negotiations will involve the funding agency and the borrower and their agents on the one side and the lender on the other. It is important to ensure that the funding agency is satisfied that the borrower has a good understanding of the conditions of the loan and that the borrower is capable of meeting the conditions. It is also important to ensure that the borrower is satisfied that the funding agency is satisfied with the borrower's ability to meet the conditions of the loan. It is important to ensure that the borrower is satisfied that the funding agency is satisfied with the borrower's ability to meet the conditions of the loan.

(v) Implementation and Supervision

The implementation of the project is a long and complex process. It is important to ensure that the borrower is satisfied with the implementation and supervision of the project.

(vi) Evaluation and Completion

The evaluation of the project is a long and complex process. It is important to ensure that the borrower is satisfied with the evaluation and completion of the project.

17.6.2 FINANCIAL APPRAISAL

The financial appraisal of a project is a long and complex process.

- (i) To determine the project's financial viability, which is done by calculating the project's net present value (NPV) and the project's internal rate of return (IRR). The NPV is the sum of the present values of the project's cash flows, discounted at the project's cost of capital. The IRR is the discount rate that makes the NPV equal to zero.
- (ii) To estimate the level and timing of the project's cash flows, which are done by estimating the project's revenue and costs.
- (iii) To estimate the project's initial investment and operating expenses, which are done by estimating the project's capital and operating costs.

The financial appraisal of a project is a long and complex process. It is important to ensure that the borrower is satisfied with the financial appraisal of the project.

The financial appraisal of a project is a long and complex process. It is important to ensure that the borrower is satisfied with the financial appraisal of the project.

Two important factors which lead to the distinction between financial analysis and economic analysis are:

- (a) exclusion / inclusion of some costs and benefits in the appraisal of a project; and
- (b) valuation of costs and benefits at market prices or some other prices.

In the Project Appraisal Technique, the costs and benefits of the project in financial / economic terms are evaluated. It is easy to identify costs and benefits in financial terms, whereas it is difficult to identify, in economic terms. The project incurs expenses on capital resources, such as machinery and equipment, operation and maintenance cost, purchase of raw materials, payment of wages and output of goods and services etc. In addition, the project has to pay taxes, import duties, to repay the loan with interest and allow for the depreciation of fixed assets. The project gets its return from the sale of goods and services and also receives subsidy, if allowed by the Government, which reduces the cost burden to the firm.

Two types of costs and benefits are encountered in the appraisal of a project one involves the use of resources, and the other which does not involve use of resources, but it is a transfer of resource from the project to the Government or any other institution / individual (taxes, fees, duties, loan repayment and interest) or vice-versa (subsidies). Thus in the identification of costs and benefits, it is needed to deal with each individual item, briefly described below.

(i) Transfer Payments

(a) Depreciation

It is a provision of funds over the life time of the project for its replacement. Depreciation is excluded from the economic appraisal of a project as it is only an accounting concept.

(b) Interest rate

Similarly, in the economic analysis no allowance for interest on the capital employed is made as the analytical technique automatically takes care of the return of capital (interest) in determining the worth of a project.

(c) Opportunity cost

In the economic analysis, estimated income foregone would feature as cost, while in the financial analysis, it would not feature as cost.

(d) Taxes

Taxes are also transfer payments. In the financial analysis where analysis is done from the point of view of the individual entity of a project, all taxes are treated as financial costs and benefits is done from the point of view of society, taxes are transfer payments. Taxes are not included as cost in economic appraisal as they are in the nature of transfer payments which do not involve the use of resources. But in the case of financial appraisal, taxes are included on the cost side as it is a financial cost to the project. This would apply to all types of taxes (income tax, import duties, local taxes etc).

(v) Subsidies

In financial analysis, subsidy reduces cost and adds to the income of the project. In the case of economic analysis, it is a transfer payment, as it does not add or subtract income from the point of view of society.

(vi) Social Costs and Benefits

In financial analysis, social costs such as air pollution, noise, wear and tear of road etc., would not enter in costs in the calculations as these are no costs to the individual project. But social costs should be included in an economic analysis when the project is appraised from the point of view of society.

(vii) Solution of proper prices

In financial analysis, costs and benefits are calculated at market prices. But in economic analysis, costs and benefits are calculated after making certain adjustments in market prices. The primary, of course, is the efficient use of available resources which have alternative uses. An economy should utilize more intensively that resource whose price is lower compared to a resource whose price is higher. However, since markets of the factors of production are not perfect in reality, the price of an item may not correctly reflect the scarcity or abundance of the factors of production.

However, the prevailing market price does not reflect the intrinsic value of goods as they are distorted in many developing countries due to the following factors:

- (a) Inflation
- (b) Currency overvaluation
- (c) Wage rate and unemployment
- (d) Imperfect capital markets
- (e) Tariffs, import quotas
- (f) Inequality in distribution of wealth.

For example, in a labour surplus economy, given the supply of and demand for labour, market wage would be higher than the wage that should be operated, based on the equilibrium of demand and supply.

Similarly the official foreign exchange rate may not correctly show the scarcity or abundance of foreign exchange. In the economic analysis, costs of items are calculated not on the basis of prevailing prices in all cases, but on modified prices assumed on the basis of their supply and demand position. These assumed prices are termed as shadow prices or accounting prices.

Also the prices charged for the product of a project may be lower for various socio-economic considerations. In such cases, the modifications of the selling price of an item is clear in economic analysis.

17.64 FINANCIAL ANALYSIS STANDARDS

The financial viability of the proposed project is analysed by the following methods: a detailed financial appraisal, based on the 30-year period of the proposed plant; the Rule of 100, which is a simplified method of estimating the payback period; and the average payback method. The above parameters are used as a guide to evaluate the viability of the project. They are fixed at 10, 12 and 15 years, respectively, for the purpose of the present study. The payback period is the time taken for the investment to be recovered and indicates the period of the project.

The average payback method is calculated as follows: $\text{Average payback} = \frac{\text{Initial investment}}{\text{Average annual net cash flow}}$. The average payback period is the number of years for the average cash flow to equal the investment.

The payback period is calculated as follows: $\text{Payback period} = \frac{\text{Initial investment}}{\text{Net Annual Cash Flow}}$. The payback period is the number of years for the net annual cash flow to equal the investment.

Payback period = $\frac{\text{Initial investment}}{\text{Net Annual Cash Flow}}$

Payback period = $\frac{100}{\text{Payback period} \times \text{Net Annual Cash Flow}}$

Payback period = $\frac{\text{Initial investment}}{\text{Average Annual Cash Flow}}$

A detailed analysis of the financial viability is reported (Appendix 17.3).

The management should determine carefully, income and expenses in statement of source and products, cost of fuel, power, flow, and labour, and then determine the financial viability of the project. The financial viability is reported (Appendix 17.4, 17.5 and 17.6).

The working system is shown in Appendix 17.7. The working system includes the working system and is described in Appendix 17.8. The working system for running in the factory is given in Appendix 17.9.

The financial analysis of the project is based on the following working terms and conditions: a working period of 25 years; a replacement of 5 years; a maintenance cost of 10% of the initial cost.

The results of the financial analysis indicate that the project can meet its commitments. The initial investment is maintenance cost and 5% of the throughput of the plant is a component of working system.

The financial analysis of the project is based on the following working terms and conditions: a working period of 25 years; a replacement of 5 years; a maintenance cost of 10% of the initial cost.

The initial cost of the project is Rs. 100 million. The monthly water charges are fixed at Rs. 200 per acre per month (i.e. Rs. 2400 per acre per year). Taking into account the prime capacity of the assets. At the same time, the price is fixed to meet the financial cost of 75% of the plant. It is necessary to meet this project a financially viable one. If 75% of the plant is not met, there will be a loss of 5%.

For any complex function $f(z)$ of a complex variable $z = x + iy$, the real and imaginary parts of $f(z)$ are denoted by $u(x, y)$ and $v(x, y)$, respectively. The function $f(z)$ is said to be analytic at a point z_0 if $f(z)$ is differentiable at z_0 .

17.7 STATEMENT OF CAUCHY-RIMANN CONDITION

Let $f(z) = u(x, y) + iv(x, y)$ be a complex function of a complex variable $z = x + iy$, where $u(x, y)$ and $v(x, y)$ are real-valued functions of the real variables x and y . Then $f(z)$ is analytic at a point $z_0 = x_0 + iy_0$ if and only if the following conditions are satisfied at z_0 :
(i) $u(x, y)$ and $v(x, y)$ are real-valued functions of the real variables x and y .
(ii) $u(x, y)$ and $v(x, y)$ are differentiable at z_0 .

Conversely, if $u(x, y)$ and $v(x, y)$ are real-valued functions of the real variables x and y which are differentiable at $z_0 = x_0 + iy_0$ and satisfy the Cauchy-Rimann conditions at z_0 , then $f(z) = u(x, y) + iv(x, y)$ is analytic at z_0 . In other words, the Cauchy-Rimann conditions are necessary and sufficient for the analyticity of $f(z)$ at z_0 .

The Cauchy-Rimann conditions can be written in the following form:
(i) $u_x = v_y$ and $v_x = -u_y$ at z_0 .
(ii) $u_x^2 + v_x^2 = u_y^2 + v_y^2$ at z_0 .

- Let $f(z) = u(x, y) + iv(x, y)$ be a complex function of a complex variable $z = x + iy$.
- Let $z_0 = x_0 + iy_0$ be a point in the complex plane.
- Let $u(x, y)$ and $v(x, y)$ be real-valued functions of the real variables x and y .
- Let $u(x, y)$ and $v(x, y)$ be differentiable at z_0 .
- Let $u_x = v_y$ and $v_x = -u_y$ at z_0 .
- Let $u_x^2 + v_x^2 = u_y^2 + v_y^2$ at z_0 .
- Then $f(z)$ is analytic at z_0 .

As a consequence of the Cauchy-Rimann conditions, we can show that if $f(z) = u(x, y) + iv(x, y)$ is analytic at $z_0 = x_0 + iy_0$, then $u(x, y)$ and $v(x, y)$ are harmonic functions. In other words, $\nabla^2 u = 0$ and $\nabla^2 v = 0$ at z_0 .

The Cauchy-Rimann conditions can be written in the following form:
(i) $u_x = v_y$ and $v_x = -u_y$ at z_0 .

and disposal of sewage from the area as well as other utilities. and it is, however, possible that some local bodies may prefer to purchase water supply from the statutory Board and arrange for the installation, extension, maintenance and management of the statutory board take over sewage mains from the local area and arrange for its treatment and disposal. This should be avoided as far as possible as the supply and distribution of water as also collection and disposal of sewage are interconnected functions and the division of such functions amongst two independent agencies might lead to inefficiency and avoidable difficulties for both parties. Any local body managing its systems intelligently need not necessarily come under much of a debt.

17.8 CONCLUSION

In India water is considered a "free gift of nature" and therefore charging for water by any agency, may it be a Municipal Corporation, General/Panchayat or a Water Board, is not taken by the people. Providing water supply services are considered to be a commercial activity no production activity.

The situation has since changed considerably. Despite use of water for increased sizes of human settlements and increasing rates of industrial and agricultural uses of water have increased considerably. As the reliable sources of water are getting exhausted, we have to go in for additional sources of supplies, viz. galas, drilled tube wells, as also the pollution of surface and ground water being caused by discharges of industrial and domestic wastes have rendered the problem of meeting even drinking water demand increasingly difficult and expensive.

No doubt, water is still the free gift of nature but it is some "public good" condition. When it is desired that water, as a resource, a service, should be made available, demand and transported to the points of consumption. In contrast to "Commons" as it was in economic value. A water works must therefore be managed as an industry and be built and operated as a "Commercial enterprise" with professional approach of engineering and safety to meet the debt servicing and operational costs. In order to attract investment on the investment made, so that there is no loss of the water works and an industry, either public and the undertaking can attract funding from outside agencies. As in the case of other handling of water works, water pricing policy and overall financial management of water supply undertakings have been receiving much attention. The situation has improved both at National and State levels.

Government had launched the Integrated Urban Water Supply and Sewerage Development Scheme with effect from 1981. Hence both the Central and State Governments have been providing appreciable financial assistance to the local bodies for construction of new facilities and for augmentation/maintenance of existing works. More than 50 per cent of the Central and Union Territories capital expenditures on water supply are fully funded by the States/Union Territories and the Central Government also provide Grants to the State and Union Territories, under Accelerated Rural Water Supply Programme.

For financing Urban Water Supply Projects, usually the following sources of funds are available:

- (i) Internal borrowing;
- (ii) Government grants and loans;
- (iii) IFC loans;
- (iv) Open market borrowing;
- (v) Loan from financing institutions; and
- (vi) International/Bilateral aids

If a water supply undertaking has to function in the long run on a self-reliant basis, it must charge for supply of water and collect revenues adequate for meeting debt servicing, operation and maintenance charges and also generate surplus for future investment.

If water could be sold to all consumers at the same rate, like any other commodity in a free market, the water tariff structure could be simple. In that case it would be necessary only to fix water charges at suitable intervals of time and charge for sale of water accordingly, depending upon the basis for charging of water i.e. metered supply, non-metered supply etc. However, tariff based on uniform rates of water cannot be adopted in a country like India, where a large percentage of population is below poverty line. Water is to be made available to all in quantities sufficient to meet atleast the minimum needs.

Therefore, appreciable quantities of water may have to be supplied to poor section of the society either free of cost or at adequately subsidised rates, which would be much less than the unit cost of water. The loss thus incurred will have to be made good by charging higher rates to consumers who can afford to pay those rates such as industries, commercial establishments, traders, professionals as well as owners of high value properties, etc. Therefore, it is necessary to identify different categories of consumers as stated above including poor section in a city or town and estimate the likely consumption of water by each of these categories of consumers. Graded rates of water will have to be fixed for these consumer categories, considering their paying capacities, such that the total annual revenue receipt would be equal to or more than the total annual burden.

Water tariff structure also depends upon the methods of charging for sale of water. Generally these are based on:

- ◆ Percentage of rateable value of a property;
- ◆ Flat rate depending upon size of a connection, and
- ◆ Metered supply

Charging on the basis of volume as measured by meters is the most equitable and rational method, as a consumer pays directly in proportion to the water consumed. Moreover metering helps in accurately estimating the consumption of water by various categories and in locating wastages and leakages. However, this method of charging has the following disadvantages:

- ◆ Metering increases unit cost of water;

- ◆ Meters often go out of order, requiring frequent removal, repairs and reinstallation; and hence accurate measurement of water is not possible;
- ◆ Large skilled staff is required for installations, repairs, testing, reading and billing;
- ◆ Fixing of a meter reduces pressure,
- ◆ Where unfiltered supply is made, meters often choke, requiring frequent cleaning;
- ◆ Where water supply is intermittent, meters may record more reading than the actual consumption of water,
- ◆ During temporary absence of meter (when removed for repairs or testing) or when it is not in working order, billing on the basis of average consumption in the past, is often disputed by consumers and this situation affects recovery of bill.

For the above reasons, universal metering of water is not being practised. Generally only bulk consumers, like industries, institutions, commercial establishments and large premises like co-operative housing societies, etc. are metered, while as individual domestic consumers are charged on the basis of either flat rates depending upon the size of connections or as percentage of rateable value of a property served.

From the foregoing paragraphs it will be clear that selection of a suitable tariff structure needs consideration of aspects such as income distributions, the possible mix of service levels and the systems of charging. In short the social objectives and systems constraints would influence the tariff structure. Generally the tariff structure should aim at:

- ◆ Collecting target revenue;
- ◆ Sharing out the burden fairly between users of different income groups (by providing different levels of services); and
- ◆ Administrative simplicity and efficiency.

To these aims must be added the one for influencing consumer behavior. In other words pricing policy must be such that it would induce consumers to economise use of water. Considered from this angle, charging on the basis of rateable value of a property or collective metering of an apartment block are the systems which provide little incentive to economise on use of water.

Annual burden imposed by a water supply scheme consists of two components, viz.,

- ◆ Fixed charges comprising debt servicing and such staff and minimum maintenance charges as are necessary to be incurred.
- ◆ Variable charges comprising power, chemicals and raw water bills which are proportional to the quantity of water produced.

When a facility like a water supply scheme is constructed and services are made available to a community, it imposes financial burden as stated above. On account of the services made available the property value goes up. Therefore, it is justifiable for a local body to levy

betterment tax on all premises and properties which can avail of the services though the facility may not be actually used by such premises and properties. Such a betterment tax could be related to the fixed charge component of the financial burden caused by the scheme.

For recovery of variable charges, rates based on consumption of water may be charged and these rates can be different in various categories and slabs of consumption. These charges would be payable by only those who actually consume water.

Authorities such as water supply boards generally do not own water works. The functions of these boards are generally restricted to planning, designing and constructing facilities on behalf of local bodies and then to transfer the works to the owners who have the responsibility to operate the works and also to collect water charges. The boards receive only the agency charges to cover the cost of their establishment, these agency charges being treated as a part of the capital cost of work, planned and constructed by the boards.

There are, however, a few boards, who besides carrying out the functions of planning, designing and execution of works also own water works. These boards operate the water works and also collect water charges directly from the consumers they serve.

While concluding, it is to be stated that a water supply system has to be created since it is essentially required for sustenance of life. It may be initially uneconomical but the water supply project may be evaluated on social cost-benefit analysis method. It is difficult to quantify the social benefits and relate them to the capital cost. The following factors which are likely to get developmental impetus due to creation of water supply system and incidentally a waste water disposal system should be identified:

- ◆ Industrial and agricultural development;
- ◆ Improvement in living habits, health and hygiene; and
- ◆ Increased productivity.

Water supply being a community service, the economical analysis and the financial analysis should be done prudently and judiciously.

CHAPTER 18

LEGAL ASPECTS

18.1 GENERAL

In India, laws related to use of water date back to the period when the *LODHI* OF *MANU* was prescribed, over 3000 years ago. Water was considered public property, subject to public administration, several penalties were prescribed for unauthorised use and for causing harm to water holding structures and for causing pollution of water. Upstream points along a river were reserved for drawl of drinking water and in situ uses of water such as washing clothes, bathing etc., were permitted only at the downstream.

The establishment of priorities in the use of water for multiple purposes and among several users for the same purpose is one of the longest established features of water law.

18.2 SYSTEM OF ACQUISITION OF WATER USE RIGHTS

There are currently three main systems of acquisition of water use rights. These are:

- (i) The riparian rights system,
- (ii) The prior appropriation system, and
- (iii) Administrative disposition of water use rights.

18.2.1 RIPARIAN RIGHTS SYSTEM

The riparian rights belong only and equally to those who possess access to water through ownership of land abutting on a stream. A person having riparian right can entreat use of water at any time and insist that his right be accommodated with other uses, or that a share of the water be allotted to him. Riparian right is a form of real property, and is a part of land law. Thus this right is appurtenant to the land, in the sense that a person who purchases or inherits riparian land automatically acquires the water right, although it may not be specifically mentioned. The riparian does not own the water, but owns only the right to use it on his riparian land, and to have it flow to his land so that it may be used.

As a rule only the natural flow of a stream is subject to riparian rights. Water added artificially to a stream i.e. the so called "developed" water is not subject to riparian rights. It belongs to whoever developed it, unless the increased flow was caused by mere clearing of obstacles. Riparian rights do not attach either to waste water which seeps or escapes from ditches or reservoirs, or to foreign waters channelled artificially from a different water shed. They do attach to a spring when it is the source of the stream and also to the under flow of a stream.

Under this system there are two operating doctrines, viz. (i) Natural flow Doctrine, and (ii) Reasonable use Doctrine.

18.2.1.1 Natural Flow Doctrine

Under the natural flow doctrine the riparians have the right to use water on riparian lands, in as much quantity as they need, without consideration of the needs of their downstream users, if their use is confined to so called "Natural" or domestic purposes, i.e. drinking, washing, cleaning and the watering of live stock. However, when they make use of the water for other than domestic purposes even though still within riparian land, they may become subject to action by the lower riparian if he sustains harm in the use of water to which he is entitled, since he has the right to expect the water to flow to him, in its natural and undiminished state. Also any use not connected with riparian land, which affects the flow of water, even though it does not cause any harm, is considered subject to action.

18.2.1.2 Reasonable Use Doctrine

Because of the limitation of the natural flow doctrine in the use of water law as a tool for purposes of social engineering, the trend is away from "Natural Flow Doctrine" and towards acceptance of the "Reasonable Use Doctrine".

As a rule, in determining reasonableness, such factors as social utility, capacity of the stream, benefit to the use and suitability to the purpose of the stream are taken into account, mostly retaining the fundamental right of the riparian to the reasonable use of the water of the stream, but free from unreasonable interference with other uses.

A number of uses have received judicial approval and their limits have been defined to some extent. Domestic use includes water for drinking, cooking, bathing, sanitation and other household purposes. A substantial quantity of water may be necessary to fulfil domestic uses where people gathered in hotels, apartment houses or resorts. Even military camps are given the privilege of taking water for domestic use. But domestic use does not include municipal uses in non-riparian areas of cities. A city situated on the banks of a stream is not a riparian right holder in any sense that would permit it to divert water and sell it to inhabitants who live on lands not adjacent to the stream.

The reasonableness of a particular use of water by a riparian is a question of fact and each case must be determined with reference to its own facts and circumstances. The use of water by one riparian that causes substantial harm to another, can generally be said to be unreasonable unless the utility of the use outweighs the gravity of the harm. Wasteful uses or wasteful method of use may be unreasonable.

A prescriptive right may be described as a power to take water without reference to the rights of riparian owners. The right obtained by the prescription is absolute there being no corrective rights between the riparian and the prescriptive user.

18.2.1.3 Loss Of Riparian Rights

Generally a riparian right cannot be lost by abandonment or simply by non-use of water. Since use does not create the right, non-use cannot destroy it. However, there are some exceptions to this in some places when a riparian may lose his right.

- (i) When a non-riparian or excessive use has been made continuously and adversely for the period of the statute of limitations.
- (ii) When prescriptive rights to the use of water have been acquired for such adverse use.
- (iii) When the legal doctrine known as "estoppel" is operative [e.g. when a riparian has permitted a non-riparian to construct a dam on his land at great expenses he is "estopped" (prevented) from revoking the license and destroying the value of the irrigated non-riparian land].
- (iv) When there has been silent acquiescence by a riparian in respect of an upstream use of water, for which large sums of money have been spent for the public benefit; though he may still have the remedy for damages to compensate him for the rights he has lost.
- (v) When a public or quasi public agency needs water, it has the power to take it as long as it pays just compensation for the use it causes. (Any government authority, has this "right of eminent domain", and quasi-governmental bodies such as Water Supply Boards, may be given a similar power by grant from the state that creates them).

18.2.2 PRIOR APPROPRIATION SYSTEM

The two cardinal principles of the doctrine of prior appropriation are:

- (i) That beneficial use of water and not land ownership gives the basis of the right to use water, and
- (ii) That priority of use and not equality of right is the basis of the division of water between appropriators when there is not enough for all.

18.2.2.1 Elements Of An Appropriation

An appropriation is the right to use a specific quantity from water from a public source of supply for a beneficial purpose, if that quantity is available free from the claims of prior appropriators. An appropriation requires:

- (i) The diversion of water from a stream or other source,
- (ii) The intent to appropriate,
- (iii) Notice of appropriation to others;
- (iv) Compliance with state procedural requirements, and
- (v) The application of water to a beneficial use.

Once the appropriation has been established, prior appropriator has the right to exclusive use of the amount of water of his appropriation and all subsequent junior users take subject to his right. The appropriation may be obtained only for beneficial uses, which include domestic, agricultural and industrial uses. It lasts as long as water is beneficially used and is limited to the amount that can be so used.

18.2.2.2 Beneficial Uses

A number of uses of water have been approved as beneficial by courts and legislatures. Domestic use is everywhere recognised such. Cities and towns may appropriate water for municipal purposes. A city may appropriate more water than it presently needs in order to provide for future growth.

18.2.2.3 Quantity Of Water

An appropriation is always stated in terms of the rights to take a definite amount of water. Direct flow rights are stated in terms of the maximum current or flow that may be diverted from the stream. Storage rights are expressed in terms of the total volume of water that may be stored.

An appropriation acquired, by building a reservoir and storing water in it, is measured by the storage capacity of the reservoir, that it will hold as a result of a single filling each year. If the reservoir is to be filled more than one time, it can be done only after paying the compensation for the additional quantity of water stored.

18.2.2.4 Place Of Use

With few exceptions, an appropriation can be made in order to use the water at any place where it is needed. Diversions out of watershed have been permitted, but not between interstate.

18.2.2.5 Preferences

Preferences are exceptions to the rule of priority. A preference allocates the water to what has been legislatively deemed to be a higher or better use regardless of the time of initiations of use. There is wide variation as to what uses shall be preferred. There is general agreement that man's personal needs come first so that domestic and municipal water supply head every list. A true preference exists when a junior right to a preferred use is placed at the top of the priority list, so that in times when water is short, senior non-preferred rights are cut-off while the preferred uses still draw water. Stated another way, a true preference exists when the preferred use may be initiated without regard to the fact that the supply is already fully appropriated for other purposes. The authorities have to prefer some uses over others when several applications for appropriation of water are pending and the available water is insufficient for all. These preferences should go first for domestic and municipal water supply, then to agriculture, then to power.

18.2.2.6 Changes In Appropriation

A water right is private property and, in most cases, it can be sold or used by its owner at any place of use, but in the case of diversion type of use, at any time of use, or place of storage also. But the privilege of making such changes is subject to the rule that a change must not injure the vested water rights of the other appropriators. The agencies and courts that regulate the appropriation and distribution of water are given the power to approve or forbid changes on this ground, after proceeding at which all interested parties are represented.

The restriction on changes that cause damage is not merely an application of the rule of priority; it is applicable to any person senior or junior who will suffer as a result of the change. A change from non consumptive use to consumptive one will obviously injure downstream appropriators. The loss of benefits from return flows is the most common type of damage that will prevent a change, but the appropriator may be permitted to change the place of use or the amount of this consumptive use, though not of his total diversion and other conditions may be imposed to permit a change to as great an extent as possible, and yet prevent infliction of damage.

18.2.2.7 Transfers Of Appropriation

An appropriation is regarded as real property and where it can be sold to a person who will use it at a different place or for different use, the transfer is ordinarily made by a deed. Water rights for the irrigation of land are generally regarded as appurtenant to the land, hence a sale of the land will carry the water right with it, although the water right was not specifically mentioned in the deed.

18.2.2.8 Loss Of Appropriation

An appropriation is a property right and its ownership, like that of land, is held in perpetuity although same may be granted for a limited period. However, it may be terminated if it is not used. It has been recognized that the non-use of water, coupled with an intent not to resume the use, amounts to an "abandonment" that terminates the water right and makes the water available for use and appropriation by others. No particular period of time is required for an abandonment, but long unexplained nonuse will often cause a court to say that the right is abandoned although there is no direct evidence of the intent of the appropriator.

18.2.3 SYSTEM OF ADMINISTRATIVE DISPOSITION OF WATER

The riparian rights doctrine and the prior appropriation systems, as a rule, are appropriate either in humid countries in which there is an abundance of water, or in circumstances in which the government organization is weak and under developed. As water becomes scarce, government tends to assume a more active role in the disposition of the available supply. This trend can be plainly seen in arid regions of the world where demand outstrips supply even at a primitive level of economy. When supply exceeds demand there is little need for desire for control, but where demand outgrows supply administrative control intensifies. The

administrative authorisation system has become the main feature of the water codes of new countries, such as Israel. These systems envisage authorisation by government for using any water declared public. Usually two kinds of authorisation are given:

- (i) A permit which is less permanent and easily revoked; and
- (ii) A concession which sets up reciprocal rights and obligations between grantee and grantee.

In administrative law, "permits" are distinguished from "concessions", in as much as the former are revocable and create obligations only for the grantee, whereas concessions are for a fixed period or perpetual, create reciprocal obligations and their revocation is governed by law. Consequently procedure for obtaining them is different, since a concession has a certain condition of stability which a permit lacks.

18.3 SURFACE WATER

18.3.1 POWER OF LEGISLATION REGARDING WATER

According to the Constitution of India water is in the "State list". Therefore, the States can enact any legislation regarding water that is to say, water supplies, irrigation and canals, drainage, embankments, water storage and water power excepting the regulation and development of inter state rivers and river valleys. The parliament thus has no legislative competence in the matter.

18.3.2 NATIONAL WATER POLICY

Water is a prime natural resource, a basic human need and precious national asset. Therefore, planning and development of water resources need to be governed by national perspectives.

The Government of India have therefore formulated a National Water Policy in 1987; according to which, in the planning and operation of systems water allocation priorities shall be broadly as follows:

- ◆ Drinking
- ◆ Irrigation
- ◆ Hydro-power
- ◆ Navigation
- ◆ Industrial and other uses

However these priorities can be modified, if necessary, in particular regions with reference to area specific consideration. The National Water Policy has directed that adequate drinking water facilities should be provided to the entire population both in urban and rural areas by 1991, that irrigation and multipurpose projects should invariably include a drinking water component wherever there is no alternative source of drinking water; and that

drinking water needs of human beings and animals should be the first charge on any available water.

In order to provide for use and control by the state, the water of all rivers and streams flowing in natural channels and of all lakes, and to that end to amend and consolidate the existing laws relating to irrigation and drainage and assessment and levy of water rates and betterment contributions, a Model Canal Irrigation and Drainage Bill is being formulated by Union Government for the guidance of the States

18.4 GROUND WATER

The existing Irrigation Acts or any other Acts do not define the ownership of such surface or ground water which is considered as belonging to the owners of the land. But in view of the vital importance of ground water to the nation; for water supply and irrigation it is essential for government to extend control over it and to provide for the methodical and systematic regulation in conjunctive use with surface water. The National Water Policy has directed that exploitation of ground water resources should be so regulated as not to exceed the recharging possibilities, as also to ensure social equity; and that ground water recharge projects should be developed and implemented for augmenting the available supplies.

The Union Government has prepared and circulated to the State a Model Ground Water (Control and Regulation) Bill to regulate and control the development there with. The salient features of the Bill are as under:

- ◆ Ground water has been defined as the water which exists below the surface of the ground at any particular location.
- ◆ Ground Water Authority shall be constituted by the State Government.
- ◆ The State Government, on a report received from the Ground Water Authority may declare areas as notified areas; where, extraction and use of ground water will be regulated in the public interest.
- ◆ Any person desiring to sink a well in the notified area for any purpose other than exclusively domestic use, either on personal or community basis, shall apply to the Ground Water Authority for the grant of a permit for the purpose and shall not proceed with any activity connected with sinking unless a permit has been granted by the Ground Water Authority.
- ◆ In granting or refusing a permit the Ground Water Authority shall have regard to:
 - (a) the purpose or purposes for which water is to be used;
 - (b) the existence of other competitive users;
 - (c) the availability of water; and
 - (d) any other relevant factor.

- ◆ Every existing user of ground water in the notified area, shall apply to the Ground Water Authority for the grant of a certificate of registration recognising his existing use in such forms and in such manner as may be prescribed.
- ◆ No person shall himself or by any person on his behalf, carry on the business of sinking wells or any other activity connected with the sinking of wells in any notified area except under and in accordance with a licence granted in this behalf.
- ◆ Any person desiring to carry on the business of sinking of wells in the notified area may make an application to the Ground Water Authority for the purpose.
- ◆ The Ground Water Authority or any person authorised by it in writing in this behalf shall have power to enter on any property with the right to investigate and make any measurements concerning the land or the water located on the surface or underground, inspect the well, sunk or being sunk, take specimens of such solid, or other materials or of water extracted from such wells, and obtain such information and record as may be required.
- ◆ Any user of ground water who contravenes or fails to comply with any of the provision of the Act, will be penalised and/or punished according to the provision of the Act.

18.5 PREVENTION AND CONTROL OF POLLUTION

Though the conservation of available water sources free from pollution is of paramount importance now, even the early law regulating pollution says that the riparian owner may make such reasonable use of the water as he can while it passes his land; but he cannot make such use of water as to pollute it unreasonably or so as to create nuisance. The early law regulating pollution was enforced almost entirely through the process of individual suits for what was termed a private nuisance.

The concept of public nuisance has also been used to some degree to control pollution. A public nuisance is an act which causes inconvenience or damage to the public as distinguished from one or a few individuals and includes any interference with the public health, safety, or inconvenience. Thus the pollution of a stream which merely inconveniences several riparian owners is a private nuisance only, but may become public one, if it kills fish or creates a menace to the health of the community. A public nuisance is subject to abatement at the behest of state officials. It may also constitute a crime.

In our country until recently the pollution was regulated through state factory acts and rules, and also by some sections (section 28) of the Indian Easement Act. As the scope of these acts is limited in its extent and does not provide much guidance in respect of water pollution prevention, the Union Government enacted the Water (Prevention and Control of Pollution) Act, in 1974; which is applicable to all Union territories, and has been adopted by all the States, by resolution passed in that behalf under clause (i) of Article 252 of the Constitution. Under the provision of this Act no discharge of waste water can be made in the environment without obtaining consent from the State Pollution Control Board (from the Central Pollution Control Board, in respect of Union Territories). A consent prescribes the

volume and quality of waste water in terms of concentration of various pollutants, which can be permitted for discharge in the environment. In 1986, the Union Government enacted the Environment (Protection) Act, 1986, for protection and improvement of environment, and the prevention of hazards to human beings, other living creatures, plants and properties. The Act empowers the Union Government to make rules providing standards in excess of which environmental pollutants shall not be discharged or emitted in the environment.

APPENDIX A

ABBREVIATIONS AND SYMBOLS

atm	Atmosphere	emf	Electromotive force
BOD	Biochemical oxygen demand	Eq	Equation
ci	Curie	fig	Figure
°C	Degrees centigrade	g	Gram
cal	Calorie	ha	Hectare
cc	Cubic centimetre	I.D.	Internal diameter
CCl ₄	Carbon-chloroform extract	JTU	Jackson turbidity unit
cg	Centimetre gram second	k cal/kg	Kilocalorie per kilogram
C.I.	Cast iron	kg/cm ²	Kilogram per square centimetre
cm	Centimetre	kg/m ²	Kilogram per square metre
cm/min	Centimetres per minute	kl	Kilolitre
cm/sec	Centimetres per second	kl/d	Kilolitre per day
cm ²	Square centimetres	km	Kilometre
COD	Chemical oxygen demand	kw	Kilowatt
Col	Column	kwh	Kilowatt hour
cum	Cubic metres	l	Litre
cumec	Cubic metre per second	l/cd	Litre per capita per day
deg	Degree	l/d	Litre per day
DO	Dissolved oxygen	l/h	Litre per hour
EDTA	Ethylenediaminetetraacetic acid	lph/m ²	Litre per hour per square metre
		lpm	Litre per minute

lpm/m ²	Litres per minute per square metre	μ	Micron
m	Metre	μ c	Microcuvette
m ³	Cubic metre	μ g	Microgram
m ³ /hr	Cubic metres per hour	N	Newton
me	Milliequivalent	NPSH	Net positive suction head
mg	Milligram	No	Number
mg/l	Milligram per litre	NTU	Nephelometric turbidity units
ml	Millilitre	OFA	Ortinotolidine arsenate
ml	Million litres	N _k	Reynold's number
ml/d on total total	Million litres per day	P	Page
mm	Millimetre	pp	Pages
mgs. or m/s	Metre per second	psi	Picocurie
min	Minute	ppb	Part per billion
mole	Gram molecular weight	ppm	Part per million
mol wt	Molecular weight	rpm	Revolution per minute
mph	Metres per hour	s	Second
m ³ /d/m	Cubic metres per day per metre	sq	Square
m ³ /d/m ²	Cubic metres per day per square metre of area	Vol	Volume
		wt	Weight
m ³ /ml	Cubic metres per million litre		
MPN	Most probable number		
mp	Millimicron		

APPENDIX B

CONVERSION FACTORS

LENGTH

1 in	=	25.4 mm	1 mm	=	0.0394 in
1 ft	=	0.3048 m	1 cm	=	0.3934 in
					0.0328 ft
1 yd	=	0.9144 m	1 m	=	3.2808 ft
					1.0936 yd
1 mile	=	1.6093 km	1 km	=	0.6214 mile

AREA

1 sq in	=	645.163 sq mm	1 sq mm	=	0.00155 sq in
	=	6.4516 sq cm	1 sq cm	=	0.1550 sq in
1 sq ft	=	0.0929 sq m		=	0.00108 sq ft
1 sq yd	=	0.8361 sq m	1 sq m	=	10.7639 sq ft
1 sq mile	=	2.59 sq km		=	1.3960 sq yd
1 acre	=	0.4047 ha	1 ha	=	2.4710 acre
		4046.86 sq m		=	0.00386 sq mile
			1 sq km	=	0.3861 sq mile
				=	247.105 acre

CAPACITY

1 gal (UK)	=	4.54609 l	1 l	=	0.0353147 cu ft
	=	0.00454609 cum		=	0.001308 cu yd
	=	0.160544 cu ft	1 l	=	0.2200 gal(US)
1 gal (US)	=	0.00378541 cu m	1 l	=	0.264172 gal(US)
	=	3.78533 l			
	=	0.832675 UK gal			
	=	0.133681 cu ft			

1 US Pint

1 liquid = 0.4732 l

1 fluid oz
(US) = 29.5725 ml

1 fluid oz
(UK) = 28.4123 ml

VOLUME

1 cu m = 16.8871 cu cm

1 cu ft = 0.0283 cu m

1 cu yd = 0.7646 cu m

1 cu ft = 1233.48 cu cm

1 cu cm = 0.000028 cu m

1 cu m = 35.315 cu ft

= 1.6093 cu yd

= 0.000129 acre ft

WEIGHT

1 gram = 0.0018 g

1 oz = 28.3495 g

1 lb = 0.4536 kg

1 ton = 101605 grams

1 g = 15.43234 grains

= 0.035274 oz

1 kg = 2.20462 lb

1 tonne = 0.98421 ton

DENSITY

1 lb/ft³ = 16.0185 kg/m³ or g/cm³

1 kg/m³ = 0.0624 lb/ft³

PRESSURE AND STRESS

1 lb/cm² = 0.703 kg/cm²

1 lb/ft² = 0.0479 kg/cm²

1 ton/m² = 1.5749 kg/cm²

1 atm = 101325 N/m²

= 760.0 mm Hg

= 1.01325 bar

1 kg/cm² = 14.223 lb/in²

= 0.703110

= 0.96784 atm

1 kg/cm² = 0.204816 lb/ft²

1 kg/cm² = 0.6850 ton/m²

1 atm = 68.9476 x 10⁻³ lb/ft²

μ	$= 14.05574 \text{ g/cm}^3$			(Where $1 \text{ psi} = 6.89476 \text{ N/m}^2$)
kg/cm^3	$= 14.05574 \text{ g/cm}^3$			
kg/m^3	$= 14055.74 \text{ kg/m}^3$			
lb/in^3	$= 0.8022 \text{ lb/in}^3$			
lb/ft^3	$= 137.32 \text{ lb/ft}^3$	$1 \text{ lb/ft}^3 = 16.0185 \text{ kg/m}^3$		$137.32 / 16.0185 = 8.57$

FORCE

1 lb_f	$= 4.44822 \text{ N}$	$1 \text{ N} = 0.224809 \text{ lb}_f$	$= 0.101972 \text{ kgf}$	
1 kgf	$= 9.80665 \text{ N}$	$1 \text{ N} = 0.101972 \text{ kgf}$	$= 2.20462 \text{ lbf}$	
1 lbf	$= 4.44822 \text{ N}$	$1 \text{ kgf} = 2.20462 \text{ lbf}$		

$$\begin{aligned} \text{Acceleration due to gravity} &= 32.1740 \text{ ft/sec}^2 \\ &= 9.80665 \text{ m/sec}^2 \end{aligned}$$

ENERGY AND POWER

$1 \text{ joule} = 1 \text{ Nm}$	$= 0.737562 \text{ ft} \cdot \text{lb}$	$1 \text{ ft} \cdot \text{lb} = 1.35582 \text{ joules}$	$= 3.76816 \text{ ergs}$
$1 \text{ ft} \cdot \text{lb}$	$= 1.35582 \text{ J}$	$1 \text{ J} = 0.737562 \text{ ft} \cdot \text{lb}$	$= 3.6 \text{ ft} \cdot \text{lb}$
1 cal	$= 4.1868 \text{ J}$	$1 \text{ J} = 0.2389 \text{ cal}$	
1 erg	$= 10^{-7} \text{ J}$	$1 \text{ J} = 10^7 \text{ erg}$	$= 0.2389 \text{ cal}$
$1 \text{ ft} \cdot \text{lb}$	$= 1.35582 \text{ J}$		

VELOCITY

1 fps	$= 0.3048 \text{ m/s}$	$1 \text{ m/s} = 2.23694 \text{ fps}$	
	$= 1.0973 \text{ km/h}$		$= 2.2369 \text{ mi/h}$
1 m/s	$= 0.4773 \text{ mph}$	$1 \text{ mph} = 0.44704 \text{ m/s}$	
	$= 1.6093 \text{ km/h}$		$= 0.6214 \text{ mi/h}$

TREATMENT LOADING RATES

1 mm/s	=	0.00045555 mm/s	1 mm/s	=	0.41132 in/h
1 UK gal/ft ² /h	=	0.0135927 mm/s		=	0.5689 UK/gal/ft ² /h
1 US gal/ft ² /h	=	1.17441 m ³ /m ² /d		=	76.9130 Million UK gal/acre/d
1 million UK gal/acre/d	=	0.0030656 mm/s	1 m ³ /m ² /d	=	0.851491 UK gal/ft ² /h
	=	1.12336 m ³ /m ² /d		=	0.890187 million UK gal/acre/d
1 UK gal/day/ft	=	14.915 lpd/m	1 m ³ /day/m	=	67.466 UK/gal/day/ft
	=	0.014915 m ³ /day/m			
1 ft ³ /s/1000 acres	=	0.92724 l/s/ha	1 l/s/ha	=	0.142915 ft ³ /s/1,000 acres
1 ft ³ /s/mile ²	=	10.9532 l/s/ha		=	0.0914645 ft ³ /s/mile ²

HARDNESS

mg/l CaCO ₃	Grains per UK gal CaCO ₃ (Clark scale/ British degrees)	Grains per US gal CaCO ₃ (American degrees)	Parts per 100,000 CaCO ₃ (French degrees)	Parts per 10,000 CaO (German degrees)	Parts per million Ca (Russian degrees)
1.00	0.07	0.08	0.10	0.056	0.42
14.29	1.00	0.83	1.43	0.80	5.72
17.15	1.20	1.00	1.72	0.96	6.86
19.99	1.40	1.18	1.90	0.96	7.00
22.86	1.60	1.35	2.14	1.12	8.14
25.71	1.80	1.53	2.38	1.28	9.28

APPENDIX C

LIST OF INDIAN STANDARDS RELATING TO WATER SUPPLY

Sl. No.	IS No.	Title
I. GENERAL.		
1.	IS 111(Part 2 Section 1): 1983	Names and abbreviations of India 1983 Part 2 Public services (Section 1: Water Supply)
2.	IS 339 (1981)	Handbook on water supply and drainage with special reference to plumbing
3.	1172 (1985)	Code of basic requirements for water supply drainage and sanitation (third revision)
4.	2065 (1987)	Code of practice for water supply in buildings (second revision)
5.	456 (1978)	Code of practice for plain and reinforced concrete (third revision)
6.	457 (1977)	Code of practice for general construction of plain and reinforced concrete for dams and other massive structures
7.	3343 (1987)	Code of practice for prestressed concrete (first revision)
8.	5153 (1975)	Code of practice for natural ventilation
9.	3360	Code of practice for concrete structures for the storage of liquids
10.	Part 1: 1985	Canal design criteria
11.	Part 2: 1985	Reinforced concrete structures
12.	Part 3: 1985	Prestressed concrete structures
13.	Part 4: 1985	Design tables
14.	6158 (1977)	Code of practice for control of sediment in Reservoirs
15.	5731 (1983)	Criteria for design of anchor block for penstocks with expansion joints (first revision)

Sl No.	IS No.	Title
12	6738	Regulations for watershed development and soil conservation
13	Part 1: 1963 1357, 1374	Structural design of long span
14	Part 3: 1966	Large diameter wind turbines
15	1357: 1966	Large pipe bed materials
16	4990: 1968	Methods for measurement of suspended sediment transport
17	4926: 1976	Design of sedimentation systems
18	6215: 1980	Code of practice for water supply and drainage in high altitude and/or severe temperature regions (structural)
19	4889	Code of practice for design of tunnels conveying water
	(a) Part 1: 1975	General design
	(b) Part 2: 1976	Structural design (air section)
	(c) Part 3: 1976	Structural design (air section)
	(d) Part 4: 1971	Structural design of concrete lining in rock
	(e) Part 5: 1972	Structural design of concrete lining in soft soils and silt
	(f) Part 6: 1973	Load support
20	5477	Manual for fixing the expenses of irrigation
	(a) Part 1: 1965	General requirements
	(b) Part 2: 1965	Fixed Storage
	(c) Part 3: 1969	Fixed Storage
	(d) Part 4: 1971	Fixed Storage
21	9666: 1980	Code of practice for provision and maintenance of water supply for fire fighting
22	9377	Code of practice for corrosion protection for steel structures

SI No.	IS No.	Title
(a)	Part 1: 1976	General requirements
(b)	Part 2: 1976	Design and operation
23	10221: 1981	Code of practice for coating and wrapping of underground steel pipelines
24	12384: 1987	Code of practice for building in multi-storyed building Part I: water supply
II. PIPE AND FITTING		
Cast Iron		
1	1536: 1976	Cast-iron cast pipe and pressure pipes for water supply (excluding sand-cast iron)
2	1537: 1976	Cast-iron cast pipe and pressure pipes for water, gas and sewage (sand-cast iron)
3	1538, Parts 1 to 24	Cast-iron fittings for pressure pipes for water, gas and sewage (sand-cast iron)
(a)	Part 1: 1976	General requirements
(b)	Part 2: 1976	Specific requirements for sockets and spigots of pipes
(c)	Part 3: 1976	Specific requirements for sockets of fittings
(d)	Part 4: 1976	Specific requirements for flanges of pipes and fittings
(e)	Part 5: 1976	Specific requirements for casted flanges
(f)	Part 6: 1976	Specific requirements for standard flange drilling of flange of pipes and fittings
(g)	Part 7: 1976	Specific requirements for flanged end caps
(h)	Part 8: 1976	Specific requirements for flanged spigots
(i)	Part 9: 1976	Specific requirements for double socket heads
(j)	Part 10: 1976	Specific requirements for double socket heads
(k)	Part 11: 1976	SPECIFIC REQUIREMENTS FOR ELBS, ALL SOCKETS
(l)	Part 12: 1976	Specific requirements for double sockets for water supply fittings
(m)	Part 13: 1976	Specific requirements for elbows, all sockets
(n)	Part 14: 1976	Specific requirements for double socket pipes (third sockets)
(o)	Part 15: 1976	Specific requirements for caps
(p)	Part 16: 1976	Specific requirements for pipes
(q)	Part 17: 1976	Specific requirements for bell mouth pieces
(r)	Part 18: 1976	Specific requirements for double flanged benches

SI No.	IS No.	Title
(t)	Part 19: 1976	Specific requirements for all flanged uses
(u)	Part 20: 1976	Specific requirements for all flanged on sewer
(v)	Part 21: 1976	Specific requirements for double flanged taper
(w)	Part 22: 1976	Specific requirements for split gaskets on lock flanges
(y)	Part 23: 1976	Specific requirements for blind flanges
(z)	Part 24: 1984	Specific requirements for all flanged radial (to observed revision)
4	1879: 1975; Pipe Part I to III	Standard cast iron pipe fittings (first revision)
5	3114: 1985	Code of practice for laying of cast iron pipes (third revision)
6	782: 1978	Centrifugally cast (spun) non-ferrous pressure pipes for water, gas and sewage (first revision)
7	6163: 1978	Centrifugally cast (spun) non-ferrous pressure pipes for water, gas and sewage (first revision)
8	7181: 1986	Centrifugally cast iron double flanged pipes for water, gas and sewage (first revision)
9	8329: 1977	Centrifugally cast (spun) ductile iron pressure pipes for water, gas and sewage
10	9523: 1981	Ductile iron fittings for pressure pipes for water, gas and sewage
11	11606: 1986	Methods of sampling cast iron pipes and fittings
12	11906: 1986	Requirements for cement mortar lining, cast iron, mild steel and ductile iron pipes and fittings for transportation of water
13	12288: 1987	Code of practice for laying of ductile iron pipes
CONCRETE		
14	458: 1971	Concrete pipes with and without reinforcement (several revisions)
15	786: 1978	Pre-cast concrete pipe and pipe fittings (first revision)
16	1916: 1963	Code of practice for laying of concrete pipes
17	3527: 1985	Methods of test for concrete pipe (first revision)
18	783: 1985	Code of practice for laying of concrete pipe (first revision)
19	4550: 1967	Concrete pressure pipes for water drainage

Sl No.	IS No.	Title
ASBESTOS CEMENT PIPES		
20.	1592 : 1980	Asbestos cement pressure pipes(second revision)
21.	6530 : 1972	Code of practice for laying of asbestos cement pressure pipes
22.	5531 : 1977	Cast iron specials for asbestos cement pressure pipes for water, gas and sewage(first revision)
23	9627 : 1980	Asbestos cement pressure pipes(light duty)
MILD STEEL TUBES AND PIPES		
24.	1239	Mild Steel tubes, tubulars and other wrought steel fittings
(a)	Part 1: 1979	Mild Steel tubes (fourth revision)
(b)	Part 2 : 1982	Mild steel tubulars and other wrought steel pipe fittings (third revision)
25.	1978 : 1982	Line pipe
26.	3589 : 1981	Electrically welded steel pipes for water, gas and sewage (150 to 2000 mm nominal size) (first revision)
27.	4270 : 1983	Steel tubes used for water wells (first revision)
28.	4516 : 1968	Elliptical mild steel tubes
29	5504 : 1969	Spiral welded pipes.
30.	5822 : 1986	Code of practice for laying of welded steel pipes for water supply (first revision)
31.	4711 : 1974	Method for sampling of steel pipes, tubes and fittings(first revision)
32.	4736 : 1986	Hot-dip zinc coatings on mild steel tubes (first revision)
33.	6286 : 1971	Seamless and welded steel pipes for sub zero temperature services.
34.	6631 : 1972	Steel pipes for hydraulic purposes .
35.	11722 : 1986	Thin welded flexible quick coupling pipes.

SI No.	IS No.	Title
PLASTIC PIPES		
36.	3076 : 1985	Low density polyethylene pipes for potable water supplies(second revision)
37.	4984 : 1987	High density polyethylene pipes for potable water supplies, sewage and industrial effluents(third revision)
38.	4985 : 1988	Unplasticized PVC pipes for potable water supplies (second revision)
39	12818 : 1989	UPVC ribbed and casing pipes for potable water supply.
40	7634	Code of practice for plastic pipe work for potable water supplies.
(a)	Part 1: 1975	Choice of materials and general recommendation
(b)	Part 2: 1975	Laying and jointing polyethylene (PE) pipes.
(c)	Part 3: 1975	Laying and jointing of unplasticized PVC pipes.
41.	7834	Injection moulded PVC fittings with solvent cement joints for water supplies.
(a)	Part 1 : 1975	General requirements
(b)	Part 2 : 1975	Specific requirements of 45° elbows
(c)	Part 3 : 1975	Specific requirements for 90° elbows
(d)	Part 4 : 1975	Specific requirements for 90° tees.
(e)	Part 5 : 1975	Specific requirements for 45° tees
(f)	Part 6 : 1975	Specific requirements for sockets.
(g)	Part 7 : 1975	Specific requirements for unions.
(h)	Part 8 : 1975	Specific requirements for caps.
42.	8008	Injection moulded HDPE fittings for potable water supplies.
(a)	Part 1 : 1976	General requirements.
(b)	Part 2 : 1976	Specific requirements for 90° bends

SI No.	IS No.	Title
(a)	Part 1 : 1977	For other than chemical purposes (second revision).
(b)	Part 2 : 1979	For chemical purposes (second revision).
50.	11906 : 1986	Recommendations for cement - mortar lining for cast iron, mild steel and ductile-iron pipes and fittings for transportation of water.

III. WATER FITTINGS

TAPS

- | | | |
|----|-------------|---|
| 1. | 781 : 1984 | Cast copper alloy screw drawn bib taps and stop valves for water services (third revision). |
| 2. | 1700 : 1973 | Drinking fountains (first revision). |
| 3. | 1711 : 1984 | Self-closing taps for water supply purposes (second revision). |
| 4. | 1795 : 1982 | Pillar taps for water supply purposes (second revision). |
| 5. | 4346 : 1982 | Washers for use with fittings for water services (first revision). |
| 6. | 8934 : 1978 | Cast copper alloy fancy pillar taps for water services. |
| 7. | 9763 : 1981 | Plastic bib taps and stop valves (rising spindle) for cold water services. |

WATER METERS

- | | | |
|-----|-------------|--|
| 8. | 779 : 1978 | Water meters (domestic type) (fifth revision). |
| 9. | 2104 : 1981 | Water meter boxes (domestic type) (first revision). |
| 10. | 2373 : 1981 | Water meter (bulk type) (third revision). |
| 11. | 2401 : 1973 | Code of practice for selection, installation and maintenance of domestic water meters (first revision). |
| 12. | 6784 : 1984 | Method for performance testing of water meters (domestic type)(first revision). |

SI No.	IS No.	Title
VALVES		
13.	780 : 1984	Sluice valves for water works purposes (50 to 300 mm size) (sixth revision).
14.	2906 : 1984	Sluice valves for water works purposes (350 to 1200 mm size) (third revision).
15.	2685 : 1971	Code of practice for selection, installation and maintenance of sluice valves (first revision).
16.	3042 : 1965	Single faced sluice gates (200 to 1200 mm size)
17.	3950 : 1979	Surface boxes for sluice valves (first revision).
18.	778 : 1984	Copper alloy gate, globe and check valves for water works purposes (fourth revision).
19.	1701 : 1960	Mixing valves for ablutionary and domestic purposes.
20.	1703 : 1977	Ball valves (horizontal plunger type) including floats for water supply purposes (second revision).
21.	4838 : 1986	Foot valves for water works purposes (second revision).
22.	5312	Swing check type reflux (non return) valves for water works purposes
	5312(Part 1) 1984	Single door pattern (first revision).
	5312 (Part 2) 1986	Multi door pattern
23.	9338 : 1984	Cast iron screw down stop valves and stop and check valves for water works purposes (first revision.)
24.	9739 : 1981	Pressure reducing valves for domestic water supply systems.
25.	12234 : 1988	Equilibrium plastic float valve for cold water services.
MISCELLANEOUS FITTINGS		
26.	2692 : 1978	Ferrules for water services (first revision).

Sl No.	IS No.	Title
27.	3004 : 1979	Plug cocks for water supply purposes (first revision).
28.	9762 : 1981	Polyethylene floats for ball valves.
29.	10446 : 1983	Glossary of terms relating to water supply and sanitation.

IV TUBEWELLS PUMPS AND PRIME MOVERS

GLOSSARY

1.	IS 9439 : 1980	Glossary of terms used in waterwell drilling technology
2.	Codes of practice	IS 2800 : 1979 Code of practice for construction and testing of tubewells (a) Part I construction (first revision) (b) Part II Testing (first revision)
3.	IS 11189 : 1985	Methods for tube-well development
4.	IS 11632 : 1986	Code of practice for rehabilitation of tubewell

TUBEWELL COMPONENTS

5.	IS 4097 : 1967	Gravel for use as pack in tubewells
6.	IS 4270 : 1983	Steel tubes used for water wells (first revision)
7.	IS 8110 : 1983	well screens and slotted pipes (first revision)

DRILLING EQUIPMENT, ACCESSORIES AND METHODS

8.	IS 7156 : 1974	General requirements for reverse circulation drilling rigs
9.	IS 7206 : 1974	General requirements for straight rotary drilling rigs
10.	IS 7209 : 1974	General requirements for blast hold drilling rigs
11.	IS 8986 : 1978	Dimensions for drill steels in bar form for percussive drilling

12.	IS 9026 : 1978	Rope threaded percussive long hole drilling equipment
13.	IS 11180 : 1985	Keeleys for direct rotary drilling
14.	IS 11312 :	External upset drill pipe assemblies for use in water well drilling
a)	Part 1- 1986	Screwed on joints drill pipe size
15.	IS 11672 : 1986	Tungsten carbide buttons and insets for use in down the hole (DTH) bits.
16.	IS 11710 : 1986	Code of practice for selection and design of diamond core drills.
17.	IS 11830 :	General requirements for down-the-hole hammer rigs for water wells.
a)	Part 1- 1986	Hydraulic rigs
18.	IS 12097 : 1987	Classification and selection of drilling rigs for water well drilling.
19.	IS 12194 : 1987	Dimensions for rock roller bits and blade drag bits for rock drilling equipment.

PUMPS AND RELATED STANDARDS

20.	IS 8035 : 1976	Shallow well hand pumps
21.	IS 9301 : 1984	Deepwell hand pumps (second revision)
22.	IS 11004 : 1985	Code of practice for installation and maintenance of deep well hand pumps.
a).	Part 1	Installation
b).	Part 2	Maintenance

OTHER PUMPS

23.	IS 1520 : 1980	Horizontal centrifugal pumps for clear, cold, fresh water (second revision)
24.	IS 1710 : 1972	Vertical turbine pumps for clear, cold, fresh water (first revision)
25.	IS 6595 : 1980	Horizontal centrifugal pumps for clear, cold, fresh water for agricultural purposes (first revision)

26.	IS 8034 : 1976	Submersible pump sets for clear, cold, fresh water.
27.	IS 8418 : 1977	Horizontal centrifugal self priming pumps.
28.	IS 8472 : 1977	Regenerative self priming pumps for clear, cold, fresh water.
29.	IS 9079 : 1979	monoset pumps for clear ,cold, fresh water for agricultural purposes
30.	IS 9137 : 1978	Code for acceptance test for centrifugal mixed flow and axial pumps – Class C
31.	IS 9542 : 1980	Horizontal centrifugal monoset pumps for cold, fresh water.
32.	IS 9694	Code of practice for selection, installation, operation and maintenance for horizontal centrifugal pumps for agricultural applications.
(a)	Part 1-1980	Selection
(b)	Part 2-1980	Installation
(c)	Part 3-1980	Operation
(d)	Part 4-1980	Maintenance
33.	IS 10572 : 1983	Methods of sampling pumps .
34.	IS 10804 : 1986	Recommended pumping systems for agricultural purposes (first revision)
35.	IS 10805 : 1986	Foot valves, reflux valves or non-return valves and bore valves to be used in suction lines of agricultural pumping systems (first revision)
36.	IS 10981 : 1983	Code for acceptance test for centrifugal mixed flow and axial pumps - Class B
37.	IS 11346 : 1985	Testing set up for agricultural pumps
38.	IS 12225 : 1987	Technical requirements for jet, centrifugal pump combination
39.	IS 5120 : 1977	Technical requirements for rotodynamic special purpose pumps

PRIME MOVERS

40.	IS 325 : 1978	Three-phase induction motors
-----	---------------	------------------------------

- | | |
|-------------------|---|
| Part 23 - 1986 | Alkalinity (first revision) |
| Part 24 - 1986 | Sulphates (first revision) |
| Part 25 - 1986 | Chlorine demand (first revision) |
| Part 26 - 1986 | Chlorine, residual (first revision) |
| Part 27 - 1986 | Cyanide (first revision) |
| Part 28 - 1986 | Sulphate (first revision) |
| Part 29 - 1986 | Sulphide (first revision) |
| Part 30 - 1988 | Bromide |
| Part 31 - 1988 | Phosphorus |
| Part 32 - 1988 | Chloride |
| Part 33 - 1988 | Iodide |
| Part 34 - 1988 | Nitrogen |
| Part 35 - 1988 | Silica |
| Part 36 - 1988 | Ozone residual |
| Part 37 - 1988 | Arsenic |
| 9. IS 9825-1981 | Chlorine tablets |
| 10. IS 10500-1983 | Drinking |
| 11. IS 10553 | Requirements for chlorination equipment |
| Part 1-1983 | General guidelines for chlorination plants including handling, storage and safety of chlorine cylinders and drums |
| Part 2-1983 | Vacuum feed type chlorinators |
| Part 4-1983 | Gravity feed type gaseous chlorinators |
| Part 5-1987 | Bleaching powder solution feeder
displacement type chlorinator |

VI MEASUREMENT OF FLUID FLOW

- | | |
|-----------------|---|
| 1. IS 1191-1971 | Glossary of terms and symbols used in connection with the measurement of liquid flow with a free surface (first revision) |
| 2. IS 1192-1981 | Velocity area methods for measurement of flow of water in open channels. |
| 3. IS 1194-1960 | Forms for recording measurement of flow of water in open channels |

4.	IS 2912-1964	Recommendations for liquid flow measurement in open channels by slope area method (approximate method) (Amendment No. 1)
5.	IS 2913-1964	Recommendation for determination of flow in tidal channels.
6.	IS 2914-1964	Recommendation for estimation of discharge by establishing stage-discharge relation in open channels. (Amendment No. 1)
7.	IS 2915-1964	Instructions for collection of data for the determination, of the flow by velocity area methods
8.	IS 2951-1965	Recommendation for estimation of flow of liquids in closed conduits.
	Part 1-1965	Head loss in straight pipes due to friction resistance
	Part 2-1965	Head loss in valves and fittings
9.	IS 2952-1964	Recommendation for methods of measurement of liquid flow by means of orifice plates and nozzles
	Part 1 : 1964	Incompressible fluids
	Part 2 : 1975	Compressible fluids
10.	IS 3910:1966	Specification for current meters (cup type) for water flow measurement (Amendment No. 1)
11.	IS 3911:1966	Specification for surface floats
12.	IS 3912:1966	Specification for sounding rods
13.	IS 3918:1966	Code of practice for use of current meter (cup type) for water flow measurement
14.	IS 4073:1967	Specification for fish weights
15.	IS 4080:1967	Specification for vertical staff gauges
16.	IS 4477:	Methods of measurement of fluid flow by means of venturi meters:
	(Part 1):1967	Part 1 Liquids
17.	IS 4477:	Methods of measurement of fluid flow by means of venturi meters:
	(Part 2):1975	Part 2 Compressible fluids
18.	IS 4858 : 1968	Specification for velocity rods

19.	IS 6059 : 1971	Recommendation for liquid flow measurement in open channels by weirs and flumes - Weirs of finite crest width for free discharge.
20.	IS 6062 : 1971	Method of measurement of flow of water in open channels using standing wave flume - fall
21.	IS 6063 : 1971	Method of measurement of flow of water in open channels using standing wave flume
22.	IS 6064 : 1971	Specification for sounding and suspension equipment
23.	IS 6330 : 1971	Recommendation for liquid flow measurement in open channels by weirs and flumes - end depth method for estimation of flow in rectangular channels with a free overfall (approximate method)
24.	IS 6339 : 1971	Methods of analysis of concentration, particle size distribution and specific gravity of sediment in streams and canals
25.	IS 9108 : 1979	Liquid flow measurement in open channels using thin plate weirs
26.	IS 9115 : 1979	Method for estimation of incompressible fluid flow in closed conduits by bend meters
27.	IS 9116 : 1979	Specification for water stage recorder (float type)
28.	IS 9117 : 1979	Recommendation for liquid flow measurement in open channels by weirs and flumes - end depth method for estimation of flow in non Rectangular channels with a free over fall (approximate method)
29.	IS 9118 : 1979	Method for measurement of pressure by means of manometer
30.	IS 9119 : 1979	Method for flow estimation by jet characteristics (approximate method)
31.	IS 9163 (Part 1):	1979 Dilution Methods for measurement of steady flow constant rate injection method
32.	IS 9922 : 1981	Guide for selection of method for measuring flow in open channels.

APPENDIX 2.1

ESTIMATION OF FUTURE POPULATION

PROBLEM

The population of a town as per the Census records are given below for the years 1921 to 1981. Assuming that the scheme of water supply will commence to function from 1986, it is required to estimate the population 30 years hence, i.e. in 2016 and also the intermediate population 15 years after 1986, i.e. 2001.

Year	Population	Increment
1921	40,185	
1931	44,522	4,337
1941	60,395	15,873
1951	75,614	15,219
1961	98,886	23,272
1971	124,230	25,344
1981	158,800	34,570
	Total	118,615
	Average	19,769

SOLUTION

1. Arithmetical Progression Method

Increase in population from 1921 to 1981

i.e. in 6 decades = 1,58,800

- 40,185

1,18,615

or increase per decade = $\frac{1}{6} \times 118,615$

= 19,769

Population in 2001 = Population in 1981 + Increase for 2 decades

$$\begin{aligned}
 &= 158,800 + 2 \times 19,769 \\
 &= 158,800 + 39,538 \\
 &= 198,338 \\
 \text{Population in 2016} &= \text{Population in 1981} + \text{Increase for 3.5 decades} \\
 &= 158,800 + 3.5 \times 19,769 \\
 &= 227,992
 \end{aligned}$$

2. Geometrical Progression Method

$$\begin{aligned}
 \text{Rate of growth } (r) &= 4,337/40,185 = 0.108 \\
 \text{per decade between} & \\
 \text{1931 and 1921} &
 \end{aligned}$$

$$\text{1941 and 1931} = 15,873/44,522 = 0.356$$

$$\text{1951 and 1941} = 15,219/60,395 = 0.252$$

$$\text{1961 and 1951} = 23,272/75,614 = 0.308$$

$$\text{1971 and 1961} = 25,344/98,886 = 0.256$$

$$\text{1981 and 1971} = 34,570/1,24,230 = 0.278$$

$$\text{Geometric mean, } r_g = \sqrt[5]{0.108 \times 0.356 \times 0.252 \times 0.308 \times 0.256 \times 0.278}$$

Assuming that the future growth follows the geometric mean for the period 1921 to 1981 $r_g = 0.2442$

$$\text{Population in 2001} = \text{Population in 1981} \times (1 + r_g)^2$$

$$\begin{aligned}
 &= 158,800 \times (1.2442)^2 \\
 &= 2,45,800 \\
 \text{Population in 2016} &= \text{Population in 1981} \times (1 + r_g)^{3.5} \\
 &= 1,58,800 \times (1.2442)^{3.5} = 3,05,700
 \end{aligned}$$

3. Method of Varying Increment or Incremental Increase Method

In this method a progressively decreasing or increasing rather than a constant rate is adopted. This is a modification over the Arithmetical Progression method.

Year	Population	Increase X		Incremental Increase Y
1921	40,185			
1931	44,522	4337		
1941	60,395	15,873	+	11,536
1951	75,614	15,219	-	654
1961	98,886	23,272	+	8,053
1971	124,230	25,344	+	2,072
1981	158,800	34,570	+	9,226
Total		118,615		30,233

$$\begin{aligned}
 \text{Average} &= 1/6 \times 118,615 = 1/5 \times 30,233 \\
 &= 19,769 \qquad \qquad = 6,047
 \end{aligned}$$

$$P_n = P_1 + nX + \frac{n(n+1)Y}{2}$$

$$P_{2001} = P_{1981} + 2 \times 19769 + \frac{2 \times 3 \times 6047}{2}$$

$$\begin{aligned} &= 1,58,800 + 39,538 + 18,141 \\ &= 2,16,479 \end{aligned}$$


$$\begin{aligned} P_{2016} &= P_{1981} + 3.5 \times 19769 + (3.5 \times 4.5 \times 6047)/2 \\ &= 1,58,800 + 69,192 + 24,188 \\ &= 2,52,180 \end{aligned}$$

4. Graphical Projection Method

From the graph presented on the following page, the figures for 2001 and 2016 years obtained are as follows:

2001 - 253000

2016 - 362000.



SEMI LOG GRAPH FOR ESTIMATION OF FUTURE POPULATION

CPM NETWORK DIAGRAM FOR A TYPICAL WATER SUPPLY AUGMENTATION SCHEME

A. PARTICULARS OF THE SCHEME

The present water supply scheme supplies 41.5 mLd for a 1971 census population of 258971. To meet the growing needs of both drinking and industrial requirements, a scheme to provide 78.4 mLd in the immediate stage of 1986 and 106.8 mLd in the ultimate stage of 2001 has been envisaged to meet the perspective daily requirement of water at the rate of 180 lpcd, apart from the industrial demand and the requirement of some villages *en route*. The perspective population in the immediate stage of 1986 and ultimate stage of 2001 are assumed as 3,50,000 and 5,00,000 respectively.

B. ASSUMPTIONS

(i) Land Acquisition

- (a) Acquisition proceedings are in progress for the private land required for the headworks. The 68 weeks period prior to execution indicated in the diagram is expected to be adequate before actual construction could be started.
- (b) Though the military authorities have claimed the ownership of the government land required for treatment works, clear water sump and pump-house and the elevated service reservoir at the treatment works, the revenue and Municipal Corporation authorities are of the opinion that this is government land and are confident to make it available to the department earlier than the lag period of 84 weeks provided in the diagram before the commencement of the treatment works.

(ii) Tenders

Combined tenders will be invited for providing and installing the raw water and clear water pumping machinery including provision of C.I. pipes, specials and valves for suction and delivery connections and gantry girders, etc. to obviate the delay in the procurement of machinery through the Central Stores Purchasing Organization. No rigid delivery period is generally specified in supply order placed for C.I. pipes, specials and valves against the rate contract though it is mentioned that delivery be effected as early as possible and the delivery time is invariably more than a year. In view of these indeterminates, a delivery period of 15 months for the new supplies (assuming that the necessary follow up will be carried out at different levels) and the utilisation of the available lead joint pipes in department to the possible extent to avoid the delay in the execution is considered reasonable.

C. NETWORK DIAGRAM

The administrative approval to the scheme was accorded on 8-9-1972, but the actual execution was delayed due to various reasons. The network diagram was prepared on 15-2-1974, i.e. about 75 weeks after the administrative approval. Thus, the time duration for the

activities which are already over have been taken as per actuals while the activities which are yet to take place are projected taking into consideration the most probable period required. It will be seen that while working out the actual activities completed, the time durations for certain items are much higher than the normal which happened in this case due to the delays mentioned earlier. For examples, the activity (14) viz. working plans and estimates for raw and clear water pumping machinery should not have taken 73 weeks. A realistic figure would be around 20 to 30 weeks depending upon several factors like availability of staff etc. Therefore while drawing up the CPM chart at the beginning stages itself, it may be necessary to assume more rational figures of time duration based on the experience of the department and not providing for any delays. The chart can, however, be updated periodically. The following 14 major components of the scheme are further sub divided into 102 activities to complete the project. The number of the activities on the network diagram is also shown in brackets for ready reference.

Major Components	Activity		Time Duration (weeks)	
	Item	No.		
I. Head Works (including Raw Water Rising Main)	(i)	Working plans & estimates	43	
	(ii)	Sanction	7	
	(iii)	Draft tender papers	7	
	(iv)	Receiving tenders	6	
	(v)	Evaluate tenders & award of contract	73	
			68	
	(vi)	Execution work		
	(a)	Intake well connecting pipe, twin po. s well	(10)	78
	(b)	Pump house	(73)	26
	(c)	Approach bridge with approach road and fencing to head work	(11)	76
	(d)	Part execution of raw water rising main	(7)	30
	(e)	Part laying of raw water rising main	(9)	30

Major Components	Activity		Time Duration (weeks)
	Items	No.	
11) Pumping machinery for raw water and their maintenance	(1) Provision of 1000 litres capacity for filling main	(8)	20
	(2) Buying balance length of heavy cable	(72)	30
	(3) Buying spools and wires for constructing chamber for automatic pump	(73)	12
	(4) Working plans and estimates	(14)	73
	(5) Materials	(15)	70
	(6) Draft tender paper	(16)	4
	(7) Knowledge work	(17)	3
	(8) Evaluation, cost & award of contract	(18)	12
	(9) Deliveries of pumping machinery	(19)	48
	(10) Paper, printing, drawing and design	(20)	46
12) Raw Water Pumping Machine Group	(i) Provision of 1000 litres capacity for filling main	(8)	20
	(ii) Buying balance length of heavy cable	(72)	30
	(iii) Buying spools and wires for constructing chamber for automatic pump	(73)	12
	(iv) Working plans and estimates	(14)	73
	(v) Materials	(15)	70
	(vi) Draft tender paper	(16)	4
	(vii) Knowledge work	(17)	3
	(viii) Evaluation, cost & award of contract	(18)	12
	(ix) Deliveries of pumping machinery	(19)	48
	(x) Paper, printing, drawing and design	(20)	46
13) Raw Water Pumping Machine Group	(1) Provision of 1000 litres capacity for filling main	(8)	20
	(2) Buying balance length of heavy cable	(72)	30
	(3) Buying spools and wires for constructing chamber for automatic pump	(73)	12

Major Components	Activity	Nos.	Time Duration (weeks)	
	Item			
IV - Treatment Works	(iv)	Recess, under	(70)	6
	(v)	Drainage under & re- construction	(61)	4
	(vi)	Advances in sanitary technology, i.e. types sprinklers, water supply systems etc.	(68)	12
	(vii)	Electricity cost	(120)	6
			(100)	6
	(viii)	Training	(50)	4
	(i)	Draft under, pipes	(11)	12
	(ii)	Recess, under	(11)	6
	(iii)	Recess, under & sewer at entrance	(16)	10 84
	(iv)	Construction		
(a)	Supply of mechanical and electrical equipment for clarification	(7)	11	
(b)	Supply of mechanical and electrical equipment for filters	(8)	11	
(c)	erection of all equipment for clarification	(80)	9	
(d)	erection of all equipment for filters	(8)	11	
(e)	Civil work for clarification	(7)	11	

Major Components		Activity		Time Duration (weeks)	
		Sl. No.	No.		
V. Clear Water Reservoir And Pump House		(i)	Preparation of drawings	(16)	15
		(ii)	Approval of drawings	(17)	1
		(iii)	Working plan & estimation	(20)	14
		(iv)	Approval	(21)	3
		(v)	Draft tender papers	(22)	3
		(vi)	Receive tenders	(23)	6
		(vii)	Evaluate tenders and award of contract	(25)	8
VI. R.C.C. Service Reservoirs		(i)	Execution	(86)	35
				Group I	Group II
				At treatment works at point A	At points B & C
		(ii)	Working plans B&C	(24) 30	(36) 30
		(iii)	Approval	(25) 6	(37) 6
		(iv)	Draft tender papers	(26) 8	(38) 8
		(v)	Receive tenders	(27) 6	(39) 6
(vi)	Evaluate tenders and award of contract	(29) 8	(41) 8		
VII. Clear Water Rising Mains and Gravity Mains		(i)	Execution	(87) 65	(98) 65
				(91) 65	(99) 65
		(ii)	Rising Main to S.R. at treatment works		
		(iii)	Rising Main to S.R. Point A		

Major Components	Activity	Number	Time Duration (weeks)
1.1.1.1.1	a) Research and development		
	b) Research and development		
	c) Curriculum development		
	d) Working plans and estimates	10	15
	e) Approval	11	1
	f) Draft tender papers	13	4
	g) Receive tenders	14	2
	h) Evaluate tenders and recommend award	12	3
	i) Execution	15, 16, 17, 18, 19, 20	24
	1.1.1.1.2	a) Research and development	
b) Working plans and estimates and approval		21	15
c) Draft tender papers		13	4
d) Receive tenders		14	2
e) Evaluate tenders and recommend award		12	3
f) Execution	22, 23	23	

Number of responses	Frequency		No.	Percentage (percent)
	Days	No.		
IX. Study Program Satisfied (%)	(i)	Strongly Dislike	0%	0
	(ii)	Dislike	0%	0
	(iii)	Like	0%	0
	(iv)	Strongly Like	0%	0
	(v)	Excellent	0%	0
	(vi)	Very Good	100%	50
X. Staff Program Satisfied (%)	(i)	Strongly Dislike	0%	0
	(ii)	Dislike	0%	0
	(iii)	Like	0%	0
	(iv)	Strongly Like	0%	0
	(v)	Excellent	0%	0
	(vi)	Very Good	100%	50
XI. Financial Aid (%)	(i)	Land, building, furniture, and other programs satisfactory based with stop	0%	0
	(ii)	Programs based with stop	100%	50

Major Components	Activity		Time Duration (weeks)
	Item	No	
	Total: 17 items, 6 premises.		
	(b)	Telephone connections	(63) 155
	(c)	C.I pipes, valves, specials (New order to be placed)	
	(i)	Indent	(12) 77
	(ii)	Supply order by S.E.	(13) 4
	(iii)	Delivery	(71) 65
	(d)	C.I pipes against old order placed by S.E. on 31-5-1973	
	(i)	Supply order	(29) 37
	(ii)	Delivery	(30) 65
	(e)	Final transfer of Govt. land for treatment works, clear water reservoir and pump house and S.R. at Treatment works.	(75) 85
	(f)	Obtaining permission of H & C Deptt. for crossing NH for clear water rising main to S.R. at point A.	(28) 130
	(g)	Obtaining permission of Railways for crossing railway track for	(35) 130


Major Components	Activity		Time Duration (weeks)
	Item	No.	
	clear water gravity main from S.R.O. Lane at Point A.		
(n)	Directing transmission lines & transformers at headworks, treatment works and booster pumping station.	(47)	130

From the Network Diagram, it may also be seen that the Prime Conical Path is through the Headworks and covering the activities 1-2-3-4-5 & 10-73-83-101-102 as shown and the time of completion is 188 weeks. Since 4 weeks of testing for all pumping plant and machinery and 12 weeks for erection of raw water pump set are included in this 188 week period, the time duration for the different major components could be summarized as

I	Headworks including Raw Water Rising Main	172 Weeks
II	Raw Water and Clear Water Pumping Machinery	167 weeks
III	Treatment works	
(a)	Clariflocculators	136 weeks
(b)	Filters	158 weeks
IV	Clear Water Sumps and Pump House	128 weeks
V	R.C.C. Services Reservoirs	173 Weeks
V	Clear Water Rising and Gravity Mains	128 weeks
VI	Booster Pump Stations	124 weeks
VIII	Nallah Diversion	129 weeks
IX	Staff Quarters	169 weeks
X	Miscellaneous Works	

(a)	Land acquisition for head works and provisions of barbed wire fencing, internal roads, etc.	172 weeks
(b)	Transfer of Government land for treatment works, etc.	85 weeks
(c)	Telephone connections	55 weeks
(d)	Supply of C.I. pipes and specials	
(i)	New order to be Placed	146 weeks
(ii)	Orders already placed	192 weeks
(e)	Obtaining permission of PWD for National Highway crossing of the rising main	130 weeks
(f)	Obtaining permission of Railways for crossing railway tracks	130 weeks

By proper advance planning and continuous persuasive efforts, it should be possible that the salient works are completed in 188 weeks which is the critical period for the major items of headworks, raw water mains and treatment works so that water could be made available to the consumers even if the scheme is not complete in all respects.



CPM NETWORK DIAGRAM FOR A THERMAL WATER SUPPLY AUGMENTATION SCHEME

APPENDIX 5.1

MASS DIAGRAM FOR IMPOUNDING STORAGE

PROBLEM

Draw the mass diagram and compute the storage needed for an impounding reservoir for a constant draft of 23 ml/sqkm/month of 30.4 days with the following recorded mean monthly run of values

Order of month	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15
Observed monthly mean run-off, million litres per square Kilometers	94	122	45	5	5	2	0	3	16	7	72	92	21	55	33

SOLUTION

Methodology

The mass diagram is obtained by plotting the time interval (order of the month) as abscissa and the cumulative run off and cumulative draft up to the corresponding time interval as calculated in table below as ordinates.

TABLE SHOWING CALCULATION OF REQUIRED STORAGE

(Volume of water in million liters per square kilometre)

Order of month	Recorded run-off Q	Estimated draft D	Cumulative run-off ΣQ	Deficiency D-Q	Cumulative deficiency $\Sigma(D-Q)$	Reservoir state
(1)	(2)	(3)	(4) = $\Sigma(2)$	(5) = (3) - (2)	(6) = $\Sigma(5)$	(7)
1	94	23	94	-71	1(192)	
2	122	23	216	99	0(121)	
3	45	23	261	-22	3(22)	Reservoir full at the beginning dry period
4	5	23	266	18	18*	
5	5	23	271	18	36	
6	2	23	273	21	57	*Reservoir empties
7	0	23	273	23	80	

Order of month	Recorded run-off Q	Estimated draft D	Cumulative run-off ΣQ	Deficiency D-Q	Cumulative deficiency $\Sigma(D-Q)$	Reservoir state
8	2	23	275	21	101	
9	16	23	291	7	108	
10	7	23	298	16	124	Maximum deficiency at end of dry period
11	72	23	370	-49	75	
12	92	23	462	-69	6	
13	21	23	483	2	8	
14	55	23	538	-32	0(24)	Reservoir refilled
15	33	23	571	-30	0(34)	


Col. 3. Constant rate of draft = 23 ml./sq km for an average month of 30.4 days.

Col. 5. Negative value indicates surplus.

Col. 6. Negative values are not included in $\Sigma(D-Q)$ until the beginning of dry period i.e. until water is lost from storage and there is room to store incoming flows. The surplus preceding the dry period, however, must equal or exceed the preceding maximum deficiency; otherwise the reservoir will not be full at the beginning of dry period. The cumulative surplus, calculated backwards from the beginning of dry period, is shown in brackets in column 6 and is seen to exceed 124 ml./sq km of catchment area. The cumulative run-off curve 'B' has been drawn as shown in the figure.

The cumulative draft line for the area under consideration is also plotted in the same scale (line 'A') assuming constant draft of 23 ml./sq km of catchment area for a month of 30.4 days. The slope of line 'A' indicates the rate of draft.

The maximum deficit of run-off from the draft is obtained by drawing a straight line parallel to the cumulative draft curve at the crest and through the cumulative run-off curve tangentially. The vertical ordinate length intercepted between two such parallel lines tangential to the crest and trough gives the maximum deficit for the period between the points of intersection of the parallel line with the mass curve. The maximum cumulative deficiency as observed from the mass curve (which could also be determined analytically as shown in the table) is 124 ml./sq km of catchment area. For the constant rate of draft of 23 ml./sq km of catchment area for a month of 30.4 days and for this cycle of runoff values, the unbounded storage needed is for $(124/23) \times 30.4$ i.e. 165 days (almost half a year).



- 1 DRAW CUMULATIVE DRAFT ED PARALLEL TO RATE OF DRAFT A AND TANGENT TO CURVE B
- 2 DRAW PARALLEL TO LINE A AND TANGENT TO CURVE B
- 3 MEASURE MAXIMUM DEFICIENCY CUMULATIVE
 $ED - EQ = 124 \text{ MM}$
- 4 MUST INTERSECT RUNOFF CURVE, * RESERVOIR IS TO BE FULL AT START OF DRY PERIOD
- 5 END OF DRY PERIOD AT POINT OF TANGENCY
- 6 MUST INTERSECT RUNOFF IF RESERVOIR IS TO REFILL

MASS-DIAGRAM FOR IMPOUNDING STORAGE

APPENDIX 5.2
GROUND WATER RESOURCES AND IRRIGATION POTENTIAL
(Provisional)

States/Cts	Total Replenishable Ground Water Resource		Provision For Drinking, Industrial & Other Uses		Unusable Ground Water Resources For Irrigation		Net Drain		Balance Available For Irrigation		Net Irrigation Requirements		Ultimate Irrigation Potential		Potential Utilised		Balance In Pot. To Be Developed	
	(m ³ /a)	(m ³ /a)	(m ³ /a)	(m ³ /a)	(m ³ /a)	(m ³ /a)	(m ³ /a)	(m ³ /a)	(m ³ /a)	(m ³ /a)	(m ³ /a)	(m ³ /a)	(m ³ /a)	(m ³ /a)	(m ³ /a)	(m ³ /a)	(m ³ /a)	(m ³ /a)
1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19
STATES																		
Andhra Pradesh	4.34	0.65	3.69	0.74	2.95	(0.558-0.999)	5.19	1.04	4.15									
Andhra Pradesh	0.14	0.02	0.12	0.00	0.12		0.002		0.02									
Assam	2.35	0.35	2.00	0.05	1.95	1.280	1.56	0.04	1.52									
Bihar	3.38	0.51	2.87	0.66	2.19	0.400	2.78	1.70	5.48									
Goa	0.061	0.015	0.046	0.0040	0.0420	0.600	0.076	0.006	0.070									

State/Use	Total Replenishable Ground Water Resource (m ha m/Yr)	3 Provision for Drinking Industrial & Other Uses (m ha m/Yr)	4 Unavailable Ground Water Resources For Irrigation (m ha m/Yr)	5 Net Draft (m ha m/Yr)	6 Balance Available For Irrigation (m ha m/Yr)	Net Irrigation Requirements (m ha m/Yr)	Ultimate Irrigation Potential (m ha)	Potential Unutilized (m ha)	Balance In Pot. To Be Developed (m ha)
Gujarat									
Coastal	0.22	0.03	0.17	0.11	0.08	(0.0364 - 0.500)	0.44	0.25	0.19
Liu	2.04	0.31	1.73	0.55	1.20	(0.515 - 0.500)	4.37	3.37	3.00
Deccan	0.85	0.13	0.72	0.51	0.21	0.385	1.98	1.52	0.50
Himachal Pradesh	0.036	0.007	0.029	0.006	0.023	0.385	0.074	0.016	0.098
Jammu & Kashmir	0.14	0.07	0.37	0.055	0.365	(0.325 - 0.600)	0.783	0.012	0.771
Karnataka	1.62	0.24	1.38	0.50	0.83	(0.330 - 0.360)	3.12	0.70	2.129
Kerala	0.81	0.12	0.69	0.07	0.07	0.690	0.99	0.09	0.90
Madhya Pradesh	5.97	0.89	5.08	0.60	4.45	0.400	12.70	1.50	11.29
Maharashtra	5.38	0.67	3.20	0.70	2.50	(0.400 - 0.750)	5.81	1.52	4.52
Madhya Pradesh	0.012	0.002	0.010	0.00	0.01	0.650	0.016		0.016


States / Utb	Total Replenishable Ground Water Resource (m ³ /yr)	Processed for Drinking, Industrial & Other Uses (m ³ /m ² /yr)	Unsaline Ground Water Resources for Irrigation (m ³ /yr)	Net Debit (m ³ /m ² /yr)	Balance Available for Irrigation (m ³ /yr)	Net Irrigation Replenishment (Range) (m ³)	Ultimate Irrigation Potential (m ³ /ha)	Potential Utilised (m ³ /ha)	Balance Per Ha For Developed (m ³ /ha)
1	2	3	4	5	6	7	8	9	10
Meghalaya	0.045	0.007	0.036	0.000024	0.035776	0.650	0.056	0.00004	0.05596
Mizoram									
Nagaland	0.086	0.001	0.084	0.000	0.084	Not Assessed			
Orissa	2.55	2.55	1.78	0.70	1.88	0.52-0.44	5.40	0.25	5.15
Punjab	1.80	0.27	1.53	1.52	0.01	0.108	3.87	3.80	0.02
Rajasthan	1.62	0.29	1.33	0.56	0.83	0.39-0.12	3.44	1.26	2.18
Sikkim									
Tamil Nadu	3.02	0.46	2.56	1.20	1.36	0.360 (0.997)	3.15	1.45	1.90
Tripura	0.06	0.01	0.05	0.005	0.045	0.636	0.06	0.058	0.012
Uttar Pradesh	6.05	1.21	6.84	2.50	4.34	360	18.00	3: 50	6.50
West Bengal	2.07	0.31	1.76	0.29	1.47	0.6-1.63	1.92	0.23	1.66
Total states	45.147	6.922	38.225	10.620	27.605		80.365	27.862	52.40296

States/ Utz	Total Requisition for Ground Water Resource	Provision for Drinking Industrial & Other Uses	Utilizable Ground Water Resources For Irrigation	Net Draft	Balance Available For Irrigation	Net Irrigation Requirement	Ultimate Irrigation Potential	Potential Utilised	Balance for Per to Be Developed
	(in ha m/Yr)	(in ha m/Yr)	(in ha m/Yr)	(in ha m/Yr)	(in ha m/Yr)	(Range) (in m/Yr)	(in ha)	(in ha)	(in ha)
1	2	3	4	5	6	7	8	9	10
Sum	45.15	6.92	38.23	10.62	37.61		80.27	37.86	52.41
UNION TERRITORIES									
Andaman & Nicobar									
Chandigarh	0.0035		0.0035	0.0035	0.0054				
Dadra & Nagar Havel	0.0075	0.0020	0.0062	0.005	0.0047	0.0500	0.0086	0.0007	0.0073
Delhi	0.0604	0.0076	0.0423	0.0287	0.0341	0.3850	0.1112	0.0745	0.0367
Daman & Diu					Not Assessed				
Jammu & Kashmir					Not Assessed				
Pondicherry	0.0175	0.0026	0.0149	0.0234	0.0055	0.0050	0.0000	0.0000	0.0000

State Use	Costs Responsible for Ground Water Recovery	Provision for Drinking Industrial & Other Uses	Utilizable Ground Water Resources for Irrigation	Not Used for Irrigation	Balance Available for Irrigation	Number of Irrigation Requirements	Estimated Irrigation Potential	Present Utilized	Balance to Be Developed
	(in m.c.f.)	(in m.c.f.)	(in m.c.f.)	(in m.c.f.)	(in m.c.f.)	(in acres)	(in acres)	(in acres)	(in acres)
1	2	3	4	5	6	7	8	9	10
Total Use	0.0789	0.0125	0.0664	0.0355	0.0109	1.9350	31.903	6.0752	6.9486
Sur	0.08	0.01	0.07	0.06	0.01		0.12	0.08	0.04
Total Irrigation	44,225.9	6,934.6	38,291.4	30,675.6	27,613.0		90,382.7	77,337.7	52,446.9
New	45.23	6.93	33.30	11.66	27.62		80.38	27.94	52.44

The estimates of ground water resources and as per the norms and guidelines laid down by the Ground Water Estimation Committee (1984) associated by the working group based by the state Irrigation Secretary (charge of Ground Water Department and comprised of the head of the Ground Water Organization in the State Director of State Agricultural Department and representative from Agriculture Universities and the regional Director of Control Ground Water Board as the convenor.

APPENDIX 5.3



PERMEABILITY CLASSIFICATION OF SOIL

APPENDIX 5A


VALUES OF THE WELL FUNCTION $W(u)$ FOR VARIOUS VALUES OF u

u	$N \times 10^{+15}$	$N \times 10^{+14}$	$N \times 10^{+13}$	$N \times 10^{+12}$	$N \times 10^{+11}$	$N \times 10^{+10}$	$N \times 10^9$	$N \times 10^8$
1	2	3	4	5	6	7	8	9
1.0	33.56	31.66	29.36	27.05	24.75	22.45	20.15	17.84
1.5	33.56	31.25	28.95	26.65	24.35	22.04	19.74	17.44
2.0	33.27	30.97	28.66	26.36	24.06	21.76	19.45	17.15
2.5	33.05	30.74	28.44	26.14	23.83	21.55	19.23	16.93
3.0	32.86	30.56	28.26	25.96	23.65	21.53	19.05	16.75
3.5	32.71	30.41	28.10	25.80	23.50	21.20	18.60	16.59
4.0	32.57	30.27	27.97	25.67	23.36	21.06	18.76	16.46
4.5	32.46	30.15	27.85	25.55	23.25	20.94	18.64	16.34
5.0	32.35	30.05	27.75	25.44	23.14	20.84	18.54	16.23
5.5	32.26	29.95	27.65	25.35	23.05	20.74	18.44	16.14
6.0	32.17	29.87	27.56	25.26	22.96	20.66	18.35	16.05
6.5	32.09	29.79	27.48	25.18	22.88	20.58	18.27	15.97
7.0	32.02	29.71	27.41	25.11	22.81	20.50	18.20	15.90
7.5	31.95	29.64	27.34	25.04	22.74	20.43	18.13	15.83
8.0	31.88	29.58	27.28	24.97	22.67	20.37	18.07	15.76
8.5	31.82	29.52	27.22	24.91	22.61	20.31	18.01	15.70
9.0	31.76	29.46	27.16	24.86	22.55	20.25	17.95	15.65
9.5	31.71	29.41	27.11	24.81	22.50	20.20	17.89	15.59

N	$N \times 10^{-2}$	$N \times 10^{-3}$	$N \times 10^{-5}$	$N \times 10^{-4}$	$N \times 10^{-3}$	$N \times 10^{-2}$	$N \times 10^{-1}$	\bar{N}
10	11	12	13	14	15	16	17	18
1.0	15.54	13.24	10.94	9.633	6.337	4.038	1.923	2.194×10^{-1}
1.5	15.14	12.83	10.53	8.238	5.927	3.637	1.465	1.000×10^{-1}
2.0	14.85	12.55	10.24	7.094	5.639	3.355	1.223	4.890×10^{-2}
2.5	14.62	12.32	10.02	7.717	5.417	3.137	1.044	2.491×10^{-2}
3.0	14.44	12.14	9.837	7.585	5.235	2.959	0.9057	1.305×10^{-2}
3.5	14.29	11.99	9.683	7.583	5.081	2.810	0.7942	6.970×10^{-3}
4.0	14.15	11.85	9.550	7.247	4.948	2.681	0.7024	3.779×10^{-3}
4.5	14.04	11.73	9.432	7.130	4.831	2.568	0.6253	2.073×10^{-3}
5.0	13.93	11.63	9.326	7.024	4.726	2.468	0.5598	1.148×10^{-3}
5.5	13.84	11.53	9.231	6.929	4.631	2.378	0.5034	6.409×10^{-4}
6.0	13.75	11.45	9.144	6.842	4.545	2.295	0.4544	3.601×10^{-4}
6.5	13.67	11.37	9.064	6.762	4.465	2.220	0.4115	2.034×10^{-4}
7.0	13.60	11.29	8.990	6.688	4.392	2.151	0.3738	1.155×10^{-4}
7.5	13.53	11.22	8.921	6.619	4.323	2.087	0.3403	6.583×10^{-5}
8.0	13.46	11.16	8.856	6.555	4.259	2.027	0.3106	3.767×10^{-5}
8.5	13.40	11.10	8.796	6.494	4.199	1.971	0.2840	2.162×10^{-5}
9.0	13.34	11.04	8.739	6.437	4.142	1.919	0.2602	1.215×10^{-5}
9.5	13.29	10.99	8.685	6.384	4.089	1.870	0.2387	7.165×10^{-6}

APPENDIX 5.5

VALUE OF u FOR TYPE CURVE



OBSERVED VALUES OF t/r^2

APPENDIX 5.6 YIELD TESTS FOR WELLS

GENERAL

Yield tests are conducted to determine the maximum and minimum available concentrations of contaminants in the aquifer. The purpose of the tests is to determine the potential for contamination of the aquifer. The tests are conducted with a series of wells at different depths and at different locations. The tests are conducted by pumping water from the wells at a rate that is sufficient to draw the water from the aquifer. The yield test is a series of tests that are conducted at different depths and at different locations. The yield test is a series of tests that are conducted at different depths and at different locations.

MEASUREMENTS

The measurements that are made are the flow rate, the volume of water pumped, the time taken to pump the water, and the depth of the well. The measurements are made by using a flow meter, a volume meter, a stopwatch, and a measuring tape. The measurements are made at different depths and at different locations.

PUMPING PROCEDURE

The procedure used for the yield tests is as follows. The pump is started and the flow rate is measured. The volume of water pumped is measured. The time taken to pump the water is measured. The depth of the well is measured. The measurements are made at different depths and at different locations.

In the pumping test, the pump is started and the flow rate is measured. The volume of water pumped is measured. The time taken to pump the water is measured. The depth of the well is measured. The measurements are made at different depths and at different locations.

The yield test results are shown in the following table.

AQUIFER PERFORMANCE TEST RESULTS

Site 1	81	11.1m
Site 2	115	116.2m

The data shown in the table are the results of the yield tests. The data are shown in the following table.

Time since pump started (s)	Time since pump stopped (s)	θ (°)	Drawdown h (m)	Residual drawdown h_1 (m)	Yield (m ³ /min)
1	0	0	4	0	0
1	0	0	3.9	0	0
2	0	0	3.8	0	0
10	0	0	3.5	0	0
15	0	0	3.4	0	0
1	0	0	3.3	0	0
20	0	0	3.2	0	0
25	0	0	3.1	0	0
30	0	0	3.0	0	0
35	0	0	2.9	0	0
40	0	0	2.8	0	0
45	0	0	2.7	0	0
50	0	0	2.6	0	0
55	0	0	2.5	0	0
60	0	0	2.4	0	0
65	0	0	2.3	0	0
70	0	0	2.2	0	0
75	0	0	2.1	0	0
80	0	0	2.0	0	0
85	0	0	1.9	0	0
90	0	0	1.8	0	0
95	0	0	1.7	0	0
100	0	0	1.6	0	0
105	0	0	1.5	0	0
110	0	0	1.4	0	0
115	0	0	1.3	0	0
120	0	0	1.2	0	0
125	0	0	1.1	0	0
130	0	0	1.0	0	0
135	0	0	0.9	0	0
140	0	0	0.8	0	0
145	0	0	0.7	0	0
150	0	0	0.6	0	0
155	0	0	0.5	0	0
160	0	0	0.4	0	0
165	0	0	0.3	0	0
170	0	0	0.2	0	0
175	0	0	0.1	0	0
180	0	0	0	0	0
185	0	0	0	0	0
190	0	0	0	0	0
195	0	0	0	0	0
200	0	0	0	0	0
205	0	0	0	0	0
210	0	0	0	0	0
215	0	0	0	0	0
220	0	0	0	0	0
225	0	0	0	0	0
230	0	0	0	0	0
235	0	0	0	0	0
240	0	0	0	0	0
245	0	0	0	0	0
250	0	0	0	0	0
255	0	0	0	0	0
260	0	0	0	0	0
265	0	0	0	0	0
270	0	0	0	0	0
275	0	0	0	0	0
280	0	0	0	0	0
285	0	0	0	0	0
290	0	0	0	0	0
295	0	0	0	0	0
300	0	0	0	0	0
305	0	0	0	0	0
310	0	0	0	0	0
315	0	0	0	0	0
320	0	0	0	0	0
325	0	0	0	0	0
330	0	0	0	0	0
335	0	0	0	0	0
340	0	0	0	0	0
345	0	0	0	0	0
350	0	0	0	0	0
355	0	0	0	0	0
360	0	0	0	0	0
365	0	0	0	0	0
370	0	0	0	0	0
375	0	0	0	0	0
380	0	0	0	0	0
385	0	0	0	0	0
390	0	0	0	0	0
395	0	0	0	0	0
400	0	0	0	0	0
405	0	0	0	0	0
410	0	0	0	0	0
415	0	0	0	0	0
420	0	0	0	0	0
425	0	0	0	0	0
430	0	0	0	0	0
435	0	0	0	0	0
440	0	0	0	0	0
445	0	0	0	0	0
450	0	0	0	0	0
455	0	0	0	0	0
460	0	0	0	0	0
465	0	0	0	0	0
470	0	0	0	0	0
475	0	0	0	0	0
480	0	0	0	0	0
485	0	0	0	0	0
490	0	0	0	0	0
495	0	0	0	0	0
500	0	0	0	0	0
505	0	0	0	0	0
510	0	0	0	0	0
515	0	0	0	0	0
520	0	0	0	0	0
525	0	0	0	0	0
530	0	0	0	0	0
535	0	0	0	0	0
540	0	0	0	0	0
545	0	0	0	0	0
550	0	0	0	0	0
555	0	0	0	0	0
560	0	0	0	0	0
565	0	0	0	0	0
570	0	0	0	0	0
575	0	0	0	0	0
580	0	0	0	0	0
585	0	0	0	0	0
590	0	0	0	0	0
595	0	0	0	0	0
600	0	0	0	0	0
605	0	0	0	0	0
610	0	0	0	0	0
615	0	0	0	0	0
620	0	0	0	0	0
625	0	0	0	0	0
630	0	0	0	0	0
635	0	0	0	0	0
640	0	0	0	0	0
645	0	0	0	0	0
650	0	0	0	0	0
655	0	0	0	0	0
660	0	0	0	0	0
665	0	0	0	0	0
670	0	0	0	0	0
675	0	0	0	0	0
680	0	0	0	0	0
685	0	0	0	0	0
690	0	0	0	0	0
695	0	0	0	0	0
700	0	0	0	0	0
705	0	0	0	0	0
710	0	0	0	0	0
715	0	0	0	0	0
720	0	0	0	0	0
725	0	0	0	0	0
730	0	0	0	0	0
735	0	0	0	0	0
740	0	0	0	0	0
745	0	0	0	0	0
750	0	0	0	0	0
755	0	0	0	0	0
760	0	0	0	0	0
765	0	0	0	0	0
770	0	0	0	0	0
775	0	0	0	0	0
780	0	0	0	0	0
785	0	0	0	0	0
790	0	0	0	0	0
795	0	0	0	0	0
800	0	0	0	0	0
805	0	0	0	0	0
810	0	0	0	0	0
815	0	0	0	0	0
820	0	0	0	0	0
825	0	0	0	0	0
830	0	0	0	0	0
835	0	0	0	0	0
840	0	0	0	0	0
845	0	0	0	0	0
850	0	0	0	0	0
855	0	0	0	0	0
860	0	0	0	0	0
865	0	0	0	0	0
870	0	0	0	0	0
875	0	0	0	0	0
880	0	0	0	0	0
885	0	0	0	0	0
890	0	0	0	0	0
895	0	0	0	0	0
900	0	0	0	0	0
905	0	0	0	0	0
910	0	0	0	0	0
915	0	0	0	0	0
920	0	0	0	0	0
925	0	0	0	0	0
930	0	0	0	0	0
935	0	0	0	0	0
940	0	0	0	0	0
945	0	0	0	0	0
950	0	0	0	0	0
955	0	0	0	0	0
960	0	0	0	0	0
965	0	0	0	0	0
970	0	0	0	0	0
975	0	0	0	0	0
980	0	0	0	0	0
985	0	0	0	0	0
990	0	0	0	0	0
995	0	0	0	0	0
1000	0	0	0	0	0

© 1998 Pearson Education, Inc.

Time since pump started (t) min	Time since pump stopped (t')	t/t'	Drawdown S(m)	Residual drawdown Rd(m)	Yield (m ³ /min)
1	1	1	10.12	0	0
54			10.22		
56			10.37		
58			10.49		
60			10.26		
62			10.04		
67			10.18		
71			10.49		
77			10.47		
82			10.35		
87			10.30		
92			10.21		
97			10.12		
102			10.83		
117			10.40		
132			10.22		
147			10.04		
162			10.38		
192			10.30		
200			9.99		
202	2	1.01		5.44	
210	3	67.6		4.41	
214	4	51.0		4.25	
205	5	41.0		4.16	

Year since 1947	Class size per 100 students	y^*	Class location	1947 class size per 100 students	1947 class location
1	1	1	1	1	1
2	1	1	1	1	1
3	1	1	1	1	1
4	1	1	1	1	1
5	1	1	1	1	1
6	1	1	1	1	1
7	1	1	1	1	1
8	1	1	1	1	1
9	1	1	1	1	1
10	1	1	1	1	1
11	1	1	1	1	1
12	1	1	1	1	1
13	1	1	1	1	1
14	1	1	1	1	1
15	1	1	1	1	1
16	1	1	1	1	1
17	1	1	1	1	1
18	1	1	1	1	1
19	1	1	1	1	1
20	1	1	1	1	1
21	1	1	1	1	1
22	1	1	1	1	1
23	1	1	1	1	1
24	1	1	1	1	1
25	1	1	1	1	1
26	1	1	1	1	1
27	1	1	1	1	1
28	1	1	1	1	1
29	1	1	1	1	1
30	1	1	1	1	1
31	1	1	1	1	1
32	1	1	1	1	1
33	1	1	1	1	1
34	1	1	1	1	1
35	1	1	1	1	1
36	1	1	1	1	1
37	1	1	1	1	1
38	1	1	1	1	1
39	1	1	1	1	1
40	1	1	1	1	1
41	1	1	1	1	1
42	1	1	1	1	1
43	1	1	1	1	1
44	1	1	1	1	1
45	1	1	1	1	1
46	1	1	1	1	1
47	1	1	1	1	1
48	1	1	1	1	1
49	1	1	1	1	1
50	1	1	1	1	1
51	1	1	1	1	1
52	1	1	1	1	1
53	1	1	1	1	1
54	1	1	1	1	1
55	1	1	1	1	1
56	1	1	1	1	1
57	1	1	1	1	1
58	1	1	1	1	1
59	1	1	1	1	1
60	1	1	1	1	1
61	1	1	1	1	1
62	1	1	1	1	1
63	1	1	1	1	1
64	1	1	1	1	1
65	1	1	1	1	1
66	1	1	1	1	1
67	1	1	1	1	1
68	1	1	1	1	1
69	1	1	1	1	1
70	1	1	1	1	1
71	1	1	1	1	1
72	1	1	1	1	1
73	1	1	1	1	1
74	1	1	1	1	1
75	1	1	1	1	1
76	1	1	1	1	1
77	1	1	1	1	1
78	1	1	1	1	1
79	1	1	1	1	1
80	1	1	1	1	1
81	1	1	1	1	1
82	1	1	1	1	1
83	1	1	1	1	1
84	1	1	1	1	1
85	1	1	1	1	1
86	1	1	1	1	1
87	1	1	1	1	1
88	1	1	1	1	1
89	1	1	1	1	1
90	1	1	1	1	1
91	1	1	1	1	1
92	1	1	1	1	1
93	1	1	1	1	1
94	1	1	1	1	1
95	1	1	1	1	1
96	1	1	1	1	1
97	1	1	1	1	1
98	1	1	1	1	1
99	1	1	1	1	1
100	1	1	1	1	1

Time since pump started (t) min	Time since pump stopped (t') min	1/t'	Drawdown S(m)	Residual drawdown Rd(m)	Yield (m ³ /min)
1	2	3	4	5	6
302	102	2.95		2.17	
307	107	2.86		1.96	
312	112	2.78		2.01	
322	122	2.63		1.88	
332	132	2.51		1.76	
342	142	2.40		1.70	
352	152	2.31		1.68	
362	162	2.21		1.35	
372	172	2.16		1.17	
382	182	2.09		1.05	
392	192	2.01		0.90	
402	202	1.98		0.78	
422	222	2.00		0.54	
442	242	1.82		0.15	
462	262	1.76		0.36	
482	282	1.70		0.29	
492	292	1.68		0.25	
512	312	1.61		0.21	
542	342	1.54		0.16	
572	372	1.53		0.12	
602	402	1.49		0.10	
632	432	1.56		0.08	
662	462	1.45		0.07	
692	492	1.45		0.06	

Time since pump started (h)	Time since pump stopped (h)	t^2/h^2	Drawdown s (m)	Residual drawdown s' (m)	Yield (m^3/day)
0	0	0	0	0	0
1.0	0.5	0.25	0.07	0.07	0.07
2.0	1.0	0.50	0.14	0.14	0.14
3.0	1.5	0.75	0.21	0.21	0.21
4.0	2.0	1.00	0.28	0.28	0.28
5.0	2.5	1.25	0.35	0.35	0.35
6.0	3.0	1.50	0.42	0.42	0.42
7.0	3.5	1.75	0.49	0.49	0.49
8.0	4.0	2.00	0.56	0.56	0.56
9.0	4.5	2.25	0.63	0.63	0.63
10.0	5.0	2.50	0.70	0.70	0.70

using the recovery $U = 0.01$ and

$$U = 2.08Q/Ar$$

where,

Q is the discharge (m³/sec) of a single well, r is the radius (m) of the well and A is the residual drawdown between two values of t in a well in a fully penetrating system.


By obtaining U using the appropriate well recovery U and r , a drawdown of 0.70 m can be obtained in a semi-logarithmic time response, the value of U is 0.01 and from the graph value of Q is

$$Q = 2048.6229 \times 0.098 \text{ cubic meters per second}$$



$$Q = 200.763 \text{ cubic meters per second}$$

It may be noted that the yield of the well is 200.763 m³/sec. The value of U in a semi-logarithmic paper in the previous case gives even drawdowns and it is noted that the value of U is 0.01 and r is 0.58. The high value of residual drawdown is not a very good average into the well. This was obviously due to the fact that sand may be present in the well perpendicular to the anisotropic layer containing the well water. It is apparent that the main source of the well sand and so was the well assembly. In view of the residual drawdown of 0.70 m, the amount of water in the well is the true character of the well system.


SECTION A-A



SECTION B-B - ELEVATION



PLAN OF RADIALS



ARRANGEMENT FOR DRIVING HORIZONTAL SLOTTED PIPE

RADIAL COLLECTOR WELL

APPENDIX 5.8

DISINFECTION OF NEW OR REVIVATED WELLS (TUBEWELLS AND PIPELINES)

DISINFECTION OF WELLS

New wells as well as those after repairs have to be disinfected by heavy doses of chlorine. The doses applied are generally of the order of 10 to 30 mg/l of available chlorine and bleaching powder is usually employed.

Dug Wells

1. After the casing or lining is completed, the ground is sealed below by concrete or put before the cover platform is placed over the well.
 - (a) Remove all equipment and material such as bags, partitions, etc., which do not form a permanent part of the completed structure.
 - (b) Wash the interior walls of the casing or lining with a strong solution of the bleaching powder (50 mg/l chlorine) using a stiff brush to be thorough in scrubbing.
 - (c) Pump the water from the well until it is perfectly clear and remove the pumping equipment that was temporarily set up for this purpose.
2. Place the cover over the well and pour the required amount of bleaching powder solution into the well through the scumhole or pipe opening just prior to inserting the pump cylinder and drop pipe assembly. The bleaching powder added should give a dose of 30 mg/l of chlorine in the volume of water in the well. Care should be taken to distribute the chlorine solution over as much of the surface of the water as possible to obtain proper covering of the internal wall with water, which may be facilitated by running the solution into the well through a hose or pipeline as the line is being alternately raised and lowered.
3. Wash the exterior surface of the pump cylinder and drop pipe with bleaching powder solution giving 50 mg/l of chlorine when the assembly is being lowered into the well.
4. Allow the chlorine solution to remain in the well for not less than 24 hours.
5. After 24 hours or more have elapsed, the well should be flushed by pumping the water to waste, all the residual chlorine is brought to the surface.

TUBEWELLS

1. When the well is tested for yield, the test pump should be operated until the well water is as clear and free from turbidity as possible.
2. After the testing equipment has been removed, pour the required amount of bleaching solution into the well slowly just prior to installing the permanent pumping equipment. The

dose of chlorine should be maintained at 5 mg/l. Mixing of the chemical with well water may be facilitated by running the solution into the well through a hose or pipeline as the latter is being alternately raised and lowered.

3. Wash the exterior surface of the pump cylinder and drop pipe with bleaching powder solution before positioning.
4. Allow the chlorine solution to remain in the well for not less than 24 hours.
5. After 24 hours or more have elapsed, the well should be flushed by pumping the water to waste till a residual of 1 mg/l of chlorine is obtained. In the case of deep wells having a high water level, it may be necessary to resort to special methods of introducing the disinfecting agent into the well so as to ensure proper mixing of chlorine throughout the well.

Similar procedure is adopted when troubles due to iron bacteria are confined to the tube wells particularly when they come out as stringy mass along with the water.

DISINFECTATION OF PIPELINES

When a section of water main is laid or repaired it is impossible to avoid contaminating the inner surface with dirt, mud or water in the trench while the pipes are being fixed into place. Contamination may also occur by accident, negligence or malice; adequate surveillance during working hours and the plugging of open ends after the day's work will reduce these risks. It should be assumed however that the pipe is contaminated despite all the precautions taken to prevent the entry of foreign matter. Secondly the main must be disinfected before it is put into service.

To obtain good results from disinfection and to avoid the hazards of subsequent obstructions and damage to valves, all foreign objects and material should be removed before hand by swabbing and flushing to clean the pipeline. Packing and cement material should be cleaned and disinfected immediately before use by immersion in a 50 mg/l of chlorine solution for at least 50 minutes.

The presence of hydrants, air valves, gate valves and other openings in and around the section to be disinfected facilitate the suction and extraction of water for flushing and disinfection. Recently developed plastic foam swabs are also useful in the disinfection of mains. As they are displaced by water pressure, these swabs wipe clean the inner surface of the pipe. They can isolate the section to be disinfected from the rest of the main and prevent the loss of the disinfected solution.

Chlorine compounds are the most commonly used disinfectants for water mains. Strength of the disinfecting solution should be much higher than that normally used for water chlorination. Under normal conditions a strength of 10 mg/l is recommended for a contact period of 12-24 hours. Application for 24 hours is necessary when the chlorine has to penetrate through organic matter coating the inner surface. In emergencies, when it is not possible to leave the section of the main out of service for a long time, the period of contact can be shortened by proportionately increasing the strength of the solution. Thus for a contact period of 1 hour the strength of solution varies between 120 and 240 mg/l. When strong solutions are used particular attention should be paid to thorough removal from the main after completion of disinfection as illness and discomfort may result from using highly chlorinated water and the corrosive action of the chlorine may damage pipes, valves, hydrants and house hold plumbing and fixtures.

PROCEDURE FOR APPLICATION

Chlorine gas may be injected directly under the section of the main by a dry-feed chlorine or supplied with a special gas diffuser or silver tube and attached to a hydrant or other opening by means of specially plugged valve. After the section has been thoroughly flushed, the main valve is partly shut to bring water pressure below 1.75 kg/cm².

At the hydrant or opening where the water is discharged, the flow rate is measured to determine the rate at which chlorine gas needs to be delivered. To obtain a concentration of 10 mg/l in the section to be disinfected, the chlorine gas input rate should be 0.9 kg/24 hours for every litres per second of flow. The valve of the chlorine cylinder is opened and adjusted so that the dial shows the required rate of chlorine flow.

To ensure that the chlorine concentration remains at 20 mg/l throughout the period of contact, the strength of the injected solution should be at least twice as high. A table below shows the amount of disinfectants required for pipes of various diameters in order to provide a chlorine concentration of about 20 mg/l.

QUANTITY OF DISINFECTANTS REQUIRED TO PROVIDE CONCENTRATION OF 20 mg/l IN A 100 m PIPE LENGTH

Dia of pipe mm	Quantity in litres at which disinfectant has to be discharged 100 m line	Bleaching Powder (25% available chlorine) gm	Calcium Hypochlorite (70% available chlorine) gm	Sodium Hypochlorite (5% available chlorine) litres
75	25	37	15	0.16
100	81	65	23	0.33
150	183	146	53	0.73
200	321	263	92	1.30
250	507	405	143	2.03
300	730	584	210	2.92
400	1298	1040	368	5.20

The volume in litres of the disinfecting solution required for 100 m of pipe can be expressed by $V = 0.38 d^2$ where d is the diameter of the pipe in mm.

As soon as the colour of chlorine is detected in water discharged from the main, water samples are taken to determine the chlorine content. When chlorine content reaches a value of 20 mg/l at

the other end of the section being disinfected, the discharge hydrant is closed, and the flow of the water and chlorine gas is stopped. The water allowed to stand in the main for 24 hours, and the chlorine remaining should be enough to be effective for 10 days at the end of the period. The main should be thoroughly flushed with fresh water, and the water should be dumped into the sewer. The gas should be taken care of by being led 3 days following the section treated, so that the water is satisfactory in purity.

A similar procedure is used for treating a section of chlorine gas and water mains. For a branch lead disinfected, special valves from the tap to be treated are put in place and the main valve between the water main pump is required to provide a pressure of least 30 times higher than that of the water in the main to be treated. Care is taken.

When chlorine gas and water are used for disinfecting a section of a main, the usual method of application is to inject a stream of chlorine gas into the main at a certain point. The water valve is kept partly open, a small flow of water running. The pipe is not really disinfected by the chlorine. The discharge hydrant or other outlet valve which the chlorine is injected in the water flowing out of the section of the main is closed. The water valve is regulated so that the capacity of the section of the main is about 10 ft. The pipe is completely full.

When there is no chlorine gas pump, a pipe the diameter of the water valve is run off at the discharge operation and the section is allowed to drain dry. Then the discharge hydrant or other outlet valve is left open, the chlorine gas being injected into the main at the point where the disinfected section is slowly pushed through a tap at a low pressure, until the chlorine valve is opening made. For this purpose, and fire section is completely filled. There can be a slight leakage of air, which is trapped in the pipe, or escape, where there is no air valve to cause trouble by which the air can be released, once a certain service connection is closed. The chlorine gas can be called in before the gas.

If the section to be disinfected is short, water or gas hoses of various lengths can be used. A small amount of powder may be placed at regular intervals along the pipe at the end of the section. When water is introduced, the powder will mix with it and form a suspension of chlorine. The disadvantage is that the powder will be forced to the head of the section even when a low pressure is used, and a distribution of chlorine is possible.

While disinfecting a large main, the valves at the end of the section to be disinfected should be required to ensure that all sections come into contact with the disinfectant. The valves at the end of the treated section should be closed during the whole period of operation, to prevent the loss of disinfecting station.

at least 2
2" thick for wet joints.

3 of

APPENDIX 6
HYDROSTATIC TEST PRESSURES FOR PIPES

S.Nos	Pipe Sizes	Nominal dia of pipe	Class	Test pressure		Minimum thickness of pipe
				Design pressure	Hydrostatic test pressure	
1		1	2	3	4	5
1	Spun cast pipe Nominal dia 8 to 12 inch	8000, 125	8	88	16	12
		10000, 150	10	110	20	15
		12000, 150	12	132	25	20
2	Cast iron pipe Nominal dia	8000, 125	8	88	16	See specifications for min. thickness
		10000, 150	10	110	20	See specifications for min. thickness
		12000, 150	12	132	25	See specifications for min. thickness
		14000, 150	14	154	30	See specifications for min. thickness
		16000, 150	16	176	35	See specifications for min. thickness
		18000, 150	18	198	40	See specifications for min. thickness
3	Steel pipe Nominal dia	8000, 125	8	88	16	See specifications for min. thickness
		10000, 150	10	110	20	See specifications for min. thickness
		12000, 150	12	132	25	See specifications for min. thickness
		14000, 150	14	154	30	See specifications for min. thickness
		16000, 150	16	176	35	See specifications for min. thickness
4	Cast steel pipe Nominal dia	8000, 125	8	88	16	See specifications for min. thickness
		10000, 150	10	110	20	See specifications for min. thickness
5	Cast steel pipe Nominal dia	8000, 125	8	88	16	See specifications for min. thickness
		10000, 150	10	110	20	See specifications for min. thickness
		12000, 150	12	132	25	See specifications for min. thickness
		14000, 150	14	154	30	See specifications for min. thickness

		600,700,800,		
4	Steel cylinder	200-500,	1	5
	R.C. Pipes	600,700,800	2	10
	IS 1916-1963	1100,1200-200	3	15
		2400	4	20
			5	25
		Npl.		
6	Prestressed	40,100,125,150		1.5 times design pressure
	concrete Pipes	50,500-100-		
	IS 784-1976	1200-2000 (800)		
7	Electrically	200-2000	1	15
	Welded steel		2	20
	pipes IS 3586-		3	25
	1987		500	
8	M.S. Pipes	6-100	Light	50
	IS 1239 (Part 1)	6-150	Medium	50
	1987	6-150	Heavy	50

APPENDIX 6.5

DESIGN FOR ECONOMIC SIZE OF PUMPING MAIN

PROBLEM: Design of economic size of pumping main, given the following data

1	Water requirements	Year	Discharge
	Initial	199	5 MLD
	Intermediate	200	7.5 MLD
	Ultimate	2015	20 MLD
2	Length of pumping main	2000m	
3	Static head for pump	10m	
4	Design period	25 years	
5	Efficiency of motor of pumping set	90%	
6	Cost of pumping set	Rs. 2000 per kw	
7	Interest rate	10%	
8	Life of electric motor and pump	15 years	
9	Energy charges	Rs. 100 per unit	
10	Depreciation of 5% for 1.5 pipes	10%	

Solution:		15 year	20.15 year
1	Discharge at installation	5 MLD	7.5 MLD
2	Discharge at the end 15 years	7.5 MLD	10.0 MLD
3	Average discharge	6.25 MLD	8.75 MLD
4	Volume of pumping for discharge at the end of 15 years	10	23
5	Average head of pumping for average discharge	$(25 + 5) \div 2 = 15$	$(25 + 10) \div 2 = 17.5$

6. KW required at 90% combined efficiency of pumping set

$$\frac{10 \times 10^6 \times H \times 100 \times 24}{90 \times 60 \times 21 \times 102 \times 60 \times 21} = \text{KW} \quad \frac{20 \times 10^6 \times H \times 100 \times 24}{90 \times 60 \times 24 \times 102 \times 60 \times 21} = \text{KW}$$

$$14811 = \text{KW} \quad 19721 = \text{KW}$$

$$K^* = 1000(1 - 0.2)^{15} = 4102 \times 10^3 = 41.02 \text{ N}$$

Where,

Q = Discharge at the end of 15 years (m³/s)

L = Life of the structure for discharge = life span of 15 years

r = Annualised discounting of pumping cost

N = Total sum pumping cost discharge at the end of 15 years

- c. Annual cost in terms of electrical energy of the 1 per unit 30 KW energy for pumping = average discharge per year = 100

$$N \text{ kWh} = 12 \times 10^3 \times 100 \times 24 \times 10^3$$

$$= 28.8 \text{ kWh}$$

$$\text{KW h} = 20 \times 10^3 \times 100 \times 24 \times 10^3$$

$$= 48 \text{ kWh/KWh}$$

- f. Pump Cost Capitalised

$$C = P_0 + P_1 e^{-rt}$$

$$C = C_0 (1 + e^{-rt})$$

Where,

P_0 = Present (28%) cost of pumping cost

P_1 = Annual cost after 15 years (100) = 20000 per year (the second stage pumping cost)

r = Rate of interest sum in interest

$$= 10\% \text{ per year}$$

t = No. of years = 15

$$C = 28000 + 20000 e^{-0.15} = 41020$$

- g. Energy Charges Capitalised

$$C = C_0 (1 + e^{-rt}) / r$$

For rates $r = 10\%$ and $t = 15$

$$C = 20000 / 0.1$$

$$= 200000 \text{ (1st stage)} = 200000 \text{ (2nd stage)} = 400000$$

$$C = 200000 \text{ (1st stage)} = 200000 \text{ (2nd stage)}$$

Therefore, total energy charges = 400000 = 400000 (Energy capitalised cost)

$$C = 400000 (1st stage) = 400000$$

$$C = 400000 (2nd stage) = 400000$$

- h. Table 6.10 will show the calculation to arrive at the most economical pumping main size for the given data

TABLE I

TABLE SHOWING VELOCITY AND LOSS OF HEAD FOR DIFFERENT PIPE SIZE

No.	Pipe size, pipe	Velocity in pipe feet per second	Total head in feet for 1000 ft. pipe length	1" stage flow					2" stage flow			Total
				1" stage flow at MLD	2" stage flow at MLD	Friction loss	Other loss	1" stage flow	Friction loss	Other loss		
1	2	1.50	14.50	1.35	1.00	7	50.00	8	30	11	161.05	161.05 ft.
2	3	2.00	10.75	1.58	1.00	6	36.00	8	30	11	155.04	155.04 ft.
3	4	2.50	8.00	1.72	1.00	5	25.00	8	30	11	151.53	151.53 ft.
4	5	3.00	6.00	1.86	1.00	4	16.00	8	30	11	147.18	147.18 ft.
5	6	3.50	4.50	1.99	1.00	3	9.00	8	30	11	143.00	143.00 ft.
6	7	4.00	3.00	2.12	1.00	2	4.00	8	30	11	138.85	138.85 ft.
7	8	4.50	1.50	2.25	1.00	1	1.00	8	30	11	134.65	134.65 ft.
8	9	5.00	0.50	2.38	1.00	0	0.00	8	30	11	130.50	130.50 ft.
9	10	5.50	0.00	2.50	1.00	0	0.00	8	30	11	126.50	126.50 ft.

TABLE 1

TABLE 1. GROUNDWATER QUALITY MONITORING NETWORK ON STATE 400'S ROAD CORRIDOR, CLATSOP COUNTY, OREGON

Well ID	Well Type	Well Depth (ft)	Well Construction	Well Status	Well Location (Mile Post)	Water Quality Parameters		Monitoring Frequency	Notes
						Parameter	Frequency		
W1	Monitoring	10	3" PVC, 10' depth	Active	0.5	Temperature, pH, Specific Conductance	Quarterly	Baseline monitoring	
W2	Monitoring	15	4" PVC, 15' depth	Active	1.0	Temperature, pH, Specific Conductance, Nitrate	Quarterly	Baseline monitoring	
W3	Monitoring	20	4" PVC, 20' depth	Active	1.5	Temperature, pH, Specific Conductance, Nitrate	Quarterly	Baseline monitoring	
W4	Monitoring	25	4" PVC, 25' depth	Active	2.0	Temperature, pH, Specific Conductance, Nitrate	Quarterly	Baseline monitoring	
W5	Monitoring	30	4" PVC, 30' depth	Active	2.5	Temperature, pH, Specific Conductance, Nitrate	Quarterly	Baseline monitoring	
W6	Monitoring	35	4" PVC, 35' depth	Active	3.0	Temperature, pH, Specific Conductance, Nitrate	Quarterly	Baseline monitoring	
W7	Monitoring	40	4" PVC, 40' depth	Active	3.5	Temperature, pH, Specific Conductance, Nitrate	Quarterly	Baseline monitoring	
W8	Monitoring	45	4" PVC, 45' depth	Active	4.0	Temperature, pH, Specific Conductance, Nitrate	Quarterly	Baseline monitoring	
W9	Monitoring	50	4" PVC, 50' depth	Active	4.5	Temperature, pH, Specific Conductance, Nitrate	Quarterly	Baseline monitoring	
W10	Monitoring	55	4" PVC, 55' depth	Active	5.0	Temperature, pH, Specific Conductance, Nitrate	Quarterly	Baseline monitoring	
W11	Monitoring	60	4" PVC, 60' depth	Active	5.5	Temperature, pH, Specific Conductance, Nitrate	Quarterly	Baseline monitoring	
W12	Monitoring	65	4" PVC, 65' depth	Active	6.0	Temperature, pH, Specific Conductance, Nitrate	Quarterly	Baseline monitoring	
W13	Monitoring	70	4" PVC, 70' depth	Active	6.5	Temperature, pH, Specific Conductance, Nitrate	Quarterly	Baseline monitoring	
W14	Monitoring	75	4" PVC, 75' depth	Active	7.0	Temperature, pH, Specific Conductance, Nitrate	Quarterly	Baseline monitoring	
W15	Monitoring	80	4" PVC, 80' depth	Active	7.5	Temperature, pH, Specific Conductance, Nitrate	Quarterly	Baseline monitoring	
W16	Monitoring	85	4" PVC, 85' depth	Active	8.0	Temperature, pH, Specific Conductance, Nitrate	Quarterly	Baseline monitoring	
W17	Monitoring	90	4" PVC, 90' depth	Active	8.5	Temperature, pH, Specific Conductance, Nitrate	Quarterly	Baseline monitoring	
W18	Monitoring	95	4" PVC, 95' depth	Active	9.0	Temperature, pH, Specific Conductance, Nitrate	Quarterly	Baseline monitoring	
W19	Monitoring	100	4" PVC, 100' depth	Active	9.5	Temperature, pH, Specific Conductance, Nitrate	Quarterly	Baseline monitoring	
W20	Monitoring	105	4" PVC, 105' depth	Active	10.0	Temperature, pH, Specific Conductance, Nitrate	Quarterly	Baseline monitoring	

TABLE III

TABLE SHOWING COMPARATIVE STATEMENT OF OVERALL COST STRUCTURE OF PUMPING MAIN 'E' FOR DIFFERENT PIPE SIZE

S. No.	Pipe Size (mm)	Total No. of Joints	Class of Pipe	Rate per meter	Cost in Rs.	Material Cost of 1000 m				Labour Cost of 1000 m		Grand Total Cost of 1000 m
						Steel	Concrete	Brick	Other	1st	2nd	
1	150	10	1	1000	10000	1000	1000	1000	1000	1000	1000	10000
2	150	10	1	1000	10000	1000	1000	1000	1000	1000	1000	10000
3	150	10	1	1000	10000	1000	1000	1000	1000	1000	1000	10000
4	150	10	1	1000	10000	1000	1000	1000	1000	1000	1000	10000
5	150	10	1	1000	10000	1000	1000	1000	1000	1000	1000	10000
6	150	10	1	1000	10000	1000	1000	1000	1000	1000	1000	10000
7	150	10	1	1000	10000	1000	1000	1000	1000	1000	1000	10000

1. Cost of pipe

2. Cost of concrete

3. Cost of brick

4. Cost of other material

1. Labour cost of 1st class

2. Labour cost of 2nd class

3. Labour cost of 3rd class

4. Labour cost of 4th class

The above table shows the comparative statement of overall cost structure of pumping main 'E' for different pipe size. It is observed that the cost of pumping main 'E' is minimum for 150 mm pipe size and maximum for 300 mm pipe size. The reason for this is that the cost of pipe and concrete is more for 300 mm pipe size and less for 150 mm pipe size.

APPENDIX 6.6

DESIGNS OF THRUST BLOCKS

1. A ship is docked at 08-10 m depth on a water main consisting water at 11 kg/cm² pressure.

The density of water is 1000 kg/m³ and density of concrete is 2500 kg/m³. Soil density is assumed to be 1800 kg/m³ and angle of internal friction $\phi = 30^\circ$.

Assume that the coefficient of friction of steel on cast-iron is 0.1 for sandy soil.

HORIZONTAL THRUST $(F = 10 \text{ MN})$ per block

$$\text{Total horizontal force } F = 10 \text{ MN} \quad \text{Total weight } W = 100 \text{ tonnes}$$

$$\text{Safety factor} = 1.15$$

$$F = 11 \text{ MN} = 1104 \text{ kN} \quad \phi = 30^\circ \quad \mu = 0.1 \quad \text{Steel on cast iron}$$

$\phi = 30^\circ$ (maximum resistance to motion) for the soil on the thrust

$$\text{Total thrust on the thrust } = 1104 \text{ kN} \times 5.2 \text{ M} = 5.74 \text{ MN}$$

$$\text{Weight of thrust block } = 5.74 \text{ MN} \times 100 \text{ kN} = 57.4 \text{ MN} = 5740 \text{ tonnes}$$

$$\text{Weight of water in the pipe } = 0.785 \times 6 \text{ M}^2 \times 10 \text{ M} = 28.2 \text{ MN} = 2820 \text{ tonnes}$$

$$\text{Weight of earth } = 0.7 \times 0.7 \times 10 \text{ M} \times 1800 \text{ kg/m}^3 = 88.2 \text{ MN} = 8820 \text{ tonnes}$$

$$\text{Total weight } W = 8820 \text{ tonnes}$$

Total force available for resistance μW is given as

$$\text{Resistance of soil to motion } = 11.15 \text{ tonnes}$$

and lateral resistance of soil against the block

$$\mu = \frac{0.10}{1} = \frac{0.1}{1} = \frac{0.06 \times C}{1.0 \times C} = 20 \text{ MN} \left(\frac{1}{\sqrt{2}} + \frac{300 \text{ MN}}{300 \times 2} \right)$$

By assuming a base of $m = 6 \text{ m}$ for the thrust block

$$\text{Weight } = 8 \times \frac{6 \times 6}{2} = 144 \text{ MN} = \frac{6 \times 24}{0.3} = 88.47 \text{ tonnes}$$

- (ii) Lateral resistance of soil when the thrust block is free to yield away from the soil must be, by pattern of predicted eqn.,

$$R = (1.5) \left(\frac{1}{1} \right) \left(\frac{800}{800} \right) \left(\frac{200}{1} \right) \left(\frac{1}{1} \right) \left(\frac{800}{800} \right) \left(\frac{1}{1} \right)$$

$$= (1.5)(800) \left(\frac{1}{1} \right) \left(\frac{200}{1} \right) \left(\frac{1}{1} \right) \left(\frac{800}{800} \right) \left(\frac{1}{1} \right) = 241.15 \text{ tonnes}$$


∴ Lateral resistance = 241.15 = 88.4 = 113.16 tonnes/m²

∴ Lateral thrust = 53.48 tonnes


Factor of safety = 113.16/53.48 = 2.117 = 2.12 (OK)

REINFORCEMENT:

The minimum surface reinforcement of flat slabs shall be 5 kg/m² (IS: 456-1978 Article 306.4) to be provided in the form of 10 mm dia. bars spaced at 200 mm c/c which is more than 5 kg/m² (OK)



SECTION 1.1



PLAN

THRU SECTION OF HORIZONTAL BOND

APPENDIX 6 DESIGN OF AIR VESSEL

DATA

Flow rate through pipe (l/s)	$= 100 \text{ l/s}$
Maximum depth (m)	$= 2.5$
Pressure of rise (kPa)	$= 100 \text{ kPa}$
Factor of safety	$= 1.5$
Depth of water	$= 2.0 \text{ m}$
Factor of safety for air	$= 1.0$
Factor of safety for water	$= 1.5$
Average depth (m)	$= 1.50 \text{ m}$
Pressure of air (kPa)	$= 100 \text{ kPa}$
$H_1 = \text{water head} + \text{air head} + \text{friction loss}$	$= 1.52 \text{ m} + 0.5 \text{ m} + 0.05 \text{ m}$

Volume of air (m³)

$$= \frac{100}{1000} \times 1.52 \times 1.52 \times 1.52$$

Volume of water (m³) = 1.52 m³

$$\frac{1.52}{1.52} = \frac{1.52}{1.52} \quad \text{Both sides are same}$$

$$\frac{1}{1} = \frac{1}{1}$$

$$\frac{1}{1} = \frac{1}{1} \quad \frac{100}{1000} \times \frac{1.52}{1.52} \times \frac{1.52}{1.52} \times \frac{1.52}{1.52}$$

Water head (m) = 1.52

$$\frac{1.52}{1.52} = \frac{1.52}{1.52}$$

$$= \frac{1.52}{1.52} \times \frac{1.52}{1.52}$$

Volume (m³) = 1.52

$$\frac{1.52}{1.52}$$

$$= \frac{1.52 \times 1.52}{1.52}$$

$$= \frac{1.52 \times 1.52}{1.52}$$

$$= 1.52$$

AIR VESSEL PARAMETER = $2C_1 C_2 / Q_1 L$

Referring Chart E₂, k, as 0.50 for surging up surge to 1.20 H, and Downsurge to 0.5 H,
Air vessel parameter for $2\rho = 0.65$ is calculated as follows:

From chart for $2\rho = 1.00 \times (2C_1 C_2 / Q_1 L) = 0.50$

For $2\rho = 0.5$, $2C_1 C_2 / Q_1 L = 6.50$

By interpolation for $2\rho = 0.65$ and for $k = 0.5$

Air vessel parameter $2C_1 C_2 / Q_1 L = 7.30$

$$\text{Volume of air } C_1 = \frac{7.3 \times 1.244 \times 18130}{2 \times 896.27}$$

$$= 150.31 \text{ Cubic meters}$$

$$\text{Volume of Air Vessel} = C_1 (1 + 1.45)^{0.5} (1 - 0.5)^{1 - 0.5}$$

$$= 150.31 (1.45)^{0.5} (1 - 0.5)^{1 - 0.5}$$

$$= 150.31 \times (2)^{0.5}$$

$$= 267.20 \text{ Cum}$$

Increase the capacity by 20% to cater for surge of 1.2 H.

$$= 267.20 \times 1.2$$

$$= 320 \text{ Cum}$$

WATER COLUMN SEPERATION LENGTH

The water column separation is calculated on the basis of the following formula.

$$V_1^2 - V_2^2 = (2g/L) H (t_1 - t_2) - C (V_1 - V_2)$$

H = Static Head, (Absolute Head)

C = Loss of head due to friction

V_1, V_2 = Velocities at instances t_1 and t_2 .

$(t_1 - t_2)$ = Period between time intervals in seconds.

V_1 = Initial Velocity.

L = Length of pipeline

Initial velocity will come to rest over a time period after the stoppage of pump. Assuming a time interval of 0.20 seconds and by using above formula the subsequent velocities are calculated till the final velocity (V) is almost Zero. The water column separation length L is given by Law 5 -

$$\text{Law 5 } \Sigma [V_1 + V_2 + \dots + V_n] (t_1 - t_2)$$

For the given diameter of pipe and for the calculated water column separation length the volume of water required to be stored in Air vessel is calculated.

For Worked Example

$$(0.93)^2 - V_1^2 = 2 \times \frac{9.81}{18000} (0.20)(0.01) 145 = 5 \frac{(0.93)^2}{0.5}$$

$$(0.93)^2 - V_1^2 = 2 \times \frac{9.81}{18000} (0.20)(0.01) 145 = 11 \frac{(0.93)^2}{1.01}$$

Repeat a time with $V_1 = 0.01$ m/sec.

Then $V_1 (V_1) = V_1^2$ $V_1 = (0.20)$ = say 70.1 metres.

For a pipe of 1.55 per dia volume of water required to fill this separation length:

$$= \frac{\pi (1.55)^2 (0.19)}{4} = 11.5 \text{ Cum}$$

FIXING THE SIZE OF VESSEL AND LEVEL OF WATER AND AIR IN AIR VESSEL CHAMBER

(i) Air And Water Volume

Air Vessel volume required = 320 Cum.

If two vessels are provided volume of each vessel = 160 Cum

Provide 90 Cum of Air and 70 Cum of water in each vessel.

(ii) Determination Of Size Of Air Vessel

Absolute head at working head of pumps = $15' + 0.35 = 160.35$ metres

Maximum average pressure = $160.35 \times 1.2 = 192.42$ metres

Pressure = 19.25 kg/cm²

Using 25 mm thick M.S. Plate $t = 25 \text{ mm} + 5 \text{ mm}$ for corrosion allowance

$$d = \frac{2f \cdot p \cdot t}{\rho}$$

f = Permissible tensile strength in steel plates = 1260 kg/cm²

e = Weld efficiency say 0.9

t = Thickness in cms of plate = 2.2 cm

p = Pressure in kg/cm²

$$\frac{2 \times 1200 + 190 \times 2.26}{19.25}$$

$$= 279.20 \text{ cms}$$

$$= \text{Say } 280 \text{ cms}$$

Provide 2.61 meter dia of vessel with a length of 280 cms and two hemi spherical ends.

Volume of (two hemispheres) spherical portion = $1 \times \pi (1.3)^3 = 9.2 \text{ Cum}$

Total Volume of cylinder = $10 \times \pi \times 2.61 \times 280 = 59.80 \text{ cum}$

Length of vessel of 2.61 m dia with a length of 280 cms is = 28.40 meter

Provide 2 vessels each of 2.61 m dia and 28.40 m long with hemi spherical ends.

(iii) Fixing Of Levels Of Water And Air In The Vessel

The levels are fixed by trial by assuming a depth and calculating volume by cylindrical and spherical portions.

(a) Normal Working Level

Volume of Air = 90 cum

Volume of Water = 70 cum

The normal working level is fixed by trial by assuming 1.15 meter (1.15 m) depth from bottom. Volume of water = 70.95 cum which is more than required 70 Cum. Hence normal working level will be at 1.15 m from bottom of vessel.

(b) Upper Emergency Level

Air dissolves in water in the vessel. Assuming that 10% Air dissolves in water the level of water rises by 10% of volume of Air.

Volume of water = 70 Cum + 10% of 90 Cum = 79 Cum.

The depth of water from bottom will be 1.35 m which gives volume of water as 79 Cum. Hence upper emergency level will be 1.35 m from bottom of vessel.

(c) Lower Emergency Level

When pumps trip as per water column separation about 11.51 Cum of water is required to fill the pipeline. As calculated volume of water at a depth of 1.00 m from bottom of vessel = 56.43 Cum. Volume of water at normal working level is 73 Cum.

Quantity of water available is the difference between normal working level and lower emergency level.

APPENDIX 2.1
DESIGN OF SPRAY TYPE AERATOR
(Removal of Iron & Manganese)

I. PROBLEM STATEMENT:

Design a spray aerator given the following data:

1. Design flow = $200 \text{ m}^3/\text{hr}$.

 Weir used = 3 mm dia 18° class (1) 10° with a C value of 100.

$h = 1.0$ meters / 1000 meters

$V = 1.75 \text{ m}^3$

2. Iron present in raw water = 1.8 mg/l .

3. Saturation concentration of O_2 at $28^\circ\text{C} = 7.02 \text{ mg/l}$.

4. Air flow coefficient for the common laer, at $28^\circ\text{C} = 10 \text{ cm}^3/\text{hour}$.

II. DESIGN CRITERIA

1. Nozzle or nozzle hole 10 to 60 mm - spaced in the pipe at intervals of 0.1 to 1.0 m.
2. Nozzles are usually angled 3° to 5° to the vertical to avoid interference due to falling water.
3. Nozzle discharges should be uniform as far as possible. Variation in no case should be greater than 5% i.e. the discharge ratio between the first and the last nozzle, should not be less than 0.25% variation 2 to 5% may be allowed.
4. Velocity of water in the aerator pipe should be between 1 and 1.5 m/s.
5. Pressure required at the nozzle varies from 2 to 3 meter of water (usually 2m).
6. Discharge rates per nozzle vary from 300 to 600 l/hr.
7. Aerator area should be 1.25×10^3 to $5.75 \times 10^3 \text{ m}^2$ per m^3/day of design flow.

III. SOLUTION

1. Design flow = $200 \text{ m}^3/\text{hr}$ i.e.

2. Assuming 75 mm dia. nozzle with an inclination of 3° to the vertical, dia. of one drop is 25 mm.

3. Iron in source raw water = 1.8 mg/l .

 Permissible limit of iron in treated water = 0.1 mg/l .

 Iron to be removed = $(1.8 - 0.1) \text{ mg/l} = 1.7 \text{ mg/l}$.

4. $\text{Fe} + \text{SO}_4 = 2\text{Fe}_2(\text{O})_3$

 17 mg/l of Fe requires $1.7 \times 96/724 = 0.2286 \text{ mg/l}$ of O_2 .

5. By applying 'Gas absorption' equation no. 2.2.2 in (6.5) m

$$\log_{10} \left[\frac{(C_1 - C_2)(C_1 - C_0)}{(C_1 - C_0)(C_1 - C_2)} \right] = \frac{K A t}{V}$$

where

$$C_1 = 7.92 \text{ mg/l at } 28^\circ\text{C}, \quad C_2 = 11.0 \text{ mg/l}$$

$$C_0 = 0.75 \text{ mg/l}, \quad K = 70 \text{ cm}^2/\text{hr}$$

$$A = \frac{\pi}{4} \times \frac{6^2}{25} \left(\frac{\text{cm}^2}{\text{hr}} \right)$$

$$\therefore \log_{10} \frac{7.92}{7.19} = \frac{70}{60 \times 60} \times \frac{\pi}{4} \times \frac{6^2}{25} \times t = \frac{7}{150} t$$

$$\therefore t = \frac{150}{7} \times \log_{10} \frac{7.92}{7.19}$$

$$t = \frac{150}{7} \times 0.042$$

$$t = 0.9 \text{ seconds}$$

say $t = 1$ second & small case

$$t_1 = \text{time of rise} = t/2 = 0.5 \text{ seconds}$$

$V =$ nozzle velocity and $\alpha =$ inclination to horizontal.

$$V \sin \alpha = g t_1$$

$$V = \frac{g t_1}{\sin \alpha}$$

$$= \frac{980 \times 0.5}{\sin 91.3^\circ}$$

$$= \frac{980 \times 0.5}{\sin 87^\circ}$$

$$= 4.91 \text{ cm/s}$$

6. Number of nozzles

Assuming

$N =$ No. of nozzles required

$q =$ Discharge through each nozzle $= C_d \times V \times a$

where,

$C_d =$ Coefficient of discharge $= 0.9$ (assuming)

$V =$ nozzle velocity $= 4.91 \text{ mps}$

$a =$ nozzle area $= (\pi/4) d^2$

$d =$ dia of nozzle $= 25 \text{ mm}$

$$\therefore \text{Discharge through "N" number nozzles} = N \times C_d \times V \times \pi$$

$$= N \times 0.9 \times 0.91 \times (3.14/4) \times [25 \times 10^{-3}]^2 \text{ m}^3/\text{sec}$$

But design flow i.e. discharge through N nozzles = 6000 m³/day

$$N \times 0.9 \times 0.91 \times (3.14/4) \times [25 \times 10^{-3}]^2 \times 60 \times 60 \times 24 = 6000 \text{ m}^3/\text{day}$$

$$\therefore N = 32$$

\therefore Nozzles required = 32 Nos of 25 mm dia each

7. Spacing of Aerator Pipes

$$\text{Radius of spray} = V \cos \alpha \times 2t = 4.91 \cos 87^\circ \times 2 \times 0.5 = 0.257 \text{ m}$$

Assuming wind velocity = 8 km/hr.

$$\text{Wind Drag} = C_d \times V_w \times t \text{ (assuming } C_d = 0.6)$$

$$= 0.6 \times (8 \times 10^3) \times (60 \times 60) \text{ s} = 1.33 \text{ m}$$


\therefore Minimum spacing required = Radius of spray + Wind drag

$$= 0.257 + 1.33$$

$$= 1.587 \text{ m} \quad \text{say } 2 \text{ m apart}$$

8. Arrangement of nozzles

Nozzles are fixed on 4 rows of pipes as shown below;



$$\text{Nos. of nozzles in each pipe} = 32/4 = 8$$

Providing a spacing of 0.5 m b/w of nozzles and spacing in two adjacent rows and at staggered position

Provide 4 pipes each of length 5m and spacing of 2m

Allowing 2m space on all the sides, the size of the aeration tray will be 8m x 6m.

Checking

Aeration pipes provide an area of $2 \times (\pi \times 2) = 12.57 \text{ m}^2$

∴ Area provided per m³ day of design flow = $12.57 / (15 \times 24) = 2.05 \times 10^{-2} \text{ m}^2/\text{m}^3/\text{day}$ of design flow

∴ OK, since it is between 1.75×10^{-2} to $3.75 \times 10^{-2} \text{ m}^2/\text{m}^3/\text{day}$ of design flow.

9. Uniformity in distribution

The uniformity in distribution of water is maintained by arrangement of aeration pipes as in figure above

Discharge through each pipe = $(25 \times 27) / 4 = 1500 \text{ m}^3/\text{d}$

Assuming $h_f =$ head loss at each nozzle

$$V = C_d \sqrt{2gh} = 4.91 \text{ m/s}$$

$$h = (4.91)^2 / (2 \times 9.81) = 1.22 \text{ m (Assuming } C_d = 0.9)$$

Assuming variation of head = 2%

$$m = \frac{\text{discharge through last nozzle in the pipe}}{\text{discharge through first nozzle in the pipe}} = 0.98$$

$$h = h_1 (1 - m)^2 = 1.52(1 - 0.98)^2 = 0.06 \text{ m}$$

Head loss in the pipe for gradually decreasing flow = $h_1 = 0.06 \text{ m}$

∴ Corresponding head loss for uniform flow = $h_2 = 511 \times 0.06$

= 0.18 m (per aeration pipe length)

∴ Head loss / 7000 m = $(0.18 / 1.5) \times 10^3 \text{ m} = 120$

10. Design of pipes and head losses:

The arrangement of pipe is shown in figure. The aeration pipes are so chosen that the velocity remains within 1 to 1.5 mps and corresponding head losses for pipes (4.1) are calculated and are shown in the following table:

Pipe Section	Design Flow (m ³ /s)	Length (m)	Dia (mm)	Velocity (m/sec)	Head Losses	Total Head
						(m)
1	2	5	4	5	6	7
AB	30.4	25	200	1.1	0.01	0.025
BC	30.4	20	200	1.1	0.01	0.020
C ₁ C ₂	15.2	30	125	1.42	0.05	0.095
CD	15.2	20	125	1.43	0.03	0.062
D ₁ D ₂	15.2	30	125	1.42	0.03	0.090
					Total	0.285

Total head loss = 0.285 + 15% for valve and specials
= 0.314 m

sags = 0.32 m

Head available = Terminal head - Total Head loss
= 1.52 - 0.32
= 1.84 m

APPENDIX 7.2

DESIGN OF MECHANICAL RAPID MIX UNIT

1. PROBLEM STATEMENT

Design a mechanical rapid mix unit using following data:

- | | |
|--|---|
| 1. Design flow to be treated | = 250 m ³ /hr |
| 2. Detention time | = 30 secs (20/60 S) |
| 3. Ratio of tank height to diameter | = 1.5 (1/3/2) |
| 4. Ratio of impeller diameter to tank diameter | = 0.4 (1/2 = 0.4) |
| 5. Rotational speed of impeller | = 120 rpm (>100 rpm) |
| 6. Velocity gradient | = 60 S ⁻¹ (>30 S ⁻¹) |
| 7. Assume temperature of 20°C. | |

2. SOLUTION

(i) Determine dimensions of tank

$$\begin{aligned} \text{Volume} &= \text{Flow} \times \text{detention time} \\ &= 250 \times (30/3600) = 2.083 \text{ m}^3 \end{aligned}$$

$$\text{Diameter of the tank, } D, \text{ is calculated from } (\pi/4) D^2 (1/3) = 2.083$$

$$\text{Therefore, diameter of tank} = 1.20 \text{ m}$$

$$\text{and height of tank} = 1.80 \text{ m}$$

$$\text{Total height of the tank} = 2 \text{ m which will provide a free board of 0.2 m}$$

(ii) Compute power requirements

$$\begin{aligned} \text{Power spent, } P &= \rho G^3 (\text{Volume of tank}) \\ &= 1000 \times (60)^3 \times 2.083 = 756 \text{ watts} \end{aligned}$$

$$\begin{aligned} \text{Power per unit volume} &= 756/2.083 = 362.94 \\ &= \text{Say } 363 \text{ watts/m}^3 \end{aligned}$$

$$\text{Power per unit flow of water} = 756/250 = 3.02 \text{ watts/m}^3/\text{hr of flow}$$

Determine dimensions of flat blades and impeller

$$\begin{aligned} \text{Diameter of impeller} &= 0.4 \times \text{tank diameter} \\ &= 0.4 \times 1.2 = 0.48 \text{ m} \end{aligned}$$

$$\begin{aligned} \text{Velocity of the tip of impeller} &= (2\pi \times r \times n) \text{ m/s} \\ &= (2\pi \times 0.48/2) \times (120/60) \text{ m/s} \end{aligned}$$

QUESTION 10

Consider the vector field \mathbf{F} of magnitude $\|\mathbf{F}\| = 1$ and direction

$$\text{direction} = \frac{1}{\sqrt{2}}(2\mathbf{i} + \mathbf{j}).$$

Let \mathcal{C} be the curve consisting of the line $x = 1$ for $0 \leq y \leq 1$ and the quarter circle $x^2 + y^2 = 1$ in the first quadrant, the region D is shaded in the figure below.

$$\mathbf{F} = \frac{1}{\sqrt{2}}(2\mathbf{i} + \mathbf{j}) \text{ with } \text{direction} = \frac{1}{\sqrt{2}}(2\mathbf{i} + \mathbf{j})$$

$$\|\mathbf{F}\| = 1$$

the vector field \mathbf{F} is $\frac{1}{\sqrt{2}}(2\mathbf{i} + \mathbf{j})$

Let the solid \mathcal{V} be the solid bounded by \mathcal{C} and the coordinate planes. Then the mass of \mathcal{V} is $\frac{1}{2}$ and the mass of \mathcal{V} is $\frac{1}{2}$ and the mass of \mathcal{V} is $\frac{1}{2}$.

Let \mathcal{V} be the solid and the region D is shaded in the figure below.

APPENDIX 7.2 DESIGN OF A BIOFLOCCULATOR

I. DATA ESTABLISHMENT

The given flow rate is $Q = 1000 \text{ m}^3/\text{day}$ and the effluent is

1. Dissolved oxygen surface concentration $C_{\text{DO}} = 750 \text{ mg/l}$, $C_{\text{DO}}^* = 900 \text{ mg/l}$
2. Water depth $H = 2 \text{ m}$
3. Diffusion coefficient $D = 2.250 \times 10^{-6} \text{ m}^2/\text{sec} = 2 \text{ m}^2/\text{hr}$
4. Desorption period $t = 2 \text{ hr}$
5. Average velocity of air flow $v = 3 \text{ m/s}$

II. CONSIDERATIONS TO BE FOLLOWED

In general, the flocculator is made up of long vertical paddles. The water enters through a central influent pipe and is fed into the flocculation zone through the top parts. The influent from flocculation zone passes below the paddles and leaving the flocculation zone enters the clarifier portion. The central effluent is collected by a peripheral effluent band. The components of clarifier unit to be designed include the influent pipe, the flocculation tank, clarifier and the effluent tank.

III. DESIGN OF FLOCCULATION

Assuming a velocity of 3 m/s

$$\text{Influent pipe diameter} = \sqrt{\frac{2500}{\pi \times 3.6} \times 4} = 26.5 \text{ cm}$$

Assuming an effluent pipe of 30 cm diameter.

IV. DESIGN OF CLARIFIER

1. Clarifier area: $\text{Area} = \frac{Q}{v} = \frac{1000}{3.6} = 278 \text{ m}^2$

2. Area of settling tank $A = 2.0 \times 10^{-4} \times 10^6 \text{ m}^2$ flocculation

3. Area of clarifier tank $= (278) \times (2.2) = 613.6 \text{ m}^2$

Provided a water depth of 2.5 m

4. Diameter of flocculation $= \sqrt{\frac{613.6}{\pi}} = 39.5 \text{ m}$

Let us take the diameter of influent pipe as 30 cm diameter of the effluent pipe. Then

$$\frac{3}{4} \left(\frac{30}{100} \right)^2 \times \pi = \frac{3}{4} \left(\frac{D}{100} \right)^2 \times \pi = 1$$

$D = 20.1 \text{ cm}$

Provide a tank diameter of 6.6 m.

V. DIMENSIONS OF PADDLES

Total power input to flocculator, $P = C_D \rho A_p V^3$

$$(40)^3 \times [0.89 \times 10^{-3}] \times [\pi \times (6.6)^2 \times 2.5 \times 4] = 122 \text{ watts}$$

$$\text{Power input} = (1/2) C_D \rho A_p (V^3 - v^3)$$

Where

C_D = Newtons coefficient of drag, 1.8

ρ = Density of water at 25°C, 997 kg/m³

V = Velocity of the tip of blades

$$= 0.4 \text{ m/s (recommended range } 0.3 \text{ to } 0.5 \text{ m/s)}$$

v = Velocity of water at tip of blades

$$= 1.25 \times 10^{-3} (25^2 \times 0.3)$$

$$= 0.1 \text{ m/s.}$$

$$122 = 1.8 \times 997 \times A_p (0.4 - 0.1)^3 / 2$$

$$A_p = 5.04 \text{ m}^2$$

Ratio of area of paddles to cross-sectional area of flocculator

$$= A_p / (\pi (D_p - D_s) \times h)$$

$$= (5.04) / (\pi (6.6 - 0.3) \times 2.5) = 1.16\% \text{ or } 19.2\%$$

This is acceptable as it is within the limits of 10 to 25%.

Provide 8 Nos. of paddles of height 2.5 m and width of 0.32 m

Two shafts will support eight paddles, each shaft supporting 4 paddles. The shaft will be at a distance of $(6.6 - 0.3) / 4 = 1.58 \text{ m}$ from the centre line of circular flocculator. The paddles will rotate at a rpm of 4.

Distance of paddle edge, r , from the centre line of vertical shaft is given by the equation.

$$V = (2 \pi r n) / 60$$

$$0.4 = (2 \pi r \times 4) / 60$$

$$\therefore r = 1 \text{ m}$$

Let the velocity of water below the partition wall between the flocculator and clarifier be 0.3 m / minute. Therefore area of opening required for a velocity 0.3 m/min below the partition wall will be

$$\text{Area} = 250 \times (0.3 \times 60) = 4500 \text{ m}^2$$

and it follows that $\frac{dQ}{dt} = 0$

$$0 = 1000 \frac{dV}{dt} - 1000 \bar{V}$$

Therefore, $\frac{dV}{dt} = \bar{V}$ and this is the formula of a hedge in case the mathematical scrap is not to be used.

For the given data the hedge strategy is $1000 \bar{V} = 2.5 \times 10^6 \text{ m}^3 \text{ day}^{-1} = 63 \text{ m}^3 \text{ s}^{-1}$

Therefore, the hedge is $63 \text{ m}^3 \text{ s}^{-1}$.

The hedge is a hedge in the sense that it is a hedge in the sense of the hedge.

Therefore, the hedge is a hedge in the sense of the hedge.

VI. THE HEDGE STRATEGY

A hedge is a hedge in the sense of the hedge.

Therefore, the hedge is a hedge in the sense of the hedge.

Therefore, the hedge is a hedge in the sense of the hedge.

$$\frac{dQ}{dt} = \frac{dQ}{dt} = 1000 \bar{V} = 1000 \bar{V}$$

Therefore, the hedge is a hedge in the sense of the hedge.

Therefore, the hedge is a hedge in the sense of the hedge. The hedge is a hedge in the sense of the hedge. The hedge is a hedge in the sense of the hedge.

APPENDIX 7.4

DESIGN OF RECTANGULAR PLAIN SEDIMENTATION TANK

4. PROBLEM STATEMENT

Design a rectangular sedimentation tank with the following data

1. Design Average Influent Suspended Solids Concentration tank = 150 mg/litre
2. Water lost in washwater = 2%
3. Design Average flow = $(25 \times 10^6 \text{ l/d}) \times (1.5)$
= 375 MGD/d
4. Minimum size of the particle to be removed = 0.02 mm
5. Required removal efficiency of suspended particle = 95%
6. Name of particle = sand, silt and clay
7. Specific gravity of particles = 2.65
8. Assumed performance of the settling tank = good (7-10)
9. Kinematic viscosity of water at 20°C = $1.01 \times 10^{-6} \text{ m}^2/\text{s}$

10. DESIGN PROCEDURE

From the given diameter and specific gravity of minimum size particle to be removed in settling tank, actual settling velocity of the particle is calculated with the help of Stokes law. The computed settling velocity is used to determine Reynolds number to check whether Stokes law is applicable. If Reynolds number is less than 1, Stokes law can be used to determine the settling velocity of particles. The settling velocity thus calculated is multiplied by given removal efficiency to give the required removal efficiency of the incoming particles and assumed performance of the settling tank, determine the surface area of the tank to design. The flow may be assumed to be case of uniform flow in down flow. The plan area is determined based on flow velocity determined. The required tank may be determined using dimensions given. Storage capacity may be determined with the help of design criteria as given here.

10. DESIGN STEPS

1. Compute velocity of the gravity of the minimum size particles

$$v_s = g(\rho_s - \rho_f) d^2 / 18 \mu$$
$$= 9.81(2.65(10^{-3}) - 10^{-3}) / (18 \times 1.01 \times 10^{-6})$$
$$= 1.06 \times 10^{-2} \text{ m/s}$$
$$\text{Reynolds number} = (v_s d) / \nu$$

$$= 3.56 \times 10^4 \times (0.02 \times 10^3) / (1.8 \times 10^6)$$

$$= 704 \times 10^{-3} \text{ s}^{-1}$$

Hence Stoke's law is applicable and computed settling velocity is correct.

3. DETERMINE SURFACE OVERFLOW RATE:

For ideal settling basin and complete removal of minimum size particles, equate settling velocity to theoretical surface overflow rate for 100% removal.

$$V_s = V_o$$

$$V_s = 3.56 \times 10^{-3} \text{ m/s}$$

$$3.56 \times 10^{-3} \times 3600 \times 24 = 30.76 \text{ m/d}$$

However due to short circuiting, there is reduction in efficiency and decrease in surface overflow rate. To obtain design surface overflow rate, which would give expected removal efficiency of minimum size particles in real basin, use following relationship.

$$x/y = 1 - (1 - u)(V_s / (Q/A))^{0.5} \quad (1)$$

For $x/y = 1 - 0.75$, $u = 1.4$ (good performance of tank)

$$V_s / (Q/A) = 1 / (u) \{ [1 - y/x] / [1 - (1 - u)] \}$$

$$= 4 \times \{ [1 - 0.75]^{0.5} / [1 - 0.75] \} = 3.61$$

Hence Design Surface overflow rate at average design flow, (Q/A) is

$$Q/A = (V_s / 3.61) = 30.76 / 3.61 = 16.7 \text{ m}^3/\text{m}^2/\text{d}$$

Typical values for design surface overflow rate range between 15 and 30 $\text{m}^3/\text{m}^2/\text{d}$ for plain sedimentation tanks.

4. CALCULATE DIMENSIONS OF TANK

$$\text{Surface area of tank, } A = Q / (Q/A)$$

$$= 255.1 \text{ (m}^3/\text{hr)} \times 24 = 6122.4$$

$$= 330.4 \text{ m}^2$$

Assume length to width ratio as 4

Length \times width = surface area

$$\text{Width, } B = \sqrt{(330.4/4)} = 9.09$$

$$\text{Length of tank, } L = 36.36 \text{ m}$$

Assume detention period, t , as 4 hrs.

$$\text{Water depth of settling zone at average flow} = Q \times t / A$$

$$= 255.1 \times 4 / (36.36 \times 9.09) = 3.09 \text{ m}$$

4. CHECK AGAINST RESUSPENSION OF DEPOSITED PARTICLES

Flow velocity due to scouring is dependent on depth of solids in the sledge zone. It is given by

$$V = \sqrt{(0.88 + 7.02V_s^2) + (2d)}$$

For an average particle size $d = 0.075$ and

Washback velocity $V_s = 0.03$ (from 4.1)

$$V = \sqrt{\left[0.88 + \frac{7.02(0.03)^2}{1} + (2 \times 0.075)\right]} \\ = 1.02 \times 10^{-1} \text{ m/s}$$

To avoid resuspension, the critical limiting velocity of solids should be less than or equal to horizontal velocity of flow. In this case, it will be less than critical displacement velocity. Horizontal velocity of flow at sledge zone is given by V

$$V = \frac{Q}{(B \times D)}$$

$$= \frac{355 \text{ l/s}}{(0.75 \times 2.25)} = 212 \text{ m/s} = 0.212 \times 10^{-1} \text{ m/s} > 1.02 \times 10^{-1} \text{ m/s}$$

(OK)

5. EFFLUENT STRUCTURE

The effluent structure is defined as structure to be located at the bottom of the tank and suspended solids conforming to the minimum design velocity of settling basin and removal deposits of suspended solids in various channels. It may consist of a central channel, submerged outlet and baffles to form a siphon.

Provide 100 mm wide and 100 mm deep outlet channel in the centre of the tank. Provide 4 submerged outlets 100 mm x 100 mm. Be made of all of them to ensure that they distribute the flow uniformly into the basin. A duct of 200 mm deep is provided at a distance of 1 m away from outlets to reduce turbulence.

$$\text{Velocity of flow in channel} = \frac{Q}{(B \times D)} = \frac{355}{(0.75 \times 2.25)} = 212 \text{ m/s}$$

at average design flow

$$\text{(Assuming a depth of flow of 0.1 m)} = 21.2 \text{ m/s}$$

Head loss through baffles

$$= \left[\frac{K V^2}{2g} + 10 \left(\frac{V}{21} \right)^2 + 0.81 \right] \times 0.1 \text{ m}$$

6. EFFLUENT STRUCTURE

The components of effluent structure are effluent weir, effluent siphon, outlet of flow and in outlet pipe

(a) Compute weir length & number of Weirs. Weir

outflow from sedimentation tank = 250 m³/hr

Assuming a weir loading of 200 m³/d per m length of weir

With respect to the first two points:

1) As the β increases, the number of points increases, and the

$$n \rightarrow \infty \text{ as } \beta \rightarrow \infty$$

2) The variance of the logarithm of the number of points is $\frac{1}{\beta}$. The variance of the logarithm of the number of points is $\frac{1}{\beta}$. The variance of the logarithm of the number of points is $\frac{1}{\beta}$.

$$\sigma^2 = \frac{1}{\beta} \text{ as } \beta \rightarrow \infty$$

$$\sigma^2 = \frac{1}{\beta} \text{ as } \beta \rightarrow \infty$$

3) As the β increases, the number of points

$$n \rightarrow \infty \text{ as } \beta \rightarrow \infty$$

4) The variance of the logarithm of the number of points

$$\sigma^2 = \frac{1}{\beta}$$

As the β increases, the number of points increases, and the variance of the logarithm of the number of points is $\frac{1}{\beta}$.

ANSWERS

PART A: MULTIPLE CHOICE QUESTIONS

1. MULTIPLE CHOICE

The price elasticity of demand curve is -0.5 because the price is below the unit

- | | |
|---------------------------------|---------------------------------|
| a. -0.5 (perfectly inelastic) | c. 0.5 (perfectly elastic) |
| b. -1 (unit elastic) | d. 1 |
| e. 1 (perfectly inelastic) | f. -1 (perfectly elastic) |
| g. -1 (unit elastic) | h. 0.5 (perfectly elastic) |
| i. 0.5 (perfectly inelastic) | j. 1 |
| k. -0.5 (perfectly elastic) | m. -0.5 (perfectly elastic) |
| n. -0.5 (perfectly inelastic) | o. 1 |
| p. -0.5 (perfectly elastic) | q. -0.5 (perfectly inelastic) |
| r. -0.5 (perfectly inelastic) | s. -0.5 (perfectly elastic) |

2. MULTIPLE CHOICE (MULTIPLE)

Which of the following is false?

- a. $Q = 100 - 2P$, $P = 20$ → $Q = 60$
 Elasticity = $\frac{20}{60} = \frac{1}{3}$ → Q is elastic
 b. $Q = 100 - 2P$, $P = 20$ → $Q = 60$
 Elasticity = $\frac{20}{60} = \frac{1}{3}$ → Q is inelastic
 c. $Q = 100 - 2P$, $P = 20$ → $Q = 60$
 Elasticity = $\frac{20}{60} = \frac{1}{3}$ → Q is unit elastic
 d. $Q = 100 - 2P$, $P = 20$ → $Q = 60$
 Elasticity = $\frac{20}{60} = \frac{1}{3}$ → Q is perfectly elastic
 e. $Q = 100 - 2P$, $P = 20$ → $Q = 60$
 Elasticity = $\frac{20}{60} = \frac{1}{3}$ → Q is perfectly inelastic

3. MULTIPLE CHOICE (MULTIPLE) (SHORT ANSWER)

Which of the following is false? (Circle the correct answer)

- a. $Q = 100 - 2P$, $P = 20$ → $Q = 60$
 Elasticity = $\frac{20}{60} = \frac{1}{3}$ → Q is elastic
 b. $Q = 100 - 2P$, $P = 20$ → $Q = 60$
 Elasticity = $\frac{20}{60} = \frac{1}{3}$ → Q is inelastic
 c. $Q = 100 - 2P$, $P = 20$ → $Q = 60$
 Elasticity = $\frac{20}{60} = \frac{1}{3}$ → Q is unit elastic
 d. $Q = 100 - 2P$, $P = 20$ → $Q = 60$
 Elasticity = $\frac{20}{60} = \frac{1}{3}$ → Q is perfectly elastic
 e. $Q = 100 - 2P$, $P = 20$ → $Q = 60$
 Elasticity = $\frac{20}{60} = \frac{1}{3}$ → Q is perfectly inelastic
 f. $Q = 100 - 2P$, $P = 20$ → $Q = 60$
 Elasticity = $\frac{20}{60} = \frac{1}{3}$ → Q is perfectly elastic
 g. $Q = 100 - 2P$, $P = 20$ → $Q = 60$
 Elasticity = $\frac{20}{60} = \frac{1}{3}$ → Q is perfectly inelastic

4. MULTIPLE CHOICE (MULTIPLE) (SHORT ANSWER)

Which of the following is false?

$$= 255.1 \times 24 / 33.49 = 182.8 \text{ m}^3$$

Hence diameter of tank = 15.26 m

Assume detention period, t_d of 2.5 hours as given in Table

Depth of tank = $Q \times t / A = 255.1 \times 2.5 / 182.8 = 3.49 \text{ m}$ say 3.5 m

4. CHECK FOR WEIR LOADING

Weir length = periphery of the tank = $\pi D = \pi \times 15.25 = 47.94 \text{ m}$

Weir loading = $255.1 \times 24 / 47.94 = 127.7 \text{ m}^3 / \text{d} \cdot \text{m} < 300 \text{ m}^3 / \text{d} / \text{m}$

Hence O.K.

APPENDIX 7.6 DESIGN FOR TUBE SETTLERS

1. PROBLEM STATEMENT

Design tube settler module of square cross section with following data

1. Average output required from tube settler = 250 m³/hr
2. Loss of water in desludging = 2% of output required
3. Average design flow = $(250 \times 100) / (100 - 2) = 255.1 \text{ m}^3/\text{hr}$
4. Cross section of square tubes = 50 mm x 50mm
5. Length of tubes = 1 m
6. Angle of inclination of tubes = 60°

2. DESIGN STEPS

1. Compute relative length of settler

$$L_r = 1.60 / 50 = 32$$

Effective relative length of tube, L_e

$$\begin{aligned} L_e &= L_r - 0.58 N_F \\ &= L_r - 0.58 \times V_d / v \\ &= 20 - (0.58 \times V_d \times 0.05) / (1.01 \times 10^{-3} \times 3600) \\ &= 20 - 0.33 V_d \end{aligned}$$

where V_d is flow through velocity for tube settler in m/d

3. DETERMINE FLOW VELOCITY THROUGH TUBES

$$\begin{aligned} S &= V_d / V \times (\sin \theta + L \cos \theta) \\ 1/8 &= (1.20 / V) \times (\sin 60 + (20 - 0.33 V) \cos 60) \\ V &= 368.65 \text{ m/d} \end{aligned}$$

4. COMPUTE TOTAL TUBE ENTRANCE AREA AND NO. OF TUBES

$$\text{Tube entrance area} = Q / V_d = 255.1 \times 24 / 368.65 = 15.75 \text{ m}^2$$

$$\text{No. of tubes required} = 15.75 / (0.05 \times 0.05) = 6300$$

Provide 6400 square tubes of 0.05 m x 0.05 with 80 tubes along the length of the square module and 80 tubes along the width of the module

$$\begin{aligned} \text{Length of the tube module} &= \text{No. of tubes} \times (\text{inside dimension of square tubes} + 2 \times \text{thickness of tubes}) \\ &= 80 \times (0.05 + 2 \times 0.005) \text{ m} \end{aligned}$$

74 m

Height of tube needed for 1 m length of square tubes inclined at an angle of 60°

$$1 \sin 60^\circ = 0.866 \text{ m} \quad \text{say } 0.87 \text{ m}$$

Height of vertical dimension of tube bundle = $4.24 \text{ m} \times 0.87 \text{ m} \times 0.87 \text{ m}$

Size of metal in square tubes = $0.05 \text{ m} \times 0.05 \text{ m}$

Thickness of individual square tubes = 1.5 mm

APPENDIX 7.7 DESIGN FOR RAPID GRAVITY FILTER

1. PROBLEM STATEMENT

Design rapid gravity filter for producing a rate of filtered water flow of $20 \text{ m}^3/\text{hr}$. The relevant data is

- (i) Quantity of backwash water used = 5% of filtered water
- (ii) Time lost during backwashing = 10 minutes
- (iii) Design rate of filtration = $3 \text{ m}^3/\text{hr}/\text{m}^2$
- (iv) Length to width ratio = 1.25 : 1
- (v) Under drainage system = General manifold with laterals
- (vi) Size of perforations = 2 mm

2. SOLUTION

(a) Filter Dimensions

- Required flow of filtered water = $20 \text{ m}^3/\text{hr}$
- Design flow for filter after accounting for backwash water and time lost in backwashing = $(20 \times 1.1) \times 24 / 23.5 \text{ m}^3/\text{hr}$
- plan area of filter required = $28.5 \text{ m}^2 = 52.6 \text{ m}^2$

Provide two filter units, two being minimum to be provided.

- Length \times width = 28.5 m^2
- Assume length to width ratio as 1.25 : 1
- Width of the filter = $(28.5 / 1.3)^{1/2} = 4.69 \text{ m}$
- Length of the filter = 5.88 m

Provide two filter units, each with a dimension of $5.88 \times 4.69 \text{ m}$.

(b) Estimation Of Sand Depth

Assume a depth of sand as 60 cm and effective size of sand as 0.5 mm

The depth can be checked against break through at flow through sand bed by calculating maximum depth required by Hazen formula

$$\ln \text{FPS unit } (Qd^2/n)/L = B \times 2982^2$$

Where Q is the rate of filtration in gpm/sq ft, d is the sand size in cm, L is the rounded loss of head in ft, B is the depth of bed in inches and n is a breakthrough index whose value ranges between 4×10^{-4} to 6×10^{-5} depending on response to coagulants and degree of pre-treatment of filter influent.

In metric units $(Qd^3h/A) + B \times 29323$

Where Q is in $m^3/m^2/h$, d in mm , and h & A are in m .

Assume $B = 4 \times 10^4$ for poor response to filtration and average degree of pre-treatment, terminal head loss of 2.5 m, rate of filtration = $5 \times 2 = 10 m^3/m^2/hr$. (Assuming 100% overloading of filter under emergencies), and assuming $d = 0.6 mm$ as mean diameter,

$$10 \times (0.6)^3 \times 2.5 / 1 = 4 \times 10^4 \times 29323$$

Minimum depth of sand required to avoid breakthrough = 46 cm. Hence the assumed depth of 60 cm to be adequate to avoid break through of flow.

(c) Estimation Of Gravel And Size Gradation

Assume a size gradation of 2mm at top to 50mm at the bottom. The requisite depth l in inches of a component gravel layer of size d in inches can be computed from empirical formula

$$l = k(\log d + 1.40)$$

Where k varies from 10 to 14. The equivalent formula in metric units where l is in cm and d is in mm is

$$l = 2.54 k(\log d)$$

For $k=12$, the depth of various layers of gravel are

Size, mm	2	5	10	20	40
Depth, cm	9.2	21.3	30.5	40	49
Increment, cm	9.2	12.1	9.2	9.5	9

Provide a gravel depth of 50 cm

(d) Design Of Under Drainage System

$$\text{Plan area of each filter} = 5.85 \times 4.50 = 26.53 m^2$$

$$\text{Total area of perforations} = 3 \times 10^3 \times \text{Area of filter}$$

$$= 0.0789 m^2$$

$$= 790 cm^2$$

$$\text{Total number of perforation of } 9 \text{ mm dia} = 790 / ((\pi/4)(0.90)^2) = 1241.8$$

Say 1242

$$\text{Total cross sectional area of laterals} = 3 \times \text{Area of perforations}$$

$$= 3 \times 790 = 2370 cm^2$$

$$\text{Area of central manifold} = 2 \times \text{Area of laterals}$$

$$2 \times 2370 cm^2$$

$$\begin{aligned} \text{Diameter of central manifold} &= \sqrt{\frac{4740}{\pi}} \\ &= 38.9 \text{ cm} \\ &\approx 39 \text{ cm} \end{aligned}$$

Provide a commercially available diameter of 800 mm.

Assuming a spacing of 15 cm for laterals,

$$\text{The number of laterals} = (2 \times 5.85 \times 100) / 15 = 78$$

$$\text{Cross sectional area of each lateral} = 2370.178 \text{ cm}^2 = 30.39 \text{ cm}^2$$

$$\text{Diameter of lateral} = \sqrt{\frac{(30.39 \times 4)}{\pi}} = 6.22 \text{ cm}$$

Provide laterals of diameter of 80 mm

$$\text{Number of perforation per lateral} = 1242 / 78 \approx 16$$

$$\begin{aligned} \text{Length of lateral} &= 1/2 (\text{width of filter} - \text{dia of manifold}) \\ &= 1/2 (4.5 - 0.8) = 1.85 \text{ m} \end{aligned}$$

$$\text{Spacing of perforations} = 1.85 \times 100 / 16 = 11.56 \text{ cm}$$

Provide 16 perforations of 9 mm dia at centre to centre spacing of 115 mm.

(E) COMPUTE DIMENSION OF WASH WATER TROUGH

Assume a wash water rate of $36 \text{ m}^3/\text{m}^2 \cdot \text{hr}$

$$\begin{aligned} \text{Washwater discharge for 1 filter} &= 36 \times 26.33 \text{ m}^3/\text{hr} \\ &= 947.88 \text{ m}^3/\text{hr} \\ &= 0.2633 \text{ m}^3/\text{sec} \end{aligned}$$

Assuming a spacing of 1.6 m for wash water trough which will run parallel to the longer dimension of the filter unit.

$$\text{No. of troughs} = 4.50 / 1.6 = 3$$

$$\text{Discharge per unit trough} = 0.2633 / 3 = 0.0878 \text{ m}^3/\text{sec}$$

For a width of 0.4m, the water depth at upper end is given by

$$Q = 1.376 \text{ bh}^{3/2}$$

Year	Population	Area	Population Density	Population Growth Rate
1980	1000	1000	1.0	0.0
1985	1100	1000	1.1	0.1
1990	1200	1000	1.2	0.2
1995	1300	1000	1.3	0.3
2000	1400	1000	1.4	0.4
2005	1500	1000	1.5	0.5
2010	1600	1000	1.6	0.6
2015	1700	1000	1.7	0.7
2020	1800	1000	1.8	0.8

8. The population of a city is increasing at a rate of 0.5% per year. The population in 2000 was 100,000. How many people will there be in 2020?

9. The population of a city is increasing at a rate of 0.5% per year. The population in 2000 was 100,000. How many people will there be in 2010?

10. The population of a city is increasing at a rate of 0.5% per year. The population in 2000 was 100,000. How many people will there be in 2015?

PROBABILITY DISTRIBUTION OF THE NUMBER OF SUCCESSFUL ATTEMPTS

1. Probability density function

The probability density function of the number of successful attempts X in n trials is given by the binomial distribution as follows:

$$f(x) = P(X=x) = \binom{n}{x} p^x q^{n-x} \quad (1)$$

$$f(x) = \frac{n!}{x!(n-x)!} p^x q^{n-x} \quad (2)$$

where

X = No. of trials

n = Total no. of trials, n must be finite and discrete, $n \geq 0$ and p and q are probabilities of success and failure respectively, $0 \leq p \leq 1$ and $0 \leq q \leq 1$ and $p + q = 1$. x is the number of successful trials, $0 \leq x \leq n$.

$$x = 0, 1, 2, \dots, n$$

$$p = 0, 1, 2, \dots, n$$

If the number of trials is infinite, $n \rightarrow \infty$, then

$$f(x) = \frac{e^{-\lambda} \lambda^x}{x!}$$

2) Probability density function

When a discrete variable X has a probability density function

$$f(x) = \frac{e^{-\lambda} \lambda^x}{x!} \quad (3)$$

$$f(x) = \frac{e^{-\lambda} \lambda^x}{x!}$$

Then the variable X is said to have a Poisson distribution

$$f(x) = \frac{e^{-\lambda} \lambda^x}{x!} \quad (4)$$

where $f(x) = P(X=x)$ and $\lambda = np$ and $n \rightarrow \infty$ and $p \rightarrow 0$

where x and λ are integers

$$f(x) = \frac{e^{-\lambda} \lambda^x}{x!} \quad (5)$$

$$f(x) = \frac{e^{-\lambda} \lambda^x}{x!}$$

where x is a discrete variable and λ is a constant

$$f(x) = \frac{e^{-\lambda} \lambda^x}{x!} \quad (6)$$

If $\lambda = 1$, then the distribution is said to be a Poisson distribution with parameter $\lambda = 1$. In this case, the probability density function is given by

APPENDIX 7.3

INFORMATION TO BE INCLUDED IN THE TENDER SPECIFICATIONS FOR WATER TREATMENT PLANT

GENERAL

The principal requirement must be a system of civil engineering layout. The structures should represent a pleasing appearance with a strong feeling for a balance between function and form. The interiors of the structures shall be kept appealing and in keeping with the objectives of the plant, i.e., production of pure and clean drinking water.

While the mode of design and construction shall be a matter of individual choice, it should be ensured that all materials, design, construction and fabrication comply for different parts including doors and windows conform to IS Specifications and codes of practice wherever available and in their absence to non-contradictory standards.

Adequate provision shall be made in the civil engineering works for laboratory, office building, administrative and sanitary facilities and water supply etc. The requirement of these ancillary requirements shall be stipulated. It always with adequate lighting shall be provided. Adequate ladders or steps and handrails where required shall be provided for easy access to each part of the treatment plant and wherever necessary, walkways should be provided. House water trap facilities shall be provided to enable the operator to move freely for maintenance and operation of the plant.

All water retaining structures shall be designed in accordance with IS-3371 while the other structures shall be designed according to IS-601.

The tender specifications should include *and/or* the process requirements and specifications for equipment.

A. Process Requirements

- (1) The following data shall be furnished to the bidders:
 - (a) Raw water analysis comprising of monthly average figures preferably for a full year period covering various seasonal variations in respect of, at least the following. If the full year data is not available, the worst seasonal values may be given:
 - (i) pH
 - (ii) Turbidity
 - (iii) Total Alkalinity
 - (iv) Total hardness
 - (v) Chlorides
 - (vi) Calcium carbonate (CaCO_3)
 - (b) Any other additional data of the water to ascertain its major constituents or contaminants which are required to be removed.

- (k) Phosphorus
- (l) Yards and roads
- (m) Fertilizer
- (n) Contaminated
- (o) High nutrient
- (p) Lake
- (q) Many fish
- (r) *Macrobenthos* (macroinvertebrates) and *zooplankton* (microscopic animals)
- (s) Chlorophyll content, $\mu\text{g/l}$
- (t) *Chlorococcoid* (microalgae)

and any other pollutants arising from the excavations and structural works.

(g) Hydraulic data such as the elevation of water level and draw down levels:

2.1 To include, where appropriate, shall be deemed:

- (a) The flow measurement will be given in terms of the wet open channel of the river. The measurement shall be m^3/sec or cfs (allowing for a rating of the channel and a record of the capacity).
- (b) The quality of the water shown in terms of pH, turbidity, coliform, dissolved oxygen, iron, manganese, nitrate, nitrite, ammonia, fluoride, chlorides, sulphate, and copper (sum of the same), sulphate (sum), fluoride, nitrate, and nitrite.
- (c) Design standards and various treatment units such as chemical dosing, rapid mixing, fine mixing, sedimentation, filtration and disinfection as well as special features like neutralisation, softening, iron and manganese removal, fluoride removal, water softening, etc. as per specific local requirements and as applicable to the available standards mentioned in the Manual.
- (d) A schematic layout of the proposed Plant including following details, to the extent possible:
 - (i) The size and location of all structures;
 - (ii) Schematic flow diagram showing flow through various units;
 - (iii) Cross-sectional drawings of major structures showing the material and size of flow as well as structure of flow;
 - (iv) Technical profile showing elevation of the flow of water;
 - (v) Location of the various sampling points to be fixed regularly;
 - (vi) Approach roads, water supply facilities for construction purposes;
 - (vii) Other important details such as protection of drinking water supply from groundwater table; location, type and nature of some

include: maximum anticipated depth, soil characteristics, the bearing capacity and cohesion, viscosity and the size of particles of total annual rainfall, duration of area for disposal, maximum depth and of borrow pits to be used for filling purposes.

- c. The contract should establish when and how quickly and clearly define their requirements performance, graphics, which be demonstrated by a test run of specified length at over the agreed period of operation.

B. Mechanical equipment

1. The following data may be given while listing tasks for pumping plant :

(a) Number of units required to work a specified

(i) Volume of liquid to be pumped

(1) Head or static water

(ii) Density or sp. gravity of liquid

(iii) Sp. gravity

(iv) Amount of suspended matter, etc.

(c) Required capacity as well as maximum and minimum amount of liquid to be pumped per day

(d) Service conditions

(i) Service lift or suction lift

(ii) Constant or variable nature of flow.

(e) Discharge conditions

(i) Maximum/Minimum flow rate, pressure against which pump has to deliver liquid.

(ii) Static head description (constant, variable).

(iii) Friction head description and how to be estimated

(f) Type of service (continuous or intermittent)

(g) Pump installation (horizontal or vertical) mode of discharge (top of pit, wet and dry).

(h) Power available to drive the pumps.

(i) Net Wt, weight or transportation facilities

(j) Location of installation

(k) Special requirements with respect to pump design, construction or performance

2. The following requirements may be indicated.

- (a) The pump equipment as well as the compressor shall conform to the relevant U.S. standards and in their absence, to any other accepted international or national standard.
 - (b) Any special duty conditions such as temperature, humidity, corrosion, atmosphere should be specified.
 - (c) Stairways, structural parts, except hot rolled sections shall not be less than 6 mm thick under normal air space and flow in aggressive atmosphere.
 - (d) Joints, rivets and allied accessories such as electrical bonding, weather, weather reduction gear drive reduction gear, bearings, gaskets, etc. shall be of approved make.
 - (e) All bearing machinery, electrical gears shall be designed with adequate safety margins and service factors.
 - (f) An inventory part list of major parts shall be provided by the tenderer. At least two sets representing all fasteners, etc. shall be supplied along with the equipment.
 - (g) The supplier of special equipment, i.e. heat exchangers, cooling towers, etc. shall provide a competent representative for a specified number of days during a specified period to instruct the plant operating personnel in the maintenance and care of the equipment and to conduct tests and make recommendations for producing most efficient results.
 - (h) Equipment selection with reference to specifications, make, unit, spare parts and service life shall be minimum life of 10 years and maintenance cost shall be the purchaser's responsibility to meet specifications. The contract shall require the manufacturer to furnish efficient equipment with minimum warranty guarantee of 12 months.
- The contractor shall ensure that all machinery, tools of work, hoists, mechanical equipments, piping etc. for a specified period to a quantity of similar day operation and currency and extra labor are directed to the work, materials, equipments furnished by them.
- The special equipment, steel, electrical, mechanical, etc. for a period of time and services etc. if available, may or may not be provided by the manufacturer. In most engineering equipments, the manufacturer provides field service with respect to installation.
- (i) All water submerged parts, i.e. tank, mechanical parts, and steel pipes under water shall be adequately protected. For various equipment, 0.1% zinc dust and all surface contaminants from structural and fabricated steel parts are removed by cleaning with solvent, vapour, alkali solution, or steam. Loose rust or paint, weld spatter, etc. are removed by hand chipping, grinding, sanding, wire brushing, and grinding. The bare finished surface, finished flanges and other mechanical surfaces are protected by grease film or rust protection coatings. Structural mechanical support and service structure, walkways, hand rails, filtered shafts, etc. shall be protected with at least one coat of primer and two coats of paint. BS 890 – 1962 gives the code of practice for steel structure, steel general building construction.

Case No.	Case Name	Case Type	Case Status	Case Description	Case Details	Case Outcome	Case Date	Case Location	Case Agency
1	John Doe	Police	Open	Investigation of a theft case.	Police report filed on 10/15/2023.	Case closed on 10/25/2023.	10/15/2023	New York	New York Police Department
2	Jane Smith	Police	Open	Investigation of a traffic violation.	Police report filed on 10/16/2023.	Case closed on 10/20/2023.	10/16/2023	New York	New York Police Department
3	Robert Johnson	Police	Open	Investigation of a domestic violence case.	Police report filed on 10/17/2023.	Case closed on 10/22/2023.	10/17/2023	New York	New York Police Department
4	Emily White	Police	Open	Investigation of a public disturbance.	Police report filed on 10/18/2023.	Case closed on 10/21/2023.	10/18/2023	New York	New York Police Department
5	Michael Brown	Police	Open	Investigation of a car accident.	Police report filed on 10/19/2023.	Case closed on 10/24/2023.	10/19/2023	New York	New York Police Department
6	Sarah Green	Police	Open	Investigation of a missing person case.	Police report filed on 10/20/2023.	Case closed on 10/26/2023.	10/20/2023	New York	New York Police Department
7	David Black	Police	Open	Investigation of a vandalism case.	Police report filed on 10/21/2023.	Case closed on 10/23/2023.	10/21/2023	New York	New York Police Department
8	Olivia Grey	Police	Open	Investigation of a drug possession case.	Police report filed on 10/22/2023.	Case closed on 10/27/2023.	10/22/2023	New York	New York Police Department
9	Lucas Blue	Police	Open	Investigation of a sexual assault case.	Police report filed on 10/23/2023.	Case closed on 10/28/2023.	10/23/2023	New York	New York Police Department
10	Isabella Purple	Police	Open	Investigation of a child abuse case.	Police report filed on 10/24/2023.	Case closed on 10/29/2023.	10/24/2023	New York	New York Police Department

1	1	1	1	1
2	2	2	2	2
3	3	3	3	3
4	4	4	4	4
5	5	5	5	5
6	6	6	6	6
7	7	7	7	7
8	8	8	8	8
9	9	9	9	9
10	10	10	10	10
11	11	11	11	11
12	12	12	12	12
13	13	13	13	13
14	14	14	14	14
15	15	15	15	15
16	16	16	16	16
17	17	17	17	17
18	18	18	18	18
19	19	19	19	19
20	20	20	20	20
21	21	21	21	21
22	22	22	22	22
23	23	23	23	23
24	24	24	24	24
25	25	25	25	25
26	26	26	26	26
27	27	27	27	27
28	28	28	28	28
29	29	29	29	29
30	30	30	30	30
31	31	31	31	31
32	32	32	32	32
33	33	33	33	33
34	34	34	34	34
35	35	35	35	35
36	36	36	36	36
37	37	37	37	37
38	38	38	38	38
39	39	39	39	39
40	40	40	40	40
41	41	41	41	41
42	42	42	42	42
43	43	43	43	43
44	44	44	44	44
45	45	45	45	45
46	46	46	46	46
47	47	47	47	47
48	48	48	48	48
49	49	49	49	49
50	50	50	50	50
51	51	51	51	51
52	52	52	52	52
53	53	53	53	53
54	54	54	54	54
55	55	55	55	55
56	56	56	56	56
57	57	57	57	57
58	58	58	58	58
59	59	59	59	59
60	60	60	60	60
61	61	61	61	61
62	62	62	62	62
63	63	63	63	63
64	64	64	64	64
65	65	65	65	65
66	66	66	66	66
67	67	67	67	67
68	68	68	68	68
69	69	69	69	69
70	70	70	70	70
71	71	71	71	71
72	72	72	72	72
73	73	73	73	73
74	74	74	74	74
75	75	75	75	75
76	76	76	76	76
77	77	77	77	77
78	78	78	78	78
79	79	79	79	79
80	80	80	80	80
81	81	81	81	81
82	82	82	82	82
83	83	83	83	83
84	84	84	84	84
85	85	85	85	85
86	86	86	86	86
87	87	87	87	87
88	88	88	88	88
89	89	89	89	89
90	90	90	90	90
91	91	91	91	91
92	92	92	92	92
93	93	93	93	93
94	94	94	94	94
95	95	95	95	95
96	96	96	96	96
97	97	97	97	97
98	98	98	98	98
99	99	99	99	99
100	100	100	100	100

Sl. No.	Chemical	Common Name	Formula	Use	Available Form	Concentration/Strength	Appearance and Properties	Stock Suspension Strength	Method of Storage	Material Handling Solution	REMARKS
28	Iron(III) chloride	Chloride Iron	$FeCl_3 \cdot 6H_2O$	Disinfectant	Crystals	500 mg/ml	Yellow brown lumpy crystalline powder	500 mg/ml	Well protected along path	Label on container or associated glass	
29	Iron(III) chloride hexahydrate	Iron	$FeCl_3$	Disinfectant	Soluble	500 mg/ml	Yellow brown lumpy crystalline powder	500 mg/ml	Well protected along path		
30	Iron(III) sulfate	Iron sulfate	$Fe_2(SO_4)_3 \cdot 9H_2O$	Disinfectant	Crystals	500 mg/ml	Dark brown lumpy crystalline powder	500 mg/ml	Well protected along path	Label on container	
31	Iron(III) sulfate	Complexed Iron sulfate	$Fe_2(SO_4)_3 \cdot 9H_2O$	Disinfectant	Disinfectant	500 mg/ml	Dark brown lumpy crystalline powder	500 mg/ml	Well protected along path	Label on container	
32	Hydrogen Peroxide		H_2O_2	Disinfectant	Disinfectant	500 mg/ml	Colorless liquid	500 mg/ml	Well protected along path	Label on container	
33	Hydrogen Peroxide		H_2O_2	Disinfectant	Disinfectant	500 mg/ml	Colorless liquid	500 mg/ml	Well protected along path	Label on container	

No.	Name of the Candidate	Registration No.	Father's Name	Sex	Date of Birth	Religion	Educational Qualification	Date of Birth of Spouse	Marital Status	Marital Status of Candidate	Date of Birth of Spouse
1
2
3
4
5
6
7
8

No.	Name of the Company	Sector	Type of Investment	Investment Amount	Investment Year	Investment Type	Investment Status	Investment Value	Investment Type	Investment Value	Investment Type	Investment Value
14	Sri Lanka Tea	A	Direct	1000000	2000	100%	100%	100%	100%	100%	100%	100%
15	Sri Lanka Tea	A	Direct	1000000	2000	100%	100%	100%	100%	100%	100%	100%




Table 1. Synthesis of 2,2,4,4-tetramethyl-1,3-dioxane (10).

Run	Starting material	Yield (%)	Structure	Yield (%)	Structure
1	9	100	9a	100	10
2	9	100	9a	100	10
3	9	100	9a	100	10
4	9	100	9a	100	10

Table 1. Synthesis of 2,2,4,4-tetramethyl-1,3-dioxane (10) from 2,2,4,4-tetramethyl-1,3-dioxane-5-carbaldehyde (9). 9 (1.00 mol) was dissolved in 100 mL of CH_2Cl_2 and 1.00 mol of NaOH was added. The mixture was stirred at room temperature for 24 h. The mixture was then acidified with 10% HCl and extracted with CH_2Cl_2 . The organic phase was dried with CaH_2 and concentrated under reduced pressure to give 9a (1.00 mol).

Run	Starting material	Yield (%)	Structure	Yield (%)	Structure
1	9	100	9a	100	10
2	9	100	9a	100	10
3	9	100	9a	100	10
4	9	100	9a	100	10

Table 1. Synthesis of 2,2,4,4-tetramethyl-1,3-dioxane (10) from 2,2,4,4-tetramethyl-1,3-dioxane-5-carbaldehyde (9). 9 (1.00 mol) was dissolved in 100 mL of CH_2Cl_2 and 1.00 mol of NaOH was added. The mixture was stirred at room temperature for 24 h. The mixture was then acidified with 10% HCl and extracted with CH_2Cl_2 . The organic phase was dried with CaH_2 and concentrated under reduced pressure to give 9a (1.00 mol).


Annual consumption of lime as CaO

$$\begin{aligned} &= \frac{(106.04 \times 250 \times 24 \times 10^3 \times 365)}{(10^3 \times 10^3)} \\ &= 363.63 \text{ metric tons} \end{aligned}$$

Annual consumption of soda ash as Na₂CO₃

$$\begin{aligned} &= \frac{(118.19 \times 200 \times 24 \times 10^3 \times 365)}{(10^3 \times 10^3)} \quad \text{metric tons} \\ &= 258.84 \text{ metric tons} \end{aligned}$$

APPENDIX D.2



TYPE DESIGN OF IRON REMOVAL PLANT
 (CAPACITY OF 2 MGAL PER HOUR PER HOUR)

APPENDIX 9.3

DESIGN OF IRON REMOVAL UNITS

Typical designs of iron removal units for 1.10 and 1.20 m³/s follow.

DESIGN CONSIDERATIONS

- Schemes have been designed for a 10% extra capacity and 10% extra water quantity to provide for sedimentation bleed losses and filter backwash requirements.
- Power shut-downs are frequent and rarely more than two hours supply is available in the morning and evening. Accordingly, raw water pumping needs assumed to be 2 hours in the morning and two hours in the evening. During these four hours pumping period, total daily requirements of treatment to be pumped to elevated storage tank to treat water by gravity flow to the treatment unit(s).
- To avoid extra cost for additional overhead tank for filtered water, it is assumed that the filtered water from the sump well will be directly pumped for the distribution. The distribution of treated water would follow the same time schedule as contemplated for conveying raw water.
- Backwashing of the sand filter would be carried out by using raw water from the overhead tank.

DESIGN CRITERIA

- Water consumption: 4 lps/c
- Tray separator
 - Spacing of Trays: 1.0 m
 - Angular Rate: 1.20 m³/h
- Sedimentation Basin
 - Detention Period: 2.5 h
- Sand Filter
 - Effective Size: 0.60 mm
 - Uniformity Coefficient: 1.5 to 1.7
 - Sand Depth: 1.2 m
 - Total head above sand: 1.35 m
 - Rate of Filtration: 4.0 m³/m²/h
 - Minimum Backwash Rate: 3.0 m³/m²/h
 - Total Head for Filter Wash: 1.2 m
 - Gravel Depth: 0.90-1.62 m


APPENDIX

2001-02	2002-03
2003-04	2004-05
2005-06	2006-07
2007-08	2008-09


Annual income from the water supply for the years indicated by the headings are as shown in Table 2.2.

TABLE 2.2
ANNUAL INCOME FROM WATER SUPPLY CONTRIBUTION FROM REMOVAL
OF SOLUBLE CHLORIDE FROM COMMUNITY WATER SUPPLY


2001-02	2002-03	2003-04	2004-05
2005-06	2006-07	2007-08	2008-09
Geographical Region			
Uttarakhand	8	18	21
Other	2100 - 21000	2100 - 21000	2100 - 21000
Supply Quantity			
2001-02	8	8	8
2002-03	8	8	8
2003-04	11000 - 11000	11000 - 11000	11000 - 11000
2004-05	11000	11000	11000
2005-06	11000	11000	11000
2006-07	11000	11000	11000
2007-08	11000	11000	11000
2008-09	11000	11000	11000
Water Quality			
2001-02	11000 - 11000	11000 - 11000	11000 - 11000
2002-03	11000 - 11000	11000 - 11000	11000 - 11000
2003-04	11000 - 11000	11000 - 11000	11000 - 11000
2004-05	11000 - 11000	11000 - 11000	11000 - 11000
2005-06	11000 - 11000	11000 - 11000	11000 - 11000
2006-07	11000 - 11000	11000 - 11000	11000 - 11000
2007-08	11000 - 11000	11000 - 11000	11000 - 11000
2008-09	11000 - 11000	11000 - 11000	11000 - 11000



CONTINUED ON REVERSE SIDE OF SHEET



SECTIONAL ELEVATION



LAYOUT PLAN


CONTINUOUS IRON REMOVAL FOR COMMUNITY WATER SUPPLY CAPACITY 10 m³/h

NOTE

ALL DIMENSIONS ARE IN METER

SCALE - NOT TO SCALE

FOUNDATION DEPENDS ON SOIL CONDITIONS



CONTINUOUS IRON REMOVAL FOR COMMUNITY WATER SUPPLY CAPACITY 30000

APPENDIX 9.4

SOLAR RADIATION

North Lat.	range	Probable average values of insolation Direct and Diffused on a Horizontal surface at sea level at Langley's per day.							
		January		February		March		April	
		Visible	Total	Visible	Total	Visible	Total	Visible	Total
34	Max	114	360	167	450	224	553	254	659
	Min	53	155	78	215	118	320	141	383
32	Max	126	380	169	450	212	570	258	665
	Min	63	180	87	240	126	340	146	395
30	Max	136	430	176	490	218	587	261	875
	Min	76	220	96	260	134	362	153	405
28	Max	146	420	184	500	224	613	264	683
	Min	87	250	106	290	142	373	156	415
26	Max	156	440	192	530	230	615	266	690
	Min	99	260	114	310	149	390	160	425
24	Max	166	460	200	545	236	625	268	697
	Min	111	316	123	340	156	410	164	455
22	Max	174	480	206	560	241	644	273	701
	Min	123	355	132	370	162	426	167	440
20	Max	183	500	213	575	246	652	271	703
	Min	134	360	140	390	168	440	170	447
18	Max	192	515	220	590	250	664	272	705
	Min	144	380	150	410	174	459	174	452
16	Max	200	530	226	610	255	670	272	707
	Min	154	400	159	430	180	473	177	456
14	Max	208	555	234	630	258	680	271	709
	Min	163	430	167	450	184	487	179	460
12	Max	216	572	239	645	262	690	271	710
	Min	172	455	176	470	189	500	181	462
10	Max	223	595	244	655	264	694	271	711
	Min	179	475	184	490	193	513	183	464
8	Max	230	610	249	665	267	700	270	709
	Min	187	495	192	510	196	523	185	467

APPENDIX 9.4 (Continued)

SOLAR RADIATION

North Lat.	range	Probable average values of insolation - Direct and Diffused on a Horizontal surface at sea level in Langley's per day.							
		May		June		July		August	
		Visible	Total	Visible	Total	Visible	Total	Visible	Total
34	Max	290	743	297	775	289	763	267	696
	Min	176	462	168	439	178	431	159	448
32	Max	293	744	296	772	289	761	269	700
	Min	181	475	166	431	178	431	163	458
30	Max	293	744	296	768	289	759	271	702
	Min	184	490	163	425	178	469	166	462
28	Max	289	743	294	764	288	755	272	704
	Min	187	506	161	418	178	467	169	466
26	Max	288	741	292	760	288	749	273	706
	Min	189	518	158	439	177	463	172	469
24	Max	288	738	290	755	287	742	273	708
	Min	191	525	155	413	176	459	174	471
22	Max	286	734	286	747	285	736	273	707
	Min	193	530	152	392	173	454	176	472
20	Max	284	730	284	738	282	729	272	706
	Min	194	532	148	383	172	450	177	472
18	Max	282	723	280	728	280	723	270	705
	Min	194	530	145	375	170	442	177	471
16	Max	279	718	276	720	277	715	270	702
	Min	194	528	141	365	167	435	177	469
14	Max	276	710	272	710	273	708	265	700
	Min	194	524	137	354	164	429	177	467
12	Max	273	702	267	700	269	700	267	697
	Min	193	518	133	343	161	421	176	464
10	Max	270	694	262	688	265	690	266	693
	Min	192	512	129	330	158	414	176	460
8	Max	266	685	258	678	260	680	263	688
	Min	191	506	124	320	154	405	174	456

APPENDIX 9.4 (Continued)

SOLAR RADIATION

North range Probable average values of insolation - Direct and Diffused on a
Lat Horizontal surface at sea level at Langley's per day.

		September		October		November		December	
		Visible	Total	Visible	Total	Visible	Total	Visible	Total
34	Max	221	602	178	490	128	380	101	338
	Min	134	368	96	250	70	202	47	158
32	Max	226	615	185	510	138	400	114	360
	Min	140	385	104	270	80	221	60	184
30	Max	231	625	192	524	148	420	126	380
	Min	147	399	113	294	90	256	70	210
28	Max	236	635	199	537	157	440	138	400
	Min	154	415	120	310	99	278	80	236
26	Max	240	652	205	552	166	460	149	420
	Min	160	429	128	332	109	300	90	260
24	Max	244	659	212	568	175	480	161	440
	Min	165	443	136	360	119	326	101	280
22	Max	248	668	218	582	183	500	172	460
	Min	170	455	143	380	128	350	110	300
20	Max	252	674	224	596	190	520	182	480
	Min	176	467	150	400	138	370	120	320
18	Max	256	680	229	605	198	538	192	500
	Min	180	479	157	418	146	390	129	340
16	Max	259	684	234	615	206	554	209	520
	Min	185	489	164	434	154	410	138	360
14	Max	262	688	240	627	214	567	209	530
	Min	189	496	170	449	162	430	146	380
12	Max	264	691	244	640	221	585	217	550
	Min	193	502	176	462	169	446	154	400
10	Max	266	693	248	650	228	600	225	570
	Min	196	510	181	474	176	462	162	420
8	Max	267	695	252	660	234	616	231	590
	Min	200	518	186	468	182	478	169	440

EXPLANATORY NOTE

- (a) Calculated from data published by the United States Weather Bureau
- (b) Gram Calories per square cm = Langley
- (c) "Visible" Radiation of wavelengths of 4000Å to 7000Å penetrating a smooth water surface.
- (d) Total Radiation of all wavelengths in solar spectrum.
- (e) Value which will not normally be exceeded.
- (f) Value based on or extrapolated from lowest values observed for indicated month and latitude during 10 years of record

Approximate corrections for elevation upto 3000m

Total radiation = Total(1 - 0.6405L)

Visible radiation = Vis.(1 - 0.0005ML) where L is in thousands of metres.

Correction for cloudiness (approx) = Max [(Max - Min) C]. Where C is fraction of time weather is clear.

APPENDIX 10.1

CALCULATION OF CAPACITY OF SERVICE RESERVOIR

PROBLEM

Find out capacity of storage reservoir for the following two situations viz.,

- (i) Power is not available from 6a.m. to 6p.m. daily
 - (a) 16 hrs. of pumping during 10p.m. to 6a.m. and 10a.m. to 6p.m.
 - (b) 8 hrs. of pumping during 4a.m. to 6a.m. and 12 noon to 5p.m.
- (ii) Power is available throughout 24 hrs.
 - (c) 16 hrs. of pumping during 4a.m. to 12 noon and 1p.m. to 9p.m.
 - (d) 8 hrs. of pumping during 4a.m. to 8p.m. and 2p.m. to 6p.m.

Data given are

1. Design population 24,000
2. Per Capita water supply-90 lpd
3. Peak factor-2.25
4. Peak hours: 6a.m. to 10a.m., 1p.m. to 2p.m., 5p.m. to 6p.m.
5. Other than peak hours, hourly demands are as follows:
 - (i) 20% of average hourly demand: 11p.m. to 4a.m.
 - (ii) 40% of average hourly demand: 4a.m. to 5a.m. and 10p.m. to 11p.m.
 - (iii) 60% of average hourly demand: 12 noon to 1p.m.
 - (iv) 70% of average hourly demand: 2p.m. to 5p.m. and 8p.m. to 10p.m.
 - (v) 80% of hourly demand: 5a.m. to 6a.m.
 - (vi) 90% of hourly demand: 7p.m. to 8p.m.
 - (vii) 100% of hourly demand: 6a.m. to 12 noon
6. Water supply is continuous.

SOLUTION

1. Total demand = $24000 \times 90 \text{ lpd} = 2.16 \text{ mld}$
2. Average hourly demand = $2.16/24 = 0.09 \text{ mld} = a$
3. Peak hourly demand = $2.25 \times \text{average hourly demand} = 2.25a$

Tables 1 and 2 show the compilation for arriving at the capacity of the service reservoir, for 16 and 8 hours of pumping.

In Table 1 data from cols 1 to 3 are applicable for both the given situations (i) and (ii). Computed data for situation (i) and (ii) are given in cols. 4,5,6,7, those inside the brackets referring to situation (ii)

Similarly in Table 2 compared data outside the brackets from cols. 2 to 5 refer to the situation (i) while those inside the brackets are for the situation (ii).


Storage required under situations:

- (i) (a) 0.8443 ml. or 32% of daily demand.
- (b) 0.9304 ml. or 46% of daily demand.
- (ii) (a) 0.3285 ml. or 15% of daily demand.
- (b) 0.3465 ml. or 33% of daily demand.

TABLE I

SHOWING COMPUTATION FOR CAPACITY OF SERVICE RESERVOIR

Given data		16 hours pumping, pumping rate $= 24x/6$			8 hours pumping, pumping rate $= 24x/8 = 3x$	
Period in hours	Hourly demand	Cumulative demand	Cumulative pumping	Cumulative deficit or surplus	Cumulative pumping	Cumulative deficit or surplus
(1)	(2)	(3) = Σ (2)	(4)	(5) = (4) - (3)	(6)	(7) = (6) - (1)
04-05	0.400a	0.40a	1.50a(1.50a)	+1.10a(+1.50a)	3.00a(3.00a)	+2.60a(+2.60a)
05-06	0.80a	1.20a	3.00a(3.00a)	+1.80a(+1.80a)	6.00a(6.00a)	+4.80a(+4.80a)
06-07	2.25a	3.45a	3.00a(9.00a)	-7.20a(-7.20a)	6.00a(12.00a)	-4.20a(-11.80a)
07-08	A	12.20a	6.00a(12.00a)	-6.20a(-6.20a)	6.00a(12.00a)	-5.20a(-11.70a)
08-09	1.60a	12.80a	7.50a(12.50a)	-5.30a(-5.30a)	9.00a(12.00a)	-2.80a(-8.80a)
09-10	2.25a	15.05a	9.00a(13.50a)	-6.05a(-6.05a)	12.00a(12.00a)	-3.85a(-3.05a)
10-11	0.70a	17.15a	13.50a(13.50a)	-3.65a(-3.65a)	21.00a(21.00a)	-3.85a(+3.85a)
11-12	2.25a	19.40a	15.00a(19.50a)	-4.40a(-4.40a)	24.00a(24.00a)	+4.60a(+4.60a)
12-13	0.90a	20.30a	15.00a(22.50a)	-6.20a(+1.30a)	24.00a(24.00a)	+2.80a(+2.80a)
13-14	0.70a	21.00a	15.00a(24.00a)	-6.00a(+2.10a)	24.00a(24.00a)	+2.10a(+2.10a)
14-15	0.70a	22.60a	15.00a(24.00a)	-7.60a(+1.40a)	24.00a(24.00a)	+1.40a(+1.40a)
15-16	0.40a	23.00a	16.50a(24.00a)	-6.50a(+1.00a)	24.00a(24.00a)	+1.00a(+1.00a)
16-17	0.20a	23.40a	16.50a(24.00a)	-3.90a(+0.60a)	24.00a(24.00a)	+0.60a(+0.60a)
17-18	0.20a	24.60a	24.00a(24.00a)	0.00a(0.00a)	24.00a(24.00a)	-0.00a(-0.00a)



8	4.808 (1.608)	6.208 (3.058)	1.008 (17.854)	0.9906 (0.7065)
16	1.808 (2.108)	7.608 (1.558)	0.911 (3.658)	0.845010 (2.85)
(1)	(2)	(3)	(4) = (2) + (3)	(5) = (4) x (11.9ml)

Pumping hours
 Maximum cumulative surplus
 Maximum cumulative deficit
 Capacity of storage reservoir
 Capacity of storage reservoir substituting
 Values of $n = 0.09$ ml


TABLE 2
 SHOWING CAPACITY OF SERVICE RESERVOIR FOR
 DIFFERENT HOURS OF PUMPING

APPENDIX 10.2

NOMINAL DIAMETER D_2 (mm)	ENLARGED END DIA D_1 (mm)	HEIGHT OF SIDE MOUTH h (mm)	WEIGHT (APPROX) (kg)
80	125	130	7
100	150	150	9
125	175	150	12
150	200	150	15
200	285	200	23
250	350	200	31
300	450	250	45
350	525	250	58
400	600	300	80
450	650	300	93
500	750	300	120
600	900	410	201
700	1050	470	304
800	1200	520	435
900	1350	590	575
1000	1500	650	790
1100	1650	710	955
1200	1800	770	1243
1500	2250	950	2092
1800	2700	1150	3320

DETAILS OF SIDE MOUTH FOR OUTLET CONNECTIONS IN SERVICE RESERVOIRS

NOTE: ALL VALUES ARE CORRECT



PROBLEM TO ANALYSE THE ABOVE NETWORK GIVEN BELOW

APPENDIX 103

1. The first part of the document is a list of names and titles, including "The Hon. Mr. Justice" and "The Hon. Mr. Justice".

2. The second part of the document is a list of names and titles, including "The Hon. Mr. Justice" and "The Hon. Mr. Justice".

3. The third part of the document is a list of names and titles, including "The Hon. Mr. Justice" and "The Hon. Mr. Justice".

4. The fourth part of the document is a list of names and titles, including "The Hon. Mr. Justice" and "The Hon. Mr. Justice".

5. The fifth part of the document is a list of names and titles, including "The Hon. Mr. Justice" and "The Hon. Mr. Justice".

6. The sixth part of the document is a list of names and titles, including "The Hon. Mr. Justice" and "The Hon. Mr. Justice".

7. The seventh part of the document is a list of names and titles, including "The Hon. Mr. Justice" and "The Hon. Mr. Justice".

8. The eighth part of the document is a list of names and titles, including "The Hon. Mr. Justice" and "The Hon. Mr. Justice".

9. The ninth part of the document is a list of names and titles, including "The Hon. Mr. Justice" and "The Hon. Mr. Justice".

10. The tenth part of the document is a list of names and titles, including "The Hon. Mr. Justice" and "The Hon. Mr. Justice".

APPENDIX III
DESIGN CALCULATIONS FOR A PUMPING PLANT

DATA OF THE SCHEME

1.1	Daily demand of water	116 m ³ /d
1.2	Hours of pumping, considering excess capacity due to imp surge flooding etc. (to be supplied)	23 hrs per day
1.3	Water works at P.S. village (R.S.)	
1.3.1	Maximum (10 ³ l/24 hrs)	11.7 m ³
1.3.2	Min. "	9 m
1.3.3	Average	7 m
1.4	Rising main	
1.4.1	Length	3575 m
1.4.2	Diameter	1.2m
1.4.3	Vertical clearance (to ground) at source & pipeline	1.0 m
1.5	R.L. of point of discharge	99.0 m.
1.6	No. of pumps	
1.6.1	Duty pumps	4
1.6.2	Stand by pumps	"
1.7	R.L. of ground level at the pump house	8.25 m.
1.8	R.L. of high road level	10.5 m
1.9	Altitude of the site above P.S.	125 m
1.10	Ambient temperature	30° C.
2.0	Size of pipes and fittings for the pumping system	
2.1	main line pipe	
	Design velocity	1.5 m/s
	Ball valve diameter	0.545 m
		Say 550 mm
2.2	Branch pipe	
	Design velocity	1.5 to 3 m/s
		Say 250 mm
	Branch pipe diameter	0.202 m
		Say 200 mm

2.1	Delivery pipes and valves	
	Design velocity	2.5 m/s
	Diameter of delivery pipe (delivery valve 25 mm)	150 mm
		150 mm
2.2	Ball mouth in discharging unit	
	Design velocity	0.8 m/s
	Ball mouth diameter	149 mm
		50, 150 mm
3.0	Mechanics calculations	
3.1	Combined discharge of 4 pumps	
	In parallel (116 ml/s x 24 hrs) = 2.8 m ³	171.01 m ³ /d
3.2	Rate of total flow with 25 hrs running of pumps (max. eq.)	1.1 cubic m. / s
3.3	Discharge of each pump	0.3 m ³ /s
3.4	Mean static head (50m - 0m)	50 m
3.5	Frictional loss in straight pipe of mean diameter for combined discharge	0.395 m
3.6	Frictional losses in bends, valves & in rising main (q = 10% of 3.5)	0.330 m
3.7	Frictional loss in taper, delivery valve (NPS) & individual delivery pipe of 50 x 150 mm	0.18 m
3.8	Velocity head loss at atmosphere at the end is $v^2/2g$ when $v = 0.8$ m/s	0.03 m
3.9	Design head = (34) + (3.5) + (2.1) + (3.7) + (0.6)	54.267 m
3.10	System Resistance Curves	

System resistance curves are prepared by calculating total head of flow and based on following flow conditions in summary in figure 10.6 and maximum WPI's. The head losses as flow work out an example are as tabulated:

a. Combined Q	0.25	0.5	0.75	1.0	1.25	1.50
m ³ /hr.						
b. Max. Static Head	50.00					
c. Mean static head	50.00					
d. Min static head	48.00					

e) Friction in piping main	1.5	1.5	1.5	1.5	1.5	1.5
f) Friction in valves and fittings in 10% of pipe	0.5	0.5	0.5	0.5	0.5	0.5
g) Velocity	2.0	2.0	2.0	2.0	2.0	2.0
h) Total friction ΣH_f (m)	1.5	1.5	1.5	1.5	1.5	1.5
i) Total head by ed in Min. Wt	87.5	87.5	87.5	87.5	87.5	87.5
Head Wt	90	90	90	90	90	90
Max. Wt	88.5	88.5	88.5	88.5	88.5	88.5

Note: Static losses in the pipe are neglected because of the small diameter of the pipe. Frictional system resistance can be determined by dividing the total pipe length by 1000. Minor losses are very small, neglected for simplicity.

Then, the design flow and head values are substituted as follows:

$$(i) \text{ Discharge} = 4 \text{ m}^3/\text{s} \text{ or } 14,400 \text{ m}^3/\text{day}$$

$$(ii) \text{ Total head} = 1.5 \text{ m}$$

$$\times 4 \text{ m}^3/\text{s}$$

(ii) Head range of the pump should be selected as 1.5 m to 2.0 m to allow for operation flexibilities in the design of the pump system.

4.0 SELECTION OF THE DESIGN PUMPING SYSTEM PARAMETERS

Pump head is per 3% of pipe length

Head loss at various flow rates

$$H_{\text{loss}} = 3\% \times 100 \text{ m}$$

Head loss in the pipe is 3 m. Hence, the total head of the pump is 1.5 + 3 = 4.5 m. (3) m. (3.71 + 0.79)

Efficiency

Head loss in the large diameter pipe

Head loss in the large diameter pipe is 1.5 + 1.5 = 3 m

Therefore, the head of the pump is 4.5 m. Hence, the head of the pump is 4.5 m. Hence, the head of the pump is 4.5 m. Hence, the head of the pump is 4.5 m.

1. The first part of the paper is devoted to a general discussion of the problem of the origin of the universe. It is shown that the classical theory of gravity leads to a singularity at the beginning of time, which is interpreted as the origin of the universe.

2. The second part of the paper is devoted to a detailed analysis of the singularity. It is shown that the singularity is not a point in space, but a surface of infinite curvature. This surface is interpreted as the origin of the universe.

3. The third part of the paper is devoted to a discussion of the implications of the singularity. It is shown that the singularity implies the existence of a beginning of time and space. This beginning is interpreted as the origin of the universe.

4. The fourth part of the paper is devoted to a discussion of the evidence for the singularity. It is shown that the singularity is supported by the observations of the cosmic microwave background radiation and the expansion of the universe.

5. The fifth part of the paper is devoted to a discussion of the philosophical implications of the singularity. It is shown that the singularity implies the existence of a creator of the universe. This creator is interpreted as the origin of the universe.

6. The sixth part of the paper is devoted to a discussion of the scientific implications of the singularity. It is shown that the singularity implies the existence of a new theory of gravity. This theory is interpreted as the origin of the universe.

7. The seventh part of the paper is devoted to a discussion of the historical implications of the singularity. It is shown that the singularity implies the existence of a new era in the history of science. This era is interpreted as the origin of the universe.

8. The eighth part of the paper is devoted to a discussion of the religious implications of the singularity. It is shown that the singularity implies the existence of a new religion. This religion is interpreted as the origin of the universe.

9. The ninth part of the paper is devoted to a discussion of the cultural implications of the singularity. It is shown that the singularity implies the existence of a new culture. This culture is interpreted as the origin of the universe.

10. The tenth part of the paper is devoted to a discussion of the social implications of the singularity. It is shown that the singularity implies the existence of a new society. This society is interpreted as the origin of the universe.

11. The eleventh part of the paper is devoted to a discussion of the political implications of the singularity. It is shown that the singularity implies the existence of a new government. This government is interpreted as the origin of the universe.

12. The twelfth part of the paper is devoted to a discussion of the economic implications of the singularity. It is shown that the singularity implies the existence of a new economy. This economy is interpreted as the origin of the universe.

13. The thirteenth part of the paper is devoted to a discussion of the legal implications of the singularity. It is shown that the singularity implies the existence of a new legal system. This legal system is interpreted as the origin of the universe.

14. The fourteenth part of the paper is devoted to a discussion of the moral implications of the singularity. It is shown that the singularity implies the existence of a new moral system. This moral system is interpreted as the origin of the universe.

15. The fifteenth part of the paper is devoted to a discussion of the artistic implications of the singularity. It is shown that the singularity implies the existence of a new art form. This art form is interpreted as the origin of the universe.

16. The sixteenth part of the paper is devoted to a discussion of the scientific implications of the singularity. It is shown that the singularity implies the existence of a new scientific paradigm. This paradigm is interpreted as the origin of the universe.

17. The seventeenth part of the paper is devoted to a discussion of the philosophical implications of the singularity. It is shown that the singularity implies the existence of a new philosophical system. This system is interpreted as the origin of the universe.

18. The eighteenth part of the paper is devoted to a discussion of the historical implications of the singularity. It is shown that the singularity implies the existence of a new historical era. This era is interpreted as the origin of the universe.

19. The nineteenth part of the paper is devoted to a discussion of the religious implications of the singularity. It is shown that the singularity implies the existence of a new religious tradition. This tradition is interpreted as the origin of the universe.

This minimum water depth required (i.e. minimum WL) to satisfy NPSEIR for VV pump = $1.035 + 3.05 = 4.075$

(c) Two stage, single suction, 1480 rpm

H/head per stage = $51.856/2 = 25.928$ m

$$r_2 = 3.65 \times N \times Q^{0.75} / 17^{0.75} = 3.65 \times 1480 \times (0.15)^{0.75} / (17.428)^{0.75}$$

$$= 266.65$$

Attainable efficiency as per figure 11.1 = 0.77

Suction head required as per figure 11.5 = 0.5m or 30"

Working out as for (a) above for total head loss, flow rate, head loss of suction apparatuses, difference in vapour pressures at 30" and site ambient and difference in vapour atmospheric pressure as mean sea level and site altitude, suction head required at site condition = 2.05m

Location of eye of impeller (x low) for minimum WL and minimum water depth required to satisfy NPSEIR can be worked out as for (a) above.

The final value are tabulated in the table below.

Observations : Possible feasible choices, cost, damage, variation cost etc. are

- Double suction horizontal centrifugal pump with depth of excavation of 3.0m but added construction cost of pump house (and head well) which is required to be located at site of pump.
- 2/3 stage VV pump with depth of excavation of 4.325m but reduced construction cost of pump house which will be located above sump.
- Difference between efficiency of pumps a & b is very significant.

From observations and remarks it is seen that final choice is limited to either double suction horizontal centrifugal pump with pump house at site but with some risk of flood as H.L. is at RL. 10.50 m.GL = 8.25 m and pump house floor will be at RL. 8.5 m (approx).

2 or 3 stage VV pump with pump house above sump but with 1.25 m extra excavation.

Cost of two alternative will be almost at par. Considering flood risk, a alternative with VV pump is selected. In order to keep operating floor free from obstruction and pipe work, delivery is taken below floor level. The pump shall be self water lubricated.

5. SUMP DIMENSIONS

(a) Clearance between bottom of sump and lip of suction bellmouth,

$$C = (D/3) + 50 = (3/3) + 50 = 185.3 \text{ mm} \approx 185 \text{ mm}$$

(b) Distance between rim well and centre of bell mouth,

$$R = (3/4) + (3/4 \times 50) = 42.5 = 430 \text{ mm}$$

(c) Spacing between pumps

Desirable spacing between pumps is $2.5 D$ i.e. 1125 mm. However, since discharge pipe of headgear/discharge head has insulating stuffing box, pump bearing and flexible coupling would be approximately 3.5 times column pipe diameter i.e. 1500 mm. Keeping above 600 mm clearance spacing will be 2000 mm.

(d) Slope

As seen minimum depth of water required is 1.75m below maximum depth. To minimize excavation cost, permissible slope of 14 degree is taken. The shaft will connect upstream of pump at a distance equal to $3 D$ i.e. 1650 mm from pump center.

(i) Straight Approach

The portion under the pump will be flat from line of termination of slope upto shaft near false wall.

(ii) Rear False Wall

Size of base of discharge head will be 1100 mm i.e. 550 mm from center of pump whereas dimension B is 900 mm (max). Therefore, column and rear wall at pump will have to be located at least 1000 mm away from pump center keeping 300 mm margin for rail fastening, etc. Therefore, rear false wall is necessary at a distance of 400 mm from pump center. Top of false wall will be upto maximum water level.

(iii) Bellies / Dividing Walls

Dividing walls will be constructed between pumps to above ground surface. In all ends of each dividing wall shall be rounded. Front edge of dividing wall shall be in line with front edge of sector bellmouth. At rear end opening of 50-200 mm size shall be kept in line upto minimum WL. Top of dividing wall will be upto maximum WL.

5. SIZES OF IMPORTANT COMPONENTS/EQUIPMENT

(a) As calculated in 3 above

Column Pipe $\varnothing 80$ mm

Inlet bellmouth 550 mm

(b) Line shaft diameter using empirical formula

$$Kd^3 = \frac{\sum H^2}{5.01 \times 10^8}$$

Where f = Safe stress in Kg/cm²
 = 400 kg/cm² for FN 8/7 = 40 shaft
 d = 55.68 mm

Adding corrosion allowance of 3.4 mm

Minimum line shaft diameter = 59 mm

1. $\frac{1}{2} \times 100 = 50$ pages

2. $\frac{1}{3} \times 100 = 33 \frac{1}{3}$ pages

3. $\frac{1}{4} \times 100 = 25$ pages

4. $\frac{1}{5} \times 100 = 20$ pages

5. $\frac{1}{6} \times 100 = 16 \frac{2}{3}$ pages

6. $\frac{1}{7} \times 100 = 14 \frac{2}{7}$ pages

7. $\frac{1}{8} \times 100 = 12 \frac{1}{2}$ pages

8. $\frac{1}{9} \times 100 = 11 \frac{1}{9}$ pages

9. $\frac{1}{10} \times 100 = 10$ pages

10. $\frac{1}{11} \times 100 = 9 \frac{1}{11}$ pages

11. $\frac{1}{12} \times 100 = 8 \frac{1}{3}$ pages

12. $\frac{1}{13} \times 100 = 7 \frac{6}{13}$ pages

13. $\frac{1}{14} \times 100 = 7 \frac{1}{7}$ pages

14. $\frac{1}{15} \times 100 = 6 \frac{2}{3}$ pages

15. $\frac{1}{16} \times 100 = 6 \frac{1}{4}$ pages

16. $\frac{1}{17} \times 100 = 5 \frac{10}{17}$ pages

17. $\frac{1}{18} \times 100 = 5 \frac{5}{9}$ pages

18. $\frac{1}{19} \times 100 = 5 \frac{5}{19}$ pages

19. $\frac{1}{20} \times 100 = 5$ pages

20. $\frac{1}{21} \times 100 = 4 \frac{8}{21}$ pages

21. $\frac{1}{22} \times 100 = 4 \frac{4}{11}$ pages

22. $\frac{1}{23} \times 100 = 4 \frac{8}{23}$ pages

23. $\frac{1}{24} \times 100 = 4 \frac{1}{3}$ pages

24. $\frac{1}{25} \times 100 = 4$ pages

25. $\frac{1}{26} \times 100 = 3 \frac{11}{13}$ pages

26. $\frac{1}{27} \times 100 = 3 \frac{11}{9}$ pages

27. $\frac{1}{28} \times 100 = 3 \frac{5}{7}$ pages

28. $\frac{1}{29} \times 100 = 3 \frac{11}{29}$ pages

29. $\frac{1}{30} \times 100 = 3 \frac{1}{3}$ pages

30. $\frac{1}{31} \times 100 = 3 \frac{10}{31}$ pages

$\frac{1}{2} \frac{d}{dt} \left(\frac{1}{2} \frac{d^2 x}{dt^2} \right)$
 $\frac{1}{2} \frac{d}{dt} \left(\frac{1}{2} \frac{d^2 x}{dt^2} \right)$

(ii) **Steady state value**

For steady state value, $\frac{d^2 x}{dt^2} = 0$ and $\frac{dx}{dt} = 0$
 $\frac{1}{2} \frac{d}{dt} \left(\frac{1}{2} \frac{d^2 x}{dt^2} \right) = 0$

$\frac{1}{2} \frac{d}{dt} \left(\frac{1}{2} \frac{d^2 x}{dt^2} \right) = 0$
 $\frac{1}{2} \frac{d}{dt} \left(\frac{1}{2} \frac{d^2 x}{dt^2} \right) = 0$

$\frac{1}{2} \frac{d}{dt} \left(\frac{1}{2} \frac{d^2 x}{dt^2} \right) = 0$
 $\frac{1}{2} \frac{d}{dt} \left(\frac{1}{2} \frac{d^2 x}{dt^2} \right) = 0$

$\frac{1}{2} \frac{d}{dt} \left(\frac{1}{2} \frac{d^2 x}{dt^2} \right) = 0$
 $\frac{1}{2} \frac{d}{dt} \left(\frac{1}{2} \frac{d^2 x}{dt^2} \right) = 0$
 $\frac{1}{2} \frac{d}{dt} \left(\frac{1}{2} \frac{d^2 x}{dt^2} \right) = 0$

$\frac{1}{2} \frac{d}{dt} \left(\frac{1}{2} \frac{d^2 x}{dt^2} \right) = 0$

$\frac{1}{2} \frac{d}{dt} \left(\frac{1}{2} \frac{d^2 x}{dt^2} \right) = 0$

$\frac{1}{2} \frac{d}{dt} \left(\frac{1}{2} \frac{d^2 x}{dt^2} \right) = 0$

$\frac{1}{2} \frac{d}{dt} \left(\frac{1}{2} \frac{d^2 x}{dt^2} \right) = 0$

$\frac{1}{2} \frac{d}{dt} \left(\frac{1}{2} \frac{d^2 x}{dt^2} \right) = 0$

$\frac{1}{2} \frac{d}{dt} \left(\frac{1}{2} \frac{d^2 x}{dt^2} \right) = 0$

(iii) **Transient response**

$\frac{1}{2} \frac{d}{dt} \left(\frac{1}{2} \frac{d^2 x}{dt^2} \right) = 0$

$\frac{1}{2} \frac{d}{dt} \left(\frac{1}{2} \frac{d^2 x}{dt^2} \right) = 0$

$\frac{1}{2} \frac{d}{dt} \left(\frac{1}{2} \frac{d^2 x}{dt^2} \right) = 0$

(iv) **Steady state value**

For steady state value, $\frac{d^2 x}{dt^2} = 0$ and $\frac{dx}{dt} = 0$
 $\frac{1}{2} \frac{d}{dt} \left(\frac{1}{2} \frac{d^2 x}{dt^2} \right) = 0$

$\frac{1}{2} \frac{d}{dt} \left(\frac{1}{2} \frac{d^2 x}{dt^2} \right) = 0$
 $\frac{1}{2} \frac{d}{dt} \left(\frac{1}{2} \frac{d^2 x}{dt^2} \right) = 0$

Table Showing The Various Alternatives

Sl. No.	Type	No.	Number of stages	Speed (RPM)	Efficiency		Suction Head (m)	Discharge Head (m)	Depth of excavation (m)	Total length of tunnel (m)	Remarks
					η_v	η_o					
1	Centrifugal	1	Single	1450	178.54	0.87	2.31	1.525	3.775	3.775	Excavation depth 3.775
2	VF	1	Single	1450	158.52	0.87	1.875	1.075	2.95	2.95	Excavation depth 2.95
3	Centrifugal	2	Double	1450	157.54	0.88	2.37	1.750	3.12	3.750	Not required extra excavation
4	VF	2	Single	1450	230.25	0.91	2.05	3.075	3.57	3.57	Excavation depth 3.57
5	VF	3	Single	1450	341.00	0.91	1.95	3.775	3.025	3.025	Excavation depth 3.025
6	VF	4	Single	1450	500.00	0.91	1.85	3.775	2.925	2.925	Excavation depth 2.925

Note: 1) VF is not considered further as pump with 10% slip is not available.
 2) η_v does not consider head required.
 3) η_o does not consider H.P. permissible.

APPENDIX 13.1

RECOMMENDED MINIMUM OPERATION AND MAINTENANCE STAFF PATTERN SURFACE SOURCE: TYPICAL STAFF PATTERN (UPTO 5 MLD SYSTEM) WITH CONVENTIONAL TREATMENTS

System component	1	2	3	4	5	6	7
1. Inlet works	Pump house	Raw water rising main	Treatment tanks and clear water pump	Clear water rising main	Settling reservoir	Clearing main	Dist. main
2. No. of operators/staff			1				
3. Supervisor/In-charge							
4. Operator/Staff							
5. Assistant Supervisor/Staff Manager							
6. Assistant Supervisor/Staff Manager							
7. Operator							

The following information is provided for the purpose of illustrating the use of the system. It is not intended to be a complete description of the system.

The system is designed to provide a means for the user to interact with the system. The user can interact with the system through the use of a keyboard and a mouse. The system is designed to be user-friendly and easy to use.

The system is designed to be flexible and adaptable. It can be used in a variety of environments and can be customized to meet the needs of the user.

The system is designed to be secure and reliable. It uses a variety of security measures to protect the user's data and information.

The system is designed to be efficient and effective. It provides a means for the user to interact with the system in a way that is both efficient and effective.

The system is designed to be easy to learn and use. It provides a means for the user to interact with the system in a way that is both easy to learn and use.

The system is designed to be user-friendly and easy to use. It provides a means for the user to interact with the system in a way that is both user-friendly and easy to use.

District and system		1	2	3	4	5	6	7	8
Code	System	Operator	Raw water operator	Treatment operator and clear water pump	Quality control operator	Electrician	Control room	Control room	Security guard
1	De patta Purva	1	1 for every shift	3	1	1	1	1	1 for every shift
2	De patta Medani			1					
3	Watchman	1		1			1	1	

Note: 1. The above staffing pattern does not include personnel for billing, collection and accounting for water charges.

2. Above staffing pattern includes the operating staff required for one shift in a week for staff 5 in the adjustments that need to be made to cover personnel for any leave and other contingencies.

3. To ease the total length of the period, it is suggested that shift 7 and 8 are helped, but it could be dispensed.

APPENDIX B

RECOMMENDED MINIMUM OPERATION AND MAINTENANCE START PATTERN SCHEDULE
 SCHEDULE 1: TYPICAL START PATTERN FOR 25 TO 50 MHD SYSTEMS WITH CONVENTIONAL
 TREATMENT

System Component	1	2	3	4	5	6	7
Component Name	Plant Start	Power Shutdown	Normal Start and Shutdown	Overhaul Shutdown	Plant Shutdown	Overhaul Start	Plant Shutdown
1. Reactor							
2. Steam Generator							
3. Turbine							
4. Condenser							
5. Feedwater System							
6. Cooling Water System							
7. Air System							
8. Fuel System							
9. Control System							
10. Instrumentation							
11. Electrical System							
12. Piping							
13. Structural							
14. Safety System							
15. Auxiliary Systems							

Year	Population	Area	Population Density	Population Growth	Population Change	Population Change (%)	Population Change (per 1000)
1990	1000000	1000000	1000	1000000	1000000	100%	1000
2000	1100000	1000000	1100	1100000	1000000	110%	1100
2010	1200000	1000000	1200	1200000	1000000	120%	1200
2020	1300000	1000000	1300	1300000	1000000	130%	1300

Note: 1. The data is for the year 2020. 2. The data is for the year 2020. 3. The data is for the year 2020. 4. The data is for the year 2020. 5. The data is for the year 2020. 6. The data is for the year 2020. 7. The data is for the year 2020. 8. The data is for the year 2020. 9. The data is for the year 2020. 10. The data is for the year 2020.

APPENDIX 134

RECOMMENDED MINIMUM OPERATION AND MAINTENANCE STAFF PATTERNS SURFACE SOURCE TYPICAL STAFF PATTERNS (FOR 50 TO 75 MGD SYSTEM) WITH CONVENTIONAL TREATMENTS

Plant Component	1	2	3	4	5	6	7
City Office Job	Plant Towers	Raw water maintenance	In-plant works and laboratory staff	Clear water operation	Service wastewater	Sludge plant	Outside staff
1. No. of days of staff							
2. Supervisor (not Manager) (1/1)			1				
3. Supervisor (not Manager) (1/1)			1				
4. Assistant Factory (not Labor Manager)			1				
5. Operator			7				

Year	Country	Population (millions)	Per capita income (US\$)	Life expectancy (years)	Health expenditure (US\$ per person)	Health expenditure (% of GDP)	Health expenditure (% of total health expenditure)
1990	USA	248	10,000	75	1,000	1.5	100
1990	France	58	10,000	75	1,000	1.5	100
1990	Germany	61	10,000	75	1,000	1.5	100
1990	Japan	123	10,000	75	1,000	1.5	100
1990	UK	58	10,000	75	1,000	1.5	100
1990	Canada	31	10,000	75	1,000	1.5	100
1990	Italy	58	10,000	75	1,000	1.5	100
1990	Spain	40	10,000	75	1,000	1.5	100
1990	Sweden	8	10,000	75	1,000	1.5	100
1990	Norway	4	10,000	75	1,000	1.5	100
1990	Denmark	5	10,000	75	1,000	1.5	100
1990	Netherlands	16	10,000	75	1,000	1.5	100
1990	Australia	18	10,000	75	1,000	1.5	100
1990	South Korea	40	2,000	70	100	0.5	100
1990	China	1,100	200	65	10	0.05	100
1990	India	800	100	60	5	0.02	100
1990	Brazil	150	1,000	65	50	0.5	100
1990	Mexico	90	1,000	65	50	0.5	100
1990	Argentina	30	1,000	65	50	0.5	100
1990	Colombia	30	1,000	65	50	0.5	100
1990	Venezuela	25	1,000	65	50	0.5	100
1990	Chile	15	1,000	65	50	0.5	100
1990	Peru	25	1,000	65	50	0.5	100
1990	Ecuador	10	1,000	65	50	0.5	100
1990	Bolivia	8	1,000	65	50	0.5	100
1990	Paraguay	6	1,000	65	50	0.5	100
1990	Uruguay	3	1,000	65	50	0.5	100
1990	Cuba	11	1,000	75	100	1.0	100
1990	USSR	250	1,000	70	100	1.0	100
1990	Poland	35	1,000	70	100	1.0	100
1990	Czech Republic	10	1,000	70	100	1.0	100
1990	Slovakia	5	1,000	70	100	1.0	100
1990	Hungary	10	1,000	70	100	1.0	100
1990	Romania	22	1,000	70	100	1.0	100
1990	Bulgaria	9	1,000	70	100	1.0	100
1990	Greece	11	1,000	75	100	1.0	100
1990	Turkey	50	1,000	65	100	1.0	100
1990	Israel	5	1,000	75	100	1.0	100
1990	South Africa	25	1,000	65	100	1.0	100
1990	South Africa	25	1,000	65	100	1.0	100
1990	South Africa	25	1,000	65	100	1.0	100

Source: World Bank, *World Development Report 1993*, Table 1.1. *World Development Indicators*, 1993.

1. The data are for the year 1990. The population figures are in millions. The per capita income figures are in US dollars. The life expectancy figures are in years. The health expenditure figures are in US dollars per person. The health expenditure as a percentage of GDP and as a percentage of total health expenditure are in percent.

2. The data are for the year 1990. The population figures are in millions. The per capita income figures are in US dollars. The life expectancy figures are in years. The health expenditure figures are in US dollars per person. The health expenditure as a percentage of GDP and as a percentage of total health expenditure are in percent.

3. The data are for the year 1990. The population figures are in millions. The per capita income figures are in US dollars. The life expectancy figures are in years. The health expenditure figures are in US dollars per person. The health expenditure as a percentage of GDP and as a percentage of total health expenditure are in percent.

APPENDIX

REGISTRATION AND RESIDENTIAL OFFERATIONS AND SALES OF SECURITIES

PARTICULAR ASPECTS OF THE REGISTRATION

No. of Registrants	No. of Residential Offerings	No. of Securities Sold	Total Amount of Securities Sold
1. All Registrants	1,234	5,678	\$12,345,678
2. No. of Registrants	1,234	5,678	\$12,345,678
3. No. of Registrants	1,234	5,678	\$12,345,678
4. No. of Registrants	1,234	5,678	\$12,345,678
5. No. of Registrants	1,234	5,678	\$12,345,678
6. No. of Registrants	1,234	5,678	\$12,345,678
7. No. of Registrants	1,234	5,678	\$12,345,678
8. No. of Registrants	1,234	5,678	\$12,345,678
9. No. of Registrants	1,234	5,678	\$12,345,678
10. No. of Registrants	1,234	5,678	\$12,345,678

APPENDIX 11.6

RECOMMENDED MINIMUM STAFFING PATTERNS FOR FEDERAL COURT OF APPEALS AND
 COURTS OF APPEALS OF DISTRICTS OF COLUMBIA AND
 DISTRICT COURTS OF DISTRICT OF COLUMBIA

Staffing Component	Full-time		Part-time	
	Minimum	Maximum	Minimum	Maximum
1. Chief Clerk	1	1	0	0
2. Clerks	1	1	0	0
3. Support Staff	1	1	0	0
4. Maintenance	1	1	0	0
5. Security	1	1	0	0
6. Janitorial	1	1	0	0
7. Information Technology	1	1	0	0
8. Office Management	1	1	0	0
9. Reception	1	1	0	0
10. Courtroom Services	1	1	0	0
11. Public Information	1	1	0	0
12. Administration	1	1	0	0
13. Finance	1	1	0	0
14. Human Resources	1	1	0	0
15. Legal Services	1	1	0	0
16. Other	1	1	0	0

Model	Number of variables	Number of parameters	Number of observations	Number of instruments	Number of excluded instruments	Number of excluded variables
1	1	1	1	1	0	0
2	2	2	2	2	0	0
3	3	3	3	3	0	0
4	4	4	4	4	0	0
5	5	5	5	5	0	0
6	6	6	6	6	0	0
7	7	7	7	7	0	0
8	8	8	8	8	0	0
9	9	9	9	9	0	0
10	10	10	10	10	0	0
11	11	11	11	11	0	0
12	12	12	12	12	0	0
13	13	13	13	13	0	0
14	14	14	14	14	0	0
15	15	15	15	15	0	0
16	16	16	16	16	0	0
17	17	17	17	17	0	0
18	18	18	18	18	0	0
19	19	19	19	19	0	0
20	20	20	20	20	0	0
21	21	21	21	21	0	0
22	22	22	22	22	0	0
23	23	23	23	23	0	0
24	24	24	24	24	0	0
25	25	25	25	25	0	0
26	26	26	26	26	0	0
27	27	27	27	27	0	0
28	28	28	28	28	0	0
29	29	29	29	29	0	0
30	30	30	30	30	0	0
31	31	31	31	31	0	0
32	32	32	32	32	0	0
33	33	33	33	33	0	0
34	34	34	34	34	0	0
35	35	35	35	35	0	0
36	36	36	36	36	0	0
37	37	37	37	37	0	0
38	38	38	38	38	0	0
39	39	39	39	39	0	0
40	40	40	40	40	0	0
41	41	41	41	41	0	0
42	42	42	42	42	0	0
43	43	43	43	43	0	0
44	44	44	44	44	0	0
45	45	45	45	45	0	0
46	46	46	46	46	0	0
47	47	47	47	47	0	0
48	48	48	48	48	0	0
49	49	49	49	49	0	0
50	50	50	50	50	0	0
51	51	51	51	51	0	0
52	52	52	52	52	0	0
53	53	53	53	53	0	0
54	54	54	54	54	0	0
55	55	55	55	55	0	0
56	56	56	56	56	0	0
57	57	57	57	57	0	0
58	58	58	58	58	0	0
59	59	59	59	59	0	0
60	60	60	60	60	0	0
61	61	61	61	61	0	0
62	62	62	62	62	0	0
63	63	63	63	63	0	0
64	64	64	64	64	0	0
65	65	65	65	65	0	0
66	66	66	66	66	0	0
67	67	67	67	67	0	0
68	68	68	68	68	0	0
69	69	69	69	69	0	0
70	70	70	70	70	0	0
71	71	71	71	71	0	0
72	72	72	72	72	0	0
73	73	73	73	73	0	0
74	74	74	74	74	0	0
75	75	75	75	75	0	0
76	76	76	76	76	0	0
77	77	77	77	77	0	0
78	78	78	78	78	0	0
79	79	79	79	79	0	0
80	80	80	80	80	0	0
81	81	81	81	81	0	0
82	82	82	82	82	0	0
83	83	83	83	83	0	0
84	84	84	84	84	0	0
85	85	85	85	85	0	0
86	86	86	86	86	0	0
87	87	87	87	87	0	0
88	88	88	88	88	0	0
89	89	89	89	89	0	0
90	90	90	90	90	0	0
91	91	91	91	91	0	0
92	92	92	92	92	0	0
93	93	93	93	93	0	0
94	94	94	94	94	0	0
95	95	95	95	95	0	0
96	96	96	96	96	0	0
97	97	97	97	97	0	0
98	98	98	98	98	0	0
99	99	99	99	99	0	0
100	100	100	100	100	0	0

Note: (1) The number of variables is the number of variables in the model. (2) The number of parameters is the number of parameters in the model. (3) The number of observations is the number of observations in the model. (4) The number of instruments is the number of instruments in the model. (5) The number of excluded instruments is the number of excluded instruments in the model. (6) The number of excluded variables is the number of excluded variables in the model.

APPENDIX B7

RECOMMENDED MINIMUM STAFFING PATTERNS FOR OPERATION AND MAINTENANCE OF
 SOLAR THERMAL COLLECTOR FIELDS, HIGH-YIELDING TUBES/HEAT EXCHANGERS

System Configuration	1		2		3		4		5		6	
	Water Works		Temp. Control		Cleaning		General		Maintenance		Production	
	1	2	1	2	1	2	1	2	1	2	1	2
1. New Collector Field	1		1		1		1		1		1	
2. New Collector Field	1		1		1		1		1		1	
3. New Collector Field	1		1		1		1		1		1	
4. New Collector Field	1		1		1		1		1		1	
5. New Collector Field	1		1		1		1		1		1	
6. New Collector Field	1		1		1		1		1		1	
7. New Collector Field	1		1		1		1		1		1	
8. New Collector Field	1		1		1		1		1		1	
9. New Collector Field	1		1		1		1		1		1	
10. New Collector Field	1		1		1		1		1		1	
11. New Collector Field	1		1		1		1		1		1	
12. New Collector Field	1		1		1		1		1		1	
13. New Collector Field	1		1		1		1		1		1	
14. New Collector Field	1		1		1		1		1		1	
15. New Collector Field	1		1		1		1		1		1	
16. New Collector Field	1		1		1		1		1		1	
17. New Collector Field	1		1		1		1		1		1	
18. New Collector Field	1		1		1		1		1		1	
19. New Collector Field	1		1		1		1		1		1	
20. New Collector Field	1		1		1		1		1		1	
21. New Collector Field	1		1		1		1		1		1	
22. New Collector Field	1		1		1		1		1		1	
23. New Collector Field	1		1		1		1		1		1	
24. New Collector Field	1		1		1		1		1		1	
25. New Collector Field	1		1		1		1		1		1	
26. New Collector Field	1		1		1		1		1		1	
27. New Collector Field	1		1		1		1		1		1	
28. New Collector Field	1		1		1		1		1		1	
29. New Collector Field	1		1		1		1		1		1	
30. New Collector Field	1		1		1		1		1		1	
31. New Collector Field	1		1		1		1		1		1	
32. New Collector Field	1		1		1		1		1		1	
33. New Collector Field	1		1		1		1		1		1	
34. New Collector Field	1		1		1		1		1		1	
35. New Collector Field	1		1		1		1		1		1	
36. New Collector Field	1		1		1		1		1		1	
37. New Collector Field	1		1		1		1		1		1	
38. New Collector Field	1		1		1		1		1		1	
39. New Collector Field	1		1		1		1		1		1	
40. New Collector Field	1		1		1		1		1		1	
41. New Collector Field	1		1		1		1		1		1	
42. New Collector Field	1		1		1		1		1		1	
43. New Collector Field	1		1		1		1		1		1	
44. New Collector Field	1		1		1		1		1		1	
45. New Collector Field	1		1		1		1		1		1	
46. New Collector Field	1		1		1		1		1		1	
47. New Collector Field	1		1		1		1		1		1	
48. New Collector Field	1		1		1		1		1		1	
49. New Collector Field	1		1		1		1		1		1	
50. New Collector Field	1		1		1		1		1		1	

System component as per flow line		1	2	3	4	5	6
		Water Works	Pump House	Rising main	Service reservoir	Gravity main	Distribution system
		Less than 5 wells	5 wells & above				
Sl. No.	Category of staff						
2	Helpers/Helpers	-	-	1 (100%) (100/100)	12 (100%) (8/100)	-	1 (100%) (100)
5	Water meter Machinist	-	1 (100%) (5/100)	-	-	-	3 (100%) (100)
6	Check meter Watchman	-	-	1 (100%) (100)	-	1 (100%) (100)	-
7	Guard	-	-	-	-	-	-
8	City Engineer	-	-	-	-	-	-

- Note: 1. The above staffing norms are for the purpose of providing a rough estimate of the number of staff required.
 2. Staffing norms are subject to change as per the requirements of the project.
 3. The above norms are subject to change as per the requirements of the project.

APPENDIX 13.B

SCHEDULE OF PREVENTIVE MAINTENANCE
CLARIFLOCCULATORS & THEIR DRIVE

Sr. No.	Name of system or part to be checked	Maintenance to be carried out	Frequency (time interval at which inspection & maintenance to be done)	Remarks
1	Inflow of tank	Leakage/overflowing	One Month	
2	Reduction of level	Check the quantity of air level	Three Months	
3	Tilted drive mechanism	Check the oil pump drive motor	Three Months	
4	Vertical-lip Ring, Abutment	Check the oil, oil change, if oil is not present then oil change	Four Months	
5	Weld Joints	Check the joint of pipe between vessels & its supports etc.	Four Months	
6	Reduction of oil level	Check the oil level in support & foundation	Six Months	
7	Rubber type wheels Iron wheels	Check the wear & tear in operation of the pulleys	Six Months	More frequent in the old installation
8	M.C. Structure	Tightening of nut & bolts, replacement of broken parts	Year	
9	Lump Drive Mechanism	Check the oil, gear oil, oil change, steel balls, nut & washers etc.	One year	

APPENDIX 14.1

SUGGESTED STAFFING PATTERN FOR SUPERVISORY ENGINEERING DIVISION (WORKLOAD IS 200 LAKHS ANNUALLY 1988) AND FLUORINATION DIVISION (WORKLOAD IS 50 LAKHS ANNUALLY 1988) FOR CL & SW WATERWORKS

No.	Category of staff	Number	Other	Total
A) Engineering				
1	Ch. Engineer	1		1
2	Ch. Engineer (Sd.)			
3	Ch. Engineer (Sd.) (Asst.)	1		1
4	Asst. Engineer (Sd.)			
5	Ch. Engineer (Sd.)	1		1
6	Asst. Engineer (Sd.) (Asst.)	1		1
7	Inspector	1		1
8	Trainee			
B) Correspondence & Misc. Section				
9	Head Clerk	1		1
10	Senior Clerk	1		1
11	Junior Clerk (Asst.)	1		1
C) Accounts Section				
12	Senior Accountant	1		1
13	Junior Accountant	1		1
14	Store keeper	1		1
15	Assistant Store keeper			1
D) Class IV				
16	Peon	1		1
17	Classifieds	100	Asst. Insp.	100
			10	110

1. Preferably with degree in civil & elec. Engineering &

2. Excluding peon of classifieds.

APPENDIX B.2

REQUIREMENT OF STAFF FOR - O & M

1. Operation & maintenance	Revised fixed staffing pattern for operation & maintenance of water works for various operations systems as approved by M. E. J. in the department of Operation & Maintenance of water works
2. Water Billing	
3. Water Billing	
a. Meter & Bill	One person for 500 connections - the person will be in the same unit as the person that Bill's for
b. Bill Check	One person if possible has a reserve, with 6 months
4. Maintenance - Streets	One person for 12000 sq ft of paved streets - 1.0
5. Water works maintenance	same as above one full time - other part time needed
6. Meter - repair	One person every 12 months per the unit to be repaired
7. Meter - service repairs	1.0
8. Emergency Response	to cover emergency situations, per contract to be provided in Appendix B.5

APPENDIX 18.1

MINIMUM STAFF RECOMMENDED FOR WATER WORKS LABORATORIES

	Volume (liters)	Operator
(i) Water Analyst (Minimum)	1	1
(ii) Water Analyst (Maximum)	1	1
(iii) Water Analyst	1	1
(iv) Laboratory Technician	1	1
(v) Output cum clerk	1	1
(vi) Sample takers	1	1
(vii) Laboratory cleaners	1	2

APPENDIX 582

DETAILS TO BE SUPPLIED WITH THE SAMPLES

1. Name and address of the responsible authority
2. Name and address of the collector and district
3. Name of the complainant
4. Name of the complainant's place of residence (village, town, etc.)
5. Date, place and time when the sample was taken
6. Location of the area of collection and particulars of receipt (if any)
7. Description of the water supply system, including the source of water (rainfall or under any other name) if any
8. Any other details regarding the water supply. If any, the name of the complainant, the name of the village, and of the village, city, ponds, or tanks, or other water supply system, and the locality and other particulars of the location
9. Name of the public or individual and the details of the ownership and position of the property
10. Name of the well or other well
 - (a) Name of the well, name of the owner, etc.
 - (b) Location of the well, name of the owner, etc.
 - (c) Name of the village, town, and locality, which construction and relative to the property, etc.
 - (d) Name of the owner of the property, etc.
 - (e) Details of the nature of the water supply, etc.
 - (f) Details of the well, etc.
11. Whether the water is from any other source, if any, and remains clear or exposed to any contamination or pollution, etc.
12. If from any other source
 - (a) Name of the source and whether the water is from any other source
 - (b) Details of the source, etc.
 - (c) Details of the nature of the water supply, etc.

13. If in a lake, important macroinvertebrates
 - (a) How 'applied hydrology' is to be done.
 - (b) Name of instruments, where necessary to be used.
 - (c) Nature of extent of water body.
14. State 4 number of services to be given
 - (a) Whether open or closed.
 - (b) How often extended to use of the drainage.
 - (c) Date of the opening.
15. Sketch of hydraulic and sewerage distribution system.
16. Name of principle and supports.
 - (a) Population area.
 - (b) Any other details.

NOTE:

(a) positive and (b) negative effect of the water.
 (c) to be used for extending the water.

END

APPENDIX 15.3

SPECIMEN FORM FOR SHORT PHYSICAL AND CHEMICAL EXAMINATION

Name and Address

of the Laboratory

Name and Address

of Donor

Sample No.

Date

City/Town/Village/Post Office

State/Union Territory

Hospital/Institution/Referral Agency

Referring Medical Officer

Dr. _____

Department of Examination

Examination with

1. _____

2. _____

3. _____

4. _____

Date of collection of sample		1	2	3	4	5
Physical		Expressed as				
1	Temperature	°C				
2	Specific gravity	G ₂₀ ^4				
3	Colour	_____				
4	Taste & odour	_____				
Chemical						
5	pH	_____				
6	Conductivity	Micro mhos/cm				

1. Definition: A function $f: X \rightarrow Y$ is called a linear map if it satisfies the following two conditions:

$$f(x + y) = f(x) + f(y)$$

$$f(\alpha x) = \alpha f(x)$$

for all $x, y \in X$ and $\alpha \in \mathbb{R}$.

2. Properties:

- The zero map $f(x) = 0$ is a linear map.
- The identity map $f(x) = x$ is a linear map.
- The sum of two linear maps is a linear map.
- The scalar multiple of a linear map is a linear map.
- The composition of two linear maps is a linear map.

3. Kernel: The kernel of a linear map $f: X \rightarrow Y$ is the set of all $x \in X$ such that $f(x) = 0$.

4. Image: The image of a linear map $f: X \rightarrow Y$ is the set of all $y \in Y$ such that $y = f(x)$ for some $x \in X$.

5. Null Space: The null space of a linear map $f: X \rightarrow Y$ is the kernel of f .

6. Range: The range of a linear map $f: X \rightarrow Y$ is the image of f .

7. Linear Independence: A set of vectors $\{v_1, v_2, \dots, v_n\}$ in a vector space V is called linearly independent if the only solution to the equation

$$\alpha_1 v_1 + \alpha_2 v_2 + \dots + \alpha_n v_n = 0$$

is $\alpha_1 = \alpha_2 = \dots = \alpha_n = 0$.

8. Linear Dependence: A set of vectors $\{v_1, v_2, \dots, v_n\}$ in a vector space V is called linearly dependent if there exist scalars $\alpha_1, \alpha_2, \dots, \alpha_n$ not all zero such that

$$\alpha_1 v_1 + \alpha_2 v_2 + \dots + \alpha_n v_n = 0$$

9. Span: The span of a set of vectors $\{v_1, v_2, \dots, v_n\}$ in a vector space V is the set of all vectors in V that can be written as a linear combination of v_1, v_2, \dots, v_n .

10. Subspace: A subset W of a vector space V is called a subspace if it is a vector space in its own right.

11. Direct Sum: If U and V are subspaces of a vector space W such that $W = U + V$ and $U \cap V = \{0\}$, then W is called the direct sum of U and V .

12. Quotient Space: If U is a subspace of a vector space V , then the quotient space V/U is the set of all cosets of U in V .

13. Isomorphism: Two vector spaces V and W are called isomorphic if there exists a linear map $f: V \rightarrow W$ which is a bijection.

APPENDIX

STANDARD FORMS FOR SAMPLES OF TECHNICAL, CHEMICAL, AND BIOLOGICAL ANALYSIS

1. Sample No.

2. Name of Sample

3. Name of Supplier or Manufacturer

4. Lot No.

5.

6. Name of Analytical Laboratory

7. Date of Test

8. Name of Analyst or Operator

9. Test Results (See Table)

10. Name of Tester or Recorder

11. Name of Director or Head of Laboratory

12. Remarks

13. Name of Inspector

14. Name of Operator

15. Name of Analyst or Recorder

16. Name of Director

Name of Sample	Lot No.	Date of Test	Name of Analyst	Name of Recorder
1. Sample No.	2. Name of Sample	3. Name of Supplier or Manufacturer	4. Lot No.	5. Name of Analytical Laboratory
6. Name of Tester or Recorder	7. Date of Test	8. Name of Analyst or Operator	9. Test Results (See Table)	10. Name of Tester or Recorder
11. Name of Director or Head of Laboratory	12. Remarks	13. Name of Inspector	14. Name of Operator	15. Name of Analyst or Recorder
16. Name of Director				

Table of Contents		1	2	3	4
Table of Contents		1	2	3	4
26	Aluminum Nitrate	(13)	Al(NO ₃) ₃		
27	Amalgams of Bronze	(14)	Ag ₂ Sn		
	a) Vahlburg product				
28	Ammonium Dichromate	(15)	(NH ₄) ₂ Cr ₂ O ₇		
29	Ammonium Dichromate	(15)	(NH ₄) ₂ Cr ₂ O ₇		
31	Ammonium Sulfate	(16)	(NH ₄) ₂ SO ₄		
32	Antimony	(16)	Sb		
33	Phenolic	(16)	Phenol		
	a) Antiseptics				
34	Synthetic detergents	(16)	(C ₁₂ H ₂₅) ₂ NH ₂ SO ₃ Na		
35	Asbestos	(16)	As		
36	Asenic	(16)	As		
37	Cadmium	(16)	Cd		
38	Hexavalent	(16)	Cr ⁶⁺		
	Chromates				
39	Chromium	(16)	Cr		
40	Cyanide	(16)	CN ⁻		
41	Selenic	(16)	Se		
42	Zinc	(16)	Zn		
43	Mercury	(16)	Hg		
44	Cellulose	(16)	C ₆ H ₁₀ O ₅		
45	Cellulose	(16)	C ₆ H ₁₀ O ₅		
	Acetate				
	Hydroxyethyl				
46	Radical cation	(16)	RC ⁺		
	a) Cross alpha				
	Action				
	b) Cross beta				
	Action				

Time of collection: _____

MOLECULAR

47 Total count of plankton: _____

Comments:

Date: _____

APPENDIX 1
 SPECIFICATION FOR MATERIALS, PART 1 (MATERIALS)
 DRAWING 11115-00-000-100

Material Name:

Chemical Symbol:

Material Condition: Annealed Cold Rolled Hot Rolled Other _____

Quantity:

Quantity:

Material Specification:

Material Specification:

Material Specification:

Remarks:

1. _____

2. _____

3. _____

Material Name: _____

Material Condition: _____

Quantity: _____

Quantity:

Quantity:

Quantity: _____

Quantity:

Quantity:

Quantity:

Quantity:

Quantity: _____

1. The following are the types of the following elements. Give the number of the element.

QUESTION 138

QUESTION 138: ELEMENTS OF THE PERIODIC TABLE

1. The element is Ca (Calcium) (20)
2. The element is Mg (Magnesium) (12)
3. The element is Fe (Iron) (26)
4. The element is Cu (Copper) (29)
5. The element is Zn (Zinc) (30)
6. The element is Al (Aluminum) (13)
7. The element is Si (Silicon) (14)
8. The element is P (Phosphorus) (15)
9. The element is S (Sulfur) (16)
10. The element is Cl (Chlorine) (17)
11. The element is Br (Bromine) (35)
12. The element is I (Iodine) (53)
13. The element is F (Fluorine) (9)
14. The element is O (Oxygen) (8)
15. The element is N (Nitrogen) (7)
16. The element is C (Carbon) (6)
17. The element is H (Hydrogen) (1)
18. The element is Li (Lithium) (3)
19. The element is Na (Sodium) (11)
20. The element is K (Potassium) (19)
21. The element is Rb (Rubidium) (37)
22. The element is Cs (Cesium) (55)
23. The element is Fr (Francium) (87)
24. The element is Ba (Barium) (56)
25. The element is Sr (Strontium) (38)
26. The element is Ca (Calcium) (20)
27. The element is Mg (Magnesium) (12)
28. The element is Be (Beryllium) (4)
29. The element is Li (Lithium) (3)
30. The element is H (Hydrogen) (1)

QUESTION 139: ELEMENTS OF THE PERIODIC TABLE

1. The element is Ca (Calcium) (20)
2. The element is Mg (Magnesium) (12)
3. The element is Fe (Iron) (26)
4. The element is Cu (Copper) (29)
5. The element is Zn (Zinc) (30)
6. The element is Al (Aluminum) (13)
7. The element is Si (Silicon) (14)
8. The element is P (Phosphorus) (15)
9. The element is S (Sulfur) (16)
10. The element is Cl (Chlorine) (17)
11. The element is Br (Bromine) (35)
12. The element is I (Iodine) (53)
13. The element is F (Fluorine) (9)
14. The element is O (Oxygen) (8)
15. The element is N (Nitrogen) (7)
16. The element is C (Carbon) (6)
17. The element is H (Hydrogen) (1)
18. The element is Li (Lithium) (3)
19. The element is Na (Sodium) (11)
20. The element is K (Potassium) (19)
21. The element is Rb (Rubidium) (37)
22. The element is Cs (Cesium) (55)
23. The element is Fr (Francium) (87)
24. The element is Ba (Barium) (56)
25. The element is Sr (Strontium) (38)
26. The element is Ca (Calcium) (20)
27. The element is Mg (Magnesium) (12)
28. The element is Be (Beryllium) (4)
29. The element is Li (Lithium) (3)
30. The element is H (Hydrogen) (1)

APPENDIX I

TABLE I. **PHYSICAL QUANTITIES AND THEIR DIMENSIONS**

No.	Quantity	Dimension	Dimension	Dimension
1	Length	L	L	L
2	Area	L^2	L^2	L^2
3	Volume	L^3	L^3	L^3
4	Velocity	$L T^{-1}$	$L T^{-1}$	$L T^{-1}$
5	Acceleration	$L T^{-2}$	$L T^{-2}$	$L T^{-2}$
6	Force	$M L T^{-2}$	$M L T^{-2}$	$M L T^{-2}$
7	Pressure	$M L^{-1} T^{-2}$	$M L^{-1} T^{-2}$	$M L^{-1} T^{-2}$
8	Energy	$M L^2 T^{-2}$	$M L^2 T^{-2}$	$M L^2 T^{-2}$
9	Power	$M L^2 T^{-3}$	$M L^2 T^{-3}$	$M L^2 T^{-3}$
10	Angular displacement	L	L	L
11	Angular velocity	$L T^{-1}$	$L T^{-1}$	$L T^{-1}$
12	Angular acceleration	$L T^{-2}$	$L T^{-2}$	$L T^{-2}$
13	Angle	L	L	L
14	Mass	M	M	M
15	Time	T	T	T
16	Temperature	θ	θ	θ
17	Temperature difference	θ	θ	θ
18	Temperature coefficient	θ^{-1}	θ^{-1}	θ^{-1}
19	Temperature coefficient of resistance	θ^{-1}	θ^{-1}	θ^{-1}
20	Temperature coefficient of expansion	θ^{-1}	θ^{-1}	θ^{-1}
21	Temperature coefficient of resistance	θ^{-1}	θ^{-1}	θ^{-1}
22	Temperature coefficient of resistance	θ^{-1}	θ^{-1}	θ^{-1}
23	Temperature coefficient of resistance	θ^{-1}	θ^{-1}	θ^{-1}
24	Temperature coefficient of resistance	θ^{-1}	θ^{-1}	θ^{-1}
25	Temperature coefficient of resistance	θ^{-1}	θ^{-1}	θ^{-1}
26	Temperature coefficient of resistance	θ^{-1}	θ^{-1}	θ^{-1}
27	Temperature coefficient of resistance	θ^{-1}	θ^{-1}	θ^{-1}
28	Temperature coefficient of resistance	θ^{-1}	θ^{-1}	θ^{-1}
29	Temperature coefficient of resistance	θ^{-1}	θ^{-1}	θ^{-1}
30	Temperature coefficient of resistance	θ^{-1}	θ^{-1}	θ^{-1}

APPENDIX 2.1

AVERAGE PURCHASE PRICE PER UNIT (APU) BY FUND

Year	Global Money Fund	North America Fund	Global Fund	US & Int'l Fund	Asia Fund	Domestic Value Fund
1983-84			1.000		1.000	1.000
1984-85			1.000		1.000	1.000
1985-86	1.000	1.000	1.000	1.000	1.000	1.000
1986-87	1.000	1.000	1.000	1.000	1.000	1.000
1987-88	1.000	1.000	1.000	1.000	1.000	1.000
1988-89	1.000	1.000	1.000	1.000	1.000	1.000
1989-90	1.000	1.000	1.000	1.000	1.000	1.000
1990-91	1.000	1.000	1.000	1.000	1.000	1.000
1991-92	1.000	1.000	1.000	1.000	1.000	1.000
1992-93	1.000	1.000	1.000	1.000	1.000	1.000
1993-94	1.000	1.000	1.000	1.000	1.000	1.000
1994-95	1.000	1.000	1.000	1.000	1.000	1.000
1995-96	1.000	1.000	1.000	1.000	1.000	1.000
1996-97	1.000	1.000	1.000	1.000	1.000	1.000
1997-98	1.000	1.000	1.000	1.000	1.000	1.000
1998-99	1.000	1.000	1.000	1.000	1.000	1.000
1999-00	1.000	1.000	1.000	1.000	1.000	1.000
2000-01	1.000	1.000	1.000	1.000	1.000	1.000
2001-02	1.000	1.000	1.000	1.000	1.000	1.000
2002-03	1.000	1.000	1.000	1.000	1.000	1.000
2003-04	1.000	1.000	1.000	1.000	1.000	1.000
2004-05	1.000	1.000	1.000	1.000	1.000	1.000
2005-06	1.000	1.000	1.000	1.000	1.000	1.000
2006-07	1.000	1.000	1.000	1.000	1.000	1.000
2007-08	1.000	1.000	1.000	1.000	1.000	1.000
2008-09	1.000	1.000	1.000	1.000	1.000	1.000
2009-10	1.000	1.000	1.000	1.000	1.000	1.000
2010-11	1.000	1.000	1.000	1.000	1.000	1.000
2011-12	1.000	1.000	1.000	1.000	1.000	1.000
2012-13	1.000	1.000	1.000	1.000	1.000	1.000
2013-14	1.000	1.000	1.000	1.000	1.000	1.000
2014-15	1.000	1.000	1.000	1.000	1.000	1.000
2015-16	1.000	1.000	1.000	1.000	1.000	1.000
2016-17	1.000	1.000	1.000	1.000	1.000	1.000
2017-18	1.000	1.000	1.000	1.000	1.000	1.000
2018-19	1.000	1.000	1.000	1.000	1.000	1.000
2019-20	1.000	1.000	1.000	1.000	1.000	1.000
2020-21	1.000	1.000	1.000	1.000	1.000	1.000
2021-22	1.000	1.000	1.000	1.000	1.000	1.000
2022-23	1.000	1.000	1.000	1.000	1.000	1.000
2023-24	1.000	1.000	1.000	1.000	1.000	1.000
2024-25	1.000	1.000	1.000	1.000	1.000	1.000
2025-26	1.000	1.000	1.000	1.000	1.000	1.000
2026-27	1.000	1.000	1.000	1.000	1.000	1.000
2027-28	1.000	1.000	1.000	1.000	1.000	1.000
2028-29	1.000	1.000	1.000	1.000	1.000	1.000
2029-30	1.000	1.000	1.000	1.000	1.000	1.000
2030-31	1.000	1.000	1.000	1.000	1.000	1.000
2031-32	1.000	1.000	1.000	1.000	1.000	1.000
2032-33	1.000	1.000	1.000	1.000	1.000	1.000
2033-34	1.000	1.000	1.000	1.000	1.000	1.000
2034-35	1.000	1.000	1.000	1.000	1.000	1.000
2035-36	1.000	1.000	1.000	1.000	1.000	1.000
2036-37	1.000	1.000	1.000	1.000	1.000	1.000
2037-38	1.000	1.000	1.000	1.000	1.000	1.000
2038-39	1.000	1.000	1.000	1.000	1.000	1.000
2039-40	1.000	1.000	1.000	1.000	1.000	1.000
2040-41	1.000	1.000	1.000	1.000	1.000	1.000
2041-42	1.000	1.000	1.000	1.000	1.000	1.000
2042-43	1.000	1.000	1.000	1.000	1.000	1.000
2043-44	1.000	1.000	1.000	1.000	1.000	1.000
2044-45	1.000	1.000	1.000	1.000	1.000	1.000
2045-46	1.000	1.000	1.000	1.000	1.000	1.000
2046-47	1.000	1.000	1.000	1.000	1.000	1.000
2047-48	1.000	1.000	1.000	1.000	1.000	1.000
2048-49	1.000	1.000	1.000	1.000	1.000	1.000
2049-50	1.000	1.000	1.000	1.000	1.000	1.000
2050-51	1.000	1.000	1.000	1.000	1.000	1.000
2051-52	1.000	1.000	1.000	1.000	1.000	1.000
2052-53	1.000	1.000	1.000	1.000	1.000	1.000
2053-54	1.000	1.000	1.000	1.000	1.000	1.000
2054-55	1.000	1.000	1.000	1.000	1.000	1.000
2055-56	1.000	1.000	1.000	1.000	1.000	1.000
2056-57	1.000	1.000	1.000	1.000	1.000	1.000
2057-58	1.000	1.000	1.000	1.000	1.000	1.000
2058-59	1.000	1.000	1.000	1.000	1.000	1.000
2059-60	1.000	1.000	1.000	1.000	1.000	1.000
2060-61	1.000	1.000	1.000	1.000	1.000	1.000
2061-62	1.000	1.000	1.000	1.000	1.000	1.000
2062-63	1.000	1.000	1.000	1.000	1.000	1.000
2063-64	1.000	1.000	1.000	1.000	1.000	1.000
2064-65	1.000	1.000	1.000	1.000	1.000	1.000
2065-66	1.000	1.000	1.000	1.000	1.000	1.000
2066-67	1.000	1.000	1.000	1.000	1.000	1.000
2067-68	1.000	1.000	1.000	1.000	1.000	1.000
2068-69	1.000	1.000	1.000	1.000	1.000	1.000
2069-70	1.000	1.000	1.000	1.000	1.000	1.000
2070-71	1.000	1.000	1.000	1.000	1.000	1.000
2071-72	1.000	1.000	1.000	1.000	1.000	1.000
2072-73	1.000	1.000	1.000	1.000	1.000	1.000
2073-74	1.000	1.000	1.000	1.000	1.000	1.000
2074-75	1.000	1.000	1.000	1.000	1.000	1.000
2075-76	1.000	1.000	1.000	1.000	1.000	1.000
2076-77	1.000	1.000	1.000	1.000	1.000	1.000
2077-78	1.000	1.000	1.000	1.000	1.000	1.000
2078-79	1.000	1.000	1.000	1.000	1.000	1.000
2079-80	1.000	1.000	1.000	1.000	1.000	1.000
2080-81	1.000	1.000	1.000	1.000	1.000	1.000
2081-82	1.000	1.000	1.000	1.000	1.000	1.000
2082-83	1.000	1.000	1.000	1.000	1.000	1.000
2083-84	1.000	1.000	1.000	1.000	1.000	1.000
2084-85	1.000	1.000	1.000	1.000	1.000	1.000
2085-86	1.000	1.000	1.000	1.000	1.000	1.000
2086-87	1.000	1.000	1.000	1.000	1.000	1.000
2087-88	1.000	1.000	1.000	1.000	1.000	1.000
2088-89	1.000	1.000	1.000	1.000	1.000	1.000
2089-90	1.000	1.000	1.000	1.000	1.000	1.000
2090-91	1.000	1.000	1.000	1.000	1.000	1.000
2091-92	1.000	1.000	1.000	1.000	1.000	1.000
2092-93	1.000	1.000	1.000	1.000	1.000	1.000
2093-94	1.000	1.000	1.000	1.000	1.000	1.000
2094-95	1.000	1.000	1.000	1.000	1.000	1.000
2095-96	1.000	1.000	1.000	1.000	1.000	1.000
2096-97	1.000	1.000	1.000	1.000	1.000	1.000
2097-98	1.000	1.000	1.000	1.000	1.000	1.000
2098-99	1.000	1.000	1.000	1.000	1.000	1.000
2099-00	1.000	1.000	1.000	1.000	1.000	1.000
2100-01	1.000	1.000	1.000	1.000	1.000	1.000

(A) Includes price loading charges and fund fees.
 (B) Excludes the impact of purchases and sales on the average price.
 (C) Average price for the year.
 Average price for the year ending 31/12/2024 is 1.000.

APPENDIX 37.2

NET PRESENT WORTH AND BENEFIT-COST RATIO OF THE PROJECT AT DISCOUNT RATE 3.5% AND INTERNAL RATE OF RETURN

Sl. No.	Year	Capital cost	Benefit		Benefit-Cost Ratio	Discount factor	
		(Rs. lakhs)	(Rs. lakhs)	(Rs. lakhs)		(%)	(%)
			Benefit	Benefit			
1	1987-88	50000	7747	57713			
2	88-89	0	8411	62120			
3	89-90	22475	8748	57741	0.97	0.924	0.924
4	90-91	10000	8802	57741	0.917	0.863	0.863
5	91-92	10000	8858	57741	0.91	0.825	0.825
6	92-93	10000	8915	57741	0.903	0.797	0.797
7	93-94	10000	8973	57741	0.895	0.79	0.797
8	94-95	10000	9030	57741	0.888	0.783	0.797
9	95-96	10000	9087	57741	0.88	0.776	0.797
10	96-97	10000	9145	57741	0.873	0.769	0.797
11	97-98	10000	9202	57741	0.865	0.762	0.797
12	1998-99	10000	9260	57741	0.858	0.755	0.797
13	2000-01	0.000000 + 100000000					
14	2001-02	0	9318	57741	0.85	0.748	0.797
15	02-03	0	9376	57741			
16	2003-04	0	9434	57741	0.843	0.741	0.797
17	2004-05	0	9492	57741	0.835	0.734	0.797
18	2005-06	0	9550	57741	0.828	0.727	0.797
19	2006-07	0	9608	57741	0.82	0.72	0.797
20	2007-08	0	9666	57741			
21	2008-09	0	9724	57741	0.813	0.713	0.797
22	2009-10	0	9782	57741	0.805	0.706	0.797
23	2010-11	0	9840	57741	0.798	0.7	0.797
24	2011-12	0	9898	57741	0.79	0.693	0.797
25	2012-13	0	9956	57741	0.783	0.686	0.797
26	2013-14	0	10014	57741	0.775	0.679	0.797
27	2014-15	0	10072	57741	0.768	0.672	0.797
28	2015-16	0	10130	57741	0.76	0.665	0.797
29	2016-17	0	10188	57741	0.753	0.658	0.797
30	2017-18	0	10246	57741	0.745	0.651	0.797
31	2018-19	0	10304	57741	0.738	0.644	0.797
32	2019-20	0	10362	57741	0.73	0.637	0.797
33	2020-21	0	10420	57741	0.723	0.63	0.797
34	2021-22	0	10478	57741	0.715	0.623	0.797
35	2022-23	0	10536	57741	0.708	0.616	0.797
36	2023-24	0	10594	57741	0.7	0.609	0.797
37	2024-25	0	10652	57741	0.693	0.602	0.797
38	2025-26	0	10710	57741	0.685	0.595	0.797
39	2026-27	0	10768	57741	0.678	0.588	0.797
40	2027-28	0	10826	57741	0.67	0.581	0.797
41	2028-29	0	10884	57741	0.663	0.574	0.797
42	2029-30	0	10942	57741	0.655	0.567	0.797
43	2030-31	0	11000	57741	0.648	0.56	0.797
44	2031-32	0	11058	57741	0.64	0.553	0.797
45	2032-33	0	11116	57741	0.633	0.546	0.797
46	2033-34	0	11174	57741	0.625	0.539	0.797
47	2034-35	0	11232	57741	0.618	0.532	0.797
48	2035-36	0	11290	57741	0.61	0.525	0.797
49	2036-37	0	11348	57741	0.603	0.518	0.797
50	2037-38	0	11406	57741	0.595	0.511	0.797
51	2038-39	0	11464	57741	0.588	0.504	0.797
52	2039-40	0	11522	57741	0.58	0.497	0.797
53	2040-41	0	11580	57741	0.573	0.49	0.797
54	2041-42	0	11638	57741	0.565	0.483	0.797
55	2042-43	0	11696	57741	0.558	0.476	0.797
56	2043-44	0	11754	57741	0.55	0.469	0.797
57	2044-45	0	11812	57741	0.543	0.462	0.797
58	2045-46	0	11870	57741	0.535	0.455	0.797
59	2046-47	0	11928	57741	0.528	0.448	0.797
60	2047-48	0	11986	57741	0.52	0.441	0.797
61	2048-49	0	12044	57741	0.513	0.434	0.797
62	2049-50	0	12102	57741	0.505	0.427	0.797
63	2050-51	0	12160	57741	0.498	0.42	0.797
64	2051-52	0	12218	57741	0.49	0.413	0.797
65	2052-53	0	12276	57741	0.483	0.406	0.797
66	2053-54	0	12334	57741	0.475	0.399	0.797
67	2054-55	0	12392	57741	0.468	0.392	0.797
68	2055-56	0	12450	57741	0.46	0.385	0.797
69	2056-57	0	12508	57741	0.453	0.378	0.797
70	2057-58	0	12566	57741	0.445	0.371	0.797
71	2058-59	0	12624	57741	0.438	0.364	0.797
72	2059-60	0	12682	57741	0.43	0.357	0.797
73	2060-61	0	12740	57741	0.423	0.35	0.797
74	2061-62	0	12798	57741	0.415	0.343	0.797
75	2062-63	0	12856	57741	0.408	0.336	0.797
76	2063-64	0	12914	57741	0.4	0.329	0.797
77	2064-65	0	12972	57741	0.393	0.322	0.797
78	2065-66	0	13030	57741	0.385	0.315	0.797
79	2066-67	0	13088	57741	0.378	0.308	0.797
80	2067-68	0	13146	57741	0.37	0.301	0.797
81	2068-69	0	13204	57741	0.363	0.294	0.797
82	2069-70	0	13262	57741	0.355	0.287	0.797
83	2070-71	0	13320	57741	0.348	0.28	0.797
84	2071-72	0	13378	57741	0.34	0.273	0.797
85	2072-73	0	13436	57741	0.333	0.266	0.797
86	2073-74	0	13494	57741	0.325	0.259	0.797
87	2074-75	0	13552	57741	0.318	0.252	0.797
88	2075-76	0	13610	57741	0.31	0.245	0.797
89	2076-77	0	13668	57741	0.303	0.238	0.797
90	2077-78	0	13726	57741	0.295	0.231	0.797
91	2078-79	0	13784	57741	0.288	0.224	0.797
92	2079-80	0	13842	57741	0.28	0.217	0.797
93	2080-81	0	13900	57741	0.273	0.21	0.797
94	2081-82	0	13958	57741	0.265	0.203	0.797
95	2082-83	0	14016	57741	0.258	0.196	0.797
96	2083-84	0	14074	57741	0.25	0.189	0.797
97	2084-85	0	14132	57741	0.243	0.182	0.797
98	2085-86	0	14190	57741	0.235	0.175	0.797
99	2086-87	0	14248	57741	0.228	0.168	0.797
100	2087-88	0	14306	57741	0.22	0.161	0.797
101	2088-89	0	14364	57741	0.213	0.154	0.797
102	2089-90	0	14422	57741	0.205	0.147	0.797
103	2090-91	0	14480	57741	0.198	0.14	0.797
104	2091-92	0	14538	57741	0.19	0.133	0.797
105	2092-93	0	14596	57741	0.183	0.126	0.797
106	2093-94	0	14654	57741	0.175	0.119	0.797
107	2094-95	0	14712	57741	0.168	0.112	0.797
108	2095-96	0	14770	57741	0.16	0.105	0.797
109	2096-97	0	14828	57741	0.153	0.098	0.797
110	2097-98	0	14886	57741	0.145	0.091	0.797
111	2098-99	0	14944	57741	0.138	0.084	0.797
112	2099-00	0	15002	57741	0.13	0.077	0.797
113	2100-01	0	15060	57741	0.123	0.07	0.797
114	2101-02	0	15118	57741	0.115	0.063	0.797
115	2102-03	0	15176	57741	0.108	0.056	0.797
116	2103-04	0	15234	57741	0.101	0.049	0.797
117	2104-05	0	15292	57741	0.093	0.042	0.797
118	2105-06	0	15350	57741	0.086	0.035	0.797
119	2106-07	0	15408	57741	0.078	0.028	0.797
120	2107-08	0	15466	57741	0.071	0.021	0.797
121	2108-09	0	15524	57741	0.063	0.014	0.797
122	2109-10	0	15582	57741	0.056	0.007	0.797
123	2110-11	0	15640	57741	0.048	0	0.797
124	2111-12	0	15698	57741	0.041		0.797
125	2112-13	0	15756	57741	0.033		0.797
126	2113-14	0	15814	57741	0.026		0.797
127	2114-15	0	15872	57741	0.018		0.797
128	2115-16	0	15930	57741	0.011		0.797
129	2116-17	0	15988	57741	0.003		0.797
130	2117-18	0	16046	57741	0		0.797
131	2118-19	0	16104	57741			0.797
132	2119-20	0	16162	57741			0.797
133	2120-21	0	16220	57741			0.797
134	2121-22	0	16278	57741			0.797
135	2122-23	0	16336	57741			0.797
136	2123-24	0	16394	57741			0.797
137	2124-25						

1. \mathbb{R}^n is a vector space over \mathbb{R} . Give an explicit isomorphism

between \mathbb{R}^n and the vector space of column vectors in \mathbb{R}^n . (10 points)

Proof: Let $\mathbb{R}^n = \{v\}$.

So, by definition, \mathbb{R}^n is a vector space over \mathbb{R} .

Define $\phi: \mathbb{R}^n \rightarrow \mathbb{R}^n$ by $\phi(v) = [v]$. Then ϕ is a linear isomorphism.

12. Acquisition charges are calculated as 2% of the total establishment energy, excluding electric and water and sewerage for the first two years.
13. Depreciation is calculated at 3% of the total project cost (including interest).
14. Other charges are calculated as 3% of the total establishment (electric, water, sewerage, and telephone) costs.

(B) 80% RATIO AND APPLICATION OF FUND STATEMENTS (APPENDIX 17.6)

1. Income account payable is the difference of the amount in the previous line items is shown in the proposed balance sheet.
2. The loan period is a maximum of 24 years inclusive of the minimum period of 1 year during which no payments are paid for capital repayment deduction.
3. It is assumed that the entrepreneur will have to pay 75% of the total project cost up front.
4. The total interest at 8.5% per annum during the maximum period was, 199,367, 199,367, 987,88 and 988,89 is calculated for the loan and added to the principal, thus a detailed repayment is added to fixed assets and shown in the schedule.
5. The cost loan is assumed being 100% in 1983 for the 6 months' interest is taken into this part.
6. Depreciation is assumed as 3% (Rs. 1,062 million every year) begins in 1983 (2% of the capital cost of the project) 3 years at 8.5% (Rs. 1,000).
7. Income for accounts is calculated as the difference of amount on two consecutive years as given in the proposed balance sheet.

(C) BALANCE SHEET (APPENDIX 17.9)

1. Net investment made for the establishment.
 2. Difference of the sales revenue and other accounts received in every year.
 3. Net revenue obtained for every year.
- The amount of borrowing and repayment expenditure is shown as accounts payable every year.
2. Repayment is shown as given in the schedule under the section.

APPENDIX 17.1 (Cont'd)

Description	2019-2020									
	2019-2020	2018-2019	2017-2018	2016-2017	2015-2016	2014-2015	2013-2014	2012-2013	2011-2012	2010-2011
1. Water produced (mln)	303	326	317,000	314,000	311	311	318	323	321	319
2. Water sold (mln)	434	438	441	440	441	433	437	431	430	436
3. Revenue (€ millions)										
A. Water supply	6,342	6,334	6,333	6,311	6,311	6,311	6,311	6,311	6,311	6,311
B. Sewerage										
C. Other Revenue	1,777	1,751	1,671	1,671	1,671	1,671	1,671	1,671	1,671	1,671
4. Operating Costs & Expenses										
a. Water Supply										
i. Electricity	4,067	4,067	4,067	4,067	4,067	4,067	4,067	4,067	4,067	4,067
ii. Power	6,016	6,017	6,016	6,016	6,016	6,016	6,016	6,016	6,016	6,016
iii. Other costs	6,011	6,011	6,011	6,011	6,011	6,011	6,011	6,011	6,011	6,011
iv. Sewerage & Wastewater	1,416	1,416	1,416	1,416	1,416	1,416	1,416	1,416	1,416	1,416
v. Variable charges	1,416	1,416	1,416	1,416	1,416	1,416	1,416	1,416	1,416	1,416
vi. Other operating costs	1,416	1,416	1,416	1,416	1,416	1,416	1,416	1,416	1,416	1,416

.....
1. Dependent variable
2. Independent variable
3. Control variable
4. Interaction term
5. Error term

.....

APPENDIX 17.5

Existing stations

Developer	Year	Capacity	Notes
	1981/82	250,000	
		300,000 (2000)	
London Underground	1986	1,500,000	1990
London Underground	1987/88	1,000,000	1990
British Rail	1988/89	1,000,000	1990

APPENDIX 1.6

PROJECT SOURCES AND APPLICATION OF FUNDS AND FLOW STATEMENT

Description	1997/98		1998/99		1999/00		2000/01	
	Rs. M	US\$ M	Rs. M	US\$ M	Rs. M	US\$ M	Rs. M	US\$ M
SOURCES								
1. Grants								
2. Government of India			10,475	14,070	11,111	15,111	10,111	13,611
3. Government of Karnataka							1,311	1,811
4. Government of Andhra Pradesh							1,311	1,811
5. Government of Madhya Pradesh							1,311	1,811
6. Government of West Bengal							1,311	1,811
7. Government of Gujarat							1,311	1,811
8. Government of Maharashtra							1,311	1,811
9. Government of Karnataka							1,311	1,811
10. Government of Karnataka							1,311	1,811
11. Government of Karnataka							1,311	1,811
12. Government of Karnataka							1,311	1,811
13. Government of Karnataka							1,311	1,811
14. Government of Karnataka							1,311	1,811
15. Government of Karnataka							1,311	1,811
16. Government of Karnataka							1,311	1,811
17. Government of Karnataka							1,311	1,811
18. Government of Karnataka							1,311	1,811
19. Government of Karnataka							1,311	1,811
20. Government of Karnataka							1,311	1,811
21. Government of Karnataka							1,311	1,811
22. Government of Karnataka							1,311	1,811
23. Government of Karnataka							1,311	1,811
24. Government of Karnataka							1,311	1,811
25. Government of Karnataka							1,311	1,811
26. Government of Karnataka							1,311	1,811
27. Government of Karnataka							1,311	1,811
28. Government of Karnataka							1,311	1,811
29. Government of Karnataka							1,311	1,811
30. Government of Karnataka							1,311	1,811
31. Government of Karnataka							1,311	1,811
32. Government of Karnataka							1,311	1,811
33. Government of Karnataka							1,311	1,811
34. Government of Karnataka							1,311	1,811
35. Government of Karnataka							1,311	1,811
36. Government of Karnataka							1,311	1,811
37. Government of Karnataka							1,311	1,811
38. Government of Karnataka							1,311	1,811
39. Government of Karnataka							1,311	1,811
40. Government of Karnataka							1,311	1,811
41. Government of Karnataka							1,311	1,811
42. Government of Karnataka							1,311	1,811
43. Government of Karnataka							1,311	1,811
44. Government of Karnataka							1,311	1,811
45. Government of Karnataka							1,311	1,811
46. Government of Karnataka							1,311	1,811
47. Government of Karnataka							1,311	1,811
48. Government of Karnataka							1,311	1,811
49. Government of Karnataka							1,311	1,811
50. Government of Karnataka							1,311	1,811
51. Government of Karnataka							1,311	1,811
52. Government of Karnataka							1,311	1,811
53. Government of Karnataka							1,311	1,811
54. Government of Karnataka							1,311	1,811
55. Government of Karnataka							1,311	1,811
56. Government of Karnataka							1,311	1,811
57. Government of Karnataka							1,311	1,811
58. Government of Karnataka							1,311	1,811
59. Government of Karnataka							1,311	1,811
60. Government of Karnataka							1,311	1,811
61. Government of Karnataka							1,311	1,811
62. Government of Karnataka							1,311	1,811
63. Government of Karnataka							1,311	1,811
64. Government of Karnataka							1,311	1,811
65. Government of Karnataka							1,311	1,811
66. Government of Karnataka							1,311	1,811
67. Government of Karnataka							1,311	1,811
68. Government of Karnataka							1,311	1,811
69. Government of Karnataka							1,311	1,811
70. Government of Karnataka							1,311	1,811
71. Government of Karnataka							1,311	1,811
72. Government of Karnataka							1,311	1,811
73. Government of Karnataka							1,311	1,811
74. Government of Karnataka							1,311	1,811
75. Government of Karnataka							1,311	1,811
76. Government of Karnataka							1,311	1,811
77. Government of Karnataka							1,311	1,811
78. Government of Karnataka							1,311	1,811
79. Government of Karnataka							1,311	1,811
80. Government of Karnataka							1,311	1,811
81. Government of Karnataka							1,311	1,811
82. Government of Karnataka							1,311	1,811
83. Government of Karnataka							1,311	1,811
84. Government of Karnataka							1,311	1,811
85. Government of Karnataka							1,311	1,811
86. Government of Karnataka							1,311	1,811
87. Government of Karnataka							1,311	1,811
88. Government of Karnataka							1,311	1,811
89. Government of Karnataka							1,311	1,811
90. Government of Karnataka							1,311	1,811
91. Government of Karnataka							1,311	1,811
92. Government of Karnataka							1,311	1,811
93. Government of Karnataka							1,311	1,811
94. Government of Karnataka							1,311	1,811
95. Government of Karnataka							1,311	1,811
96. Government of Karnataka							1,311	1,811
97. Government of Karnataka							1,311	1,811
98. Government of Karnataka							1,311	1,811
99. Government of Karnataka							1,311	1,811
100. Government of Karnataka							1,311	1,811

4. _____

	1967-68				1968-69							
	82.83	83.43	84.05	85.19	86.17	87.09	88.89	89.77	90.71	91.11	91.93	91.94
	(in million)											
x. Cash Surplus/Defi- cit at the end of the year						15.01	17.96	20.96	24.862	28.112	31.456	33.748

APPENDIX 17.7

INTEREST ADDED TO THE CAPITAL DURING MORATORIUM PERIOD

	Interest Payable (Rs. lakhs)				
	1975	1986	1987	1988	1989
(a) Interest on loans received in 1975-76 (Rs. 107.85 million)	0.019	0.022	0.025	0.029	0.035
(b) Interest on loans received in 1976-77 (Rs. 107.85 million)		0.068	0.076	0.086	0.101
(c) Interest on loans received in 1977-78 (Rs. 107.85 million)					
(d) Interest on loans received in 1988 (Rs. 60 million)					
Total		0.087	0.101	0.111	0.141
		0.4274			

Note: (a) at 8% per cent; (b) at 10% per cent; (c) and (d) at the year of receipt of loan.

APPENDIX

FIGURE 1. KLEIN'S ESTIMATES

	1950-1954
Constant	-0.2577
Income	0.0075
Interest rate	-0.0001
Price level	0.0000
Money stock	0.0000
Money stock (lagged)	0.0000
Money stock (lagged squared)	0.0000
Money stock (lagged cubed)	0.0000
Money stock (lagged fourth power)	0.0000
Money stock (lagged fifth power)	0.0000
Money stock (lagged sixth power)	0.0000
Money stock (lagged seventh power)	0.0000
Money stock (lagged eighth power)	0.0000
Money stock (lagged ninth power)	0.0000
Money stock (lagged tenth power)	0.0000
Money stock (lagged eleventh power)	0.0000
Money stock (lagged twelfth power)	0.0000
Money stock (lagged thirteenth power)	0.0000
Money stock (lagged fourteenth power)	0.0000
Money stock (lagged fifteenth power)	0.0000
Money stock (lagged sixteenth power)	0.0000
Money stock (lagged seventeenth power)	0.0000
Money stock (lagged eighteenth power)	0.0000
Money stock (lagged nineteenth power)	0.0000
Money stock (lagged twentieth power)	0.0000
Money stock (lagged twenty-first power)	0.0000
Money stock (lagged twenty-second power)	0.0000
Money stock (lagged twenty-third power)	0.0000
Money stock (lagged twenty-fourth power)	0.0000
Money stock (lagged twenty-fifth power)	0.0000
Money stock (lagged twenty-sixth power)	0.0000
Money stock (lagged twenty-seventh power)	0.0000
Money stock (lagged twenty-eighth power)	0.0000
Money stock (lagged twenty-ninth power)	0.0000
Money stock (lagged thirtieth power)	0.0000
Money stock (lagged thirty-first power)	0.0000
Money stock (lagged thirty-second power)	0.0000
Money stock (lagged thirty-third power)	0.0000
Money stock (lagged thirty-fourth power)	0.0000
Money stock (lagged thirty-fifth power)	0.0000
Money stock (lagged thirty-sixth power)	0.0000
Money stock (lagged thirty-seventh power)	0.0000
Money stock (lagged thirty-eighth power)	0.0000
Money stock (lagged thirty-ninth power)	0.0000
Money stock (lagged fortieth power)	0.0000
Money stock (lagged forty-first power)	0.0000
Money stock (lagged forty-second power)	0.0000
Money stock (lagged forty-third power)	0.0000
Money stock (lagged forty-fourth power)	0.0000
Money stock (lagged forty-fifth power)	0.0000
Money stock (lagged forty-sixth power)	0.0000
Money stock (lagged forty-seventh power)	0.0000
Money stock (lagged forty-eighth power)	0.0000
Money stock (lagged forty-ninth power)	0.0000
Money stock (lagged fiftieth power)	0.0000
Money stock (lagged fifty-first power)	0.0000
Money stock (lagged fifty-second power)	0.0000
Money stock (lagged fifty-third power)	0.0000
Money stock (lagged fifty-fourth power)	0.0000
Money stock (lagged fifty-fifth power)	0.0000
Money stock (lagged fifty-sixth power)	0.0000
Money stock (lagged fifty-seventh power)	0.0000
Money stock (lagged fifty-eighth power)	0.0000
Money stock (lagged fifty-ninth power)	0.0000
Money stock (lagged sixtieth power)	0.0000
Money stock (lagged sixty-first power)	0.0000
Money stock (lagged sixty-second power)	0.0000
Money stock (lagged sixty-third power)	0.0000
Money stock (lagged sixty-fourth power)	0.0000
Money stock (lagged sixty-fifth power)	0.0000
Money stock (lagged sixty-sixth power)	0.0000
Money stock (lagged sixty-seventh power)	0.0000
Money stock (lagged sixty-eighth power)	0.0000
Money stock (lagged sixty-ninth power)	0.0000
Money stock (lagged seventieth power)	0.0000
Money stock (lagged seventy-first power)	0.0000
Money stock (lagged seventy-second power)	0.0000
Money stock (lagged seventy-third power)	0.0000
Money stock (lagged seventy-fourth power)	0.0000
Money stock (lagged seventy-fifth power)	0.0000
Money stock (lagged seventy-sixth power)	0.0000
Money stock (lagged seventy-seventh power)	0.0000
Money stock (lagged seventy-eighth power)	0.0000
Money stock (lagged seventy-ninth power)	0.0000
Money stock (lagged eightieth power)	0.0000
Money stock (lagged eighty-first power)	0.0000
Money stock (lagged eighty-second power)	0.0000
Money stock (lagged eighty-third power)	0.0000
Money stock (lagged eighty-fourth power)	0.0000
Money stock (lagged eighty-fifth power)	0.0000
Money stock (lagged eighty-sixth power)	0.0000
Money stock (lagged eighty-seventh power)	0.0000
Money stock (lagged eighty-eighth power)	0.0000
Money stock (lagged eighty-ninth power)	0.0000
Money stock (lagged ninetieth power)	0.0000
Money stock (lagged hundredth power)	0.0000

TABLE 1. THE ESTIMATION OF THE KLEIN MODEL FOR THE PERIOD 1950-1954

	Variable	Coefficient	Standard Error	t-Statistic
1	Income	0.0075	0.0001	75.00
2	Interest rate	-0.0001	0.0000	-1.00
3	Price level	0.0000	0.0000	0.00
4	Money stock	0.0000	0.0000	0.00
5	Money stock (lagged)	0.0000	0.0000	0.00
6	Money stock (lagged squared)	0.0000	0.0000	0.00
7	Money stock (lagged cubed)	0.0000	0.0000	0.00
8	Money stock (lagged fourth power)	0.0000	0.0000	0.00
9	Money stock (lagged fifth power)	0.0000	0.0000	0.00
10	Money stock (lagged sixth power)	0.0000	0.0000	0.00
11	Money stock (lagged seventh power)	0.0000	0.0000	0.00
12	Money stock (lagged eighth power)	0.0000	0.0000	0.00
13	Money stock (lagged ninth power)	0.0000	0.0000	0.00
14	Money stock (lagged tenth power)	0.0000	0.0000	0.00
15	Money stock (lagged eleventh power)	0.0000	0.0000	0.00
16	Money stock (lagged twelfth power)	0.0000	0.0000	0.00
17	Money stock (lagged thirteenth power)	0.0000	0.0000	0.00
18	Money stock (lagged fourteenth power)	0.0000	0.0000	0.00
19	Money stock (lagged fifteenth power)	0.0000	0.0000	0.00
20	Money stock (lagged sixteenth power)	0.0000	0.0000	0.00
21	Money stock (lagged seventeenth power)	0.0000	0.0000	0.00
22	Money stock (lagged eighteenth power)	0.0000	0.0000	0.00
23	Money stock (lagged nineteenth power)	0.0000	0.0000	0.00
24	Money stock (lagged twentieth power)	0.0000	0.0000	0.00
25	Money stock (lagged twenty-first power)	0.0000	0.0000	0.00
26	Money stock (lagged twenty-second power)	0.0000	0.0000	0.00
27	Money stock (lagged twenty-third power)	0.0000	0.0000	0.00
28	Money stock (lagged twenty-fourth power)	0.0000	0.0000	0.00
29	Money stock (lagged twenty-fifth power)	0.0000	0.0000	0.00
30	Money stock (lagged twenty-sixth power)	0.0000	0.0000	0.00
31	Money stock (lagged twenty-seventh power)	0.0000	0.0000	0.00
32	Money stock (lagged twenty-eighth power)	0.0000	0.0000	0.00
33	Money stock (lagged twenty-ninth power)	0.0000	0.0000	0.00
34	Money stock (lagged thirtieth power)	0.0000	0.0000	0.00
35	Money stock (lagged thirty-first power)	0.0000	0.0000	0.00
36	Money stock (lagged thirty-second power)	0.0000	0.0000	0.00
37	Money stock (lagged thirty-third power)	0.0000	0.0000	0.00
38	Money stock (lagged thirty-fourth power)	0.0000	0.0000	0.00
39	Money stock (lagged thirty-fifth power)	0.0000	0.0000	0.00
40	Money stock (lagged thirty-sixth power)	0.0000	0.0000	0.00
41	Money stock (lagged thirty-seventh power)	0.0000	0.0000	0.00
42	Money stock (lagged thirty-eighth power)	0.0000	0.0000	0.00
43	Money stock (lagged thirty-ninth power)	0.0000	0.0000	0.00
44	Money stock (lagged fortieth power)	0.0000	0.0000	0.00
45	Money stock (lagged forty-first power)	0.0000	0.0000	0.00
46	Money stock (lagged forty-second power)	0.0000	0.0000	0.00
47	Money stock (lagged forty-third power)	0.0000	0.0000	0.00
48	Money stock (lagged forty-fourth power)	0.0000	0.0000	0.00
49	Money stock (lagged forty-fifth power)	0.0000	0.0000	0.00
50	Money stock (lagged forty-sixth power)	0.0000	0.0000	0.00
51	Money stock (lagged forty-seventh power)	0.0000	0.0000	0.00
52	Money stock (lagged forty-eighth power)	0.0000	0.0000	0.00
53	Money stock (lagged forty-ninth power)	0.0000	0.0000	0.00
54	Money stock (lagged fiftieth power)	0.0000	0.0000	0.00
55	Money stock (lagged fifty-first power)	0.0000	0.0000	0.00
56	Money stock (lagged fifty-second power)	0.0000	0.0000	0.00
57	Money stock (lagged fifty-third power)	0.0000	0.0000	0.00
58	Money stock (lagged fifty-fourth power)	0.0000	0.0000	0.00
59	Money stock (lagged fifty-fifth power)	0.0000	0.0000	0.00
60	Money stock (lagged fifty-sixth power)	0.0000	0.0000	0.00
61	Money stock (lagged fifty-seventh power)	0.0000	0.0000	0.00
62	Money stock (lagged fifty-eighth power)	0.0000	0.0000	0.00
63	Money stock (lagged fifty-ninth power)	0.0000	0.0000	0.00
64	Money stock (lagged sixtieth power)	0.0000	0.0000	0.00
65	Money stock (lagged sixty-first power)	0.0000	0.0000	0.00
66	Money stock (lagged sixty-second power)	0.0000	0.0000	0.00
67	Money stock (lagged sixty-third power)	0.0000	0.0000	0.00
68	Money stock (lagged sixty-fourth power)	0.0000	0.0000	0.00
69	Money stock (lagged sixty-fifth power)	0.0000	0.0000	0.00
70	Money stock (lagged sixty-sixth power)	0.0000	0.0000	0.00
71	Money stock (lagged sixty-seventh power)	0.0000	0.0000	0.00
72	Money stock (lagged sixty-eighth power)	0.0000	0.0000	0.00
73	Money stock (lagged sixty-ninth power)	0.0000	0.0000	0.00
74	Money stock (lagged seventieth power)	0.0000	0.0000	0.00
75	Money stock (lagged seventy-first power)	0.0000	0.0000	0.00
76	Money stock (lagged seventy-second power)	0.0000	0.0000	0.00
77	Money stock (lagged seventy-third power)	0.0000	0.0000	0.00
78	Money stock (lagged seventy-fourth power)	0.0000	0.0000	0.00
79	Money stock (lagged seventy-fifth power)	0.0000	0.0000	0.00
80	Money stock (lagged seventy-sixth power)	0.0000	0.0000	0.00
81	Money stock (lagged seventy-seventh power)	0.0000	0.0000	0.00
82	Money stock (lagged seventy-eighth power)	0.0000	0.0000	0.00
83	Money stock (lagged seventy-ninth power)	0.0000	0.0000	0.00
84	Money stock (lagged eightieth power)	0.0000	0.0000	0.00
85	Money stock (lagged eighty-first power)	0.0000	0.0000	0.00
86	Money stock (lagged eighty-second power)	0.0000	0.0000	0.00
87	Money stock (lagged eighty-third power)	0.0000	0.0000	0.00
88	Money stock (lagged eighty-fourth power)	0.0000	0.0000	0.00
89	Money stock (lagged eighty-fifth power)	0.0000	0.0000	0.00
90	Money stock (lagged eighty-sixth power)	0.0000	0.0000	0.00
91	Money stock (lagged eighty-seventh power)	0.0000	0.0000	0.00
92	Money stock (lagged eighty-eighth power)	0.0000	0.0000	0.00
93	Money stock (lagged eighty-ninth power)	0.0000	0.0000	0.00
94	Money stock (lagged ninetieth power)	0.0000	0.0000	0.00
95	Money stock (lagged hundredth power)	0.0000	0.0000	0.00

QUESTION 1

1. The following table shows the results of a survey of 1000 people regarding their preferred mode of transport to work.

Mode of Transport	Male	Female	Total
Car	350	250	600
Bus	200	150	350
Bicycle	100	100	200
Walking	50	50	100
Other	0	0	0
Total	700	550	1250

1.1

1.1.1

1.1.2

1.1.3

1.1.4

1.1.5

1.1.6

1.1.7

1.1.8

1.1.9

1.1.10

1.1.11

1.1.12

1.1.13

1.1.14

	Historical						Forecast					
	1983	1984	1985	1986	1987	1988	1989	1990	1991	1992	1993	1994
	(82-83)	(83-84)	(84-85)	(85-86)	(86-87)	(87-88)	(88-89)	(89-90)	(90-91)	(91-92)	(92-93)	(93-94)
	(\$ million)											
Total current assets	-	-	-	-	0.631	0.034	1.27	1.395	0.313	0.181	0.215	-
B. Fixed assets												
A. Depreciable												
i. Leasehold improvements	-	-	0.12	0.34	1.00	1.53	1.84	1.50	1.11	1.11	1.00	-
ii. Depreciable equipment	-	-	-	-	0.06	0.26	0.67	0.84	0.97	0.94	0.61	-
iii. Net fixed assets	-	-	0.12	0.34	1.06	1.79	2.51	2.34	2.08	2.05	1.61	-

Year	2000		2001		2002		2003		2004	2005
	2000	2001	2000	2001	2000	2001	2000	2001		
1997	100	100	100	100	100	100	100	100	100	100
1998	100	100	100	100	100	100	100	100	100	100
1999	100	100	100	100	100	100	100	100	100	100

100

100

100

100

100

100

100

100

100

100

100 100 100 100 100 100 100 100 100 100

100 100 100 100 100 100 100 100 100 100

	Historical				Projected							
	1983	1984	1985	1986	1987	1988	1989	1990	1991	1992	1993	1994
	82.85	83.86	84.65	(85-86)	86.67	87.38	88.92	90.04	91.97	93.22	94.95	95.98
					(\$ million)							
10. Future revenues	-	-	-	-	-	-	-	0.04	0.028	0.039	0.151	0.164
Total wage cost				0.2675	0.4833	0.5249	0.6704	0.7777	0.891	0.830	0.6158	0.4691
100% (A-B) =100												
Total change				1.0000	1.0000	1.0000	1.0000	1.0000	1.0000	1.0000	0.6908	0.5307

* Interest accrued during the year ending in the "Total Assets"


BIBLIOGRAPHY

1. "Water and Sewer Waste Capacity," 1966, Vol. I Water supply and Waste Water Reclamation, Vol. II Water Pollution and Waste Water Treatment and Disposal, and Vol. III Capacity Estimation, ICA.
2. "Water supply engineering," 1967, Baltimore, U.S.A., McGraw-Hill and Co., Inc.
3. "Manual of public Water Supply and Sewerage," Fourth Edition, 1955, Vol. I Organization and Management, Vol. II Engineering Practice, Vol. III Water Quality and Treatment, Institution of Water Engineers and Institution of Municipal Engineers.
4. "Manual of Water Supply and Sewerage," American Water Works Association.
5. "Manual of Water Treatment Plant Design," 1966, American Society of Civil Engineering and American Water Works Association.
6. "Observations on water pollution," 1964, Chesham, UK, World Health Organization.
7. "Water Supply for Rural Areas and Small Towns," Vol. I, 1967, Part 1 and Part 2, World Health Organization.
8. "Water and Sewerage Works," 1966, 1st Edition, James and Sons.
9. "Water and Sewerage Engineering," P. D. Kulkarni.
10. "Handbook of Applied Hydrology," 1965, McGraw-Hill.
11. "World Bank Manual," Survey and Planning, Rural Water Supply and Sewerage Health Services, Office of Water and Urban, Agency for International Development, Washington, D.C.
12. "Design Handbook," Reinforcement, 1967, 1st Edition.
13. "Design Guidelines," 1967, 1st Edition.
14. "Concrete Pipes as Handbook," 1967, James and Sons, Page, 111.
15. "Proceedings of International Association of Agricultural Engineers," 1967, International Association, London.
16. "Statistical Methods for the Examination of Water and Pollution," 1972, 12th Edition, 1977, American Public Health Association, Water Pollution Control Federation and American Public Works Association.
17. "Statistical Methods for the Examination of Water and Pollution," 1972, 12th Edition, 1977, American Public Health Association, Water Pollution Control Federation and American Public Works Association.
18. "Computer Methods in Statistics," 1977, 1st Edition, James and Sons, 1967, Chapman, Geneva.
19. "Water and Sewerage for Engineers," 1977, 1st Edition, World Health Organization, Geneva.

20. *U.S. Food and Drug Administration Drinking Water Manual* (1971), 1976.
21. *Statistical Methods Water Sampling and Analysis*, Part 1, by Department of National Health and Welfare, Canada.
22. *Watering of Livestocks of Water Supply*, 4th Edition, 1969, Department of Health and Social Security, Welfare Office, Ministry of Housing and Local Government.
23. *Water Manual* (California Institute, 1973).
24. *Water Quality and National Health* (1972), M. A. von Wedel Health Organization.
25. *Report of the International League Committee*, Ministry of Health, New Delhi.
26. *Water Supply and Distribution Manual for Local Bodies*, 1972, United Nations Publication (Department of Economic and Social Affairs), New York.
27. *Water and Health and Water Supply*, Vol. 1, 1974, ITI Edition, I.P.
28. *Water Supply and Distribution Manual of Water Distribution System*, 1973, National Environmental Engineering Research Institute, Nagpur.
29. *Water Supply and Distribution Manual*, 2nd Edition, W. L. Weber, Wiley Interscience.
30. *Water Supply and Distribution Manual*, 1st Edition, United R. Quisenberry, Holt, Rinehart & Winston.
31. *Water Supply and Distribution*, W. L. Weber, McGraw-Hill.
32. *Water Supply and Distribution Manual*, 1st Edition, McGraw-Hill, New York.
33. *Water Supply and Distribution Manual*, 1st Edition, McGraw-Hill, New York.
34. *Water Supply and Distribution Manual*, 1st Edition, McGraw-Hill, New York.
35. *Water Supply and Distribution Manual*, 1st Edition, McGraw-Hill, New York.
36. *Water Supply and Distribution Manual*, 1st Edition, McGraw-Hill, New York.
37. *Water Supply and Distribution Manual*, 1st Edition, McGraw-Hill, New York.
38. *Water Supply and Distribution Manual*, 1st Edition, McGraw-Hill, New York.
39. *Water Supply and Distribution Manual*, 1st Edition, McGraw-Hill, New York.

40. "Analysis of Pumping Test Data at Long Mountain Reservoir", 1986, Central Ground Water Board.
41. "Ground Water Pollution Monitoring" Report of the Ground Water Estimation Committee, 1984.
42. "Hydrogeological Map of India", 2nd edition, 1977.
43. R.L. Shukla and V.V. Chari, "Ground Water Protection for Contamination in Developing Countries", John Wiley, New York, 1985.
44. R.L. Shukla (Ed.), "Water Pollution Control Design", 1978, Van Nostrand Reinhold.
45. K.J. Ives, "Coagulation and Flocculation of Colloidal Suspensions in a Solid-Liquid Separator", 2nd Edition, 1980, J. Svarovsky (Ed.), Butterworths, London.
46. Journal of American Water Works Association.
47. Journal of Environmental Engineering, Canada, American Society of Civil Engineers.
48. Journal of Indian Water Works Association.
49. Indian Journal of Environmental Health.
50. Journal of Institution of Engineers (India), Environmental Engineering Division.
51. Asian Environment.
52. Journal of Institution Society of Civil Engineering.


SLOPE IN METRES PER 1000 METRES



CONTOUR MAP SHOWING SLOPE IN METRES PER 1000 METRES

NOTE: FOR VALUES OF σ_{11} LESS THAN
 INDICATED BY THE CURVES, THE CURVES SHOULD BE
 MULTIPLIED BY 0.5 OR 1.0 OR 2.0 AS APPROPRIATE.

CHARACTERISTICS OF THE SOILS USED IN THE
 PRESENTATION OF THE DATA ARE AS FOLLOWS:
 GRAIN SIZE DISTRIBUTION AS PER
 TABLE 1.1
 LIQUID LIMIT 25%
 PLASTICITY INDEX 10%
 UNSATURATED SWELLING INDEX 10%
 UNSATURATED SHRINKAGE INDEX 10%



DISCHARGE IN KILOMETRES PER DAY (KLD)

NOTE: The above chart is a typical example of a hydrograph for a given catchment area. The discharge is measured in KLD and the time is measured in hours. The chart is plotted on a grid with a scale of 100 KLD per vertical division and 100 hours per horizontal division. The peak discharge is approximately 800 KLD and occurs at about 200 hours.

CHART FOR DISCHARGE (KLD) BY HAZEN & WILLIAMS FORMULA

This chart is used to determine the discharge (KLD) for a given catchment area. The discharge is measured in KLD and the time is measured in hours. The chart is plotted on a grid with a scale of 100 KLD per vertical division and 100 hours per horizontal division.

The discharge is measured in KLD and the time is measured in hours. The chart is plotted on a grid with a scale of 100 KLD per vertical division and 100 hours per horizontal division. The peak discharge is approximately 800 KLD and occurs at about 200 hours.

Time (Hours)	Discharge (KLD)
0	0
100	100
200	800
300	400
400	100
500	0